

Naddod N9200-64DC and N9500-640C Switch

SONiC CLI Guide



NADDOD Pte.Ltd.

Preface

Intended Audience

This document is intended for:

- Network engineers
- Technical support and servicing engineers
- Network administrators

Technical Support

- Naddod Networks website: <https://www.naddod.com>
- Online support center: <https://www.naddod.com/support>
- Community: <https://www.naddod.com/ai-insights>
- Email support: support@naddod.com
- Live chat: <https://www.naddod.com/about-us/contact-us>
- Documentation feedback: info@naddod.com

Notes

The manual provides configuration information, including models, port types, and command line interfaces, for reference purposes only. In the event of any discrepancy or inconsistency between the manual and the actual version, the actual version shall take precedence.

Contents

1 Introduction	16
2 Scope of this Document	17
3 Not Supported Commands in this Document	17
4 Content Index of Articles	18
5 Getting Started with SONiC	18
5.1 SSH Login	19
5.2 Configuring the Management Interface	19
5.3 Getting Help	20
5.4 Basic Show Commands	25
6 Authentication, Authorization, and Accounting	47
6.1 AAA	47
6.2 TACACS+	53
6.3 RADIUS	60
6.4 User privilege	70
7 ACL	73
ACL Show Commands	74
ACL Configuration Commands	79
8 ARP	95
ARP show commands	96

ARP Config Command	97
9 BFD	103
BFD Show Commands	104
BFD Peer Specific Commands	109
BGP BFD Commands	113
10 BGP	118
BGP show commands	119
BGP config commands	151
11 Configuration File Management	155
Loading the Configuration from a JSON File	156
Loading the Configuration from a Minigraph (XML) File	157
Reloading the Configuration	158
Loading the Management Configuration	160
Saving the Configuration to a File for Persistence	161
12 Container Auto-restart	162
Container Auto-restart Show Commands	162
Container Auto-restart Config Command	163
13 CoPP	164
Schema	165
Supported trap IDs	167

Predefined trap groups and trap IDs in system	169
Example	171
14 Critical Resource Monitoring	172
CRM show commands	174
CRM config command	188
15 Device Hostname	212
Update Device Hostname Configuration Commands	212
16 DHCP Relay	213
DHCP Relay show commands	214
DHCP Relay config commands	215
17 DHCPv6 Relay	220
DHCPv6 Relay show commands	221
DHCPv6 Relay config commands	224
18 Drop Counters	226
Drop Counters Show Commands	227
Drop Counters Config Commands	230
Drop Counters Clear Commands	232
19 Fast Reboot	232
Fast Reboot Configuration Commands	232
20 FDB	234

FDB Show Commands	234
FDB Configuration Commands	238
21 Interfaces	241
Interface Show Commands	246
Interface Clear Counters Commands	266
Interface Configuration Commands	267
Interface Naming Mode	287
Interface VRF Binding Commands	289
Transceiver Config and Show Commands	290
22 IP/IPv6	318
IP Show Commands	319
IPv6 Show Commands	324
23 Kubernetes Configuration	330
Kubernetes Server Setting	330
SONiC Feature Setting	332
24 LLDP	335
LLDP Show Commands	336
LLDP Config Commands	343
25 Management VRF	350
Management VRF Show Commands	351

Management VRF Config Commands	353
26 MC LAG	355
MCLAG show commands	356
MCLAG Configuration Commands	358
27 Mirroring	361
Mirroring Show Commands	361
Mirroring Configuration Commands	362
28 NAT	367
NAT Show Commands	368
NAT Configuration Commands	372
NAT Clear Commands	378
29 NDP	379
NDP Show Commands	380
NDP Config Command	381
30 NTP	384
NTP Show Commands	384
NTP Config Commands	385
31 PFC	399
PFC Show commands	400
PFC Configuration Commands	404

PFC Clear Commands	408
32 PFC Watchdog	409
PFC Watchdog Configure Command	409
PFC Watchdog Show Command	413
33 Policer	414
Policer Show Commands	414
Policer Config Commands	415
34 Port Channels	420
Port Channel Show Commands	420
Port Channel Config Commands	422
35 Port Rate Limit	426
Port Rate Limit Show Commands	427
Port Rate Limit Configuration Commands	427
36 PVST	429
PVST show commands	431
PVST configuration commands	433
PVST debug commands	442
PVST clear commands	445
37 QoS	446
Qos Classification	447

Qos Marking	462
Qos Configuration Commands	468
38 Rate	470
Rate Config Commands	470
39 Routing Stack	471
40 SAG	472
SAG Show Commands	473
SAG Configuration Commands	474
41 Scheduling & Shaping	476
Scheduling & Shaping Show Commands	477
Scheduling & Shaping Configuration Commands	478
42 sFlow	483
sFlow Show Commands	484
sFlow Config Commands	485
43 Shared Buffer	491
Shared Buffer Show Commands	493
Shared Buffer Configuration Commands	496
Queue and Priority-Group	501
44 SNMP	509
SNMP Show commands	510

SNMP Config commands	513
45 SNMP Traps	518
SNMP Trap Show Commands	519
SNMP Trap Config Commands	519
45.1 SNMP inform	521
SNMP Inform show commands	521
SNMP Inform Config Commands	522
46 Software Installation and Management	524
SONiC Installer	525
47 Startup & Running Configuration	530
Startup Configuration	531
Running Configuration	533
48 Syslog	544
Syslog Configuration Commands	544
49 Subport	547
Subport Show commands	547
Subport Configuration commands	548
50 System State	549
Processes	549
Services & Memory	552

System-Health	557
51 Troubleshooting	562
Collect techsupport information	563
Example demonstration	564
52 TFTP	567
53 VLAN	567
VLAN Show Commands	568
VLAN Config Commands	570
54 VLAN Stacking	573
VLAN Stacking Show Commands	573
VLAN Stacking Config Commands	574
Caveat	576
55 VRF Configuration	576
VRF Show Commands	577
VRF Config Commands	578
56 VRF Route Leaking	579
57 VxLAN (includes EVPN and EVPN-MH)	582
VxLAN Show Commands	583
VxLAN Configuration Commands	589
58 Warm Reboot	593

Warm Reboot Configuration Commands	593
59 Warm Restart	595
Warm Restart Show Commands	596
Warm Restart Config Commands	597
60 Watermark	601
Watermark Show Commands	602
Watermark Config Commands	602
61 WRED & ECN	603
WRED & ECN Show Commands	604
WRED & ECN Configuration Commands	605
ECN Show Commands	610
ECN Config Commands	611
62 ZTP	613
ZTP Show Commands	614
ZTP Configuration Commands	617
63 Reloading Configuration	619
64 Linux Kernel Dump	620
Linux Kernel Dump show commands	621
Linux Kernel Dump config commands	624
65 XSTP	625

STP show commands	627
STP configuration commands	634
66 Hardware-Reset	648
Hardware Reset Commands	648
67 Object Track	649
Object Track Terminology	650
Object Track Configuration Commands	651
Object Track Show Commands	658
Object Track Guidelines	659
68 Port Protocol Down	663
Port Protocol Down Show Commands	664
Interface Show Command	666
Port Protocol Down Guidelines	667
69 DHCP Snooping	670
DHCP Snooping show commands	671
DHCP Snooping config commands	673
70 IGMP Snooping	675
IGMP Snooping Configuration Commands	676
IGMP Snooping Show Commands	682
71 Policy-Based Routing (PBR)	688

PBR Config Commands	688
PBR Show Commands	690
72 VRRP	692
VRRP interface command	692
VRRP group command	693
VRRP show command	693
73 Isolation-myself	696
74 Static DNS	698
Static DNS display command	698
75 Hash	699
76 Routing Security	704
Routing Security show commands	704
Routing Security config commands	707
77 Fine-grained ECMP	709
78 Monitor Link	719
Monitor Link Group show commands	719
Monitor Link Group config commands	720
79 Platform Component Firmware	723
80 Latency Distribution Histogram (LDH)	723
LDH show commands	723

LDH config commands	724
81 AR	726
Adaptive Routing show commands	726
Adaptive Routing config commands	727

1 Introduction

SONiC is an open source network operating system based on Linux that runs on switches from multiple vendors and ASICs. SONiC offers a full-suite of network functionality, like BGP and RDMA, that has been production-hardened in the data centers of some of the largest cloud-service providers. It offers teams the flexibility to create the network solutions they need while leveraging the collective strength of a large ecosystem and community.

SONiC software shall be loaded in these [supported devices](#) and this CLI guide shall be used to configure the devices as well as to display the configuration, state and status.

Follow the [Quick Start Guide](#) to boot the device in ONIE mode, install the SONiC software using the steps specified in the document and login to the device using the default username and password.

After logging into the device, SONiC software can be configured in following three methods.

1. Command Line Interface (CLI)
2. [config_db.json](#)
3. [minigraph.xml](#)

This document explains the first method and gives the complete list of commands that are supported in SONiC 201904 version (build#19). All the configuration commands need root privileges to execute them. Note that show commands can be executed by all users without the root privileges. Root privileges can be obtained either by using "sudo" keyword in front of all config commands, or by going to root prompt using "sudo -i". Note that all commands are case sensitive.

Example
<pre>admin@sonic:~\$ sudo config aaa authentication login tacacs+ OR admin@sonic:~\$ sudo -i root@sonic:~# config aaa authentication login tacacs+</pre>

Note that the command list given in this document is just a subset of all possible configurations in SONiC. Please

follow config_db.json based configuration for the complete list of configuration options.

2 Scope of this Document

It is assumed that all configuration commands start with the keyword "config" as prefix. Any other scripts/utilities/commands that need user configuration control are wrapped as sub-commands under the "config" command. The direct scripts/utilities/commands (examples given below) that are not wrapped under the "config" command are not in the scope of this document.

acl_loader – This script is already wrapped inside "config acl" command; i.e. any ACL configuration that user is allowed to do is already part of "config acl" command; users are not expected to use the acl_loader script directly and hence this document need not explain the "acl_loader" script.

3 Not Supported Commands in this Document

In this document, some CLI commands or parameters of specific features are marked as "Not support". It may caused by varies reasons. These non-supported commands and parameters are still listed in this document to notify the user these commands, although existed in the Sonic CLI command Line, but it is not recommended to use these commands or parameters. Errors or unexpected results may occur if these commands or parameters are issued.

These commands existed in Community Sonic version, however, these commands/parameters are not working well due to the following reasons.

- The corresponding operations are not supported in the hardware platform.
- The corresponding operations are not fully implemented in Sonic platform or SAI driver.

- The corresponding operations are obsoleted compared with current Sonic implementation but the command is still kept.
- The corresponding operations has defects and under fixing.

4 Content Index of Articles

5 Getting Started with SONiC

This section covers the basic configurations related to the following:

- [SSH Login](#)
- [Configuring the Management Interface](#)

5.1 SSH Login

All SONiC devices support both serial console-based login and SSH-based login by default. The default credentials (if not modified at image build time) for login is admin/YourPaSsWoRd. In the case of SSH login, users can log in to the management interface (eth0) IP address after configuring the same using the serial console. Refer to the following section for configuring the IP address for the management interface.

Example

At Console:

```
Debian GNU/Linux 9 sonic ttyS1
```

```
sonic login: admin
```

```
Password: YourPaSsWoRd
```

SSH from any remote server to sonic can be done by connecting to SONiC IP

```
user@debug:~$ ssh admin@sonic_ip_address(or SONIC DNS Name)
```

```
admin@sonic's password:
```

By default, login takes the user to the default prompt from which all the show commands can be executed.

5.2 Configuring the Management Interface

The management interface (eth0) in SONiC is configured (by default) to use DHCP client to get an IP address from a DHCP server.

Connect the management interface to the same network in which your DHCP server is connected and get the IP address from DHCP server. The IP address received from the DHCP server can be verified using the `/sbin/ifconfig eth0` Linux command.

SONiC provides a CLI to configure a static IP for the management interface. There are a few ways by which a static IP address can be configured for the management interface.

Use the `config interface ip add eth0` command.

Example

```
admin@sonic:~$ sudo config interface ip add eth0 20.11.12.13/24 20.11.12.254
```

Use config_db.json and configure the MGMT_INTERFACE key with the appropriate values. Refer to this [page](#).

Use minigraph.xml and configure "Management IP Interfaces" tag inside "DpgDesc" tag, as given on this [page](#).

Once the IP address is configured, it can be verified using either the show management_interface address command or the /sbin/ifconfig eth0 Linux command. Users can use SSH to log in to this management interface IP address from their management network.

Example

```
admin@sonic:~$ /sbin/ifconfig eth0
eth0: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
inet 10.11.11.13 netmask 255.255.255.0 broadcast 10.11.12.255
```

5.3 Getting Help

Help for Config Commands

All commands have in-built help that aids the user in understanding the command as well as the possible sub-commands and options. "-- help" can be used at any level of the command; i.e. it can be used at the command level, or sub-command level or at argument level.

The in-built help will display the available possibilities corresponding to that particular command/sub-command.

config --help

This command lists all the possible configuration commands at the top level.

Usage

config (-?|-h|--help)

Example

```
admin@sonic:~$ config --help
```

Usage: config [OPTIONS] COMMAND [ARGS]...

SONiC command line - 'config' command

Options:

-, -h, --help Show this message and exit.

Commands:

aaa	AAA command line
acl	ACL-related configuration tasks
bgp	BGP-related configuration tasks
container	Modify configuration of containers
dropcounters	Drop counter related configuration tasks
ecn	ECN-related configuration tasks
feature	Configure status of feature
hostname	Change device hostname without impacting the...
interface	Interface-related configuration tasks
interface_naming_mode	Modify interface naming mode for interacting with...
is-loopback-name-valid	Loopback name validation
kdump	Configure kdump
load	Import a previous saved config DB dump file.
load_mgmt_config	Reconfigure hostname and mgmt interface based on...
load_minigraph	Reconfigure based on minigraph.
loopback	Loopback-related configuration tasks
mclag	Multi-Chassis Link Aggregation Group-related...
mirror_session	
nat	NAT-related configuration tasks
neigh_suppress	Neighbour Suppress VLAN-related configuration
ntp	NTP server configuration tasks

pfcwd	Configure pfc watchdog
platform	Platform-related configuration tasks
portchannel	
pvlan	Private VLAN-related configuration tasks
qos	QoS-related configuration tasks
reload	Clear current configuration and import a previous...
route	route-related configuration tasks
sag	Static Anycast Gateway
save	Export current config DB to a file on disk.
sflow	sFlow-related configuration tasks
snmpagentaddress	SNMP agent listening IP address, port, vrf...
snmptrap	SNMP Trap server configuration to send traps
syslog	Syslog server configuration tasks
tacacs	TACACS+ server configuration
vlan	VLAN-related configuration tasks
vrf	VRF-related configuration tasks
vxlan	
warm_restart	warm_restart-related configuration tasks
watermark	Configure watermark
ztp	Configure Zero Touch Provisioning

Help for Show Commands

show -help

This command displays the full list of show commands available in the software; the output of each of those show commands can be used to analyze, debug or troubleshoot the network node.

Usage

show (-?|-h|--help)

Example

```
admin@sonic:~$ show --help
```

Usage: show [OPTIONS] COMMAND [ARGS]...

SONiC command line - 'show' command

Options:

-, -h, --help Show this message and exit.

Commands:

aaa	Show AAA configuration
acl	Show ACL related information
arp	Show IP ARP table
boot	Show boot configuration
buffer_pool	Show details of the buffer pools
clock	Show date and time
container	Show container
dropcounters	Show drop counter related information
ecn	Show ECN configuration
environment	Show environmentals (voltages, fans, temps)
features	Show status of optional features
interfaces	Show details of the network interfaces
ip	Show IP (IPv4) commands
ipv6	Show IPv6 commands
kdump	Show kdump configuration, status and information
line	Show all /dev/ttyUSB lines and their info
lldp	LLDP (Link Layer Discovery Protocol) information
logging	Show system log
mac	Show MAC (FDB) entries
management_interface	Show management interface parameters
mclag	Show MCLAG related information
mgmt-vrf	Show management VRF attributes
mirror_session	Show existing everflow sessions
mmu	Show mmu configuration
nat	Show details of the nat
ndp	Show IPv6 Neighbour table

neigh-suppress	show neigh_suppress
ntp	Show NTP information
pfc	Show details of the priority-flow-control (pfc)
pfcwd	Show details of the pfc watchdog
pim	Show details of the pims
platform	Show platform-specific hardware info
policer	Show existing policers
priority-group	Show details of the PGs
processes	Display process information
pvlan	Show Private VLAN related information
queue	Show details of the queues
reboot-cause	Show cause of most recent reboot
route-map	show route-map
runningconfiguration	Show current running configuration information
sag	show sag information
services	Show all daemon services
sflow	Show sFlow related information
snmpagentaddress	Show SNMP agent listening IP address configuration
snmptrap	Show SNMP agent Trap server configuration
startupconfiguration	Show startup configuration information
subinterfaces	Show details of the sub port interfaces
system-memory	Show memory information
tacacs	Show TACACS+ configuration
techsupport	Gather information for troubleshooting
uptime	Show system uptime
users	Show users
version	Show version information
vlan	Show VLAN information
vnet	Show vnet related information
vrf	Show vrf config
vxlan	Show VXLAN information
warm_restart	Show warm restart configuration and state
watermark	Show details of watermark
ztp	Show Zero Touch Provisioning status

The same syntax applies to all subgroups of show which themselves contain subcommands, and subcommands which accept options/arguments.

Example

```
admin@sonic:~$ show interface -?
Usage: show interface [OPTIONS] COMMAND [ARGS]...
Show details of the network interfaces

Options:
  -?, -h, --help  Show this message and exit.

Commands:
  alias      Show Interface Name/Alias Mapping
  breakout   Show Breakout Mode information by interfaces
  counters   Show interface counters
  description Show interface status, protocol and description
  naming_mode Show interface naming_mode status
  neighbor   Show neighbor related information
  portchannel Show PortChannel information
  status     Show Interface status information
  transceiver Show SFP Transceiver information
```

5.4 Basic Show Commands

Table of Contents

[Display system version](#)

[show version](#)

[Show System Status](#)

[show clock](#)

[show boot](#)

[show environment](#)

[show system status](#)

[show reboot-cause](#)

[show uptime](#)

[show logging](#)

[show users](#)

[Show Hardware Platform](#)

[show platform fan](#)

[show platform firmware status](#)

[show platform firmware update status\(not supported\)](#)

[show platform firmware updates](#)

[show platform firmware version](#)

[show platform pcieinfo](#)

[show platform psustatus](#)

[show platform ssdhealth](#)

[show platform summary](#)

[show platform syseeprom](#)

[show platform temperature](#)

[Transceivers](#)

[show interfaces transceiver](#)

[Show PIM Status](#)

[show pim status](#)

Display system version

show version

This command displays software component versions of the currently running SONiC image. This includes the SONiC image version as well as Docker image versions. This command displays relevant information as the SONiC and Linux kernel version being utilized, as well as the ID of the commit used to build the SONiC image. The second section of the output displays the various docker images and their associated IDs.

Usage

show version

Example

```
admin@sonic:~$ show version
```

SONiC Software Version: SONiC.2305.1.8_MLNX

SONiC OS Version: 11

Distribution: Debian 11.9

Kernel: 5.10.0-23-2-amd64

Build commit: ab82058e7

Build date: Tue Jun 25 03:53:22 UTC 2024

Built by: jenkins@server2

Platform: x86_64-accton_as9746-128d-r0

HwSKU: AS9746-128D

ASIC: mellanox

ASIC Count: 1

Serial Number: ATO42000011

Model Number: AS9746-128D

Hardware Revision: R0B

Uptime: 05:38:24 up 5 min, 1 user, load average: 2.03, 1.37, 0.63

Date: Wed 20 Nov 2024 05:38:24

Show System Status

This section explains some command sets that are used to display the status of various parameters pertaining to the physical state of the network node.

show clock

This command displays the current date and time configured on the system.

Usage
show clock

Example
admin@sonic:~\$ show clock Mon Mar 25 20:25:16 UTC 2019

show boot

This command displays the current OS image, the image to be loaded on next reboot, and lists all the available images installed on the device.

Usage
show boot

Example
admin@sonic:~\$ show boot Current: SONiC-OS-20181130.31 Next: SONiC-OS-20181130.31 Available: SONiC-OS-20181130.31

show environment

This command displays the platform environmentals, such as voltages, temperatures and fan speeds.

Usage

show environment

Example

Example

```
admin@sonic:~$ show environment
```

```
coretemp-isa-0000
```

```
Adapter: ISA adapter
```

```
Core 0:   +28.0 C (high = +98.0 C, crit = +98.0 C)
```

```
Core 1:   +28.0 C (high = +98.0 C, crit = +98.0 C)
```

```
Core 2:   +28.0 C (high = +98.0 C, crit = +98.0 C)
```

```
Core 3:   +28.0 C (high = +98.0 C, crit = +98.0 C)
```

```
SMF_Z9100_ON-isa-0000
```

```
Adapter: ISA adapter
```

```
CPU XP3R3V_EARLY:      +3.22 V
```

```
<... few more things ...>
```

```
Onboard Temperature Sensors:
```

```
CPU:                  30 C
```

```
BCM56960 (PSU side):   35 C
```

```
<... few more things ...>
```

```
Onboard Voltage Sensors:
```

```
CPU XP3R3V_EARLY      3.22 V
```

```
<... few more things ...>
```

```
Fan Trays:
```

```
Fan Tray 1:
```

```
Fan1 Speed:  6192 RPM
```

```
Fan2 Speed:  6362 RPM
```

```
Fan1 State:   Normal
```

```
Fan2 State:   Normal
```

```
Air Flow:     F2B
```

```
<... few more things ...>
```

```
PSUs:
PSU 1:
    Input:    AC
<... few more things ...>
```

NOTE: The show output includes a lot of information; only a sample output is shown in the above example. Though the displayed output slightly differs from one platform to another platform, the overall content will be similar to the example above.

show system status

This command displays if the SONiC system has finished booting or not.

You may use this command to inspect the progress state of the SONiC system bring-up. It might show the message in Example 2 (or 3) in the middle of the bring-up. If it is seen after the system is up, there could be some configuration issues in the configuration file.

Usage

```
show system status
```

The result of executing this command could be:

SONiC is ready, i.e. port provision is done and services are activated. (refer to Example1)

Port configuration is not fully provisioned (refer to Example2)

Not all SONiC services are ready (Example3, the "teamd" is not in service)

Example1 (SONiC is ready)

```
admin@sonic:~$ show system status
```

System is ready

Example2 (port provisioning incomplete)

admin@sonic:~\$ show system status

System is not ready - Ports are not up

Example3 (SONiC system is not ready)

admin@sonic:~\$ show system status

System is not ready - core service is down

Container and Inside Process Status

```
-----
database           Up
- redis            Up
swss                Up
- buffermgrd       Up
- fdbsyncd         Up
- intfmgd          Up
- intfsyncd        Up
- nbrmgrd          Up
- neighsyncd       Up
- orchagent        Up
- portmgrd         Up
- portsyncd        Up
- vlanmgrd         Up
- vrfmgrd          Up
- vxlanmgrd        Up
syncd              Up
- syncd            Up
bgp                Up
- bgpcfgd          Up
```

- bgpd	Up
- fpm syncd	Up
- staticd	Up
- zebra	Up
mgmt-framework	Up
pmon	Up
- psud	Up
- xcvr	Up
teamd	Down
- teammgrd	N/A
- teamsyncd	N/A
lldp	Up
- lldp syncd	Up
- lldpd	Up
- lldpmgrd	Up

Status:

- Up: container or process (inside the container) is active/running.
- Down: container or process (inside the container) is not active/running.
 - In this example, teamd is the container.
- N/A: daemons (inside of the container) are not available when the container is Down.
 - In this example, teammgrd or teamsyncd is the daemon.

show reboot-cause

This command displays the cause of the previous reboot.

Usage
show reboot-cause

Example

```
admin@sonic:~$ show reboot-cause
```

```
User issued reboot command [User: admin, Time: Mon Mar 25 01:02:03 UTC 2019]
```

show uptime

This command displays the current system uptime.

Usage

```
show uptime
```

Example

```
admin@sonic:~$ show uptime
```

```
up 2 days, 21 hours, 30 minutes
```

show logging

This command displays all the currently stored log messages. All the latest processes and corresponding transactions are stored in the "syslog" file. This file is saved in the path /var/log and can be viewed using the command `sudo cat syslog` as this requires root login.

Usage

```
show logging [(<process_name> [-l|--lines <number_of_lines>]) | (-f|--follow)]
```

Example

```
admin@sonic:~$ show logging
```

It can be useful to pipe the output from `show logging` to the command `more` in order to examine one screenful of log messages at a time.

Example

```
admin@sonic:~$ show logging | more
```

Optionally, you can specify a process name in order to display only log messages mentioning that process.

Example

```
admin@sonic:~$ show logging sensord
```

Optionally, you can specify a number of lines to display using the `-l` or `--lines` option. Only the most recent N lines will be displayed. Also, note that this option can be combined with a process name.

Example

```
admin@sonic:~$ show logging --lines 50
```

```
admin@sonic:~$ show logging sensord --lines 50
```

Optionally, you can follow the log live as entries are written to it by specifying the `-f` or `--follow` flag.

Example

```
admin@sonic:~$ show logging --follow
```

show users

This command displays a list of users currently logged in to the device.

Usage
show users

Example
admin@sonic:~\$ show users
admin pts/9 Mar 25 20:31 (100.127.20.23)
admin ttyS1 2019-03-25 20:31

Show Hardware Platform

The information displayed in this set of commands partially overlaps with the one generated by the "show environment" instruction. In this case though, the information is presented in a more succinct fashion. In the future, these two CLI stanzas may end up being combined.

show platform fan

This command displays the fans status and information.

Usage
show platform fan

Example								
admin@sonic:~\$ show platform fan								
<table><tr><th>Drawer</th><th>LED</th><th>FAN</th><th>Speed</th><th>Direction</th><th>Presence</th><th>Status</th><th>Timestamp</th></tr></table>	Drawer	LED	FAN	Speed	Direction	Presence	Status	Timestamp
Drawer	LED	FAN	Speed	Direction	Presence	Status	Timestamp	

```

-----
FanTray1 green    FAN-1F  40%  exhaust  Present  OK 20220527 07:21:02
FanTray1 green    FAN-1R  40%  exhaust  Present  OK 20220527 07:21:02
FanTray2 green    FAN-2F  40%  exhaust  Present  OK 20220527 07:21:02
FanTray2 green    FAN-2R  40%  exhaust  Present  OK 20220527 07:21:02
FanTray3 green    FAN-3F  40%  exhaust  Present  OK 20220527 07:21:02
FanTray3 green    FAN-3R  40%  exhaust  Present  OK 20220527 07:21:02
FanTray4 green    FAN-4F  40%  exhaust  Present  OK 20220527 07:21:02
FanTray4 green    FAN-4R  40%  exhaust  Present  OK 20220527 07:21:02
FanTray5 green    FAN-5F  40%  exhaust  Present  OK 20220527 07:21:02
FanTray5 green    FAN-5R  40%  exhaust  Present  OK 20220527 07:21:02
  N/A green PSU-1 FAN-1  12%  exhaust  Present  OK 20220527 07:21:19
  N/A green PSU-2 FAN-1  13%  exhaust  Present  OK 20220527 07:21:20

```

show platform firmware status

This command displays the platform components status.

Usage

```
show platform firmware status
```

Example

```
admin@sonic:~$ show platform firmware status
```

Chassis	Module	Component	Version	Description
5835-54X-O-AC-F	N/A	CPLD1	1	CPLD 1
		CPLD2	1	CPLD 2
		CPLD3	1	CPLD 3
		BIOS	v47.01.01.00	Basic Input/Output System

show platform firmware update status(not supported)

This command displays the platform components auto_update status.

Usage

```
show platform firmware update status
```

Note:

This command do not supported.

show platform firmware updates

This command displays the available updates.

Usage

```
show platform firmware updates
```

Example

```
root@sonic:/home/admin# show platform firmware updates
```

Chassis	Module	Component	Firmware	Version	Status
		OCM_CPLD	/etc/naddod/fw/n9500-64oc/components_fw/CX9880_OCM_CPLD_v0A07_Internal.vme	0a.07 / 0a.07	up-to-date
		BASE_CPLD	/etc/naddod/fw/n9500-64oc/components_fw/BASE_Board_CPLD_v0A.0Ah_Internal.vme	0a.0a / 0a.0a	up-to-date
		PORT_CPLD1	/etc/naddod/fw/n9500-64oc/components_fw/PORT1_CPLD_v0A05.vme	0a.05 / 0a.05	up-to-date
		PORT_CPLD2	/etc/naddod/fw/n9500-64oc/components_fw/PORT2_CPLD_v0A06.vme	0a.06 / 0a.06	up-to-date

FPGA	/etc/naddod/fw/n9500-64oc/components_fw/Switch_FPGA_v1A_04h_golden_v0A_04h_primary.bin	0a.04 / 0a.04	up-to-date
BIOS	/etc/naddod/fw/n9500-64oc/components_fw/cx9880_d1734-bios_v41.0A.00.05-SPS_05.00.04.0100.0.bin	v41.0A.00.05 / v41.0A.00.05	up-to-date
SDA_SSD	/etc/naddod/fw/n9500-64oc/components_fw/F3C1T108_240_480_960.bin		
TEV35U / F3C1T108	update is required		
SDB_SSD	/etc/naddod/fw/n9500-64oc/components_fw/F3C1T108_240_480_960.bin		
TEV35U / F3C1T108	update is required		

Note:

Not supported on DCS8500-128D, N9200-64D, N9500-128D, CN9500-128D, CN9500-64D, AS9736-64D.

Supported on AS9817-64OC, N9500-64OC.

This function check EEPROM TLV "0x21 Product Name" field, If not match platform/device name, this command will failed.

show platform firmware version

This command displays the utility version.

Usage

```
show platform firmware version
```

Example

```
admin@sonic:~$ show platform firmware version
```

```
fwutil version 2.0.0.0
```

show platform pcieinfo

This command displays the platform pcie information .

Usage

```
show platform pcieinfo
```

Example

```
admin@as5835-54x:~$ show platform pcieinfo
Failed to load platform Pcie module. Error : No module named 'sonic_platform.pcie', fallback to load Pcie
common utility.
=====Display PCIe Device=====
bus:dev.fn 00:00.0 - dev_id=0x1980, Host bridge: Intel Corporation Atom Processor C3000 Series System
Agent(rev 11)
bus:dev.fn 00:04.0 - dev_id=0x19a1, Host bridge: Intel Corporation Atom Processor C3000 Series
ErrorRegisters (rev 11)
bus:dev.fn 00:05.0 - dev_id=0x19a2, Generic system peripheral [0807]: Intel Corporation Atom Processor
C3000 Series Root Complex Event Collector (rev 11)
bus:dev.fn 00:06.0 - dev_id=0x19a3, PCI bridge: Intel Corporation Atom Processor C3000 Series Integrated
QATRoot Port (rev 11)
bus:dev.fn 00:09.0 - dev_id=0x19a4, PCI bridge: Intel Corporation Atom Processor C3000 Series PCI
ExpressRoot Port #0 (rev 11)
bus:dev.fn 00:0b.0 - dev_id=0x19a6, PCI bridge: Intel Corporation Atom Processor C3000 Series PCI
ExpressRoot Port #2 (rev 11)
bus:dev.fn 00:0e.0 - dev_id=0x19a8, PCI bridge: Intel Corporation Atom Processor C3000 Series PCI
ExpressRoot Port #4 (rev 11)
bus:dev.fn 00:10.0 - dev_id=0x19aa, PCI bridge: Intel Corporation Atom Processor C3000 Series PCI
ExpressRoot Port #6 (rev 11)
```

bus:dev.fn 00:12.0 - dev_id=0x19ac, System peripheral: Intel Corporation Atom Processor C3000 Series SMBus
Controller - Host (rev 11)

bus:dev.fn 00:13.0 - dev_id=0x19b2, SATA controller: Intel Corporation Atom Processor C3000 Series SATA Controller 0 (rev 11)

bus:dev.fn 00:15.0 - dev_id=0x19d0, USB controller: Intel Corporation Atom Processor C3000 Series USB 3.0 xHCI Controller (rev 11)

bus:dev.fn 00:16.0 - dev_id=0x19d1, PCI bridge: Intel Corporation Atom Processor C3000 Series Integrated LAN Root Port #0 (rev 11)

bus:dev.fn 00:17.0 - dev_id=0x19d2, PCI bridge: Intel Corporation Atom Processor C3000 Series Integrated LAN Root Port #1 (rev 11)

bus:dev.fn 00:18.0 - dev_id=0x19d3, Communication controller: Intel Corporation Atom Processor C3000 Series ME HECI 1 (rev 11)

bus:dev.fn 00:1a.0 - dev_id=0x19d8, Serial controller: Intel Corporation Atom Processor C3000 Series HSUART Controller (rev 11)

bus:dev.fn 00:1a.1 - dev_id=0x19d8, Serial controller: Intel Corporation Atom Processor C3000 Series HSUART Controller (rev 11)

bus:dev.fn 00:1a.2 - dev_id=0x19d8, Serial controller: Intel Corporation Atom Processor C3000 Series HSUART Controller (rev 11)

bus:dev.fn 00:1f.0 - dev_id=0x19dc, ISA bridge: Intel Corporation Atom Processor C3000 Series LPC or eSPI (rev 11)

bus:dev.fn 00:1f.1 - dev_id=0x19dd, Memory controller: Intel Corporation Atom Processor C3000 Series Primary to Side Band (P2SB) Bridge (rev 11)

bus:dev.fn 00:1f.2 - dev_id=0x19de, Memory controller: Intel Corporation Atom Processor C3000 Series Power Management Controller (rev 11)

bus:dev.fn 00:1f.4 - dev_id=0x19df, SMBus: Intel Corporation Atom Processor C3000 Series SMBus controller (rev 11)

```
bus:dev.fn 00:1f.5 - dev_id=0x19e0, Serial bus controller [0c80]: Intel Corporation Atom Processor C3000
Series SPI Controller (rev 11)
bus:dev.fn 01:00.0 - dev_id=0x19e2, Co-processor: Intel Corporation Atom Processor C3000 Series
QuickAssist
Technology (rev 11)
bus:dev.fn 02:00.0 - dev_id=0xb771, Ethernet controller: Broadcom Inc. and subsidiaries Device b771 (rev
01)
bus:dev.fn 05:00.0 - dev_id=0x1533, Ethernet controller: Intel Corporation I210 Gigabit Network Connection
(rev 03)
bus:dev.fn 06:00.0 - dev_id=0x15c2, Ethernet controller: Intel Corporation Ethernet Connection X553
Backplane (rev 11)
bus:dev.fn 08:00.0 - dev_id=0x15e5, Ethernet controller: Intel Corporation Ethernet Connection X553 1GbE
(rev 11)
```

show platform psustatus

This command displays the status of the device's power supply units.

Usage

```
show platform psustatus
```

Example

```
admin@sonic:~$ show platform psustatus
```

PSU	Model	Serial	HW Rev	Voltage (V)	Current (A)	Power (W)	Status	LED
PSU 1	YM-2651Y	N/A	N/A	12.06	4.62	56.00 OK	green	
PSU 2	YM-2651Y	N/A	N/A	12.23	5.82	71.00 OK	green	

show platform ssdhealth

This command displays health parameters of the device's SSD.

Usage

```
show platform ssdhealth [--vendor]
```

Example

```
admin@as9716-32d-1:~$ show platform ssdhealth
Device Model : M.2 (S42) 3ME4
Health      : 98.633%
Temperature : 40C
```

Note: This command needs root privilege.

show platform summary

This command displays a summary of the device's hardware platform.

Usage

```
show platform summary
```

Example

```
admin@Sonic:~$ show platform summary
Platform: x86_64-accton_as9746_32d-r0
HwSKU: Accton-AS9746-32D-100G
ASIC: broadcom
```

show platform syseeprom

This command displays information stored on the system EEPROM. Note that the output of this command is not the same for all vendor's platforms. A couple of example outputs are given below.

Usage	
show platform syseeprom	
Example	
<pre>admin@sonic:~\$ show platform syseeprom TlvInfo Header: Id String: TlvInfo Version: 1 Total Length: 117 TLV Name Code Len Value ----- Product Name 0x21 15 5835-54X-O-AC-F Part Number 0x22 13 FP1ZZ56540B7A Serial Number 0x23 14 583554X1218123 Base MAC Address 0x24 6 80:A2:35:D2:4C:B5 Platform Name 0x28 27 x86_64-accton_as5835_54x-r0 MAC Addresses 0x2A 2 256 Manufacturer 0x2B 6 Accton Manufacture Country 0x2C 2 CN Vendor Name 0x2D 8 Accton CRC-32 0xFE 4 0xA334B01A (checksum valid)</pre>	

show platform temperature

The command displays device temperature information.

Usage

```
show platform temperature
```

Example

```
admin@sonic:~$ show platform temperature
```

Sensor	Temperature	High TH	Low TH	Crit High TH	Crit Low TH	Warning	Timestamp
PSU-1 temp sensor 1	32	80	N/A	N/A	N/A	False	2022052707:51:05
PSU-2 temp sensor 2	32	80	N/A	N/A	N/A	False	2022052707:51:06
Temp sensor 1	35.5	80	N/A	N/A	N/A	False	2022052707:51:04
Temp sensor 2	26.5	80	N/A	N/A	N/A	False	2022052707:51:04
Temp sensor 3	28.5	80	N/A	N/A	N/A	False	2022052707:51:04
Temp sensor 4	28	80	N/A	N/A	N/A	False	2022052707:51:04

Transceivers

Displays diagnostic monitoring information of the transceivers.

show interfaces transceiver

This command displays transceiver information for all interfaces, or for a specific interface when the option `interface_name` is specified.

Usage

```
show interfaces transceiver (eeprom [-d|--dom] | lpmode | presence) [<interface_name>]
```

Example (Decode and display information stored on the EEPROM of SFP transceiver connected to Ethernet0)

```
admin@sonic:~$ show interfaces transceiver eeprom --dom Ethernet0
```

Ethernet0: SFP detected

Connector : No separable connector

Encoding : Unspecified

Extended Identifier : Unknown

Extended RateSelect Compliance : QSFP+ Rate Select Version 1

Identifier : QSFP+

Length Cable Assembly(m) : 1

Specification compliance :

10/40G Ethernet Compliance Code : 40GBASE-CR4

Fibre Channel Speed : 1200 Mbytes/Sec

Fibre Channel link length/Transmitter Technology : Electrical inter-enclosure (EL)

Fibre Channel transmission media : Twin Axial Pair (TW)

Vendor Date Code(YYYY-MM-DD Lot) : 2015-10-31

Vendor Name : XXXXX

Vendor OUI : XX-XX-XX

Vendor PN : 1111111111

Vendor Rev :

Vendor SN : 111111111

ChannelMonitorValues:

RX1Power: -1.1936dBm

RX2Power: -1.1793dBm

RX3Power: -0.9388dBm

RX4Power: -1.0729dBm

TX1Bias: 4.0140mA

TX2Bias: 4.0140mA

TX3Bias: 4.0140mA

TX4Bias: 4.0140mA

ModuleMonitorValues :

Temperature : 1.1111C

Vcc : 0.0000Volts

Example (Display status of low-power mode of SFP transceiver connected to Ethernet100):

```
admin@sonic:~$ show interfaces transceiver lpmode Ethernet100
```

Port	Low-power Mode
Ethernet100	On

Example (Display presence of SFP transceiver connected to Ethernet100):

```
admin@sonic:~$ show interfaces transceiver presence Ethernet100
```

Port	Presence
Ethernet100	Present

Show PIM Status

Displays the status of the PIM cards.

show pim status

This command displays information for all PIM cards.

Example (Display status for all PIM card):

```
admin@sonic:~$ show pim status
```

Slot Index	Operation	Status	Type	HW Status
slot 2	up	PIM-16Q	status code: 0b1	
slot 3	up	PIM-16Q	status code: 0b1	

slot 4	up	PIM-16Q status code: 0b1
slot 5	up	PIM-16Q status code: 0b1
slot 6	up	PIM-16Q status code: 0b1
slot 7	up	PIM-16Q status code: 0b1
slot 8	up	PIM-16Q status code: 0b1
slot 9	up	PIM-16Q status code: 0b0

Note: This command only works for platforms that support PIM hotswap, for example the AS8000.

6 Authentication, Authorization, and Accounting

This section captures the various show and configuration commands that are applicable to the AAA (Authentication, Authorization, and Accounting) module. You can configure the type of authentication (local or remote TACACS based) required for the users and also the authentication failthrough and fallback options.

6.1 AAA

Table of Contents

[AAA show commands](#)

[show aaa](#)

[AAA config commands](#)

[aaa authentication failthrough](#)

[aaa authentication fallback](#)

[aaa authentication login](#)

[aaa authentication login default](#)

[aaa authorization](#)

[aaa authorization default](#)

[aaa accounting](#)

[aaa accounting disable](#)

AAA show commands

This command is used to view the Authentication, Authorization & Accounting settings that are configured in the network node.

show aaa

This command displays the AAA settings currently present in the network node.

Usage
show aaa

Example
admin@sonic:~\$ show aaa AAA authentication login local (default) AAA authentication failthrough False (default) AAA authorization login local (default) AAA accounting login disable (default)

AAA config commands

This sub-section explains all the possible CLI based configuration options for the AAA module. The list of commands/sub-commands possible for AAA is given below.

Commands:

aaa authentication sub-commands:

aaa authentication failthrough

aaa authentication fallback

aaa authentication login

aaa authentication failthrough

This command is used to either enable or disable the failthrough option. This command is useful when a user has configured more than one authentication servers or methods. When an authentication request to the first server fails, this configuration allows it to continue the request to the next server or method. When this configuration is enabled, the authentication process continues through all servers or methods configured. When disabled and if the authentication request fails on first server, the authentication process will stop and the login will be disallowed.

Usage
config aaa authentication failthrough (enable disable default)

Parameters:

enable: This allows the AAA module to process with local authentication if remote authentication fails.

disable: This disallows the AAA module to proceed further if remote authentication fails.

default: This re-configures the default value, which is "disable".

The below example enables the failthrough option.

Example

```
admin@sonic:~$ sudo config aaa authentication failthrough enable
```

aaa authentication fallback

When the servers used in TACACS+ authentication are unreachable, it falls back to local authentication by default.

The fallback function is always enabled in the current design, which means this command takes no effect.

Usage

```
config aaa authentication fallback (enable | disable | default)
```

The below example enables the fallback option.

Example

```
admin@sonic:~$ sudo config aaa authentication fallback enable
```

aaa authentication login

This command is used to configure the sequence of the authentication methods must be performed.

Usage

```
config aaa authentication login {radius | tacacs+ | local} [radius | tacacs+ | local]...
```

Parameters:

radius: Enables remote authentication based on RADIUS.

tacacs+: Enables remote authentication based on TACACS+.

local: Uses local authentication.

default: Resets back to the default value, which is only "local" authentication.

The command below configures AAA to use a remote TACACS+ database for user authentication.

Example

```
admin@sonic:~$ sudo config aaa authentication login tacacs+ local
```

aaa authentication login default

This command is used to restore the aaa authentication login configuration.

Usage

```
config aaa authentication login default
```

Parameters:

default: Resets back to the default value, which is only "local" authentication.

aaa authorization

This command is used to enable authorization and define the sequence of the authorization methods must be performed.

Usage

```
config aaa authorization {tacacs+ | local} [local]
```

Parameters:

tacacs+: Enables TACACS+ authorization.

local: Enables local authorization.

default: Resets back to the default value, which is only "local" authorization.

Example

```
admin@sonic:~$ sudo config aaa authorization tacacs+
```

aaa authorization default

This command is used to restore the aaa authorization configuration.

Usage

```
config aaa authorization default
```

Parameters:

default: Resets back to the default value, which is only "local" authorization.

aaa accounting

This command is used to enable or disable accounting. If accounting enabled, all the methods will be performed.

Usage

```
config aaa accounting {tacacs+ | local} [tacacs+ | local]
```

Parameters:

tacacs+: Enable TACACS+ accounting.

local: Enable local accounting in syslog.

disable: Disable accounting.

Example
admin@sonic:~\$ sudo config aaa accounting tacacs+

aaa accounting disable

This command is used to disable accounting.

Usage
config aaa accounting disable

Parameters:

disable: Disable accounting.

6.2 TACACS+

Table of Contents

[TACACS+ show commands](#)

[show tacacs](#)

[TACACS+ config commands](#)

[config tacacs add](#)
[config tacacs delete](#)
[config tacacs authtype](#)
[config tacacs default authtype](#)
[config tacacs passkey](#)
[config tacacs default passkey](#)
[config tacacs timeout](#)
[config tacacs default timeout](#)
[config tacacs source ip](#)

TACACS+ show commands

show tacacs

This command displays the global configuration fields and the list of all TACACS+ servers and their corresponding configurations.

Usage
show tacacs

The command below shows the TACACS+ configuration.

Example

```
admin@sonic:~$ show tacacs
TACPLUS global auth_type pap (default)
TACPLUS global timeout 99
TACPLUS global passkey <EMPTY_STRING> (default)
TACPLUS_SERVER address 10.11.12.14
priority 9
tcp_port 50
auth_type mschap
timeout 10
```

```
passkey testing789
TACPLUS_SERVER address 10.0.0.9
priority 1
tcp_port 49
```

TACACS+ config commands

config tacacs add

This command is used to add a TACACS+ server to the TACACS server list. Note that more than one TACACS+ server (maximum of eight) can be added to the device. When a user tries to log in, the TACACS client will contact the servers one by one. When any server times

out, the device will try the other servers one by one based on the priority value configured for that server. When this command is executed, the configured TACACS+ server addresses are updated in the `/etc/pam.d/common-auth-sonic` configuration file that is being used by the TACACS service.

Usage

```
config tacacs add <ip_address> [-t|--timeout <seconds>] [-k|--key <secret>] [-a|--type <type>] [-o|--port <port>] [-p|--pri <priority>] [-m|--use-mgmt-vrf]
```

Parameters:

- `ip_address` : TACACS+ server IP address.
- `timeout` : transmission timeout interval in seconds. range 1 to 60, default 5
- `key` : shared secret key for authentication.
- `type` , "chap" or "pap" or "mschap" or "login".
 - default is "pap". port: TCP
 - "mschap" is not supported now and "pap" is used instead if authtype is configured as "mschap".
- `port` : port range is 1 to 65535. default 49.

- `pri` : priority.
 - range 1 to 64, default 1.
- `use-mgmt-vrf` : indicate that the server is part of the Management VRF.
 - default is "no vrf".

The command below adds a new TACACS+ server with the parameters.

Example

```
admin@sonic:~$ sudo config tacacs add 10.11.12.13 -t 10 -k testing789 -a pap -o 50 -p 9
```

config tacacs delete

This command is used to delete the TACACS+ servers configured.

Usage

```
config tacacs delete <ip_address>
```

Parameters:

`ip_address` : TACACS+ server IP address.

The example below deletes a TACACS+ server by IP address.

Example

```
admin@sonic:~$ sudo config tacacs delete 10.11.12.13
```

config tacacs authtype

This command is used to specify the global auth-type of TACACS+ servers.

Usage
<code>config tacacs authtype {chap pap mschap login}</code>

Parameters:

chap : Challenge-handshake authentication protocol.

pap: Password authentication protocol.

mschap : Microsoft version (version 2) of the challenge-handshake authentication protocol.

login : Clear text.

Example
<code>sudo config tacacs authtype mschap</code>

config tacacs default authtype

This command is used to restore the global auth-type of TACACS+ servers.

Usage
<code>config tacacs default authtype</code>

Parameters:

none. The default is pap .

Example
<code>sudo config tacacs default authtype</code>

config tacacs passkey

This command is used to specify the global passkey of TACACS+ servers.

Usage
config tacacs passkey <passkey>

Parameters:

passkey: shared secret key (Valid chars: ASCII printable except SPACE, '#', and COMMA).

Example
admin@sonic:~\$ sudo config tacacs passkey testing123

config tacacs default passkey

This command is used to restore the global passkey of TACACS+ servers.

Usage
config tacacs default passkey

Parameters:

none.

The default is blank string.

Example
sudo config tacacs default passkey

config tacacs timeout

This command is used to specify the global timeout of TACACS+ servers.

Usage
config tacacs timeout <timeout>

Parameters:

timeout : duration in seconds to wait for before determining that the server has failed to respond. Minimum:

1. Maximum: 60.

Example (Configure non-default case)
sudo config tacacs timeout 60

config tacacs default timeout

This command is used to restore the global timeout of TACACS+ servers.

Usage
config tacacs default timeout

Parameters:

none

The default is 5 seconds.

Example
sudo config tacacs default timeout

config tacacs source ip

This command is used to specify the global source address of TACACS+ servers.

Usage
<code>config tacacs sourceip <source-ip></code>

Parameters:

source-ip: source IP address (IPv4 or IPv6) for the outgoing TCP/IP dgram.

Example
<code>sudo config tacacs sourceip 192.168.3.45</code>

6.3 RADIUS

Table of Contents

[RADIUS Show Commands](#)

[show radius](#)

[RADIUS Configuration Commands](#)

[config radius timeout](#)

[config radius default timeout](#)

[config radius retransmit](#)

[config radius default retransmit](#)

[config radius authtype](#)

[config radius default authtype](#)

[config radius passkey](#)

[config radius default passkey](#)

[config radius source ip](#)

[config radius default source ip](#)

[config radius nasip](#)

[config radius default nasip](#)

[config radius statistics](#)

[config radius add](#)

[config radius delete](#)

The document shows several commands related to RADIUS service as a RADIUS client (NAS).

RADIUS Show Commands

show radius

This command is used to show RADIUS configuration.

Usage
show radius

Example
<pre>admin@sonic:~\$ show radius RADIUS global auth_type pap (default) RADIUS global retransmit 3 (default) RADIUS global timeout 5 (default) RADIUS global passkey <EMPTY_STRING> (default) RADIUS_SERVER address 192.168.3.45 auth_port 1812 priority 1</pre>

RADIUS Configuration Commands

config radius timeout

This command is used to specify the global timeout of RADIUS servers.

Usage
config radius timeout <timeout>

Parameters:

timeout: duration in seconds to wait for before determining that the server has failed to respond. Minimum:

1. Maximum: 60.

Example
sudo config radius time 5

config radius default timeout

This command is used to restore the global timeout of RADIUS servers.

Usage
config radius default timeout

Parameters:

none

The default is 5 seconds.

Example

```
sudo config radius default timeout
```

config radius retransmit

This command is used to specify the global retry attempts of RADIUS servers.

Usage

```
config radius retransmit <retries>
```

Parameters:

retries: number of times to re-send a packet, if there is no response. Minimum: 0. Maximum: 10.

Example

```
config radius retransmit 5
```

config radius default retransmit

This command is used to restore the global retry attempts of RADIUS servers.

Usage

```
config radius default retransmit
```

Parameters:

none

The default is 3 times.

Example

```
sudo config radius default retransmit
```

config radius authtype

This command is used to specify the global auth-type of RADIUS servers.

Usage

```
config radius authtype {chap|pap|mschapv2}
```

Parameters:

chap : Challenge-handshake authentication protocol.

pap: Password authentication protocol.

mschapv2 : Microsoft version (version 2) of the challenge-handshake authentication protocol.

Example

```
sudo config radius authtype chap
```

config radius default authtype

This command is used to restore the global auth-type of RADIUS servers.

Usage

```
config radius default authtype
```

Parameters:

none

The default is pap .

Example

<pre>sudo config radius default authtype</pre>
--

config radius passkey

This command is used to specify the global passkey of RADIUS servers.

Usage

<pre>config radius passkey <passkey></pre>
--

Parameters:

passkey: shared secret key (Valid chars: ASCII printable except SPACE, '#', and COMMA).

Example

<pre>sudo config radius passkey PASSKEY</pre>

config radius default passkey

This command is used to restore the global passkey of RADIUS servers.

Usage

<pre>config radius default passkey</pre>
--

Parameters:

none

The default is blank string.

Example

<pre>sudo config radius default passkey</pre>

config radius source ip

This command is used to specify the global source address of RADIUS servers.

Usage

<pre>config radius sourceip <source-ip></pre>

Parameters:

source-ip: source IP address (IPv4 or IPv6) used in the IP header of the outgoing UDP/IP dgram.

Example

<pre>sudo config radius sourceip 192.168.3.45</pre>

config radius default source ip

This command is use to restore the global source address of RADIUS servers.

Usage

<pre>config radius default sourceip</pre>

Parameters:

none

The default ip address is determined by routing stack.

Example

<pre>sudo config radius default sourceip</pre>
--

config radius nasip

This command is used to specify the global NAS-IP address of RADIUS servers.

Usage

<pre>config radius nasip <nas-ip></pre>

Parameters:

nas-ip: NAS-IP (IPv4 Address, Type4) or IPV6-Address (Type 95) attribute in the outgoing RADIUS PDU. If the nas-ip is not configured, one of the management IP addresses or the source IP address will be used as NAS-IP.

Example

<pre>sudo config radius nasip 192.168.3.45</pre>
--

config radius default nasip

This command is used to remove the global NAS-IP address of RADIUS servers.

Usage

<pre>config radius default nasip</pre>
--

Parameters:

none

Example

```
sudo config radius default nasip
```

config radius statistics

This command is used to specify the global statistics RADIUS servers.

Usage

```
config radius statistics {enable|disable|default}
```

Parameters:

enable: enable statistics collection.

disable: disable statistics collection.

default: reset to disable.

Example

```
sudo config radius statistics default
```

config radius add

Usage

```
config radius add <ip_address_or_domain_name> [--retransmit <retransmit>] [--timeout <timeout>] [--key  
<key>] [--auth_type {chap | pap | mschapv2}] [--auth-port <auth-port>] [--pri <priority>] [--user-mgmt-vrf]
```

```
[--source-interface <source-interface>]
```

Parameters:

- <ip_address_or_domain_name>: RADIUS server's DNS name, IPv4 or IPv6 address.
- <retransmit>: number of times to re-send a packet if there is no response.
- <timeout>: duration in seconds to wait for before determining that the server has failed to respond. <key>: shared secret key (Valid chars: ASCII printable except SPACE, '#', and COMMA).
- <auth_type>: authentication type. Valid values are:
 - chap : Challenge-handshake authentication protocol.
 - pap: Password authentication protocol.
 - mschapv2 : Microsoft version (version 2) of the challenge-handshake authentication protocol.
- <auth-port>: authentication port number.
- <priority>: specify RADIUS server's priority.
- --use-mgmt-vrf: use default vrf if not specified.
- <source-interface>: eg: eth0, Loopback0... Use the first IP address retrieved for the interface for the outgoing UDP/IP dgram. The default interface is determined by the routing stack.

Example

```
sudo config radius add 192.168.3.45 --key test --auth-port 10240
```

config radius delete

This command is used to delete a RADIUS server.

Usage

```
config radius delete <ip_address_or_domain_name>
```

Parameters:

<ip_address_or_domain_name>: IP address or domain name of RADIUS server.

Example
<pre>sudo config radius delete 192.168.3.45</pre>

6.4 User privilege

User privilege show command

userpri show

This command is used to show the privilege level information of users.

Usage

userpri show

Example

```
root@sonic:/home/admin# userpri show
test 7
local 1
root@sonic:/home/admin#
```

Notes:

- userpri show can display all users except root and admin.

Different user privilege levels correspond to different access permissions, which are locally authorized. The planning is as follows:

Privilege Level	Type	Group	Permissions
15	Admin	sudo/ docker	Can access all commands.

2-14	Regular User	users	Cannot use sudo su or access configuration commands (e.g., redis-cli , sonic-cli , vtysh , docker , etc.). Other commands, such as common Linux commands and show , are accessible.
1	Guest	users	Can only access show commands.

User privilege config command

userpri <username> <privilege>

This command is used to config the privilege level information of users.

Usage

userpri <username> <privilege>

Example

```
root@sonic:/home/admin# userpri local 1
root@sonic:/home/admin# userpri show
test 7
local 1
root@sonic:/home/admin#
```

Note:

- If the username does not exist, an error will be reported.
- It is not allowed to configure the privilege levels for root and admin.

7 ACL

Table of Contents

[ACL Show Commands](#)

[show acl table-type](#)

[show acl table](#)

[show acl rule](#)

[aclshow](#)

[counterpoll show](#)

[ACL Configuration Commands](#)

[config acl remove table-type](#)

[config acl add table](#)

[config acl remove table](#)

[config acl add rule](#)

[config acl remove rule](#)

[config acl update full](#)

[config acl update incremental](#)

[counterpoll acl enable](#)

[counterpoll acl disable](#)

[counterpoll acl interval](#)

This section explains the various show and configuration commands available **for** users.

ACL Show Commands

show acl table-type

This command is used to display the user-defined ACL table type.

Usage
<code>show acl table-type [<type_name>]</code>

Parameter

- **<type_name>**: The table type to be displayed.

The following example shows how to display all the ACL table types that are currently defined.

Example
<code>admin@sonic:~\$ show acl table-type</code>

Name	Bind Point	Match	Policer

L3_DSCP	PORT	Src IPv4 address	
		Dst IPv4 address	
		DSCP	
		IP type	

show acl table

Displays a specific table or all.

Usage

```
show acl table [<table_name>]
```

Parameter

- <table_name>, the table to be displayed.

This command shows the table's name, type, bound interface(s), and applied stage.

Example

```
admin@sonic:~$ show acl table
```

Name	Type	Binding	Description	Stage	Policer

EVERFLOW	MIRROR	Ethernet16	EVERFLOW	ingress	
		Ethernet96			
		Ethernet108			
		Ethernet112			

PortChannel0001
PortChannel0002
SNMP_ACL CTRLPLANE SNMP SNMP_ACL ingress
DT_ACL_T1 L3 Ethernet0 DATA_ACL_TABLE_1 egress
Ethernet4
Ethernet112
Ethernet116
SSH_ONLY CTRLPLANE SSH SSH_ONLY ingress

show acl rule

Displays the rules in a specific ACL table or all tables, or a specific rule in the specified table.

Usage
show acl rule [<table_name> [<rule_name>]]

Parameter

- <table_name>: The name of the ACL table to display the rules for.
- <rule_name>: The name of the rule to display.

Example						
admin@sonic:~\$ show acl rule						
Table	Rule	Priority	Action	Match	Status	

SNMP_ACL	RULE_1	9999	ACCEPT	IP_PROTOCOL: 17	Active	
			SRC_IP: 1.1.1.1/32	Active		

SSH_ONLY RULE_2	9998	ACCEPT	IP_PROTOCOL: 6	Active
		SRC_IP: 1.1.1.1/32	Active	
EVERFLOW RULE_3	9997	MIRROR INGRESS: everflow0	SRC_IP: 20.0.0.2/32	Active
EVERFLOW RULE_4	9996	MIRROR EGRESS : everflow1	L4_SRC_PORT: 4621	Active
DATAACL RULE_5	9995	REDIRECT: Ethernet8	IP_PROTOCOL: 126	Active
DATAACL RULE_6	9994	FORWARD	L4_SRC_PORT: 179	Active
DATAACL RULE_7	9993	FORWARD	L4_DST_PORT: 179	Active
SNMP_ACL DEFAULT_RULE 1		DROP	ETHER_TYPE: 2048	Active
SSH_ONLY DEFAULT_RULE 1		DROP	ETHER_TYPE: 2048	Active

Information in the table(s):

- Table: ACL table name
- Rule: ACL rule name in the table
- Priority: The priority of the rule, where a larger value indicating higher priority. The priority value is automatically assigned based on the sequence-id in the ACL rule configuration file. Please refer to the ACL Rule Configuration File section for more information.
- Action

action to be executed when a packet matches the rule. One of the following:

- ACCEPT
 - for control plane ACL
- DROP
- FORWARD
- MIRROR INGRESS <mirror section>
- MIRROR EGRESS <mirror section>
- REDIRECT <redirect-object>
 - <redirect-object> One of the following::
 - interface; e.g., physical interface (Ethernet10) or port channel (PortChannel0002)
 - next-hop IP address, e.g., "10.0.0.1"
 - next-hop group of IP address(s), e.g., "10.0.0.1, 10.0.0.3"

counterpoll show

Show each counter configuration.

Usage

counterpoll show

Example

```
admin@sonic:~$ counterpoll show
```

Type	Interval (in ms)	Status
QUEUE_STAT	1000	enable
PORT_STAT	default (1000)	enable
PORT_BUFFER_DROP	default (60000)	enable
RIF_STAT	default (1000)	enable
QUEUE_WATERMARK_STAT	10000	enable
PG_WATERMARK_STAT	10000	enable
PG_DROP_STAT	default (10000)	enable
BUFFER_POOL_WATERMARK_STAT	10000	enable
ACL	default (10000)	enable

ACL Configuration Commands

This sub-section explains the list of configuration options available **for** the ACL module.

config acl add table-type

This command is used to create a user-defined ACL table type.

```
config acl add table-type <type_name> [--bind-points <bind_points>]
[--match-vlan-id] [--match-cos]
[--match-src-ip4] [--match-dst-ip4]
[--match-src-ip6] [--match-dst-ip6]
[--match-dscp] [--match-l4-src-port] [--match-l4-dst-port]
[--action-set-policer]
```

Parameters:

- <type_name>: The name of the ACL table type.
- bind-points: A comma-separated list of interface types that can be bound to the ACL table type. Valid values are "PORT" and "PORTCHANNEL". The default value is "PORT".
- match-vlan-id: Specifies that the ACL table type can match the VLAN ID of IP packets.
- match-cos: Specifies that the ACL table type can match the VLAN PCP of IP packets.
- match-src-ip4: Specifies that the ACL table type can match the source IP address of IPv4 packets. This parameter cannot be specified with match-src-ip6 and match-dst-ip6 at the same time.
- match-dst-ip4: Specifies that the ACL table type can match the destination IP address of IPv4 packets. This parameter cannot be specified with match-src-ip6 and match-dst-ip6 at the same time.
- match-src-ip6: Specifies that the ACL table type can match the source IP address of IPv6 packets. This parameter cannot be specified with match-src-ip4 and match-dst-ip4 at the same time.
- match-dst-ip6: Specifies that the ACL table type can match the destination IP address of IPv6 packets. This parameter cannot be specified with match-src-ip4 and match-dst-ip4 at the same time.
- match-dscp: Specifies that the ACL table type can match the DSCP value of IP packets.
- match-l4-src-port: Specifies that the ACL table type can match the source port of TCP/UDP packets.
- match-l4-dst-port: Specifies that the ACL table type can match the destination port of TCP/UDP packets.
- action-set-policer: Specifies that the ACL table type can be bound to a policer.
- Notes:
 - The ACL table type only is supported to match IP packets (IPv4 or IPv6).
 - AS9736-64D switches, match-vlan-id and match-cos are not supported for the egress stage.

- The following example shows how to create a user-defined ACL table type that can be used to match the source IP address and DSCP for IPv4 packets.

Example

```
config acl add table-type L3_DSCP --match-src-ip4 --match-dscp
```

config acl remove table-type

This command is used to remove a user-defined ACL table type.

Usage

```
config acl remove table-type <type_name>
```

Parameters:

- **<type_name>**: The name of the ACL table type.

The following example shows how to remove a user-defined ACL table type.

Example

```
admin@sonic:~$ sudo config acl remove table-type L3_DSCP
```

config acl add table

This command applies an ACL to the data plane or control plane. When it's applied to the data plane, the rules are applied to the frame in chip. When it's applied to the control plane, they are applied to the frame trapped to the CPU from the chip.

When applying an ACL to the data plane, you need to use **<type>** to specify the IP header type or mirroring, the interface, and the stage at which the ACL rules of the table are applied for filtering or forwarding packets.

Usage for data plane

```
config acl add table <table_name> <type> [{-d | --description} <description>] [{-p | --ports} <interfaces>]
[{-s | --stage} {ingress | egress}] [--set-policer]
```

Parameter

- <table_name>: The name of the ACL table type.
- <type>: One of the following:
 - L3 : Inspect IPv4 header
 - L3V6 : Inspect IPv6 header
 - MIRROR : Inspect IPv4 header for mirroring
 - MIRRORV6 : Inspect IPv6 header for mirroring
 - MIRROR_DSCP: Inspect DSCP for mirroring
 - <table-type> : Specifies a user-defined ACL table type.
- <description>: A description to remind users of the goal. The default is the ACL table name.
- <interfaces>: The interface(s) that are bound to this ACL.
 - The interface(s) can be Ethernet, PortChannel, or VLAN. You may use commas ',' to separate multiple interfaces in the list (for example, "Ethernet01, Ethernet02, PortChannel0001"), but VLANs cannot be mix-configured with Ethernet or PortChannel interfaces.
 - The default option is to apply the ACL to all front ports and PortChannels.
- <stage>: The stage this ACL table will be applied to, either ingress or egress. The default is "ingress". set-policer: Specifies to enable the capability for binding a policer for the ACL rules in this table.

When applying to the control plane, use the keyword CTRLPLANE and list the service protocols to be examined. You cannot use <interface> since it is a management frame and the destination is the CPU.

Usage for control plane

```
config acl add table <table_name> CTRLPLANE [{-d | --description} <description>] {-v | --services}
<services_string>
```

Parameters:

- <table_name>, the ACL table to be applied to management frames.
- <description>, a description to remind users of the goal. The default is the ACL table name.
- <services_string>, a list of services to be matched, which are separated by commas. Valid values are:
 - "SNMP": SNMP protocol.
 - "NTP": NTP protocol.
 - "SSH": SSH protocol.

Some examples follow:

The ACL table "DATA_L3" is applied to interfaces "Ethernet0, Ethernet4" and inspects the IPv4 header in the ingress direction.

Example

```
admin@sonic:~$ sudo config acl add table DATA_L3 L3 --description "L3 table" --ports
"Ethernet0,Ethernet4" --
stage "ingress"
```

The ACL table "DATA_L3V6" is applied to interfaces "PortChannel0001, PortChannel0002" and inspects the IPv6 header in the ingressndirection.

Example

```
admin@sonic:~$ sudo config acl add table DATA_L3V6 L3V6 --description "L3V6 table" --ports
"PortChannel0001,PortChannel0002" --stage "ingress"
```

Note:

- The ACL table may not be provisioned **if** the chip is out of capacity, even when the ACL table exists in the configuration file. You would see "sonic ERR swss#orchagent: :- addAcITable: Failed to create ACL table" in syslog when an ACL table provisioning has failed.

The ACL table "DATA_CTRL" is applied to frames that are trapped to the CPU and whose services are SSH or SNMP.

Example

```
admin@sonic:~$ sudo config acl add table DATA_CTRL CTRLPLANE --description "CTRLPLANE table" --  
services "SSH,SNMP"
```

config acl remove table

This command is used to remove the binding of an ACL table on an interface. That is, the frames going through the interface are not inspected by the rule(s).

Usage

```
config acl remove table <table_name>
```

Parameters:

- <table_name>, the ACL table to be removed from binding.

Example

```
admin@sonic:~$ sudo config acl remove table DATA_L3  
  
admin@sonic:~$ sudo config acl remove table DATA_L3V6
```

config acl add rule

This command is used to create an ACL rule.

Usage for data plane

```
config acl add rule <table-name> {permit | deny}  
  
    [--priority <priority>]  
  
    [--name <name>]
```

```

[--vlan-id <vlan-id>] [--cos <cos>]

[--dscp <dscp>]

[--ip-protocol <ip-protocol>]

[--next-header <next-header>]

[--src-ip4 <src-ip>] [--dst-ip4 <dst-ip>]

[--src-ip6 <src-ip>] [--dst-ip6 <dst-ip>]

[--src-l4-port <src-l4-port>] [--dst-l4-port <dst-l4-port>]

[--src-l4-port-range <src-l4-port-range>] [--dst-l4-port-range <dst-l4-port-range>]

[--tcp-flags <tcp-flags>]

[--icmp-type <icmp-type>] [--icmp-code <icmp-code>]

[--icmpv6-type <icmp-type>] [--icmpv6-code <icmp-code>]

[--policer <policer-name>] [--set-dscp <set-dscp>] [--set-tc <set-tc>] [--set-cos <set-cos>]

[--mirror-ingress <mirror-session>]

```

Parameters:

- <table-name>: The name of the ACL table to add the rule to.
- <packet-action>: Specifies the action to take on packets that match the rule.
 - permit : Forward the packet. Default value.
 - deny : Drop the packet.
- priority: The priority of the rule. This is used to determine the order in which rules are evaluated. Higher numbers have
- higher priority. Minimum: "0". Maximum: "10000". If the value is not specified, a new priority is automatically assigned by adding a delta to the smallest priority such that the new priority is divisible by 10. For example, if the smallest priority is 11, the value will be 10 (delta is 1).
- name: The name of the rule. If the name is not specified, the name is automatically assigned as priority of the rule. • vlan-id: The VLAN ID of the packet. This is used to match tagged packets. Minimum: "1". Maximum: "4094".
- cos: The VLAN PCP field of the packet. This is used to match tagged packets. Minimum: "0". Maximum: "7".

- dscp: The DSCP value of the packet. This is used to match IP packets. Minimum: "0". Maximum: "63".
- ip-protocol: The IP protocol of the packet. Minimum: "0". Maximum: "255".
- next-header: The IPv6 next header of the packet. Minimum: "0". Maximum: "255".
- src-ip4: The source IPv4 address of the packet.
- dst-ip4: The destination IPv4 address of the packet.
- src-ip6: The source IPv6 address of the packet.
- dst-ip6: The destination IPv6 address of the packet.
- src-l4-port: The source TCP or UDP port of the packet. Minimum: "0". Maximum: "65535".
- dst-l4-port: The destination TCP or UDP port of the packet. Minimum: "0". Maximum: "65535".
- src-l4-port-range: The source TCP or UDP port range of the packet. Format: "<min>-<max>". Minimum: "0". Maximum: "65535".
- dst-l4-port-range: The destination TCP or UDP port range of the packet. Format: "<min>-<max>". Minimum: "0". Maximum: "65535".
- tcp-flags: The TCP flags of the packet, support comma-separated lists. The valid value is "fin", "syn", "rst", "psh", "ack", "urg", "ece" and "cwr".
- icmp-type: The ICMP type of the packet. Minimum: "0". Maximum: "255".
- icmp-code: The ICMP code of the packet. Minimum: "0". Maximum: "255".
- icmpv6-type: The ICMPv6 type of the packet. Minimum: "0". Maximum: "255".
- icmpv6-code: The ICMPv6 code of the packet. Minimum: "0". Maximum: "255".
- policer: The name of the policer to bind to this rule.
- set-cos: The new VLAN PCP value to set for packets that match this rule.
- set-dscp: The new DSCP value to set for packets that match this rule.
- set-tc: The new Traffic Class (TC) value to set for packets that match this rule.
- mirror-session: The mirror session name. This option is only supported for the ACL table type is MIRROR, MIRRORV6, and MIRROR_DSCP.

Notes:

- This command is not supported to add a rule for the CTRLPLANE ACL table type.
- The priority of actions is: drop (packet_action) > policer's actions > { set_dscp, set_tc, set_cos }. · If no match criteria are specified, all IP packets will be matched.
- If specified the set-cos action, it will override the value configured in TC2COS QoS map.
- If specified the set-dscp action, it will override the value configured in TC2DSCP QoS map.
- The AS9736-64D switch does not support specifying set-cos and policer for the egress stage.

The following example shows how to create a rule that uses to remark the DSCP from 0 to 7.

Example

```
sudo config acl add table-type L3_DSCP --match-dscp

sudo config acl add table L3_DSCP_TABLE L3_DSCP --description "DiffServ table" --ports
"Ethernet0,Ethernet4" --stage "ingress"

sudo config acl add rule L3_DSCP_TABLE permit --priority 10000 --name DSCP 0 rule --dscp 0 --set-dscp 7
```

The following example shows how to create a rule that uses to drop the packets with DSCP of 63.

Example

```
sudo config acl add table-type L3_DSCP --match-dscp

sudo config acl add table L3_DSCP_TABLE L3_DSCP --description "DiffServ table" --ports
"Ethernet0,Ethernet4" --stage "ingress" sudo config acl add rule diffserv_table deny --priority 10 --dscp 63
```

config acl remove rule

This command is used to remove an ACL rule.

Usage

```
config acl remove rule <table_name> [--priority <priority> | --name <name>]
```

Parameters:

- <table_name>: The ACL table name.
- <priority>: The priority of the rule to delete.
- <name>: The name of the rule to delete.

The following examples show how to delete the rule with priority 10 in ACL table "L3_DSCP_TABLE".

```
sudo config acl remove rule L3_DSCP_TABLE --priority 10
```

config acl update full

This command is used to update the rules in all tables, or one specific table that already exists. That is, this command does not create an ACL table if it has not been created. You can use the `show acl rule` command to examine the updated ACL rules.

Usage

```
config acl update full [--table_name <table_name>] [--session_name <session_name>]
<acl_configuration_file>
```

Parameters:

- `<table_name>`, the name of the ACL table to be loaded from the configuration file. Example:
`config acl update full "- - table_name DT_ACL_T1 /etc/sonic/acl_table_1.json"`
- `<session_name>`, the mirror session to be loaded from the configuration file. Example: `config acl update full "- -session_name mirror_ses1 /etc/sonic/acl_table_1.json"`
 - this command fails if the `<session_name>` does not exist in the the configuration file when it is specified.
- `<acl_configuration_file>`, a json file that contains the ACL configurations. Refer to section ACL Rule Configuration File for details.

Note :

- The ACL rules may not be provisioned if the chip is out of capacity (even when the rules exist in the configuration file) or the value of some parameters are invalid. You would see "sonic ERR swss#orchagent: :- Failed to create ACL rule. Rule configuration is invalid" in syslog when an ACL rule provisioning has failed.
- Each ACL table contains a default rule that matches everything if none of the higher priority rules are matched. The default rule is used to deny any unmatched traffic.

The following examples show how to 1. replace all ACL tables, 2. replace the ACL table "DATA_L3" only, 3. replace the mirroring session "flow_local_l3" only.

Example

```
admin@sonic:~$ sudo config acl update full acl_rule_L3_scrip_dstip.json
```

```
admin@sonic:~$ sudo config acl update full --table_name DATA_L3 acl_rule_L3_scrip_dstip.json
```

```
admin@sonic:~$ sudo config acl update full --session_name flow_local_l3 acl_rule_L3_mirror_session.json
```

The configuration file "acl_rule_L3_scrip_dstip.json" has one rule in the "DATA_L3" table: forward (ACCEPT) the IPv4 packet whose destination IP address is "4.4.4.4" and source IP address is "3.3.3.3".

acl_rule_L3_scrip_dstip.json

```
{
  "acl":
  {
    "acl-sets":
    {
      "acl-set":
      {
        "DATA_L3":
        {
          "acl-entries":
          {
            "acl-entry":
            {
              "1":
              {
                "ip":
```

```
{
  "config":
  {
    "destination-ip-address": "4.4.4.4/32",
    "source-ip-address": "3.3.3.3/32"
  }
},
"config":
{
  "sequence-id": 1
},
"actions":
{
  "config":
  {
    "forwarding-action": "ACCEPT"
  }
}
}
}
}
}
}
```

```
}  
}
```

Note: This command removes all the rules in ACL tables and inserts the rules in the input file, i.e., it replaces the rule(s) with those in the configuration file.

The following example shows how to create a rule to match any packets and forward them.

Example

```
admin@sonic:~$ sudo config acl update full acl_rule_match_any_forward.json
```

The configuration file "acl_rule_match_any_forward.json" has one rule in the "DATA_L3" table: forward (ACCEPT) any packets.

acl_rule_match_any_forward.json

```
cat > acl_rule.json << EEE  
{  
  "acl":  
  {  
    "acl-sets":  
    {  
      "acl-set":  
      {  
        "DATA_L3":  
        {
```

```
"acl-entries":
{
  "acl-entry":
  {
    "1":
    {
      "config":
      {
        "sequence-id": 1
      },
      "actions":
      {
        "config":
        {
          "forwarding-action": "ACCEPT"
        }
      }
    }
  }
}
```

```
}
```

config acl update incremental

Compared to `config acl update full`, this command performs incremental updates, which checks and modifies the corresponding rule(s), or updates the mirror session **if** `<session name>` is specified and configured.

Usage

```
config acl update incremental [--session_name <session_name>] <acl_json_file>
```

Parameters

- `<session_name>`, the mirror session to be loaded from the configuration file. Example: `config acl update incremental "- - session_name mirror_ses1 /etc/sonic/acl_table_1.json"`
- `<acl_json_file>`, a json file that contains the ACL configurations. Refer to section ACL Rule Configuration File **for** details.

Note :

- The ACL rules may not be provisioned **if** the chip is out of capacity (even when the rules exist in the configuration file) or the value of some parameters are invalid. You would see "sonic ERR swss#orchagent: :- Failed to create ACL rule. Rule configuration is invalid" in syslog when an ACL table provisioning has failed.
- Each ACL table contains a default rule that matches everything **if** none of the higher priority rules are matched. The default rule is used to deny any unmatched traffic.

Example

```
admin@sonic:~$ sudo config acl update incremental acl_rule_L3_scrip_dstip.json

admin@sonic:~$ sudo config acl update incremental --session_name flow_local_l3
acl_rule_L3_mirror_session.json
```

counterpoll acl enable

Activate the flex counter to monitor the number and the size (in bytes) of packets that match the ACL rule.

Usage
<code>counterpoll acl enable</code>

Example
<code>admin@sonic:~\$ counterpoll acl enable</code>

counterpoll acl disable

Deactivate the flex counter to monitor the number of packets and bytes that match the ACL rule. When the flex counter is disabled, the hardware counter will still increase **if** the packets match the ACL rule. Once the flex counter is activate again, it will obtainthe latest number of packets matched the ACL rule. To clear the counter, use the `aclshow -c` command.

Usage
<code>counterpoll acl disable</code>

Example
<code>admin@sonic:~\$ counterpoll acl disable</code>

counterpoll acl interval

Set the polling interval of flex counter.

Usage

```
counterpoll acl interval <poll_interval>
```

Parameters

- <poll_interval>: the interval in milliseconds to poll the ACL rule matched count. Minimum: 1000. Maximum: 30000.

Configure the polling interval to 2 seconds.

Example

```
admin@sonic:~$ counterpoll acl interval 2000
```

8 ARP

[ARP show commands](#)

[show arp](#)

[ARP Config Command](#)

[config interface arp add/remove](#)

[config interface arp aging](#)

[config interface arp gratuitous](#)

[config vlan arp_host_route](#)

[config vlan proxy_arp](#)

ARP show commands

show arp

This command displays the ARP entries in the device with the following options.

1. Display the entire table.
2. Display the ARP entries learned on a specific interface.
3. Display the ARP of a specific IP address.

Usage

```
show arp [-if|--iface <interface_name>] [<ip_address>]
```

Details:

- show arp: Displays all entries.
- show arp -if <interface_name>: Displays the entries that are associated with the specified interface <interface_name>.
- show arp <ip_address>: Displays the entries that are associated with the specified address <ip_address>.

Example

```
admin@sonic:~$ show arp
```

Address	MacAddress	Iface	Vlan
192.168.1.183	88:5a:92:fb:bf:41	Ethernet44	-
192.168.1.175	88:5a:92:fc:95:81	Ethernet28	-
192.168.1.181	e4:c7:22:c1:07:7c	Ethernet40	-
192.168.1.179	88:5a:92:de:a8:bc	Ethernet36	-
192.168.1.118	00:1c:73:3c:de:43	Ethernet64	-

```
192.168.1.11 00:1c:73:3c:e1:38 Ethernet88 -
192.168.1.161 24:e9:b3:71:3a:01 Ethernet0 -
192.168.1.189 24:e9:b3:9d:57:41 Ethernet56 -
192.168.1.187 74:26:ac:8b:8f:c1 Ethernet52 -
192.168.1.165 88:5a:92:de:a0:7c Ethernet8 -
Total number of entries 10
```

Optionally, you can specify the interface in order to display the ARPs learnt on that particular interface.

Example

```
admin@sonic:~$ show arp -if Ethernet40
Address      MacAddress    Iface    Vlan
-----
192.168.1.181 e4:c7:22:c1:07:7c Ethernet40 -
Total number of entries 1
```

Optionally, you can specify an IP address in order to display only that particular entry.

Example

```
admin@sonic:~$ show arp 192.168.1.181
Address      MacAddress    Iface    Vlan
192.168.1.181 e4:c7:22:c1:07:7c Ethernet40 -
Total number of entries 1
```

ARP Config Command

config interface arp add/remove

Usage

```
config interface arp add <interface_name> <arp_address> <mac-address>
```

```
config interface arp remove <interface_name> <arp_address>
```

Parameter:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <arp_address>, arp_address can be an IPv4 or IPv6 address (A.B.C.D/X:X::X:X) .
- <mac-address>, mac address as xx:xx:xx:xx:xx:xx.

Example

```
admin@sonic:~$ sudo config interface arp add Vlan10 10.10.10.10 a8:eb:d3:36:a5:82
admin@sonic:~$ sudo config interface arp remove Vlan10 10.10.10.10
```

Example

```
admin@sonic:~$ sudo config interface ip add Ethernet16 2016::6/64
admin@sonic:~$ sudo config interface arp add Ethernet16 2016::80 a8:eb:d3:36:80:80
admin@sonic:~$ sudo config interface arp remove Ethernet16 2016::80
```

config interface arp aging

Usage

```
config interface arp aging <interface_name> <interface_arp_aging>
```

Parameter:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <interface_arp_aging>: The default ARP aging time is 1800s, and the configuration range is 300~86400

Note:

- If you have already learned ARP, configuring ARP aging time will not take effect immediately. You need to wait for ARP aging before the aging time configuration will take effect.
- Use **show interfaces arp** command, you can view ARP aging configuration information on the interface.

Example

```
admin@sonic:~$ sudo config interface arp aging Vlan10 10000
```

config interface arp gratuitous

Usage

```
config interface arp gratuitous enable  
config interface arp gratuitous remove
```

Note:

The default for free ARP is discard, and after enabling free ARP, the received free ARP packets can be added to the ARP cache.

Use **show interfaces arp** command, you can view ARP gratuitous configuration information on the interface.

Example

```
admin@sonic:~$ sudo config interface arp gratuitous enable Vlan10
admin@sonic:~$ sudo config interface arp gratuitous disable Vlan10
```

config vlan arp_host_route

Usage

```
config vlan arp_host_route < vid > { enabled | disable }
```

Note:

- ARP host routing is disabled by default and can only be configured on VLAN interfaces. ARP to host routing converts ARP to "K" type routing.
- Use **show interfaces arp** command, you can view ARP arp_host_route configuration information on the interface.

Usage

```
admin@sonic:~$ sudo config vlan proxy_arp 10 enabled
admin@sonic:~$ sudo config vlan proxy_arp 10 disabled
```

config vlan proxy_arp

Usage

```
config vlan proxy_arp < vid > { enabled | disable }
```

Note:

ARP proxy is disabled by default and can only be configured on VLAN interfaces.

Use **show vlan brief** to show the configuration.

Usage

```
admin@sonic:~$ sudo config vlan proxy_arp 10 enabled
admin@sonic:~$ sudo config vlan proxy_arp 10 disabled
```

9 BFD

Table of Contents

[BFD Show Commands](#)

[show bfd peers](#)

[show bfd peer](#)

[show bfd peer\(s\) counters](#)

[show peer summary](#)

[BFD Peer Specific Commands](#)

[peer](#)

[receive-interval](#)

[transmit-interval](#)

[echo-interval](#)

[echo-mode](#)

[BGP BFD Commands](#)

[bfd](#)

[ebgp-multihop](#)

[bfd info on bgp neighbors](#)

Bidirectional Forwarding Detection (BFD) uses the FRR vtysh shell CLI. The following commands are available in the FRR shell. Use the command vtysh to enter FRR mode.

Example

```
admin@sonic:~$ vtysh
Hello, this is FRRouting (version 7.2.1-sonic).
Copyright 1996-2005 Kunihiro Ishiguro, et al.

sonic#
```

Refer to FRR BFDd Commands and FRR BGP Commands for more related FRR commands.

BFD Show Commands

This sub-section explains how to display BFD information.

show bfd peers

Shows all configured BFD peer information and the current status. Note: This command is executed within vtysh.

Usage

```
show bfd [vrf <vrf_name>] peers [json]
```

Example

```
sonic# show bfd peers
```

BFD Peers:

peer 192.169.3.33 vrf default

ID: 1766365608

Remote ID: 455730325

Status: up

Uptime: 9 second(s)

Diagnostics: ok

Remote diagnostics: ok

Local timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 50ms

Remote timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 50ms

peer 192.169.1.11 vrf default

ID: 1991080464

Remote ID: 3120344281

Status: up

Uptime: 2 hour(s), 5 minute(s), 11 second(s)

Diagnostics: ok

Remote diagnostics: ok

Local timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 50ms

Remote timers:

Receive interval: 300ms
Transmission interval: 300ms
Echo transmission interval: 50ms

Example (json)

```
sonic# show bfd peers json
[{"multihop":false,"peer":"192.169.3.33","vrf":"default","id":1766365608,"remote-id":455730325,"status":"up","uptime":355,"diagnostic":"ok","remote-diagnostic":"ok","receive-interval":300,"transmit-interval":300,"echo-interval":0,"remote-receive-interval":300,"remote-transmit-interval":300,"remote-echo-interval":50},{"multihop":false,"peer":"192.169.1.11","vrf":"default","id":1991080464,"remote-id":3120344281,"status":"up","uptime":7857,"diagnostic":"ok","remote-diagnostic":"ok","receive-interval":300,"transmit-interval":300,"echo-interval":0,"remote-receive-interval":300,"remote-transmit-interval":300,"remote-echo-interval":50}]
```

show bfd peer

shows specified BFD peer information and the current status. Note: This command is executed within vtysh.

Usage

```
show bfd [vrf <vrf_name>] peer [ipv4_addr|peer_label|ipv6_addr]
```

Example

```
sonic# show bfd vrf default peer 192.169.1.11
BFD Peer:
  peer 192.169.1.11 vrf default
  ID: 1991080464
  Remote ID: 3120344281
  Status: up
  Uptime: 2 hour(s), 42 minute(s), 25 second(s)
  Diagnostics: ok
  Remote diagnostics: ok
```

Local timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 50ms

Remote timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 50ms

Example (json)

```
sonic# show bfd peer 192.169.1.11 json
```

```
{ "multihop": false, "peer": "192.169.1.11", "vrf": "default", "id": 1991080464, "remote-id": 3120344281, "status": "up", "uptime": 10273, "diagnostic": "ok", "remote-diagnostic": "ok", "receive-interval": 300, "transmit-interval": 300, "echo-interval": 0, "remote-receive-interval": 300, "remote-transmit-interval": 300, "remote-echo-interval": 50 }
```

Please note that this command can be executed on the host interface, as shown in the following example executed outside of vtysh.

Example

```
admin@sonic:~$ show bfd peer 10.0.1.1
```

Total number of BFD sessions for peer IP 10.0.1.1: 1

Peer Addr	Interface	Vrf	State	Type	Local Addr	TX Interval	RX Interval	Multiplier	Multihop
10.0.1.1	default	default	DOWN	async_active	10.0.0.1	300	500	3	true

show bfd peer(s) counters

Shows BFD counters for a particular BFD session. Note: This command is executed within vtysh.

Usage

```
show bfd peer counters
show bfd peers counters
```

Example (all peers)

```
sonic# show bfd peers counters
```

BFD Peers:

peer 192.169.3.33 vrf default

Control packet input: 15996 packets

Control packet output: 16008 packets

Echo packet input: 0 packets

Echo packet output: 0 packets

Session up events: 1

Session down events: 0

Zebra notifications: 1

peer 192.169.1.11 vrf default

Control packet input: 44536 packets

Control packet output: 44542 packets

Echo packet input: 0 packets

Echo packet output: 0 packets

Session up events: 1

Session down events: 0

Zebra notifications: 1

Example (specified peer)

```
sonic# show bfd peer 192.169.3.33 counters
```

BFD Peers:

peer 192.169.3.33 vrf default

Control packet input: 15996 packets

Control packet output: 16008 packets

Echo packet input: 0 packets

Echo packet output: 0 packets

```
Session up events: 1
Session down events: 0
Zebra notifications: 1
```

show peer summary

This command displays the state and key parameters of all BFD sessions.

Note: This command can be executed on the host interface, and the following example shows the result when executed outside of vtysh.

Usage

```
show bfd summary
```

Example

```
admin@sonic:~$ show bfd summary
```

Total number of BFD sessions: 3

Peer Addr	Interface	Vrf	State	Type	Local Addr	TX Interval	RX Interval	Multiplier	Multihop
10.0.1.1	default	default	DOWN	async_active	10.0.0.1	300	500	3	true
10.0.2.1	Ethernet12	default	UP	async_active	10.0.0.1	200	600	3	false
2000::10:1	default	default	UP	async_active	2000::1	100	700	3	false

BFD Peer Specific Commands

This sub-section explains how to configure a BFD peer and its settings.

All commands in this sub-section are entered in BFD mode. Use the `bfd` command to open the BFD daemon configuration mode.

Example

```
sonic# config
sonic(config)# bfd
sonic(config-bfd)#
```

peer

Creates and configures a new BFD peer to listen and talk to.

Usage

```
peer <ipv4_addr|ipv6_addr>
```

Example

```
sonic(config-bfd)# peer 192.169.1.11
sonic(config-bfd-peer)#
```

receive-interval

Configures the minimum interval that this system is capable of receiving control packets. The default value is 300 milliseconds.

Usage

```
receive-interval <value_in_ms>
```

Example

```
sonic(config-bfd)# peer 192.169.1.11
sonic(config-bfd-peer)# receive-interval 1000
sonic(config-bfd-peer)# end
sonic# show bfd peer 192.169.1.11
BFD Peer:
  peer 192.169.1.11 vrf default
  ID: 1991080464
  Remote ID: 3120344281
  Status: up
```

Uptime: 4 hour(s), 11 minute(s), 22 second(s)

Diagnostics: ok

Remote diagnostics: ok

Local timers:

Receive interval: 1000ms

Transmission interval: 300ms

Echo transmission interval: 50ms

Remote timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 50ms

transmit-interval

Configures the minimum transmission interval that this system wants to use to send BFD control packets. The default value is 300 milliseconds.

Usage

```
transmit-interval <value_in_ms>
```

Example

```
sonic(config-bfd)# peer 192.169.1.11
sonic(config-bfd-peer)# transmit-interval 1000
sonic(config-bfd-peer)# end
sonic# show bfd peer 192.169.1.11
BFD Peer:
  peer 192.169.1.11 vrf default
  ID: 1991080464
  Remote ID: 3120344281
  Status: up
  Uptime: 4 hour(s), 13 minute(s), 36 second(s)
```

```

Diagnostics: ok
Remote diagnostics: ok
Local timers:
    Receive interval: 1000ms
    Transmission interval: 1000ms
    Echo transmission interval: 50ms
Remote timers:
    Receive interval: 300ms
    Transmission interval: 300ms
    Echo transmission interval: 50ms

```

echo-interval

Configures the minimum echo receive transmission interval. The default value is 50 milliseconds.

Usage

```
echo-interval <value_in_ms>
```

Example

```

sonic(config-bfd)# peer 192.169.1.11
sonic(config-bfd-peer)# echo-interval 100
sonic(config-bfd-peer)# end
sonic# show bfd peer 192.169.1.11
BFD Peer:
    peer 192.169.1.11 vrf default
    ID: 1991080464
    Remote ID: 3120344281
    Status: up
    Uptime: 4 hour(s), 29 minute(s), 12 second(s)
    Diagnostics: ok
    Remote diagnostics: ok
    Local timers:

```

Receive interval: 1000ms Transmission interval: 1000ms Echo transmission interval: 100ms Remote timers: Receive interval: 300ms Transmission interval: 300ms Echo transmission interval: 50ms

echo-mode

Enables/disables the echo transmission mode. This mode is disabled by default.

It is recommended that the transmission interval of control packets to be increased after enabling echo-mode to reduce bandwidth usage. For example: transmit-interval 2000.

When using multi-hop mode, echo-mode will not work (see RFC 5883 section 3).

Usage

[no] echo-mode

Example

```
sonic(config-bfd)# peer 192.169.1.11
sonic(config-bfd-peer)# echo-mode
sonic(config-bfd-peer)# no echo-mode
```

BGP BFD Commands

This sub-section explains how to configure or display BFD related settings on BGP neighbors.

The following commands are available in BGP configuration mode.

Usage

```
router bgp <as_id>
```

Example

```
sonic# config
sonic(config)# router bgp 65101
sonic(config-router)#
```

bfd

Enables/disables BFD on BGP neighbors.

Usage

```
[no] neighbor <ipv4_addr|ipv6_addr|peer_label> bfd
```

Example

```
sonic(config-router)# neighbor 192.169.0.2 remote-as 65101
sonic(config-router)# neighbor 192.169.0.2 bfd
```

ebgp-multihop

Specifying ebgp-multihop allows sessions with eBGP neighbors to establish when they are multiple hops away.

Usage

```
[no] neighbor <ipv4_addr|neighbor_interface|ipv6_addr> ebgp-multihop
```

Example

```
sonic(config-router)# neighbor 192.169.0.2 ebgp-multihop
```

bfd info on bgp neighbors

When BGP neighbors use BFD to detect if the next hop router is alive, the BFD related information is shown in `show bgp neighbors`.

Usage

```
show bgp neighbors [ipv4_addr|neighbor_interface|ipv6_addr]
```

Example (single hop)

```
sonic# config
sonic(config)# router bgp 65101
sonic(config-router)# neighbor 192.169.0.2 remote-as 65101
sonic(config-router)# neighbor 192.169.0.2 bfd
sonic(config-router)# end
sonic# show bgp neighbors
BGP neighbor is 192.169.0.2, remote AS 65101, local AS 65101, internal link
Hostname: sonic
BGP version 4, remote router ID 192.169.0.2, local router ID 192.169.0.1
BGP state = Established, up for 00:01:18
Last read 00:00:18, Last write 00:00:18
Hold time is 180, keepalive interval is 60 seconds
Neighbor capabilities:
  4 Byte AS: advertised and received
  AddPath:
    IPv4 Unicast: RX advertised IPv4 Unicast and received
  Route refresh: advertised and received(old & new)
  Address Family IPv4 Unicast: advertised and received
  Hostname Capability: advertised (name: sonic, domain name: n/a) received (name: sonic, domain name: n/a)
  Graceful Restart Capabilty: advertised and received
  Remote Restart timer is 120 seconds
  Address families by peer:
    none
Graceful restart information:
  End-of-RIB send: IPv4 Unicast
```

End-of-RIB received: IPv4 Unicast

Message statistics:

Inq depth is 0

Outq depth is 0

	Sent	Rcvd
Opens:	1	1
Notifications:	0	0
Updates:	1	1
Keepalives:	2	2
Route Refresh:	0	0
Capability:	0	0
Total:	4	4

Minimum time between advertisement runs is 0 seconds

For address family: IPv4 Unicast

Update group 1, subgroup 1

Packet Queue length 0

Community attribute sent to this neighbor(all)

0 accepted prefixes

Connections established 1; dropped 0

Last reset 00:01:36, No AFI/SAFI activated for peer

Local host: 192.169.0.1, Local port: 179

Foreign host: 192.169.0.2, Foreign port: 53912

Nexthop: 192.169.0.1

Nexthop global: fe80::6f8:f8ff:fee5:c2ba

Nexthop local: fe80::6f8:f8ff:fee5:c2ba

BGP connection: shared network

BGP Connect Retry Timer in Seconds: 120

Read thread: on Write thread: on FD used: 27

BFD: Type: single hop

Detect Multiplier: 3, Min Rx interval: 300, Min Tx interval: 300

Status: Up, Last update: 0:00:00:05

Example (multi hop)

```
sonic# config
sonic(config)# router bgp 65101
sonic(config-router)# neighbor 192.169.2.2 remote-as 65102
sonic(config-router)# neighbor 192.169.2.2 ebgp-multihop
sonic(config-router)# neighbor 192.169.2.2 bfd
sonic# show bgp neighbors
BGP neighbor is 192.169.2.2, remote AS 65102, local AS 65101, external link
Hostname: sonic
BGP version 4, remote router ID 192.169.2.2, local router ID 192.169.1.1
BGP state = Established, up for 00:00:02
Last read 00:00:01, Last write 00:00:01
Hold time is 180, keepalive interval is 60 seconds
Neighbor capabilities:
  4 Byte AS: advertised and received
  AddPath:
    IPv4 Unicast: RX advertised IPv4 Unicast and received
  Route refresh: advertised and received(old & new)
  Address Family IPv4 Unicast: advertised and received
  Hostname Capability: advertised (name: sonic, domain name: n/a) received (name: sonic, domain name: n/a)
  Graceful Restart Capabilty: advertised and received
    Remote Restart timer is 120 seconds
  Address families by peer:
    none
Graceful restart information:
  End-of-RIB send: IPv4 Unicast
  End-of-RIB received: IPv4 Unicast
Message statistics:
  Inq depth is 0
  Outq depth is 0
      Sent Rcvd
Opens:      2 2
Notifications: 0 0
Updates:    2 2
```

Keepalives: 5 5
Route Refresh: 0 0
Capability: 0 0
Total: 9 9

Minimum time between advertisement runs is 0 seconds

For address family: IPv4 Unicast

Update group 2, subgroup 2

Packet Queue length 0

Community attribute sent to this neighbor(all)

0 accepted prefixes

Connections established 2; dropped 1

Last reset 00:01:59, Waiting for NHT

External BGP neighbor may be up to 255 hops away.

Local host: 192.169.1.1, Local port: 51462

Foreign host: 192.169.2.2, Foreign port: 179

Nexthop: 192.169.1.1

Nexthop global: fe80::6f8:f8ff:fee5:c2ba

Nexthop local: fe80::6f8:f8ff:fee5:c2ba

BGP connection: non shared network

BGP Connect Retry Timer in Seconds: 120

Estimated round trip time: 877 ms

Read thread: on Write thread: on FD used: 27

BFD: Type: multi hop

Detect Multiplier: 3, Min Rx interval: 300, Min Tx interval: 300

Status: Up, Last update: 0:00:00:02

10 BGP

Table of Contents

[BGP show commands](#)

[show bgp summary \(FRR, SONiC versions 201904 - 201911\)](#)

[show ip bgp summary \(Quagga, SONiC versions before 201811 or FRR, SONiC versions after 202006\)](#)

[show bgp neighbors \(FRR, SONiC version after 201904 and before 201911\)](#)

[show ip bgp neighbors \(Quagga, SONiC version before 201811 or FRR, SONiC version after 202006\)](#)

[show ip bgp network](#)

[show bgp ipv6 summary \(FRR, SONiC versions after 201904 and before 201911\)](#)

[show ipv6 bgp summary \(Quagga, SONiC versions before 201811 or FRR, SONiC versions after 202006\)](#)

[show bgp ipv6 neighbors \(FRR, SONiC versions after 201904 and before 201911\)](#)

[show ipv6 bgp neighbors \(Quagga, SONiC versions before 201811 or FRR, SONiC versions after 202006\)](#)

[show ipv6 bgp network](#)

[show route-map](#)

[BGP config commands](#)

[config bgp shutdown all](#)

[config bgp shutdown neighbor](#)

[config bgp startup all](#)

[config bgp startup neighbor](#)

[config bgp remove neighbor](#)

This section explains all the BGP show commands and BGP configuration commands in both Quagga" and "FRR" routing software that are supported in SONiC. In 201811 and older versions "Quagga" was enabled by default. In current version "FRR" is enabled by default.

Most of the FRR show commands start with "show bgp" (201904 - 201911) or "show ip bgp" (after 202006). Similar commands in Quagga starts with "show ip bgp". All sub-options supported in all these show commands are common for FRR and Quagga. Detailed show command examples for Quagga are provided at the end of this document. This section covers only the commands supported by FRR.

BGP show commands

show bgp summary (FRR, SONiC versions 201904 - 201911)

This command displays the summary of all IPv4 and IPv6 BGP neighbors that are configured and the corresponding states.

(FRR, SONiC versions $\geq$ 201904 and $\leq$ 201911)

Usage (FRR, version after 201904 and before 201911)

show bgp summary

Example (FRR, bgp)

admin@sonic:~\$ show bgp summary

IPv4 Unicast Summary:

BGP router identifier 10.1.0.32, local AS number 65100 vrf-id 0

BGP table version 6465

RIB entries 12807, using 2001 KiB of memory

Peers 4, using 83 KiB of memory

Peer groups 2, using 128 bytes of memory

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd
10.0.0.57	4	64600	3995	4001	0	0	0	00:39:32	6400
10.0.0.59	4	64600	3995	3998	0	0	0	00:39:32	6400
10.0.0.61	4	64600	3995	4001	0	0	0	00:39:32	6400
10.0.0.63	4	64600	3995	3998	0	0	0	00:39:32	6400

Total number of neighbors 4

IPv6 Unicast Summary:

BGP router identifier 10.1.0.32, local AS number 65100 vrf-id 0

BGP table version 12803

RIB entries 12805, using 2001 KiB of memory

Peers 4, using 83 KiB of memory

Peer groups 2, using 128 bytes of memory

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd
fc00::72	4	64600	3995	5208	0	0	0	00:39:30	6400
fc00::76	4	64600	3994	5208	0	0	0	00:39:30	6400
fc00::7a	4	64600	3993	5208	0	0	0	00:39:30	6400
fc00::7e	4	64600	3993	5208	0	0	0	00:39:30	6400

Total number of neighbors 4

show ip bgp summary (Quagga, SONiC versions before 201811 or FRR, SONiC versions after 202006)

This command displays a summary of all IPv4 and IPv6 BGP neighbors that are configured and the corresponding states.

(Quagga, SONiC version <= 201811 or FRR, SONiC version >= 202006)

Usage (Quagga, version before 201811 or FRR, version after 202006)

show ip bgp summary

Example (Quagga/FRR after 202006, ip bgp)

admin@sonic:~\$ show ip bgp summary

IPv4 Unicast Summary:

BGP router identifier 10.1.0.32, local AS number 65100 vrf-id 0

BGP table version 12770

RIB entries 12807, using 2301 KiB of memory

Peers 4, using 82 KiB of memory

Peer groups 6, using 384 bytes of memory

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd	NeighborName
10.0.0.57	4	64600	3346	4494	0	0	0	00:07:09	6400	ARISTA01T1

```
10.0.0.59 4 64600 3346 4494 0 0 0 00:07:09 6400 ARISTA02T1
10.0.0.61 4 64600 3348 4493 0 0 0 00:07:09 6400 ARISTA03T1
10.0.0.63 4 64600 3347 4493 0 0 0 00:07:09 6400 ARISTA04T1
```

Total number of neighbors 4

show bgp neighbors (FRR, SONiC version after 201904 and before 201911)

This command displays all the details of IPv4 and IPv6 BGP neighbors when no optional argument is specified. When the optional argument `IPv4_address` is specified, it displays the detailed neighbor information about that specific IPv4 neighbor. The command has additional optional arguments to display only the advertised routes, or the received routes, or all routes. In order to see details for an IPv6 neighbor, use the `show bgp ipv6 neighbor <ipv6_address>` command.

Usage (FRR, after 201904 and before 201911)

```
show bgp neighbors [<ipv4-address> [advertised-routes | received-routes | routes]]
```

Example (FRR, after 201904 and before 201911)

```
admin@sonic:~$ show bgp neighbors
BGP neighbor is 10.0.0.57, remote AS 64600, local AS 65100, external link
Description: ARISTA01T1
BGP version 4, remote router ID 100.1.0.29, local router ID 10.1.0.32
BGP state = Established, up for 00:42:15
Last read 00:00:00, Last write 00:00:03
Hold time is 10, keepalive interval is 3 seconds
Configured hold time is 10, keepalive interval is 3 seconds
Neighbor capabilities:
 4 Byte AS: advertised and received
AddPath:
  IPv4 Unicast: RX advertised IPv4 Unicast and received
Route refresh: advertised and received(new)
```

Address Family IPv4 Unicast: advertised and received

Hostname Capability: advertised (name: sonic-z9264f-9251, domain name: n/a) not received

Graceful Restart Capability: advertised and received

Remote Restart timer is 300 seconds

Address families by peer:

none

Graceful restart information:

End-of-RIB send: IPv4 Unicast

End-of-RIB received: IPv4 Unicast

Message statistics:

Inq depth is 0

Outq depth is 0

	Sent	Rcvd
Opens:	2	1
Notifications:	2	0
Updates:	3206	3202
Keepalives:	845	847
Route Refresh:	0	0
Capability:	0	0
Total:	4055	4050

Minimum time between advertisement runs is 0 seconds

For address family: IPv4 Unicast

Update group 1, subgroup 1

Packet Queue length 0

Inbound soft reconfiguration allowed

Community attribute sent to this neighbor(all)

6400 accepted prefixes

Connections established 1; dropped 0

Last reset 00:42:37, due to NOTIFICATION sent (Cease/Connection collision resolution)

Local host: 10.0.0.56, Local port: 179

Foreign host: 10.0.0.57, Foreign port: 46419

Nexthop: 10.0.0.56

Nexthop global: fc00::71

Nexthop local: fe80::2204:fff:fe36:9449

BGP connection: shared network
 BGP Connect Retry Timer in Seconds: 120
 Read thread: on Write thread: on

Optionally, you can specify an IP address in order to display only that particular neighbor. In this mode, you can optionally specify whether you want to display all routes advertised to the specified neighbor, all routes received from the specified neighbor, or all routes (received and accepted) from the specified neighbor.

Example (FRR, specific neighbor's information)

```
admin@sonic:~$ show bgp neighbors 10.0.0.57
BGP neighbor is 10.0.0.57, remote AS 64600, local AS 65100, external link
Description: ARISTA01T1
Member of peer-group PEER_V4 for session parameters
BGP version 4, remote router ID 100.1.0.29, local router ID 10.1.0.32
BGP state = Established, up for 00:04:24
Last read 00:00:00, Last write 00:00:01
Hold time is 10, keepalive interval is 3 seconds
Configured hold time is 10, keepalive interval is 3 seconds
Neighbor capabilities:
4 Byte AS: advertised and received
AddPath:
IPv4 Unicast: RX advertised IPv4 Unicast and received
Route refresh: advertised and received(new)
Address Family IPv4 Unicast: advertised and received
Hostname Capability: advertised (name: as7726-32x-1, domain name: n/a) not received
Graceful Restart Capability: advertised and received
  Remote Restart timer is 300 seconds
Address families by peer:
  none
Graceful restart information:
  End-of-RIB send: IPv4 Unicast
  End-of-RIB received: IPv4 Unicast
Message statistics:
  Inq depth is 0
```

Outq depth is 0

	Sent	Rcvd
Opens:	2	1
Notifications:	2	0
Updates:	4228	3202
Keepalives:	89	88
Route Refresh:	0	0
Capability:	0	0
Total:	4321	3291

Minimum time between advertisement runs is 0 seconds

For address family: IPv4 Unicast

PEER_V4 peer-group member

Update group 1, subgroup 1

Packet Queue length 0

Inbound soft reconfiguration allowed

Community attribute sent to this neighbor(all)

Inbound path policy configured

Outbound path policy configured

Route map for incoming advertisements is *FROM_BGP_PEER_V4

Route map for outgoing advertisements is *TO_BGP_PEER_V4

6400 accepted prefixes

Connections established 1; dropped 0

Last reset 00:04:36, No AFI/SAFI activated for peer

Local host: 10.0.0.56, Local port: 179

Foreign host: 10.0.0.57, Foreign port: 57108

Nexthop: 10.0.0.56

Nexthop global: fc00::71

Nexthop local: fe80::82a2:35ff:fe46:999

BGP connection: shared network

BGP Connect Retry Timer in Seconds: 120

Read thread: on Write thread: on FD used: 32

```
admin@sonic:~$ show bgp neighbors 10.0.0.57 advertised-routes
```

```
BGP table version is 11920, local router ID is 10.1.0.32, vrf id 0
```

```
Default local pref 100, local AS 65100
```

```
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
```

```
            i internal, r RIB-failure, S Stale, R Removed
```

```
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
```

```
Origin codes: i - IGP, e - EGP, ? - incomplete
```

Network	Next Hop	Metric	LocPrf	Weight	Path
*> 0.0.0.0/0	10.0.0.59		0	64600	65534 6666 6667 i
*> 10.1.0.32/32	0.0.0.0	0		32768	i
*> 100.1.0.29/32	10.0.0.57			0 64600	i
*> 100.1.0.30/32	10.0.0.59			0 64600	i
		...			
*> 193.11.248.0/25	10.0.0.61			0 64600	65534 64799 65515 i
*> 193.11.248.128/25					
	10.0.0.61			0 64600	65534 64799 65515 I

```
Total number of prefixes 6405
```

```
admin@sonic:~$ show bgp neighbors 10.0.0.57 received-routes
```

```
BGP table version is 0, local router ID is 10.1.0.32, vrf id 0
```

```
Default local pref 100, local AS 65100
```

```
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
```

```
            i internal, r RIB-failure, S Stale, R Removed
```

```
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
```

```
Origin codes: i - IGP, e - EGP, ? - incomplete
```

Network	Next Hop	Metric	LocPrf	Weight	Path
*> 0.0.0.0/0	10.0.0.57		0	64600	65534 6666 6667 i
*> 100.1.0.29/32	10.0.0.57			0 64600	i
*> 192.168.8.0/25	10.0.0.57			0 64600	65501 i
*> 192.168.8.128/25	10.0.0.57			0 64600	65501 i
*> 192.168.16.0/25	10.0.0.57			0 64600	65502 i

```

...
*> 193.11.248.0/25 10.0.0.57 0 64600 65534 64799 65515 i
*> 193.11.248.128/25
10.0.0.57 0 64600 65534 64799 65515 i

Total number of prefixes 6400
admin@sonic:~$ show bgp neighbors 10.0.0.57 routes
BGP table version is 11920, local router ID is 10.1.0.32, vrf id 0
Default local pref 100, local AS 65100
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
Network      Next Hop Metric LocPrf Weight Path
*= 0.0.0.0/0 10.0.0.57 0 64600 65534 6666 6667 i
*> 100.1.0.29/32 10.0.0.57 0 64600 i
*= 192.168.8.0/25 10.0.0.57 0 64600 65501 i
*= 192.168.8.128/25 10.0.0.57 0 64600 65501 i
*= 192.168.16.0/25 10.0.0.57 0 64600 65502 i
*= 192.168.16.128/25
10.0.0.57 0 64600 65502 i
...
*= 193.11.240.0/25 10.0.0.57 0 64600 65534 64799 65514 i
*= 193.11.240.128/25
10.0.0.57 0 64600 65534 64799 65514 i
*= 193.11.248.0/25 10.0.0.57 0 64600 65534 64799 65515 i
*= 193.11.248.128/25
10.0.0.57 0 64600 65534 64799 65515 i

Displayed 6400 routes and 25602 total paths

```

show ip bgp neighbors (Quagga, SONiC version before 201811 or FRR, SONiC version after 202006)

This command displays all the details of IPv4 and IPv6 BGP neighbors when no optional argument is specified.

When the optional argument IPv4_address is specified, it displays the detailed neighbor information about that specific IPv4 neighbor. The command has additional optional arguments to display only the advertised routes, or the received routes, or all routes. In order to see details for an IPv6 neighbor, use the **show bgp ipv6 neighbor <ipv6_address>** command.

Usage (Quagga, before 201811 or FRR, after 202006)

show ip bgp neighbors [[advertised-routes | received-routes | routes]]

For an example of show ip bgp neighbors, you can refer to show bgp neighbors with the same options.

show ip bgp network

This command displays all the details of IPv4 Border Gateway Protocol (BGP) prefixes.

Usage

show ip bgp network [[<ipv4-address>|<ipv4-prefix>] [(bestpath | multipath | longer-prefixes | json)]]

Example

```
admin@sonic:~$ show ip bgp network
```

```
BGP table version is 10839, local router ID is 10.1.0.32, vrf id 0
```

```
Default local pref 100, local AS 65100
```

```
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
```

```
               i internal, r RIB-failure, S Stale, R Removed
```

```
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
```

```
Origin codes: i - IGP, e - EGP, ? - incomplete
```

Network	Next Hop	Metric	LocPrf	Weight	Path
*= 0.0.0.0/0	10.0.0.63	0	64600	65534	6666 6667 i
*=	10.0.0.61	0	64600	65534	6666 6667 i
*>	10.0.0.57	0	64600	65534	6666 6667 i
*=	10.0.0.59	0	64600	65534	6666 6667 i

```

...
*= 193.11.248.128/25
    10.0.0.63 0 64600 65534 64799 65515 i
*=      10.0.0.61 0 64600 65534 64799 65515 i
*=      10.0.0.59 0 64600 65534 64799 65515 i
*>      10.0.0.57 0 64600 65534 64799 65515 i
Displayed 6405 routes and 25602 total paths
admin@sonic:~$ show ip bgp network 192.168.8.130 bestpath
BGP routing table entry for 192.168.8.128/25
Paths: (4 available, best #3, table default)
Advertised to non peer-group peers:
10.0.0.57 10.0.0.59 10.0.0.61 10.0.0.63
64600 65501
10.0.0.57 from 10.0.0.57 (100.1.0.29)
Origin IGP, valid, external, multipath, best (Router ID)
Last update: Tue Nov 24 07:23:34 2020

admin@sonic:~$ show ip bgp network 192.168.8.130 multipath
BGP routing table entry for 192.168.8.128/25
Paths: (4 available, best #3, table default)
Advertised to non peer-group peers:
10.0.0.57 10.0.0.59 10.0.0.61 10.0.0.63
64600 65501
10.0.0.63 from 10.0.0.63 (100.1.0.32)
Origin IGP, valid, external, multipath
Last update: Tue Nov 24 07:23:34 2020

64600 65501
10.0.0.61 from 10.0.0.61 (100.1.0.31)
Origin IGP, valid, external, multipath
Last update: Tue Nov 24 07:23:34 2020

64600 65501
10.0.0.57 from 10.0.0.57 (100.1.0.29)

```

Origin IGP, valid, external, multipath, best (Router ID)

Last update: Tue Nov 24 07:23:34 2020

64600 65501

10.0.0.59 from 10.0.0.59 (100.1.0.30)

Origin IGP, valid, external, multipath

Last update: Tue Nov 24 07:23:34 2020

admin@sonic:~\$ show ip bgp network 10.1.0.32 json

```
{
  "prefix":"10.1.0.32\32",
  "advertisedTo":{
    "10.0.0.57":{
    },
    "10.0.0.59":{
    },
    "10.0.0.61":{
    },
    "10.0.0.63":{
    }
  },
  "paths":[
    {
      "aspath":{
        "string":"Local",
        "segments":[
        ],
        "length":0
      },
      "origin":"IGP",
      "med":0,
      "metric":0,
      "weight":32768,
      "valid":true,
```

```

"sourced":true,
"local":true,
"bestpath":{
  "overall":true,
  "selectionReason":"First path received"
},
"lastUpdate":{
  "epoch":1606202576,
  "string":"Tue Nov 24 07:22:56 2020\n"
},
"nexthops":[
  {
    "ip":"0.0.0.0",
    "afi":"ipv4",
    "metric":0,
    "accessible":true,
    "used":true
  }
],
"peer":{
  "peerId":"0.0.0.0",
  "routerId":"10.1.0.32"
}
}

```

admin@sonic:~\$ show ip bgp network 10.1.0.32/32 bestpath

BGP routing table entry for 10.1.0.32/32

Paths: (1 available, best #1, table default)

Advertised to non peer-group peers:

10.0.0.57 10.0.0.59 10.0.0.61 10.0.0.63

Local

0.0.0.0 from 0.0.0.0 (10.1.0.32)

Origin IGP, metric 0, weight 32768, valid, sourced, local, best (First path received)

Last update: Tue Nov 24 07:22:56 2020

```
admin@sonic:~$ show ip bgp network 10.1.0.32/32 multipath
```

BGP routing table entry for 10.1.0.32/32

Paths: (1 available, best #1, table default)

Advertised to non peer-group peers:

10.0.0.57 10.0.0.59 10.0.0.61 10.0.0.63

Local

0.0.0.0 from 0.0.0.0 (10.1.0.32)

Origin IGP, metric 0, weight 32768, valid, sourced, local, best (First path received)

Last update: Tue Nov 24 07:22:56 2020

```
admin@sonic:~$ show ip bgp network 10.1.0.32/32 json
```

```
{
  "prefix":"10.1.0.32\32",
  "advertisedTo":{
    "10.0.0.57":{
    },
    "10.0.0.59":{
    },
    "10.0.0.61":{
    },
    "10.0.0.63":{
    }
  },
  "paths":[
    {
      "aspath":{
        "string":"Local",
        "segments":[
        ],
        "length":0
      },
      "origin":"IGP",
      "med":0,
```

```

"metric":0,
"weight":32768,
"valid":true,
"sourced":true,
"local":true,
"bestpath":{
  "overall":true,
  "selectionReason":"First path received"
},
"lastUpdate":{
  "epoch":1606202576,
  "string":"Tue Nov 24 07:22:56 2020\n"
},
"nexthops":[
  {
    "ip":"0.0.0.0",
    "afi":"ipv4",
    "metric":0,
    "accessible":true,
    "used":true
  }
],
"peer":{
  "peerId":"0.0.0.0",
  "routerId":"10.1.0.32"
}
}
]
}

```

admin@sonic:~\$ show ip bgp network 10.1.0.32/32 longer-prefixes

BGP table version is 10839, local router ID is 10.1.0.32, vrf id 0

Default local pref 100, local AS 65100

Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,

i internal, r RIB-failure, S Stale, R Removed

Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self

Origin codes: i - IGP, e - EGP, ? - incomplete

```

Network      Next Hop Metric LocPrf Weight Path
*> 10.1.0.32/32  0.0.0.0    0    32768 I

```

Displayed 1 routes and 25602 total paths

Note: The **longer-prefixes** option is only available when a network prefix with a "/" notation is used

show bgp ipv6 summary (FRR, SONiC versions after 201904 and before 201911)

This command displays the summary of all IPv6 BGP neighbors that are configured and the corresponding states.

Usage (FRR, after 201904 and before 201911)

```
show bgp ipv6 summary
```

Example (FRR, after 201904 and before 201911)

```
admin@sonic:~$ show bgp ipv6 summary
```

BGP router identifier 10.1.0.32, local AS number 65100 vrf-id 0

BGP table version 12803

RIB entries 12805, using 2001 KiB of memory

Peers 4, using 83 KiB of memory

Peer groups 2, using 128 bytes of memory

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd	NeighborName
fc00::72	4	64600	3995	5208	0	0	0	00:39:30	6400 Lab-T1-01	
fc00::76	4	64600	3994	5208	0	0	0	00:39:30	6400 Lab-T1-02	
fc00::7a	4	64600	3993	5208	0	0	0	00:39:30	6400 Lab-T1-03	
fc00::7e	4	64600	3993	5208	0	0	0	00:39:30	6400 Lab-T1-04	

Total number of neighbors 4

show ipv6 bgp summary (Quagga, SONiC versions before 201811 or FRR, SONiC versions after 202006)

This command displays the summary of all IPv6 BGP neighbors that are configured and the corresponding states.

Usage (Quagga, before 201811 or FRR, after 202006)

```
show ipv6 bgp summary
```

Example (Quagga, before 201811 or FRR, after 202006)

```
admin@sonic:~$ show ipv6 bgp summary
```

IPv6 Unicast Summary:

BGP router identifier 10.1.0.32, local AS number 65100 vrf-id 0

BGP table version 11661

RIB entries 12807, using 2301 KiB of memory

Peers 4, using 82 KiB of memory

Peer groups 6, using 384 bytes of memory

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd	NeighborName
fc00::72	4	64600	4341	6224	0	0	0	00:56:55	6400 ARISTA01T1	
fc00::76	4	64600	4341	6224	0	0	0	00:56:55	6400 ARISTA02T1	
fc00::7a	4	64600	4340	6224	0	0	0	00:56:55	6400 ARISTA03T1	
fc00::7e	4	64600	4339	6224	0	0	0	00:56:55	6400 ARISTA04T1	

Total number of neighbors 4

show bgp ipv6 neighbors (FRR, SONiC versions after 201904 and before 201911)

This command displays all the details of one particular IPv6 Border Gateway Protocol (BGP) neighbor. An option is also available to display only the advertised routes, or the received routes, or all routes.

Usage (FRR, after 201904 and before 201911)

```
show bgp ipv6 neighbors [<ipv6-address> [(advertised-routes | received-routes | routes)]]
```

Example (FRR, after 201904 and before 201911)

```
admin@sonic:~$ show bgp ipv6 neighbors
BGP neighbor is fc00::72, remote AS 64600, local AS 65100, external link
Description: ARISTA01T1
Member of peer-group PEER_V6 for session parameters
  BGP version 4, remote router ID 100.1.0.29, local router ID 10.1.0.32
  BGP state = Established, up for 01:18:47
    Last read 00:00:02, Last write 00:00:02
  Hold time is 10, keepalive interval is 3 seconds
  Configured hold time is 10, keepalive interval is 3 seconds
  Neighbor capabilities:
    4 Byte AS: advertised and received
    AddPath:
      IPv6 Unicast: RX advertised IPv6 Unicast and received
    Route refresh: advertised and received(new)
    Address Family IPv6 Unicast: advertised and received
    Hostname Capability: advertised (name: as5812-54x, domain name: n/a) not received
    Graceful Restart Capabilty: advertised and received
      Remote Restart timer is 300 seconds
    Address families by peer:
      none
  Graceful restart information:
    End-of-RIB send: IPv6 Unicast
    End-of-RIB received: IPv6 Unicast
  Message statistics:
    Inq depth is 0
    Outq depth is 0
      Sent  Rcvd
    Opens:      2    1
    Notifications: 2    0
```

Updates: 5081 3202

Keepalives: 1576 1575

Route Refresh: 0 0

Capability: 0 0

Total: 6661 4778

Minimum time between advertisement runs is 0 seconds

For address family: IPv6 Unicast

PEER_V6 peer-group member

Update group 2, subgroup 2

Packet Queue length 0

Inbound soft reconfiguration allowed

Community attribute sent to this neighbor(all)

Inbound path policy configured

Outbound path policy configured

Route map for incoming advertisements is *FROM_BGP_PEER_V6

Route map for outgoing advertisements is *TO_BGP_PEER_V6

6400 accepted prefixes

Connections established 1; dropped 0

Last reset 01:19:13, No AFI/SAFI activated for peer

Local host: fc00::71, Local port: 179

Foreign host: fc00::72, Foreign port: 43581

Nexthop: 10.0.0.56

Nexthop global: fc00::71

Nexthop local: fe80::3e2c:99ff:fe15:aa60

BGP connection: shared network

BGP Connect Retry Timer in Seconds: 120

Read thread: on Write thread: on FD used: 22

...

admin@sonic:~\$ show bgp ipv6 neighbors fc00::72

BGP neighbor is fc00::72, remote AS 64600, local AS 65100, external link

Description: ARISTA01T1

Member of peer-group PEER_V6 for session parameters

BGP version 4, remote router ID 100.1.0.29, local router ID 10.1.0.32

BGP state = Established, up for 01:18:47

Last read 00:00:02, Last write 00:00:02

Hold time is 10, keepalive interval is 3 seconds

Configured hold time is 10, keepalive interval is 3 seconds

Neighbor capabilities:

4 Byte AS: advertised and received

AddPath:

IPv6 Unicast: RX advertised IPv6 Unicast and received

Route refresh: advertised and received(new)

Address Family IPv6 Unicast: advertised and received

Hostname Capability: advertised (name: as5812-54x, domain name: n/a) not received

Graceful Restart Capability: advertised and received

Remote Restart timer is 300 seconds

Address families by peer:

none

Graceful restart information:

End-of-RIB send: IPv6 Unicast

End-of-RIB received: IPv6 Unicast

Message statistics:

Inq depth is 0

Outq depth is 0

	Sent	Rcvd
Opens:	2	1
Notifications:	2	0
Updates:	5081	3202
Keepalives:	1576	1575
Route Refresh:	0	0
Capability:	0	0
Total:	6661	4778

Minimum time between advertisement runs is 0 seconds

For address family: IPv6 Unicast

```

PEER_V6 peer-group member
Update group 2, subgroup 2
Packet Queue length 0
Inbound soft reconfiguration allowed
Community attribute sent to this neighbor(all)
Inbound path policy configured
Outbound path policy configured
Route map for incoming advertisements is *FROM_BGP_PEER_V6
Route map for outgoing advertisements is *TO_BGP_PEER_V6
6400 accepted prefixes

Connections established 1; dropped 0
Last reset 01:19:13, No AFI/SAFI activated for peer
Local host: fc00::71, Local port: 179
Foreign host: fc00::72, Foreign port: 43581
Nexthop: 10.0.0.56
Nexthop global: fc00::71
Nexthop local: fe80::3e2c:99ff:fe15:aa60
BGP connection: shared network
BGP Connect Retry Timer in Seconds: 120
Read thread: on Write thread: on FD used: 22

admin@sonic:~$ show bgp ipv6 neighbors fc00::72 advertised-routes
BGP table version is 11661, local router ID is 10.1.0.32, vrf id 0
Default local pref 100, local AS 65100
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network      Next Hop Metric LocPrf Weight Path
*> ::/0         fc00::72          0 64600 65534 6666 6667 i
*> 2064:100::1d/128 fc00::72          0 64600 i
*> 2064:100::1e/128 fc00::76          0 64600 i

```

```
*> 2064:100::1f/128 fc00::7a      0 64600 i
*> 2064:100::20/128 fc00::7e      0 64600 i
...
*> 20c1:bf8::/64  fc00::72      0 64600 65534 64799 65515 i
*> 20c1:bf8:0:80::/64
      fc00::72      0 64600 65534 64799 65515 i
*> fc00:1::/64    ::      0 32768 i
*> fc02:1000::/64 ::      0 32768 i
```

Total number of prefixes 6405

```
admin@sonic:~$ show bgp ipv6 neighbors fc00::72 received-routes
BGP table version is 0, local router ID is 10.1.0.32, vrf id 0
Default local pref 100, local AS 65100
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
```

```
Network      Next Hop Metric LocPrf Weight Path
*> ::/0       fc00::72      0 64600 65534 6666 6667 i
*> 2064:100::1d/128 fc00::72      0 64600 i
*> 20c0:a808::/64 fc00::72      0 64600 65501 i
*> 20c0:a808:0:80::/64
      fc00::72      0 64600 65501 i
...
*> 20c1:bf8::/64 fc00::72      0 64600 65534 64799 65515 i
*> 20c1:bf8:0:80::/64
      fc00::72      0 64600 65534 64799 65515 i
```

Total number of prefixes 6400

```
admin@sonic:~$ show bgp ipv6 neighbors fc00::72 routes
```

```

BGP table version is 11661, local router ID is 10.1.0.32, vrf id 0
Default local pref 100, local AS 65100
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

```

```

      Network      Next Hop Metric LocPrf Weight Path
*> ::/0          fc00::72          0 64600 65534 6666 6667 i
*> 2064:100::1d/128 fc00::72          0 64600 i
*> 20c0:a808::/64 fc00::72          0 64600 65501 i
*> 20c0:a808:0:80::/64
      fc00::72          0 64600 65501 i
      ...
*> 20c1:bf8::/64 fc00::72          0 64600 65534 64799 65515 i
*> 20c1:bf8:0:80::/64
      fc00::72          0 64600 65534 64799 65515 i

```

```

Displayed 6400 routes and 25602 total paths

```

show ipv6 bgp neighbors (Quagga, SONiC versions before 201811 or FRR, SONiC versions after 202006)

This command displays all the details of one particular IPv6 Border Gateway Protocol (BGP) neighbor. An option is also available to display only the advertised routes, or the received routes, or all routes.

Usage (Quagga, before 201811 or FRR, after 202006)

```
show ipv6 bgp neighbors [<ipv6-address> [(advertised-routes | received-routes | routes)]]
```

For an example of show ipv6 bgp neighbors, you can refer to show bgp ipv6 neighbors with the same options.

show ipv6 bgp network

This command displays all the details of IPv6 Border Gateway Protocol (BGP) prefixes.

Usage (Quagga or FRR after 202006)

```
show ipv6 bgp network [[<ipv6-address>|<ipv6-prefix>] [(bestpath | multipath | longer-prefixes | json)]]
```

Example (Quagga or FRR after 202006)

```
admin@sonic:~$ show ipv6 bgp network
```

BGP table version is 11661, local router ID is 10.1.0.32, vrf id 0

Default local pref 100, local AS 65100

Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,

i internal, r RIB-failure, S Stale, R Removed

Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self

Origin codes: i - IGP, e - EGP, ? - incomplete

Network	Next Hop	Metric	LocPrf	Weight	Path
*= ::/0	fc00::7a	0	64600	65534	6666 6667 i
*=	fc00::7e	0	64600	65534	6666 6667 i
*>	fc00::72	0	64600	65534	6666 6667 i
*=	fc00::76	0	64600	65534	6666 6667 i
*> 2064:100::1d/128	fc00::72	0	64600		i
*> 2064:100::1e/128	fc00::76	0	64600		i
*> 2064:100::1f/128	fc00::7a	0	64600		i
...					
*= 20c1:bf8:0:80::/64					
	fc00::7e	0	64600	65534	64799 65515 i
*=	fc00::7a	0	64600	65534	64799 65515 i
*=	fc00::76	0	64600	65534	64799 65515 i
*>	fc00::72	0	64600	65534	64799 65515 i
*> fc00:1::/64	::	0	32768		i
*> fc02:1000::/64	::	0	32768		i

Displayed 6405 routes and 25602 total paths

```
admin@sonic:~$ show ipv6 bgp network 2064:100::1d bestpath
```

```
BGP routing table entry for 2064:100::1d/128
```

```
Paths: (1 available, best #1, table default)
```

```
Advertised to non peer-group peers:
```

```
fc00::72 fc00::76 fc00::7a fc00::7e
```

```
64600
```

```
fc00::72 from fc00::72 (100.1.0.29)
```

```
(fe80::5054:ff:fe02:b909) (prefer-global)
```

```
Origin IGP, valid, external, best (First path received)
```

```
Last update: Tue Nov 24 08:56:51 2020
```

```
admin@sonic:~$ show ipv6 bgp network 20c0:a810::/64 multipath
```

```
BGP routing table entry for 20c0:a810::/64
```

```
Paths: (4 available, best #4, table default)
```

```
Advertised to non peer-group peers:
```

```
fc00::72 fc00::76 fc00::7a fc00::7e
```

```
64600 65502
```

```
fc00::76 from fc00::76 (100.1.0.30)
```

```
(fe80::5054:ff:fe25:758e) (prefer-global)
```

```
Origin IGP, valid, external, multipath
```

```
Last update: Tue Nov 24 08:56:51 2020
```

```
64600 65502
```

```
fc00::7e from fc00::7e (100.1.0.32)
```

```
(fe80::5054:ff:fe51:5f51) (prefer-global)
```

```
Origin IGP, valid, external, multipath
```

```
Last update: Tue Nov 24 08:56:51 2020
```

```
64600 65502
```

```
fc00::72 from fc00::72 (100.1.0.29)
```

```
(fe80::5054:ff:fe02:b909) (prefer-global)
```

```
Origin IGP, valid, external, multipath
```

```
Last update: Tue Nov 24 08:56:51 2020
```

64600 65502

fc00::7a from fc00::7a (100.1.0.31)

(fe80::5054:ff:fe2:88ce) (prefer-global)

Origin IGP, valid, external, multipath, best (Older Path)

Last update: Tue Nov 24 08:56:51 2020

admin@sonic:~\$ show ipv6 bgp network 2064:100::1d json

```
{
  "prefix":"2064:100::1dV128",
  "advertisedTo":{
    "fc00::72":{
    },
    "fc00::76":{
    },
    "fc00::7a":{
    },
    "fc00::7e":{
    }
  },
  "paths":[
    {
      "aspath":{
        "string":"64600",
        "segments":[
          {
            "type":"as-sequence",
            "list":[
              64600
            ]
          }
        ],
        "length":1
      },

```

```

"origin": "IGP",
"valid": true,
"bestpath": {
  "overall": true,
  "selectionReason": "First path received"
},
"lastUpdate": {
  "epoch": 1606208211,
  "string": "Tue Nov 24 08:56:51 2020\n"
},
"nexthops": [
  {
    "ip": "fc00::72",
    "afi": "ipv6",
    "scope": "global",
    "metric": 0,
    "accessible": true,
    "used": true
  },
  {
    "ip": "fe80::5054:ff:fe02:b909",
    "afi": "ipv6",
    "scope": "link-local",
    "accessible": true
  }
],
"peer": {
  "peerId": "fc00::72",
  "routerId": "100.1.0.29",
  "type": "external"
}
]
}

```

```
admin@sonic:~$ show ipv6 bgp network 2064:100::1d/128 bestpath
```

```
BGP routing table entry for 2064:100::1d/128
```

```
Paths: (1 available, best #1, table default)
```

```
Advertised to non peer-group peers:
```

```
fc00::72 fc00::76 fc00::7a fc00::7e
```

```
64600
```

```
fc00::72 from fc00::72 (100.1.0.29)
```

```
(fe80::5054:ff:fe02:b909) (prefer-global)
```

```
Origin IGP, valid, external, best (First path received)
```

```
Last update: Tue Nov 24 08:56:51 2020
```

```
admin@sonic:~$ show ipv6 bgp network 20c0:a810::/64 multipath
```

```
BGP routing table entry for 20c0:a810::/64
```

```
Paths: (4 available, best #4, table default)
```

```
Advertised to non peer-group peers:
```

```
fc00::72 fc00::76 fc00::7a fc00::7e
```

```
64600 65502
```

```
fc00::76 from fc00::76 (100.1.0.30)
```

```
(fe80::5054:ff:fe25:758e) (prefer-global)
```

```
Origin IGP, valid, external, multipath
```

```
Last update: Tue Nov 24 08:56:51 2020
```

```
64600 65502
```

```
fc00::7e from fc00::7e (100.1.0.32)
```

```
(fe80::5054:ff:fe51:5f51) (prefer-global)
```

```
Origin IGP, valid, external, multipath
```

```
Last update: Tue Nov 24 08:56:51 2020
```

```
64600 65502
```

```
fc00::72 from fc00::72 (100.1.0.29)
```

```
(fe80::5054:ff:fe02:b909) (prefer-global)
```

```
Origin IGP, valid, external, multipath
```

```
Last update: Tue Nov 24 08:56:51 2020
```

64600 65502

fc00::7a from fc00::7a (100.1.0.31)

(fe80::5054:ff:fef2:88ce) (prefer-global)

Origin IGP, valid, external, multipath, best (Older Path)

Last update: Tue Nov 24 08:56:51 2020

admin@sonic:~\$ show ipv6 bgp network 2064:100::1d/128 json

```
{
  "prefix":"2064:100::1d\128",
  "advertisedTo":{
    "fc00::72":{
    },
    "fc00::76":{
    },
    "fc00::7a":{
    },
    "fc00::7e":{
    }
  },
  "paths":[
    {
      "aspath":{
        "string":"64600",
        "segments":[
          {
            "type":"as-sequence",
            "list":[
              64600
            ]
          }
        ]
      },
      "length":1
    },
  ]
}
```

```

"origin": "IGP",
"valid": true,
"bestpath": {
  "overall": true,
  "selectionReason": "First path received"
},
"lastUpdate": {
  "epoch": 1606208211,
  "string": "Tue Nov 24 08:56:51 2020\n"
},
"nexthops": [
  {
    "ip": "fc00::72",
    "afi": "ipv6",
    "scope": "global",
    "metric": 0,
    "accessible": true,
    "used": true
  },
  {
    "ip": "fe80::5054:ff:fe02:b909",
    "afi": "ipv6",
    "scope": "link-local",
    "accessible": true
  }
],
"peer": {
  "peerId": "fc00::72",
  "routerId": "100.1.0.29",
  "type": "external"
}
]
}

```

```
admin@sonic:~$ show ipv6 bgp network 2064:100::1d/128 longer-prefixes
BGP table version is 12770, local router ID is 10.1.0.32, vrf id 0
Default local pref 100, local AS 65100
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete
```

```

Network      Next Hop Metric LocPrf Weight Path
*> 2064:100::1d/128 fc00::72          0 64600 i
```

Displayed 1 routes and 25602 total paths

Note: The **longer-prefixes** option is only available when a network prefix with a "/" notation is used.

show route-map

This command displays the routing policy that takes precedence over the other route processes that are configured.

Usage

```
show route-map
```

Example

```
admin@sonic:~$ show route-map
ZEBRA:
route-map RM_SET_SRC, permit, sequence 10
Match clauses:
Set clauses:
src 10.12.0.102
```

Call clause:

Action:

Exit routemap

ZEBRA:

route-map RM_SET_SRC6, permit, sequence 10

Match clauses:

Set clauses:

src fc00:1::102

Call clause:

Action:

Exit routemap

BGP:

route-map FROM_BGP_SPEAKER_V4, permit, sequence 10

Match clauses:

Set clauses:

Call clause:

Action:

Exit routemap

BGP:

route-map TO_BGP_SPEAKER_V4, deny, sequence 10

Match clauses:

Set clauses:

Call clause:

Action:

Exit routemap

BGP:

route-map ISOLATE, permit, sequence 10

Match clauses:

Set clauses:

as-path prepend 65000

Call clause:

Action:

Exit routemap

BGP config commands

This sub-section explains the list of configuration options available for the BGP module, both for IPv4 and IPv6 BGP neighbors.

config bgp shutdown all

This command is used to shutdown all the BGP IPv4 and IPv6 sessions. When a session is shutdown using this command, the BGP state in **show ip bgp summary** is displayed as "Idle (Admin)"

Usage

```
config bgp shutdown all
```

Example

```
admin@sonic:~$ sudo config bgp shutdown all
```

```
Shutting down BGP session with neighbor 10.0.0.57...
```

```
Shutting down BGP session with neighbor 10.0.0.59...
```

```
Shutting down BGP session with neighbor 10.0.0.61...
```

```
Shutting down BGP session with neighbor 10.0.0.63...
```

```
admin@sonic:~$ show ip bgp summary
```

IPv4 Unicast Summary:

BGP router identifier 10.1.0.32, local AS number 65100 vrf-id 0

BGP table version 21863

RIB entries 3, using 552 bytes of memory

Peers 4, using 82 KiB of memory

Peer groups 6, using 384 bytes of memory

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd	NeighborName
10.0.0.57	4	64600	4437	5982	0	0	0	00:06:02	Idle (Admin)	ARISTA01T1
10.0.0.59	4	64600	4434	4682	0	0	0	00:06:11	Idle (Admin)	ARISTA02T1
10.0.0.61	4	64600	4433	4649	0	0	0	00:06:14	Idle (Admin)	ARISTA03T1
10.0.0.63	4	64600	4431	4603	0	0	0	00:06:16	Idle (Admin)	ARISTA04T1

Total number of neighbors 4

config bgp shutdown neighbor

This command shuts down a BGP session with a neighbor by specifying the IP address or hostname.

Usage

```
sudo config bgp shutdown neighbor (<ip_address> | <hostname>)
```

Example

```
admin@sonic:~$ sudo config bgp shutdown neighbor 10.0.0.57
Shutting down BGP session with neighbor 10.0.0.57...
admin@sonic:~$ sudo config bgp shutdown neighbor ARISTA01T1
Shutting down BGP session with neighbor 10.0.0.57...
Shutting down BGP session with neighbor fc00::72...
```

config bgp startup all

This command starts up all the IPv4 and IPv6 BGP neighbors

Usage

```
config bgp startup all
```

Example

```
admin@sonic:~$ sudo config bgp startup all
Starting up BGP session with neighbor 10.0.0.57...
Starting up BGP session with neighbor 10.0.0.59...
Starting up BGP session with neighbor 10.0.0.61...
Starting up BGP session with neighbor 10.0.0.63...
```

config bgp startup neighbor

This command starts up a particular IPv4 or IPv6 BGP neighbor using either the IP address or hostname.

Usage

```
config bgp startup neighbor (<ip-address> | <hostname>)
```

Example

```
admin@sonic:~$ sudo config bgp startup neighbor 10.0.0.57
Starting up BGP session with neighbor 10.0.0.57...
admin@sonic:~$ sudo config bgp startup neighbor ARISTA01T1
Starting up BGP session with neighbor 10.0.0.57...
Starting up BGP session with neighbor fc00::72...
```

config bgp remove neighbor

This command removes a particular IPv4 or IPv6 BGP neighbor configuration using either the IP address or hostname.

Usage

```
config bgp remove neighbor <neighbor_ip_or_hostname>
```

Example

```
admin@sonic:~$ sudo config bgp remove neighbor 10.0.0.57
Removed configuration of BGP neighbor 10.0.0.57
admin@sonic:~$ sudo config bgp remove neighbor fc00::72
Removed configuration of BGP neighbor fc00::72
admin@sonic:~$ sudo config bgp remove neighbor ARISTA01T1
Removed configuration of BGP neighbor 10.0.0.57
Removed configuration of BGP neighbor fc00::72
```

Note:

- These SONiC bgp commands (**shutdown/startup/remove**) will only apply to the neighbor entries included in config_db.json (redis db). Otherwise, it will show error message about it could not locate the neighbor and take no effect.

An example entry in config_db.json

```
"BGP_NEIGHBOR": {
  "10.0.0.57": {
    "admin_status": "up",
    "asn": "64600",
    "holdtime": "10",
    "keepalive": "3",
    "local_addr": "10.0.0.56",
    "name": "ARISTA01T1",
    "nhopself": "0",
    "rrclient": "0"
  },

```

```
admin@sonic:~$ sudo config bgp shutdown neighbor 10.1.1.1
```

```
Usage: config bgp shutdown neighbor [OPTIONS] <ipaddr_or_hostname>
```

```
Try "config bgp shutdown neighbor -h" for help.
```

```
Error: Could not locate neighbor '10.1.1.1'
```

For FRR 'split' mode, please use these commands in FRR VTY shell instead:

Example

```
admin@sonic:~$ vtysh
```

```
Hello, this is FRRouting (version 8.1).
```

```
Copyright 1996-2005 Kunihiro Ishiguro, et al.
```

```
sonic# config
```

```
sonic(config)# router bgp 65100
sonic(config-router)# neighbor 10.0.0.61 shutdown (shutdown)
sonic(config-router)# no neighbor 10.0.0.61 shutdown (startup)
sonic(config-router)# no neighbor 10.0.0.61 (remove)
sonic(config-router)# bgp shutdown (shutdown all)
sonic(config-router)# no bgp shutdown (startup all)
```

11 Configuration File Management

Table of Contents

[Loading the Configuration from a JSON File](#)

[config load](#)

[Loading the Configuration from a Minigraph \(XML\) File](#)

[config load_minigraph](#)

[Reloading the Configuration](#)

[config reload](#)

[Loading the Management Configuration](#)

[config load_mgmt_config](#)

[Saving the Configuration to a File for Persistence](#)

[config save](#)

This section explains the commands that are used to load the configuration from either ConfigDB or from minigraph.

Loading the Configuration from a JSON File

config load

This command loads the configuration from a JSON file, such as the file to which SONiC saves its configuration, `/etc/sonic/config_db.json`.

This command loads the configuration from the input file (if an optional filename is specified, that input file is used, otherwise the default `/etc/sonic/config_db.json` file is used) into CONFIG_DB. The configuration present in the input file is applied on top of the already running configuration.

This command does not flush CONFIG_DB before loading the new configuration (i.e., if the configuration present in the input file is same as the current running configuration, nothing happens). If the config present in the input file is not present in the running configuration, it will be added. If the config present in the input file differs (when key matches) from that of the running configuration, it will be modified as per the new values for those keys.

Usage
<code>config load [-y --yes] [<filename>]</code>

Parameters:

- "-y" or "--yes", forces the loading without prompting the user for confirmation.
 - If this argument is not specified, it prompts the user to confirm whether the user really wants to load this configuration file.
- <filename>, loads the configuration from the input file (<filename>) and stores into CONFIG_DB; otherwise, it uses `/etc/sonic /config_db.json` as the default input file.

Note

- This command does not flush CONFIG_DB before loading the new configuration. That is, if there is a new configuration in <filename>, it will be added into CONFIG_DB (running configuration); if there is any configuration changed in <filename>, it will update CONFIG_DB with those entries.

Example

```
admin@sonic:~$ sudo config load
```

```
Load config from the file /etc/sonic/config_db.json? [y/N]: y
```

```
Running command: /usr/local/bin/sonic-cfggen -j /etc/sonic/config_db.json --write-to-db
```

Loading the Configuration from a Minigraph (XML) File

config load_minigraph

This command is used to load the configuration from /etc/sonic/minigraph.xml, when users do not want to use the configuration in config_db.json .

You can copy the minigraph.xml configuration file to the device and load it using this command. This command restarts various services running in the device and it takes some time to complete the command.

Usage

```
config load_minigraph [-y|--yes] [-n|--no-service-restart]
```

Parameter:

- "-y" or "--yes", forces the loading without prompting the user for confirmation.
 - If the argument is not specified, it prompts the user to confirm whether user really wants to load this configuration file.
- "-n" or "--no-service-restart", loads the configuration without restarting dependent services running on the device.

- One use case for this option is during boot time when config-setup service loads the minigraph configuration and there are no services running on the device.

Note

- If you are logged in using SSH, you might get disconnected and some configuration failures could happen, from which it might be hard to recover. You need to reconnect the SSH session after configuring the management IP address. It is recommended to execute this command from the console port.
- The management interface IP address and default route (or specific route) may require reconfiguration in case those parameters are not part of minigraph.xml.

Example

```
admin@sonic:~$ sudo config load_minigraph
```

```
Reload config from minigraph? [y/N]: y
```

```
Running command: /usr/local/bin/sonic-cfggen -j /etc/sonic/config_db.json --write-to-db
```

Reloading the Configuration

config reload

Clears the current configuration and imports a new configuration from an input file, or from `/etc/sonic/config_db.json`.

Usage

```
config reload [-y|--yes] [-l|--load-sysinfo] [<filename>] [-n|--no-service-restart]
```

Parameters:

- "-y" or "--yes", forces the loading without prompting the user for confirmation.
 - If the argument is not specified, it prompts the user to confirm whether user really wants to load this configuration file.
- "-n" or "--no-service-restart", clears and loads the configuration without restarting dependent services running on the device.

- One use case for this option is during boot time when config-setup service loads the existing old configuration and there are no services running on the device.

Notes:

- Stops all services before clearing the configuration and then restarts those services after configuration is reloaded. It takes some time to complete the command since it needs to restart various running services in the device.
- If users are logged in using SSH, they might be disconnected depending upon the new management IP address. Users will need to reconnect their SSH sessions. In general, it is recommended to execute this command from the console port after disconnecting all SSH sessions to the device.
- config reload may change the management IP address in the input file (<filename>), this introduces the following possible scenario:
 1. mgmtIP (management IP address) is not changed. The SSH session may not be affected if the SSH session has not timed out, but it needs to resume the connection after the interface is re-configured and up.
 2. mgmtIP is changed in new configuration file. Users will lose their SSH connections.
 3. There is not any mgmtIP in the new configuration file. Users will lose their SSH connections.

The management interface IP address and default route (or specific route) may require reconfiguration if those parameters are not part of minigraph.xml.

Example

```
admin@sonic:~$ sudo config reload
```

```
Clear current config and reload config from the file /etc/sonic/config_db.json? [y/N]: y
```

```
Running command: systemctl stop dhcp_relay
```

```
Running command: systemctl stop swss
```

```
Running command: systemctl stop snmp
```

```
Warning: Stopping snmp.service, but it can still be activated by:
```

```
snmp.timer
```

```
Running command: systemctl stop lldp
```

```
Running command: systemctl stop pmon
```

```
Running command: systemctl stop bgp
```

```
Running command: systemctl stop teamd
```

```
Running command: /usr/local/bin/sonic-cfggen -H -k Force10-Z9100-C32 --write-to-db
```

```
Running command: /usr/local/bin/sonic-cfggen -j /etc/sonic/config_db.json --write-to-db
```

```
Running command: systemctl restart hostname-config
```

```
Running command: systemctl restart interfaces-config
```

```
Timeout, server 10.11.162.42 not responding.
```

Loading the Management Configuration

config load_mgmt_config

This command is used to reconfigure the hostname and mgmt interface based on the device description file.

Usage

```
config load_mgmt_config [-y|--yes] [<filename>]
```

Parameters:

- "-y" or "--yes", forces the loading without prompting the user for confirmation.
 - If the argument is not specified, it prompts the user to confirm whether user really wants to load this configuration file.

Note

- This command either uses the optional file specified in <filename> or looks for the file /etc/sonic/device_desc.xml . The execution fails If the file does not exist or does not have valid fields for hostname and ManagementAddress .

Example

```
admin@sonic:~$ sudo config load_mgmt_config
```

```
Reload config from minigraph? [y/N]: y
```

```
Running command: /usr/local/bin/sonic-cfggen -M /etc/sonic/device_desc.xml --write-to-db
```

Saving the Configuration to a File for Persistence

config save

This command saves CONFIG_DB (the running configuration) into the user-specified filename or the default /etc/sonic/config_db.json .

Usage

```
config save [-y|--yes] [<filename>]
```

Note

- This command retains the configuration in storage after rebooting. The file can be transferred to remote machines for debugging. You can use config load to load the configuration file at any point and generate a new CONFIG_DB (running configuration) or copy to /etc/sonic/config_db.json if you want this newly generated file to be used during reboot.

Example (boot configuration file)

```
admin@sonic:~$ sudo config save -y
```

or

Example (specific file)

```
admin@sonic:~$ sudo config save -y /etc/sonic/config2.json
```

12 Container Auto-restart

Table of Contents

[Container Auto-restart Show Commands](#)

[show feature autorestart](#)

[Container Auto-restart Config Command](#)

[config feature autorestart <feature_name> <autorestart_status>](#)

SONiC includes a feature in which Docker containers can be automatically shut down and restarted if one of the critical processes running in the container exits unexpectedly. Restarting the entire container ensures that the configuration is reloaded and all processes in the container are restarted, thus increasing the likelihood of entering a healthy state.

Container Auto-restart Show Commands

show feature autorestart

This command displays the status of the auto-restart feature for containers.

Usage

```
show feature autorestart [<feature_name>]
```

Example

```
admin@sonic:~$ show feature autorestart
```

Container Name	Status
----------------	--------

database	enabled
syncd	enabled
teamd	disabled
dhcp_relay	enabled
lldp	enabled
pmon	enabled
bgp	enabled
swss	disabled
telemetry	enabled
sflow	enabled
snmp	enabled
radv	disabled

Optionally, you can specify a container name in order to display the auto-restart feature status for that container only.

Container Auto-restart Config Command

config feature autorestart <feature_name> <autorestart_status>

This command configures the status of the auto-restart feature for a specific container.

Usage

```
config feature autorestart <feature_name> (enabled | disabled)
```

Example

```
admin@sonic:~$ sudo config feature autorestart database disabled
```

13 CoPP

CoPP (Control Plane Policing) is a mechanism to manage and limit the protocol packets trapped in a control plane.

Users may modify the configuration to filter out some protocols or limit the number of packets to proceed.

Changing CoPP configuration is system-level tuning. Users should know the impact before applying it.

Note

- The default configuration of CoPP is accurately measured for system operation. For any change or modification, users should know the effect on the system and have the confidence to manage it, the system could be in an unexpected state which is out of service. To recover it, the user may restore the factory default configuration (refer to "sudo config-setup factory" in (202111) New Default Configuration)

CoPP trap(s) is composed of trap ID and trap group which has options - meter, and action to indicate how to handle the protocol packets when the condition is matched. The trap ID is predefined and associated with the protocol packet, for example, STP, LACP, EAPOL, and so on. The meter can be measured by packets or bytes, and the action can be one of trap, copy, or drop. A trap group has more options to specify the matching criteria to trigger the trap, please refer to the Schema section.

Schema

CoPP configuration has two sections, COPP_GROUP and COPP_TRAP. The previous one specifies trapping criteria and actions, and later one associates the trap ID(s) to the trap group to apply the matching criteria and actions for the protocol(s).

Schema

```
{
  "COPP_GROUP": {
    "<group-name>": {
      "queue": <CPU queue#>,
      "trap_action": <trap, copy, or drop>,
      "trap_priority": <priority>,
      "meter_type": <packets, bytes>,
      "mode": <sr_tcm, tr_tcm, storm>,
      "color": <aware, blind>,
      "cbs": <commit burst size>,
      "cir": <commit information rate>,
      "pbs": <peak burst size>,
      "pir": <peak information rate>,

```

```

    "green_action": <action for packets marked as green>,
    "yellow_action": <action for packets marked as yellow>,
    "red_action": <action for packets marked as red>,
    "genetlink_name": <psample for sflow>,
    "genetlink_mcgrp_name": <packets for sflow>
  }
},
"COPP_TRAP": {
  "<trap-name>": {
    "trap_ids": <list of trap ID>,
    "trap_group": <group name>
  }
}
}

```

Parameters:

- <group-name> : group name.
 - queue: Specifies the CPU queue number (0..47) the packets will enqueue into for processing when trap_action is trap or copy .
 - trap_action : Specifies the action for the trap group.
 - trap : trap the packets to the CPU for a process but not forward the packets.
 - copy: trap the packets to CPU for process and forward the packets.
 - drop : drop the packets.
 - trap_priority : Specifies the priority (0..65535) of the trap group. A higher number means higher priority.
 - meter_type : Specifies the meter type.
 - packets
 - bytes
 - mode : Specifies the meter mode.
 - sr_tcm: srTCM (Single Rate Three Color Marker).
 - tr_tcm: trTCM (Triple Rate Three Color Marker).
 - storm: storm control.
 - color : Specifies the color mode.

- aware: color-aware mode.
- blind: color-blind mode.
- cbs : Committed Burst Size. Packets or bytes depending on the meter_type value.
- cir : Committed Information Rate. Packets or bytes depending on the meter_type value.
- pbs : Peak Burst Size. Packets or bytes depending on the meter_type value.
- pir : Peak Information Rate. Packets or bytes depending on the meter_type value.
- green_action : action applied on the packets which are marked as green by the meter. A valid value is the same as trap_action .
- yellow_action : action applied on the packets which are marked as yellow color by the meter. A valid value is the same as trap_action .
- red_action : action applied on the packets which are marked as red color by the meter. A valid value is the same as trap_action .
- genetlink_name: genetlink name. Ignore (Don't add this parameter) if sFlow is disabled. The value only supports "psample " which is used for sFlow only.
- genetlink_mcgrp_name: genetlink multicast group name. Ignore (Don't add this parameter) if sFlow is disabled. The value only supports "packets " which is used for sFlow only.
- <trap-name> : Trap name to identify different trap configurations.
 - trap_ids : Specifies the trap ID in the trap group. It will associate the corresponding packet type with the specified trap group. The supported trap IDs are listed in the below.
 - trap_group: Specifies the trap group to which the specified Trap ID associates with.

Supported trap IDs

- stp
- lacp
- eapol
- lldp
- pvrst
- igmp_query
- sample_packet
- udd
- switch_cust_range
- arp_req

- arp_resp
- dhcp
- ospf
- pim
- dhcpv6
- neigh_discovery
- src_nat_miss
- dest_nat_miss
- isis
- arp_suppression
- nd_suppression
- ip2me
- ssh
- snmp
- bgp
- bgpv6
- bfd
- bfdv6
- l3_mtu_error
- ttl_error
- vxlan_arp

Note:

- The trap ID src_nat_miss and dest_nat_miss are only supported on the following models:
 - AS5835-54X
 - AS7326-56X, AS7726-32X
 - AS7712-32X
- The trap ID arp_suppression , nd_suppression and vxlan_arp are only supported on the Broadcom Trident3, Trident4 switches, including the following models:
 - AS5835-54X
 - AS7326-56X, AS7726-32X
- The trap ID l3_mtu_error is not supported on the following models: AS9736- 64D.

Predefined trap groups and trap IDs in system

The following shows the predefined trap groups and IDs added by default:

Trap Group

	group	queue	trap_action	trap_priority	meter_type	mode	circ	cb	red_action	genetlink_name	genetlink_mcgrp_name	(referred by)
1	default	0	trap		packets	sr_tcm	600	600	drop			
2	queue4_group1	4	trap	4								bgp, lacp,
3	queue4_group2	4	copy	4	packets	sr_tcm	600	600	drop			arp
4	queue4_group3	4	trap	4								lldp, dhcp, udld
5	queue1_group1	1	trap	1	packets	sr_tcm	6000	6000	drop			ip2me
6	queue1_group2	1	trap	1	packets	sr_tcm	600	600	drop			nat
7	queue2_group1	2	trap	1	packets	sr_tcm	1000	1000	drop	psample	packets	sflow

8	queue4_group4	4	trap	4	packet s	sr_t cm	10 00	10 00	drop			ospf
9	queue4_group5	4	trap	4	packet s	sr_t cm	10 00	10 00	drop			isis
10	queue4_group6	4	trap	5	packet s	sr_t cm	60 0	60 0	drop			evpn
11	queue4_group7	4	copy	5	packet s	sr_t cm	60 0	60 0	drop			evpn_v xlan

Trap ID

	trap	trap_ids	trap_group
1	bgp	bgp, bgpv6	queue4_group1
2	lACP	lACP	queue4_group1
3	arp	arp_req, arp_resp, neigh_discovery	queue4_group2
4	lldp	lldp	queue4_group3
5	dhcp	dhcp, dhcpv6	queue4_group3
6	udld	udld	queue4_group3
7	ip2me	ip2me	queue1_group1
8	nat	src_nat_miss, dest_nat_miss	queue1_group2
9	sflow	sample_packet	queue2_group1

10	ospf	ospf	queue4_group4
11	isis	isis	queue4_group4
12	evpn	arp_supression, nd_supression	queue4_group6
13	evpn_vxlan	vxlan_arp	queue4_group7

Note:

- The trap group default is created to trap the IPv4/IPv6 packets whose TTL fields in the IP headers are 0 to CPU.
- The trap group queue4_group7 is only created for AS4630-54PE, AS5835-54X, AS5835-54T, AS7326-56X, and AS7726-32X models.

Example

The following example configures a trap group (queue1_group2) and a trap (nat) which lists two NAT trap IDs (src_nat_miss and dest_nat_miss), and associates the trap list with the trap group (queue1_group2) which defines a meter (packet), criteria (600), and action (drop).

Example of trap group

```
{
  "COPP_GROUP": {
    "queue1_group2": {
      "trap_action": "trap",
      "trap_priority": "1",
      "queue": "1",
      "meter_type": "packets",
      "mode": "sr_tcm",
      "cir": "600",
      "cbs": "600",
      "red_action": "drop"
    }
  }
}
```

```
    }  
  },  
  "COPP_TRAP": {  
    "nat": {  
      "trap_ids": "src_nat_miss,dest_nat_miss",  
      "trap_group": "queue1_group2"  
    }  
  }  
}
```

14 Critical Resource Monitoring

Table of Contents

[CRM show commands](#)

[crm show](#)

[crm show summary](#)

[crm show resources](#)

[crm show resources all](#)

[crm show resources acl](#)

[crm show resources acl group](#)

[crm show resources acl table](#)

[crm show resources fdb](#)
[crm show resources ipmc](#)
[crm show resources ipv4](#)
[crm show resources ipv4 neighbor](#)
[crm show resources ipv4 nexthop](#)
[crm show resources ipv4 route](#)
[crm show resources ipv6](#)
[crm show resources ipv6 neighbor](#)
[crm show resources ipv6 nexthop](#)
[crm show resources ipv6 route](#)
[crm show resources mpls](#)
[crm show resources mpls inseq](#)
[crm show resources nexthop group](#)
[crm show resources nexthop group member](#)
[crm show resources nexthop group object](#)
[crm show resources snat](#)
[crm show resources srv6-my-sid-entry](#)
[crm show resources srv6-nexthop](#)

[CRM config command](#)

[crm config](#)
[crm config polling interval](#)
[crm config thresholds](#)
[crm config thresholds acl group counter type](#)
[crm config thresholds acl group counter low/high](#)
[crm config thresholds acl table type](#)
[crm config thresholds acl table low/high](#)
[crm config thresholds dnat low/high](#)
[crm config thresholds dnat type](#)
[crm config thresholds fdb type](#)
[crm config thresholds fdb low/high](#)
[crm config thresholds ipmc low/high](#)
[crm config thresholds ipmc type](#)
[crm config thresholds ipv4 neighbor type](#)
[crm config thresholds ipv4 neighbor low/high](#)
[crm config thresholds ipv4 nexthop type](#)
[crm config thresholds ipv4 nexthop low/high](#)

[crm config thresholds ipv4 route type](#)
[crm config thresholds ipv4 route low|high](#)
[crm config thresholds ipv6 neighbor type](#)
[crm config thresholds ipv6 neighbor low|high](#)
[crm config thresholds ipv6 nexthop type](#)
[crm config thresholds ipv6 nexthop low|high](#)
[crm config thresholds ipv6 route type](#)
[crm config thresholds ipv6 route low|high](#)
[crm config thresholds mpls inseq low|high](#)
[crm config thresholds mpls inseq type](#)
[crm config thresholds mpls nexthop low|high](#)
[crm config thresholds mpls nexthop type](#)
[crm config thresholds nexthop group member type](#)
[crm config thresholds nexthop group member low|high](#)
[crm config thresholds nexthop group object low|high](#)
[crm config thresholds snat low|high](#)
[crm config thresholds snat type](#)
[crm config thresholds srv6-my-sid-entry low|high](#)
[crm config thresholds srv6-my-sid-entry type](#)
[crm config thresholds srv6-nexthop low|high](#)
[crm config thresholds srv6-nexthop type](#)

CRM show commands

crm show

Display the usage of show command

Usage
<pre>admin@sonic:~\$ crm show ?</pre> Usage: crm show [OPTIONS] COMMAND [ARGS]... Show CRM related information

Options:

--help Show this message and exit.

Commands:

resources Show CRM resources information

summary Show CRM general information

thresholds Show CRM thresholds information

crm show summary

Display polling interval setting

Example

```
admin@sonic:~$ crm show summary
```

```
Polling Interval: 300 second(s)
```

crm show resources

Display the usage of show resources command

Usage

```
admin@sonic:~$ crm show resources
```

```
Usage: crm show resources [OPTIONS] COMMAND [ARGS]...
```

Show CRM resources information

Options:

--help Show this message and exit.

Commands:

acl	Show CRM information for acl resource
all	Show CRM information for all resources
dnat	Show CRM information for DNAT resource
fdb	Show CRM information for fdb resource
ipmc	Show CRM information for IPMC resource
ipv4	CRM resource IPv4 address family
ipv6	CRM resource IPv6 address family
mpls	CRM resource MPLS address family
nexthop	Show CRM information for nexthop resource
snat	Show CRM information for SNAT resource
srv6-my-sid-entry	Show CRM information for SRV6 MY_SID entry
srv6-nexthop	Show CRM information for SRV6 Nexthop

crm show resources all

Display all statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources all
```

Resource Name	Used Count	Available Count
-----	-----	-----
ipv4_route	66	100286
ipv6_route	68	39279
ipv4_nexthop	0	32765
ipv6_nexthop	0	32765
ipv4_neighbor	0	32765

ipv6_neighbor	0	4062
nexthop_group_member	0	32767
nexthop_group	0	511
fdb_entry	0	16384
ipmc_entry	0	0
snat_entry	0	45056
dnat_entry	0	45056
mpls_inseg	0	0
mpls_nexthop	0	32765
srv6_nexthop	0	32765
srv6_my_sid_entry	0	0

Stage	Bind Point	Resource Name	Used Count	Available Count
-------	------------	---------------	------------	-----------------

INGRESS	PORT	acl_group	32	224
INGRESS	PORT	acl_table	3	2
INGRESS	LAG	acl_group	0	224
INGRESS	LAG	acl_table	0	2
INGRESS	VLAN	acl_group	0	224
INGRESS	VLAN	acl_table	0	5
INGRESS	RIF	acl_group	0	224
INGRESS	RIF	acl_table	0	5
INGRESS	SWITCH	acl_group	0	224
INGRESS	SWITCH	acl_table	0	5
EGRESS	PORT	acl_group	0	224
EGRESS	PORT	acl_table	0	2
EGRESS	LAG	acl_group	0	224
EGRESS	LAG	acl_table	0	2
EGRESS	VLAN	acl_group	0	224
EGRESS	VLAN	acl_table	0	2
EGRESS	RIF	acl_group	0	224
EGRESS	RIF	acl_table	0	2
EGRESS	SWITCH	acl_group	0	224
EGRESS	SWITCH	acl_table	0	2

Table ID	Resource Name	Used Count	Available Count
----------	---------------	------------	-----------------

```
-----
0x7000000000a20 acl_entry      2      6142
0x7000000000a20 acl_counter    2      6142
```

crm show resources acl

Display the usage of ACL resources show command

Usage

```
admin@sonic:~$ crm show resources acl
```

Usage: crm show resources acl [OPTIONS] COMMAND [ARGS]...

Show CRM information for acl resource

Options:

--help Show this message and exit.

Commands:

group Show CRM information for acl group resource

table Show CRM information for acl table resource

crm show resources acl group

Display ACL group statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources acl group
```

Stage	Bind Point	Resource Name	Used Count	Available Count
INGRESS	PORT	acl_group	32	224

INGRESS PORT	acl_table	2	3
INGRESS LAG	acl_group	0	224
INGRESS LAG	acl_table	0	3
INGRESS VLAN	acl_group	0	224
INGRESS VLAN	acl_table	0	6
INGRESS RIF	acl_group	0	224
INGRESS RIF	acl_table	0	6
INGRESS SWITCH	acl_group	0	224
INGRESS SWITCH	acl_table	0	6
EGRESS PORT	acl_group	0	224
EGRESS PORT	acl_table	0	2
EGRESS LAG	acl_group	0	224
EGRESS LAG	acl_table	0	2
EGRESS VLAN	acl_group	0	224
EGRESS VLAN	acl_table	0	2
EGRESS RIF	acl_group	0	224
EGRESS RIF	acl_table	0	2
EGRESS SWITCH	acl_group	0	224
EGRESS SWITCH	acl_table	0	2

crm show resources acl table

Display ACL table statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources acl table
```

Table ID	Resource Name	Used Count	Available Count
0x7000000000a20	acl_entry	2	6142
0x7000000000a20	acl_counter	2	6142

crm show resources dn timer

(Unsupported in Broadcom platform) Display the usage of DNAT resources show command

Example

```
admin@sonic:~$ crm show resources dn timer
Resource Name    Used Count    Available Count
-----
dnat_entry       0             45056
```

crm show resources fdb

Display FDB statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources fdb
Resource Name    Used Count    Available Count
-----
fdb_entry        0             32768
```

crm show resources ipmc

(Unsupported) Display the usage of IPMC resources show command

Example

```
admin@sonic:~$ crm show resources ipmc
Resource Name    Used Count    Available Count
-----
ipmc_entry
```

crm show resources ipv4

Display the usage of IPv4 resources show command

Usage

```
admin@sonic:~$ crm show resources ipv4
```

Usage: crm show resources ipv4 [OPTIONS] COMMAND [ARGS]...

CRM resource IPv4 address family

Options:

--help Show this message and exit.

Commands:

neighbor Show CRM information for neighbor resource

nexthop Show CRM information for nexthop resource

route Show CRM information for route resource

crm show resources ipv4 neighbor

Display IPv4 neighbor statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources ipv4
```

Usage: crm show resources ipv4 [OPTIONS] COMMAND [ARGS]...

CRM resource IPv4 address family

Options:

--help Show this message and exit.

Commands:

neighbor Show CRM information for neighbor resource

nexthop Show CRM information for nexthop resource

route Show CRM information for route resource

```
admin@as5812-54x:~$ crm show resources ipv4 neighbor
```

Resource Name	Used Count	Available Count
-----	-----	-----
ipv4_neighbor	0	8192

crm show resources ipv4 nexthop

Display IPv4 nexthop statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources ipv4 nexthop
```

Resource Name	Used Count	Available Count
-----	-----	-----
ipv4_nexthop	0	49118

crm show resources ipv4 route

Display IPv4 route statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources ipv4 route
```

Resource Name	Used Count	Available Count
-----	-----	-----
ipv4_route	66	98238

crm show resources ipv6

Display the usage of IPv6 resources show command

Usage

```
admin@sonic:~$ crm show resources ipv6
```

Usage: crm show resources ipv6 [OPTIONS] COMMAND [ARGS]...

CRM resource IPv6 address family

Options:

--help Show this message and exit.

Commands:

neighbor Show CRM information for neighbor resource

nexthop Show CRM information for nexthop resource

route Show CRM information for route resource

crm show resources ipv6 neighbor

Display IPv6 neighbor statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources ipv6 neighbor
```

Resource Name	Used Count	Available Count
ipv6_neighbor	33	4096

crm show resources ipv6 nexthop

Display IPv6 nexthop statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources ipv6 nexthop
```

Resource Name	Used Count	Available Count
-----	-----	-----
ipv6_nexthop	33	49117

crm show resources ipv6 route

Display IPv6 route statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources ipv6 route
```

Resource Name	Used Count	Available Count
-----	-----	-----
ipv6_route	68	16316

crm show resources mpls

(Unsupported in Broadcom platform) Display the usage of MPLS resources show command

Example

```
admin@sonic:~$ crm show resources mpls
```

Usage: crm show resources mpls [OPTIONS] COMMAND [ARGS]...

CRM resource MPLS address family

Options:

--help Show this message and exit.

Commands:

inseg Show CRM information for in-segment resource

nexthop Show CRM information for nexthop resource

crm show resources mpls inseg

(Unsupported in Broadcom platform) Display MPLS inseg statistic which include used by all components and available resources in the ASIC.

Example

```
admin@sonic:~$ crm show resources mpls inseg
```

Resource Name	Used Count	Available Count
-----	-----	-----
mpls_inseg	0	0

crm show resources mpls nexthop

(Unsupported in Broadcom platform) Display MPLS nexthop statistic which include used by all components and available resources in the ASIC.

Example

```
admin@sonic:~$ crm show resources mpls nexthop
```

Resource Name	Used Count	Available Count
-----	-----	-----
mpls_nexthop	0	32765

crm show resources nexthop group

Display the usage of nexthop group resources show command

Usage

```
admin@sonic:~$ crm show resources nexthop group
```

Usage: crm show resources nexthop group [OPTIONS] COMMAND [ARGS]...

Show CRM information for nexthop group resource

Options:

--help Show this message and exit.

Commands:

member Show CRM information for nexthop group member resource

object Show CRM information for nexthop group resource

crm show resources nexthop group member

Display nexthop group member statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources nexthop group member
```

Resource Name	Used Count	Available Count
-----	-----	-----
nexthop_group_member	0	16384

crm show resources nexthop group object

Display nexthop group object statistic which include used by all components and available resources in the ASIC

Example

```
admin@sonic:~$ crm show resources nexthop group object
```

Resource Name	Used Count	Available Count
-----	-----	-----

nexthop_group	0	128
---------------	---	-----

crm show resources snat

Display the usage of SNAT resources show command

Example

```
admin@sonic:~$ crm show resources snat
```

Resource Name	Used Count	Available Count
snat_entry	0	45056

crm show resources srv6-my-sid-entry

(Unsupported in Broadcom platform) Display the usage of srv6-my-sid-entry resources show command.

Example

```
admin@sonic:~$ crm show resources srv6-my-sid-entry
```

Resource Name	Used Count	Available Count
srv6-my-sid-entry	0	45056

crm show resources srv6-nexthop

(Unsupported in Broadcom platform) Display the usage of srv6-nexthop resources show command

Example

```
admin@sonic:~$ crm show resources srv6-nexthop
```

Resource Name	Used Count	Available Count
---------------	------------	-----------------

```
-----
srv6-nexthop      0      45056
```

CRM config command

Config command should be extended in order to add "crm" alias to the CRM utility.

crm config

Display the usage of config command

Usage

```
admin@sonic:~$ crm config
```

```
Usage: crm config [OPTIONS] COMMAND [ARGS]...
```

CRM related configuration

Options:

```
--help Show this message and exit.
```

Commands:

```
polling  CRM polling configuration
```

```
thresholds CRM thresholds configuration
```

crm config polling interval

Configure the polling interval to fetch available resources from ASIC

Usage

```
admin@sonic:~$ crm config polling interval
```

Usage: `crm config polling interval [OPTIONS] INTERVAL`

Example

```
admin@sonic:~$ crm config polling interval 400
```

crm config thresholds

Display the usage of config thresholds command

Usage

```
admin@as5812-54x:~$ crm config thresholds
```

Usage: `crm config thresholds [OPTIONS] COMMAND [ARGS]...`

CRM thresholds configuration

Options:

`--help` Show this message and exit.

Commands:

<code>acl</code>	CRM configuration for ACL resource
<code>dnat</code>	CRM configuration for Destination NAT resource
<code>fdb</code>	CRM configuration for FDB resource
<code>ipmc</code>	CRM configuration for IPMC resource
<code>ipv4</code>	CRM resource IPv4 address-family
<code>ipv6</code>	CRM resource IPv6 address-family
<code>mpls</code>	CRM resource MPLS address-family
<code>nexthop</code>	CRM configuration for nexthop resource

snat	CRM configuration for Source NAT resource
srv6-my-sid-entry	CRM configuration for SRV6 MY_SID resource
srv6-nexthop	CRM configuration for SRV6 Nexthop resource

crm config thresholds acl group counter type

Configure threshold type of ACL group

Usage

```
admin@sonic:~$ crm config thresholds acl group type
```

Usage: crm config thresholds acl group type [OPTIONS] [percentage|used|free]

Try "crm config thresholds acl group type --help" for help.

Example

```
admin@sonic:~$ crm config thresholds acl group type percentage
admin@sonic:~$ crm config thresholds acl group type used
admin@sonic:~$ crm config thresholds acl group type free
```

crm config thresholds acl group counter low|high

Configure low|high threshold of ACL group

Usage

```
admin@sonic:~$ crm config thresholds acl group low
```

Usage: crm config thresholds acl group low [OPTIONS] VALUE

Try "crm config thresholds acl group low --help" for help.

```
admin@sonic:~$ crm config thresholds acl group high
```

Usage: crm config thresholds acl group high [OPTIONS] VALUE

Try "crm config thresholds acl group high --help" for help.

Example

```
admin@sonic:~$ crm config thresholds acl group high 90
```

```
admin@sonic:~$ crm config thresholds acl group low 10
```

crm config thresholds acl table type

Configure threshold type of ACL table

Usage

```
admin@sonic:~$ crm config thresholds acl table type
```

Usage: crm config thresholds acl table type [OPTIONS] [percentage|used|free]

Try "crm config thresholds acl table type --help" for help.

Example

```
admin@sonic:~$ crm config thresholds acl table type percentage
```

```
admin@sonic:~$ crm config thresholds acl table type used
```

```
admin@sonic:~$ crm config thresholds acl table type free
```

crm config thresholds acl table low|high

Configure low|high threshold of ACL table

Usage

```
admin@sonic:~$ crm config thresholds acl table low
```

Usage: crm config thresholds acl table low [OPTIONS] VALUE

Try "crm config thresholds acl table low --help" for help.

```
admin@sonic:~$ crm config thresholds acl table high
```

Usage: crm config thresholds acl table high [OPTIONS] VALUE

Try "crm config thresholds acl table high --help" for help.

Example

```
admin@sonic:~$ crm config thresholds acl table low 3
```

```
admin@sonic:~$ crm config thresholds acl table high 80
```

crm config thresholds dnat low|high

(Unsupported in Broadcom platform) Configure low|high threshold of DNAT

Usage

```
admin@sonic:~$ crm config thresholds dnat low
```

Usage: crm config thresholds dnat low [OPTIONS] VALUE

Try "crm config thresholds dnat low --help" for help

```
admin@sonic:~$ crm config thresholds dnat high
```

Usage: crm config thresholds dnat high [OPTIONS] VALUE

Try "crm config thresholds dnat high -help" for help.

Example

```
admin@sonic:~$ crm config thresholds dnat low 3
admin@sonic:~$ crm config thresholds dnat high 80
```

crm config thresholds dnat type

(Unsupported in Broadcom platform) Configure threshold type of DNAT

Usage

```
admin@sonic:~$ crm config thresholds dnat type

Usage: crm config thresholds dnat type [OPTIONS] [percentage|used|free]

Try "crm config thresholds dnat type -help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds dnat type percentage
admin@sonic:~$ crm config thresholds dnat type used
admin@sonic:~$ crm config thresholds dnat type free
```

crm config thresholds fdb type

Configure threshold type of FDB

Usage

```
dmin@sonic:~$ crm config thresholds fdb type
```

```
Usage: crm config thresholds fdb type [OPTIONS] [percentage|used|free]
```

```
Try "crm config thresholds fdb type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds fdb type percentage
```

```
admin@sonic:~$ crm config thresholds fdb type used
```

```
admin@sonic:~$ crm config thresholds fdb type free
```

crm config thresholds fdb low|high

Configure low|high threshold of FDB

Usage

```
admin@sonic:~$ crm config thresholds fdb low
```

```
Usage: crm config thresholds fdb low [OPTIONS] VALUE
```

```
Try "crm config thresholds fdb low --help" for help.
```

```
admin@sonic:~$ crm config thresholds fdb high
```

```
Usage: crm config thresholds fdb high [OPTIONS] VALUE
```

```
Try "crm config thresholds fdb high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds fdb low 20
```

```
admin@sonic:~$ crm config thresholds fdb high 311111
```

crm config thresholds ipmc low|high

(Unsupported) Configure low|high threshold of IPMC

Usage

```
admin@sonic:~$ crm config thresholds ipmc low
```

Usage: crm config thresholds ipmc low [OPTIONS] VALUE

Try "crm config thresholds ipmc low --help" for help.

```
admin@sonic:~$ crm config thresholds ipmc high
```

Usage: crm config thresholds ipmc high [OPTIONS] VALUE

Try "crm config thresholds ipmc high --help" for help.

Example

```
admin@sonic:~$ crm config thresholds ipmc low 3
```

```
admin@sonic:~$ crm config thresholds ipmc high 80
```

crm config thresholds ipmc type

Configure threshold type of IPMC

Usage

```
admin@sonic:~$ crm config thresholds ipmc type
```

Usage: crm config thresholds ipmc type [OPTIONS] [percentage|used|free]

Try "crm config thresholds ipmc type --help" for help.

Example

```
admin@sonic:~$ crm config thresholds ipmc type percentage
admin@sonic:~$ crm config thresholds ipmc type used
admin@sonic:~$ crm config thresholds ipmc type free
```

crm config thresholds ipv4 neighbor type

Configure threshold type of IPv4 neighbor

Usage

```
admin@sonic:~$ crm config thresholds ipv4 neighbor type

Usage: crm config thresholds ipv4 neighbor type [OPTIONS]

        [percentage|used|free]

Try "crm config thresholds ipv4 neighbor type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv4 neighbor type percentage
admin@sonic:~$ crm config thresholds ipv4 neighbor type used
admin@sonic:~$ crm config thresholds ipv4 neighbor type free
```

crm config thresholds ipv4 neighbor low|high

Configure low|high threshold of IPv4 neighbor

Usage

```
admin@sonic:~$ crm config thresholds ipv4 neighbor low

Usage: crm config thresholds ipv4 neighbor low [OPTIONS] VALUE

Try "crm config thresholds ipv4 neighbor low --help" for help.
```

```
admin@sonic:~$ crm config thresholds ipv4 neighbor high

Usage: crm config thresholds ipv4 neighbor high [OPTIONS] VALUE

Try "crm config thresholds ipv4 neighbor high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv4 neighbor low 2
admin@sonic:~$ crm config thresholds ipv4 neighbor high 5566
```

crm config thresholds ipv4 nexthop type

Configure threshold type of IPv4 nexthop

Usage

```
admin@sonic:~$ crm config thresholds ipv4 nexthop type

Usage: crm config thresholds ipv4 nexthop type [OPTIONS]

                                [percentage|used|free]

Try "crm config thresholds ipv4 nexthop type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv4 nexthop type percentage
admin@sonic:~$ crm config thresholds ipv4 nexthop type free
admin@sonic:~$ crm config thresholds ipv4 nexthop type used
```

crm config thresholds ipv4 nexthop low|high

Configure low|high threshold of IPv4 nexthop

Usage

```
admin@sonic:~$ crm config thresholds ipv4 nexthop low
Usage: crm config thresholds ipv4 nexthop low [OPTIONS] VALUE
Try "crm config thresholds ipv4 nexthop low --help" for help.
admin@sonic:~$ crm config thresholds ipv4 nexthop high
Usage: crm config thresholds ipv4 nexthop high [OPTIONS] VALUE
Try "crm config thresholds ipv4 nexthop high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv4 nexthop high 90
admin@sonic:~$ crm config thresholds ipv4 nexthop high 9000000
```

crm config thresholds ipv4 route type

Configure threshold type of IPv4 route

Usage

```
admin@sonic:~$ crm config thresholds ipv4 route type
```

```
Usage: crm config thresholds ipv4 route type [OPTIONS] [percentage|used|free]
```

```
Try "crm config thresholds ipv4 route type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv4 route type percentage
```

```
admin@sonic:~$ crm config thresholds ipv4 route type used
```

```
admin@sonic:~$ crm config thresholds ipv4 route type free
```

crm config thresholds ipv4 route low|high

Configure low|high threshold of IPv4 route

Usage

```
admin@sonic:~$ crm config thresholds ipv4 route low
```

```
Usage: crm config thresholds ipv4 route low [OPTIONS] VALUE
```

```
Try "crm config thresholds ipv4 route low --help" for help.
```

```
admin@sonic:~$ crm config thresholds ipv4 route high
```

```
Usage: crm config thresholds ipv4 route high [OPTIONS] VALUE
```

```
Try "crm config thresholds ipv4 route high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv4 route low 11
```

```
admin@sonic:~$ crm config thresholds ipv4 route high 800000
```

crm config thresholds ipv6 neighbor type

Configure threshold type of IPv6 neighbor

Usage
<pre>admin@sonic:~\$ crm config thresholds ipv6 neighbor type</pre> Usage: crm config thresholds ipv6 neighbor type [OPTIONS] [percentage used free] Try "crm config thresholds ipv6 neighbor type --help" for help.

Example
<pre>admin@sonic:~\$ crm config thresholds ipv6 neighbor type percentage admin@sonic:~\$ crm config thresholds ipv6 neighbor type used admin@sonic:~\$ crm config thresholds ipv6 neighbor type free</pre>

crm config thresholds ipv6 neighbor low|high

Configure low|high threshold of IPv6 neighbor

Usage
<pre>admin@sonic:~\$ crm config thresholds ipv6 neighbor low</pre> Usage: crm config thresholds ipv6 neighbor low [OPTIONS] VALUE Try "crm config thresholds ipv6 neighbor low --help" for help. <pre>admin@sonic:~\$ crm config thresholds ipv6 neighbor high</pre> Usage: crm config thresholds ipv6 neighbor high [OPTIONS] VALUE

Try "crm config thresholds ipv6 neighbor high --help" for help.

Example

```
admin@sonic:~$ crm config thresholds ipv6 neighbor low 100
admin@sonic:~$ crm config thresholds ipv6 neighbor high 50000
```

crm config thresholds ipv6 nexthop type

Configure threshold type of IPv6 nexthop

Usage

```
admin@sonic:~$ crm config thresholds ipv6 nexthop type

Usage: crm config thresholds ipv6 nexthop type [OPTIONS]

                                [percentage|used|free]

Try "crm config thresholds ipv6 nexthop type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv6 nexthop type percentage
admin@sonic:~$ crm config thresholds ipv6 nexthop type used
admin@sonic:~$ crm config thresholds ipv6 nexthop type free
```

crm config thresholds ipv6 nexthop low|high

Configure low|high threshold of IPv6 nexthop

Usage

```
admin@sonic:~$ crm config thresholds ipv6 nexthop low

Usage: crm config thresholds ipv6 nexthop low [OPTIONS] VALUE

Try "crm config thresholds ipv6 nexthop low --help" for help.

admin@sonic:~$ crm config thresholds ipv6 nexthop high

Usage: crm config thresholds ipv6 nexthop high [OPTIONS] VALUE

Try "crm config thresholds ipv6 nexthop high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv6 nexthop low 10
admin@sonic:~$ crm config thresholds ipv6 nexthop high 80000
```

crm config thresholds ipv6 route type

Configure threshold type of IPv6 route

Usage

```
admin@sonic:~$ crm config thresholds ipv6 route type

Usage: crm config thresholds ipv6 route type [OPTIONS] [percentage|used|free]

Try "crm config thresholds ipv6 route type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv6 route type percentage
```

```
admin@sonic:~$ crm config thresholds ipv6 route type used
admin@sonic:~$ crm config thresholds ipv6 route type free
```

crm config thresholds ipv6 route low|high

Configure low|high threshold of IPv6 route

Usage

```
admin@sonic:~$ crm config thresholds ipv6 route low

Usage: crm config thresholds ipv6 route low [OPTIONS] VALUE

Try "crm config thresholds ipv6 route low --help" for help.

admin@sonic:~$ crm config thresholds ipv6 route high

Usage: crm config thresholds ipv6 route high [OPTIONS] VALUE

Try "crm config thresholds ipv6 route high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds ipv6 route low 100
admin@sonic:~$ crm config thresholds ipv6 route low 80000
```

crm config thresholds mpls inseq low|high

(Unsupported in Broadcom platform) Configure low|high threshold of MPLS inseq

Usage

```
admin@sonic:~$ crm config thresholds mpls inseq low
```

Usage: `crm config thresholds mpls inseg low [OPTIONS] VALUE`

Try "`crm config thresholds mpls inseg low --help`" for help

`admin@sonic:~$ crm config thresholds mpls inseg high`

Usage: `crm config thresholds mpls inseg high [OPTIONS] VALUE`

Try "`crm config thresholds mpls inseg high --help`" for help.

Example

`admin@sonic:~$ crm config thresholds mpls inseg low 3`

`admin@sonic:~$ crm config thresholds mpls inseg high 80`

crm config thresholds mpls inseg type

(Unsupported in Broadcom platform) Configure threshold type of mpls inseg

Usage

`admin@sonic:~$ crm config thresholds mpls inseg type`

Usage: `crm config thresholds mpls inseg type [OPTIONS] [percentage|used|free]`

Try "`crm config thresholds mpls inseg type --help`" for help.

Example

`admin@sonic:~$ crm config thresholds mpls inseg type percentage`

`admin@sonic:~$ crm config thresholds mpls inseg type used`

`admin@sonic:~$ crm config thresholds mpls inseg type free`

crm config thresholds mpls nexthop low|high

(Unsupported in Broadcom platform) Configure low|high threshold of MPLS nexthop

Usage

```
admin@sonic:~$ crm config thresholds mpls nexthop low
```

```
Usage: crm config thresholds mpls nexthop low [OPTIONS] VALUE
```

```
Try "crm config thresholds mpls nexthop low --help" for help
```

```
admin@sonic:~$ crm config thresholds mpls nexthop high
```

```
Usage: crm config thresholds mpls nexthop high [OPTIONS] VALUE
```

```
Try "crm config thresholds mpls nexthop high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds mpls nexthop low 3
```

```
admin@sonic:~$ crm config thresholds mpls nexthop high 80
```

crm config thresholds mpls nexthop type

(Unsupported in Broadcom platform) Configure threshold type of mpls nexthop

Usage

```
admin@sonic:~$ crm config thresholds mpls nexthop type
```

```
Usage: crm config thresholds mpls nexthop type [OPTIONS] [percentage|used|free]
```

```
Try "crm config thresholds mpls nexthop type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds mpls nexthop type percentage
admin@sonic:~$ crm config thresholds mpls nexthop type used
admin@sonic:~$ crm config thresholds mpls nexthop type free
```

crm config thresholds nexthop group member type

Configure threshold type of nexthop group member

Usage

```
admin@sonic:~$ crm config thresholds nexthop group member type

Usage: crm config thresholds nexthop group member type [OPTIONS]

                                [percentage|used|free]

Try "crm config thresholds nexthop group member type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds nexthop group member type percentage
admin@sonic:~$ crm config thresholds nexthop group member type used
admin@sonic:~$ crm config thresholds nexthop group member type free
```

crm config thresholds nexthop group member low|high

Configure low|high threshold of nexthop group member

Usage

```
admin@sonic:~$ crm config thresholds nexthop group member low

Usage: crm config thresholds nexthop group member low [OPTIONS] VALUE

Try "crm config thresholds nexthop group member low --help" for help.

admin@sonic:~$ crm config thresholds nexthop group member high

Usage: crm config thresholds nexthop group member high [OPTIONS] VALUE

Try "crm config thresholds nexthop group member high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds nexthop group member low 1000
admin@sonic:~$ crm config thresholds nexthop group member high 12345
```

crm config thresholds nexthop group object type

Configure threshold type of nexthop group object

Usage

```
admin@sonic:~$ crm config thresholds nexthop group object type

Usage: crm config thresholds nexthop group object type [OPTIONS]

                                [percentage|used|free]

Try "crm config thresholds nexthop group object type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds nexthop group object type percentage
admin@sonic:~$ crm config thresholds nexthop group object type used
```

```
admin@sonic:~$ crm config thresholds nexthop group object type free
```

crm config thresholds nexthop group object low|high

Configure threshold type of nexthop group object

Usage

```
admin@sonic:~$ crm config thresholds nexthop group object low
```

Usage: crm config thresholds nexthop group object low [OPTIONS] VALUE

Try "crm config thresholds nexthop group object low --help" for help.

```
admin@sonic:~$ crm config thresholds nexthop group object high
```

Usage: crm config thresholds nexthop group object high [OPTIONS] VALUE

Try "crm config thresholds nexthop group object high --help" for help.

Example

```
admin@sonic:~$ crm config thresholds nexthop group object low 100
```

```
admin@sonic:~$ crm config thresholds nexthop group object high 2000
```

crm config thresholds snat low|high

Configure low|high threshold of SNAT

Usage

```
admin@sonic:~$ crm config thresholds snat low
```

Usage: crm config thresholds snat low [OPTIONS] VALUE

```
Try "crm config thresholds snat low --help" for help

admin@sonic:~$ crm config thresholds snat high

Usage: crm config thresholds snat high [OPTIONS] VALUE

Try "crm config thresholds snat high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds snat low 3
admin@sonic:~$ crm config thresholds snat high 80
```

crm config thresholds snat type

Configure threshold type of SNAT

Usage

```
admin@sonic:~$ crm config thresholds snat type

Usage: crm config thresholds snat type [OPTIONS] [percentage|used|free]

Try "crm config thresholds snat type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds snat type percentage
admin@sonic:~$ crm config thresholds snat type used
admin@sonic:~$ crm config thresholds snat type free
```

crm config thresholds srv6-my-sid-entry low|high

(Unsupported in Broadcom platform) Configure low|high threshold of srv6-my-sid-entry

Usage

```
admin@sonic:~$ crm config thresholds srv6-my-sid-entry low
```

Usage: crm config thresholds srv6-my-sid-entry low [OPTIONS] VALUE

Try "crm config thresholds srv6-my-sid-entry low --help" for help

```
admin@sonic:~$ crm config thresholds srv6-my-sid-entry high
```

Usage: crm config thresholds srv6-my-sid-entry high [OPTIONS] VALUE

Try "crm config thresholds srv6-my-sid-entry high --help" for help.

Example

```
admin@sonic:~$ crm config thresholds srv6-my-sid-entry low 3
```

```
admin@sonic:~$ crm config thresholds srv6-my-sid-entry high 80
```

crm config thresholds srv6-my-sid-entry type

(Unsupported in Broadcom platform) Configure threshold type of srv6-my-sid-entry

Usage

```
admin@sonic:~$ crm config thresholds srv6-my-sid-entry type
```

Usage: crm config thresholds srv6-my-sid-entry type [OPTIONS] [percentage|used|free]

Try "crm config thresholds srv6-my-sid-entry type --help" for help.

Example

```
admin@sonic:~$ crm config thresholds srv6-my-sid-entry type percentage
admin@sonic:~$ crm config thresholds srv6-my-sid-entry type used
admin@sonic:~$ crm config thresholds srv6-my-sid-entry type free
```

crm config thresholds srv6-nexthop low|high

Configure low|high threshold of srv6-nexthop

Usage

```
admin@sonic:~$ crm config thresholds srv6-nexthop low

Usage: crm config thresholds srv6-nexthop low [OPTIONS] VALUE

Try "crm config thresholds srv6-nexthop low --help" for help

admin@sonic:~$ crm config thresholds srv6-nexthop high

Usage: crm config thresholds srv6-nexthop high [OPTIONS] VALUE

Try "crm config thresholds srv6-nexthop high --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds srv6-nexthop low 3
admin@sonic:~$ crm config thresholds srv6-nexthop high 80
```

crm config thresholds srv6-nexthop type

Configure threshold type of srv6-nexthop

Usage

```
admin@sonic:~$ crm config thresholds srv6-nexthop type
```

```
Usage: crm config thresholds srv6-nexthop type [OPTIONS] [percentage|used|free]
```

```
Try "crm config thresholds srv6-nexthop type --help" for help.
```

Example

```
admin@sonic:~$ crm config thresholds srv6-nexthop type percentage
```

```
admin@sonic:~$ crm config thresholds srv6-nexthop type used
```

```
admin@sonic:~$ crm config thresholds srv6-nexthop type free
```

15 Device Hostname

This section of commands is used to change the device hostname without traffic being impacted.

Update Device Hostname Configuration Commands

config hostname

This command is used to change the device hostname without traffic being impacted.

Usage

```
config hostname <new_hostname>
```

Example

```
admin@sonic:~$ sudo config hostname CSW06
```

Note: The configured setting will be lost after a system reboot. To preserve the setting, run `config save`.

16 DHCP Relay

Table of Contents

[DHCP Relay show commands](#)

[show vlan brief](#)

[DHCP Relay config commands](#)

[config vlan dhcp_relay add](#)

[config vlan dhcp_relay delete](#)
[config vlan dhcp_relay link_selection del](#)
[config vlan dhcp_relay src_intf add](#)
[config vlan dhcp_relay src_intf del](#)
[config vlan dhcp_relay server_vrf add](#)
[config vlan dhcp_relay server_vrf del](#)
[config vlan dhcp_relay server_override add](#)
[config vlan dhcp_relay server_override del](#)

These commands are used to add or remove DHCP Relay destination IP addresses for VLAN interfaces.

When the DHCP Relay service is enabled, and the switch sees a DHCP client request from an attached host, it inserts its own IP address into the request so that the DHCP server will know the subnet where the client is located. Then, the switch forwards the packet to a DHCP server (destination IP) on another network. When the server receives the DHCP request, it allocates a free IP address for the DHCP client from its defined scope for the DHCP client's subnet, and sends a DHCP response back to the DHCP Relay agent (the switch). The switch then passes the DHCP response received from the server to the client.

DHCP Relay show commands

show vlan brief

This command displays brief information about all the vlans configured in the device. It displays the vlan ID, IP address (if configured for the vlan), list of vlan member ports, whether the port is tagged or in untagged mode and the DHCP Helper Address.

Usage
show vlan brief
show vlan brief --verbose

Example

VLAN ID	IP Address	Ports	Port	Proxy	DHCP Helper	DHCP Relay Configuration
		Tagging	ARP	Address		
100	100.0.0.1/24	Ethernet512	tagged	disabled		Source Interface:
		Ethernet513	tagged			Link Selection:
						Server Vrf:
						Server ID Override:

DHCP Relay config commands

config vlan dhcp_relay add

This command adds a DHCP Relay Destination IP address to a VLAN. Note that more than one DHCP Relay Destination IP address can be added on a VLAN interface.

Usage

```
config vlan dhcp_relay add <vlan_id> <dhcp_relay_destination_ip>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay add 1000 7.7.7.7
```

Added DHCP relay destination address 7.7.7.7 to Vlan1000

Restarting DHCP relay service..

config vlan dhcp_relay delete

This command deletes a configured DHCP Relay destination IP address from a VLAN interface.

Usage

```
config vlan dhcp_relay del <vlan-id> <dhcp_relay_destination_ip>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay del 1000 7.7.7.7  
Removed DHCP relay destination address 7.7.7.7 from Vlan1000  
Restarting DHCP relay service...  
Running command: systemctl restart dhcp_relay
```

config vlan dhcp_relay link_selection add

This command is used to enable DHCP relay link selection on a VLAN. Note that users need to add the dhcp relay source interface first.

Usage

```
config vlan dhcp_relay link_selection add <vlan_id>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay link_selection add 1000
```

Enable DHCP relay link selection for Vlan1000

Restarting DHCP relay service...

config vlan dhcp_relay link_selection del

This command is used to disable DHCP relay link selection on a VLAN.

Usage

```
config vlan dhcp_relay link_selection del <vlan_id>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay link_selection del 1000
```

Removed DHCP relay link selection from Vlan1000

Restarting DHCP relay service...

config vlan dhcp_relay src_intf add

This command is used to set the DHCP relay source interface on a VLAN.

Usage

```
config vlan dhcp_relay src_intf add <vlan_id> <dhcp_relay_src_intf>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay src_intf add 1000 PortChannel0001  
  
Added DHCP relay source interface PortChannel0001 for Vlan1000  
  
Restarting DHCP relay service...
```

config vlan dhcp_relay src_intf del

This command is used to remove the configured DHCP relay source interface from a VLAN. Note that users need to disable the dhcp relay link selection first.

Usage

```
config vlan dhcp_relay src_intf del <vlan_id> <dhcp_relay_src_intf>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay src_intf del 1000 PortChannel0001  
  
Removed DHCP relay source interface PortChannel0001 from Vlan1000  
  
Restarting DHCP relay service...
```

config vlan dhcp_relay server_vrf add

The config vlan dhcp_relay server_vrf add command is used to specify the DHCP relay server vrf on a VLAN.

Usage

```
config vlan dhcp_relay server_vrf add <vlan_id> <dhcp_relay_server_vrf>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay server_vrf add 1000 Vrf1  
  
Added DHCP relay server vrf Vrf1 for Vlan1000  
  
Restarting DHCP relay service...
```

config vlan dhcp_relay server_vrf del

The config vlan dhcp_relay server_vrf del command is used to remove the configured DHCP relay server vrf from a VLAN.

Usage

```
config vlan dhcp_relay server_vrf del <vlan_id>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay server_vrf del 1000  
  
Removed DHCP relay server vrf from Vlan1000  
  
Restarting DHCP relay service...
```

config vlan dhcp_relay server_override add

The config vlan dhcp_relay server_override add command is used to specify the DHCP relay server id override option82 suboption on a VLAN.

Usage

```
config vlan dhcp_relay server_override add <vlan_id>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay server_override add 1000
```

Enable DHCP relay server override for Vlan1000

Restarting DHCP relay service...

config vlan dhcp_relay server_override del

The config vlan dhcp_relay server_override del command is used to disable DHCP relay server id override

option82 suboption on a VLAN.

Usage

```
config vlan dhcp_relay server_override del <vlan_id>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay server_override del 1000
```

Removed DHCP relay server override from Vlan1000

Restarting DHCP relay service...

17 DHCPv6 Relay

Table of Contents

[DHCPv6 Relay show commands](#)

[show dhcprelay_helper ipv6](#)

[show dhcpv6_replay counter](#)

[clear dhcpv6_replay counter](#)

[DHCPv6 Relay config commands](#)

[config vlan dhcp_relay add](#)

[config sag dhcp_relay add](#)

[config sag dhcp_relay delete](#)

These commands are used to add or remove DHCPv6 Relay destination IP addresses for VLAN interfaces.

When the DHCPv6 Relay service is enabled, and the switch sees a DHCPv6 client request from an attached host, it inserts its own IP address into the request so that the DHCPv6 server will know the subnet where the client is located. Then, the switch forwards the packet to a DHCPv6 server (destination IP) on another network. When the server receives the DHCPv6 request, it allocates a free IP address for the DHCPv6 client from its defined scope for the DHCPv6 client's subnet, and sends a DHCPv6 response back to the DHCPv6 Relay agent (the switch). The switch then passes the DHCPv6 response received from the server to the client.

DHCPv6 Relay show commands

show dhcprelay_helper ipv6

This command is used to show the config of DHCPv6 Relay.

Usage
<code>show dhcprelay_helper ipv6</code>

Example

```
admin@sonic:~$ show dhcprelay_helper ipv6
```

```
-----
```

```
Vlan1000 fc02:2000::5
```

```
-----
```

show dhcpv6_replay counter

This command is used to show the counter of DHCPv6 relay packets

Usage

```
show dhcp6relay_counters counts
```

Example

```
admin@sonic:~$ show dhcp6relay_counters counts
```

```
Message Type  Vlan1000
```

```
-----
```

```
Unknown      0
```

```
Solicit      2
```

```
Advertise    2
```

```
Request      2
```

```
Confirm      0
```

```
Renew        0
```

```
Rebind       0
```

Reply	2
Release	0
Decline	0
Relay-Forward	16
Relay-Reply	4

clear dhcpv6_replay counter

This command is used to clear counter of DHCPv6 relay packets

Usage

```
sudo sonic-clear dhcp6relay_counters
```

Example

```
admin@sonic:~$ sudo sonic-clear dhcp6relay_counters
```

```
admin@sonic:~$ show dhcp6relay_counters counts
```

```
Message Type  Vlan1000
```

```
-----
```

```
Unknown      0
```

```
Solicit      0
```

```
Advertise    0
```

```
Request      0
```

Confirm	0
Renew	0
Rebind	0
Reply	0
Release	0
Decline	0
Relay-Forward	0
Relay-Reply	0

DHCPv6 Relay config commands

config vlan dhcp_relay add

This command is used to add a DHCPv6 Relay Destination IPv6 address to a VLAN.

Usage

```
config vlan dhcp_relay add <vlan_id> <dhcpv6_relay_destination_ips>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay add 1000 fc02:2000::5
Added DHCP relay destination addresses ['fc02:2000::5'] to Vlan1000
Restarting DHCP relay service...
```

config vlan dhcp_relay delete

This command is used to delete a DHCPv6 Relay Destination IPv6 address.

Usage

```
config vlan dhcp_relay del <vlan_id> <dhcpv6_relay_destination_ips>
```

Example

```
admin@sonic:~$ sudo config vlan dhcp_relay del 1000 fc02:2000::5
```

Removed DHCP relay destination addresses ['fc02:2000::5'] from Vlan1000

Restarting DHCP relay service...

config sag dhcp_relay add

This command is used to add a DHCPv6 Relay Destination IPv6 address to a SAG.

Usage

```
config sag dhcp_relay add <sag_id> <dhcpv6_relay_destination_ips>
```

Example

```
admin@sonic:~$ sudo config sag dhcp_relay add 1000 fc02:2000::5
```

Added DHCP relay destination addresses ['fc02:2000::5'] to Sag1000

Restarting DHCP relay service...

config sag dhcp_relay delete

This command is used to delete a DHCPv6 Relay Destination IPv6 address.

Usage

```
config sag dhcp_relay del <sag_id> <dhcpv6_relay_destination_ips>
```

Example

```
admin@sonic:~$ sudo config sag dhcp_relay del 1000 fc02:2000::5
```

Removed DHCP relay destination addresses ['fc02:2000::5'] from Sag1000

Restarting DHCP relay service...

18 Drop Counters

Table of Contents

[Drop Counters Show Commands](#)

[show dropcounters capabilities](#)

[show dropcounters configuration](#)

[show dropcounters counts](#)

[Drop Counters Config Commands](#)

[config dropcounters install](#)

[config dropcounters add reasons](#)

[config dropcounters remove reasons](#)

[config dropcounters delete](#)

[Drop Counters Clear Commands](#)

[sonic-clear dropcounters](#)

This section explains all the configurable drop counters show commands and configuration options that are supported in SONiC.

Drop Counters Show Commands

show dropcounters capabilities

This command is used to show the drop counter capabilities that are available on this device. It displays the total number of drop counters that can be configured on this device as well as the drop reasons that can be configured for the counters.

Usage

```
show dropcounters capabilities
```

Example

```
admin@sonic:~$ show dropcounters capabilities
```

```
Counter Type      Total
-----
PORT_INGRESS_DROPS    3
SWITCH_EGRESS_DROPS   2
PORT_INGRESS_DROPS:
  L2_ANY
  SMAC_MULTICAST
  SMAC_EQUALS_DMACH
```

```

INGRESS_VLAN_FILTER
EXCEEDS_L2_MTU
SIP_CLASS_E
SIP_LINK_LOCAL
DIP_LINK_LOCAL
UNRESOLVED_NEXT_HOP
DECAP_ERROR
SWITCH_EGRESS_DROPS:
  L2_ANY
  L3_ANY
  A_CUSTOM_REASON

```

show dropcounters configuration

This command is used to show the current running configuration of the drop counters on this device.

Usage

```
show dropcounters configuration [-g <group name>]
```

Example

```
admin@sonic:~$ show dropcounters configuration
```

Counter	Alias	Group	Type	Reasons	Description
DEBUG_0	RX_LEGIT	LEGIT	PORT_INGRESS_DROPS	SMAC_EQUALS_DMACE	Legitimate port-level RX pipeline drops
				INGRESS_VLAN_FILTER	
DEBUG_1	TX_LEGIT	None	SWITCH_EGRESS_DROPS	EGRESS_VLAN_FILTER	Legitimate switch-level TX pipeline drops

```

admin@sonic:~$ show dropcounters configuration -g LEGIT

```

Counter	Alias	Group	Type	Reasons	Description
DEBUG_0	RX_LEGIT	LEGIT	PORT_INGRESS_DROPS	SMAC_EQUALS_DMAC	Legitimate port-level RX pipeline drops
			INGRESS_VLAN_FILTER		

show dropcounters counts

This command is used to show the current statistics for the configured drop counters. Standard drop counters are displayed as well for convenience. Because clearing counters (see below) is handled on a per-user basis, different users may see different drop counts.

Usage

```
show dropcounters counts \[-g <group name>\] \[-t <counter type>\]
```

Example

```
admin@sonic:~$ show dropcounters counts
  IFACE  STATE  RX_ERR  RX_DROPS  TX_ERR  TX_DROPS  RX_LEGIT
-----
Ethernet0  U    10    100     0     0     20
Ethernet4  U     0   1000     0     0    100
Ethernet8  U   100    10     0     0     0
DEVICE TX_LEGIT
-----
sonic    1000
admin@sonic:~$ show dropcounters counts -g LEGIT
  IFACE  STATE  RX_ERR  RX_DROPS  TX_ERR  TX_DROPS  RX_LEGIT
-----
Ethernet0  U    10    100     0     0     20
```

Ethernet4	U	0	1000	0	0	100
Ethernet8	U	100	10	0	0	0

Drop Counters Config Commands

config dropcounters install

This command is used to initialize a new drop counter. The user must specify a name, type, and initial list of drop reasons. This command will fail if the given name is already in use, if the type of counter is not supported, or if any of the specified drop reasons are not supported. It will also fail if all available counters are already in use on the device.

Usage

```
config dropcounters install <counter name> <counter type> <reasons list> [-d <description>] [-g <group>] [-a <alias>]
```

Example

```
admin@sonic:~$ sudo config dropcounters install DEBUG_2 PORT_INGRESS_DROPS
\[EXCEEDS_L2_MTU,DECAP_ERROR\] -d
"More port ingress drops" -g BAD -a BAD_DROPS
```

config dropcounters add_reasons

This command is used to add drop reasons to an already initialized counter. This command will fail if any of the specified drop reasons are not supported.

Usage

```
config dropcounters add_reasons <counter name> <reasons list>
```

Example

```
admin@sonic:~$ sudo config dropcounters add_reasons DEBUG_2 \[SIP_CLASS_E\]
```

config dropcounters remove_reasons

This command is used to remove drop reasons from an already initialized counter.

Usage

```
config dropcounters remove_reasons <counter name> <reasons list>
```

Example

```
admin@sonic:~$ sudo config dropcounters remove_reasons DEBUG_2 \[SIP_CLASS_E\]
```

config dropcounters delete

This command is used to delete a drop counter.

Usage

```
config dropcounters delete <counter name>
```

Example

```
admin@sonic:~$ sudo config dropcounters delete DEBUG_2
```

Drop Counters Clear Commands

sonic-clear dropcounters

This command is used to clear drop counters. This is done on a per-user basis.

Usage
sonic-clear dropcounters

Example
admin@sonic:~\$ sonic-clear dropcounters
Cleared drop counters

Note: Only supports the type PORT_INGRESS_DROPS with two reasons (SMAC_EQUALS_DMACK and EXCEEDS_L3_MTU) on the hardware models uses Broadcom ASIC .

19 Fast Reboot

Fast Reboot Configuration Commands

fast-reboot

Fast-reboot feature enables a switch to reboot up quickly, with minimum disruption to the data plane. It is important for data center networking operation where infrastructure maintenance and upgrade are unavoidable.

Fast-reboot is one of the features to minimize traffic impact. This command requires root privilege.

Usage
<code>fast-reboot [options]</code>

Parameters

- `-h,-?` : get this help
- `-v` : turn on verbose
- `-f` : force execution - ignore Orchagent RESTARTCHECK failure
- `-i` : force execution - ignore ASIC MD5-checksum-verification
- `-d` : force execution - ignore database integrity check
- `-r` : reboot with `/sbin/reboot`
- `-k` : reboot with `/sbin/kexec -e` [default]
- `-x` : execute script with `-x` flag
- `-c` : specify control plane assistant IP list
- `-s` : strict mode: do not proceed without:
 - `-` control plane assistant IP list.
- `-t` : Don't tag the current kube images as latest
- `-D` : detached mode - closing terminal will not cause stopping reboot

Example
<code>admin@sonic:~\$ sudo fast-reboot</code>

20 FDB

[FDB Show Commands](#)

[show mac](#)

[FDB Configuration Commands](#)

[sonic-clear fdb](#)

[config static-mac add](#)

[config static-mac del](#)

Switches store the addresses for all known devices. This information is used to forward traffic directly between the inbound and outbound ports. All the addresses learned by monitoring traffic are stored in the dynamic address table or forwarding database (FDB).

FDB Show Commands

show mac

This command displays the MAC (FDB) entries either in full or partial as given below.

1. show mac - displays the full table
2. show mac -v <vlanid> - displays the MACs learnt on the particular VLAN ID.
3. show mac -p <port> - displays the MACs learnt on the particular port.

4. show mac -a <mac_address> - display the MACs that match a specific mac-address
5. show mac -t <type> - display the MACs that match a specific type (static/dynamic/pending)
6. show mac -c - display the count of MAC addresses

Usage

```
show mac [-v <vlan_id>] [-p <port_name>] [-a <mac_address>] [-t <type>] [-c]
```

Example

```
admin@sonic:~$ show mac
```

No.	Vlan	MacAddress	Port	Type
1	1000	E2:8C:56:85:4A:CD	Ethernet192	Dynamic
2	1000	A0:1B:5E:47:C9:76	Ethernet192	Dynamic
3	1000	AA:54:EF:2C:EE:30	Ethernet192	Dynamic
4	1000	A4:3F:F2:17:A3:FC	Ethernet192	Dynamic
5	1000	0C:FC:01:72:29:91	Ethernet192	Dynamic
6	1000	48:6D:01:7E:C9:FD	Ethernet192	Dynamic
7	1000	1C:6B:7E:34:5F:A6	Ethernet192	Dynamic
8	1000	EE:81:D9:7B:93:A9	Ethernet192	Dynamic
9	1000	CC:F8:8D:BB:85:E2	Ethernet192	Dynamic
10	1000	0A:52:B3:9C:FB:6C	Ethernet192	Dynamic
11	1000	C6:E2:72:02:D1:23	Ethernet192	Dynamic
12	1000	8A:C9:5C:25:E9:28	Ethernet192	Dynamic
13	1000	5E:CD:34:E4:94:18	Ethernet192	Dynamic
14	1000	7E:49:1F:B5:91:B5	Ethernet192	Dynamic
15	1000	AE:DD:67:F3:09:5A	Ethernet192	Pending
16	1000	DC:2F:D1:08:4B:DE	Ethernet192	Pending
17	1000	50:96:23:AD:F1:65	Ethernet192	Static

```
18 1000 C6:C9:5E:AE:24:42 Ethernet192 Static
```

Total number of entries 18

Information in table:

- Vlan: The VLAN ID of the MACs
- MacAddress: mac address
- Port: The name of the interface
- Type: The type of the MACs
 - Dynamic: The mac addresses are automatically learned from the source mac field in the ethernet frame.
 - Static: The mac address configured by the "static-fdb add" command.
 - Pending: The mac addresses are automatically learned from the source mac field in the ethernet frame when port access control feature(such as 802.1X) is enabled.

Traffic is blocked for the MACs before it passes the authentication or remains in this type if authentication is failed.

Optionally, you can specify a VLAN ID or interface name or type or mac-address in order to display only that particular entries

Examples

```
admin@sonic:~$ show mac -v 1000
```

No.	Vlan	MacAddress	Port	Type
1	1000	E2:8C:56:85:4A:CD	Ethernet192	Dynamic
2	1000	A0:1B:5E:47:C9:76	Ethernet192	Dynamic
3	1000	AA:54:EF:2C:EE:30	Ethernet192	Dynamic
4	1000	A4:3F:F2:17:A3:FC	Ethernet192	Dynamic
5	1000	0C:FC:01:72:29:91	Ethernet192	Dynamic
6	1000	48:6D:01:7E:C9:FD	Ethernet192	Dynamic
7	1000	1C:6B:7E:34:5F:A6	Ethernet192	Dynamic
8	1000	EE:81:D9:7B:93:A9	Ethernet192	Dynamic
9	1000	CC:F8:8D:BB:85:E2	Ethernet192	Dynamic
10	1000	0A:52:B3:9C:FB:6C	Ethernet192	Dynamic

```

11 1000 C6:E2:72:02:D1:23 Ethernet192 Dynamic
12 1000 8A:C9:5C:25:E9:28 Ethernet192 Dynamic
13 1000 5E:CD:34:E4:94:18 Ethernet192 Dynamic
14 1000 7E:49:1F:B5:91:B5 Ethernet192 Dynamic
15 1000 AE:DD:67:F3:09:5A Ethernet192 Pending
16 1000 DC:2F:D1:08:4B:DE Ethernet192 Pending
17 1000 50:96:23:AD:F1:65 Ethernet192 Static
18 1000 C6:C9:5E:AE:24:42 Ethernet192 Static

```

Total number of entries 18

admin@sonic:~\$ show mac -p Ethernet192

No.	Vlan	MacAddress	Port	Type
1	1000	E2:8C:56:85:4A:CD	Ethernet192	Dynamic
2	1000	A0:1B:5E:47:C9:76	Ethernet192	Dynamic
3	1000	AA:54:EF:2C:EE:30	Ethernet192	Dynamic
4	1000	A4:3F:F2:17:A3:FC	Ethernet192	Dynamic
5	1000	0C:FC:01:72:29:91	Ethernet192	Dynamic
6	1000	48:6D:01:7E:C9:FD	Ethernet192	Dynamic
7	1000	1C:6B:7E:34:5F:A6	Ethernet192	Dynamic
8	1000	EE:81:D9:7B:93:A9	Ethernet192	Dynamic
9	1000	CC:F8:8D:BB:85:E2	Ethernet192	Dynamic
10	1000	0A:52:B3:9C:FB:6C	Ethernet192	Dynamic
11	1000	C6:E2:72:02:D1:23	Ethernet192	Dynamic
12	1000	8A:C9:5C:25:E9:28	Ethernet192	Dynamic
13	1000	5E:CD:34:E4:94:18	Ethernet192	Dynamic
14	1000	7E:49:1F:B5:91:B5	Ethernet192	Dynamic
15	1000	AE:DD:67:F3:09:5A	Ethernet192	Pending
16	1000	DC:2F:D1:08:4B:DE	Ethernet192	Pending
17	1000	50:96:23:AD:F1:65	Ethernet192	Static
18	1000	C6:C9:5E:AE:24:42	Ethernet192	Static

```

1 1000 E2:8C:56:85:4A:CD Ethernet192 Dynamic
2 1000 A0:1B:5E:47:C9:76 Ethernet192 Dynamic
3 1000 AA:54:EF:2C:EE:30 Ethernet192 Dynamic
4 1000 A4:3F:F2:17:A3:FC Ethernet192 Dynamic
5 1000 0C:FC:01:72:29:91 Ethernet192 Dynamic
6 1000 48:6D:01:7E:C9:FD Ethernet192 Dynamic
7 1000 1C:6B:7E:34:5F:A6 Ethernet192 Dynamic
8 1000 EE:81:D9:7B:93:A9 Ethernet192 Dynamic
9 1000 CC:F8:8D:BB:85:E2 Ethernet192 Dynamic
10 1000 0A:52:B3:9C:FB:6C Ethernet192 Dynamic
11 1000 C6:E2:72:02:D1:23 Ethernet192 Dynamic
12 1000 8A:C9:5C:25:E9:28 Ethernet192 Dynamic
13 1000 5E:CD:34:E4:94:18 Ethernet192 Dynamic
14 1000 7E:49:1F:B5:91:B5 Ethernet192 Dynamic
15 1000 AE:DD:67:F3:09:5A Ethernet192 Pending
16 1000 DC:2F:D1:08:4B:DE Ethernet192 Pending
17 1000 50:96:23:AD:F1:65 Ethernet192 Static
18 1000 C6:C9:5E:AE:24:42 Ethernet192 Static

```

Total number of entries 18

admin@sonic:~\$ show mac -a E2:8C:56:85:4A:CD

No.	Vlan	MacAddress	Port	Type
-----	------	------------	------	------

```
1 1000 E2:8C:56:85:4A:CD Ethernet192 Dynamic
```

Total number of entries 1

```
admin@sonic:~$ show mac -t Static
```

No.	Vlan	MacAddress	Port	Type
1	1000	E2:8C:56:85:4A:CD	Ethernet192	Dynamic

```
2 1000 50:96:23:AD:F1:65 Ethernet192 Static
```

```
2 1000 C6:C9:5E:AE:24:42 Ethernet192 Static
```

Total number of entries 2

```
admin@sonic:~$ show mac -t Pending
```

No.	Vlan	MacAddress	Port	Type
2	1000	AE:DD:67:F3:09:5A	Ethernet192	Pending
2	1000	DC:2F:D1:08:4B:DE	Ethernet192	Pending

```
2 1000 AE:DD:67:F3:09:5A Ethernet192 Pending
```

```
2 1000 DC:2F:D1:08:4B:DE Ethernet192 Pending
```

Total number of entries 2

```
admin@sonic:~$ show mac -c
```

Total number of entries 18

FDB Configuration Commands

sonic-clear fdb

The command is used to clear the MAC address table. The command is used for the specified all, vlan, port, and port-vlan.

Usage

```
sonic-clear fdb <all>|<port>| <vlan_id>|<port-vlan>
```

Parameter:

- <port>: The name of a physical interface
- <vlan_id>: Vlan ID
- <port-vlan>: The name of a physical interface and Vlan ID
- <all>: All FDB table

Example

```
root@sonic:/home/admin# sonic-clear fdb
```

```
Usage: sonic-clear fdb [OPTIONS] COMMAND [ARGS]...
```

Clear FDB table

Options:

-?, -h, --help Show this message and exit.

Commands:

```
all      Clear All FDB entries
port     Clear FDB entries learned from one PORT
port-vlan Clear FDB entries learned in one PORT-VLAN
vlan     Clear FDB entries learned in one VLAN
```

```
root@sonic:/home/admin# sonic-clear fdb port Ethernet0
Port Ethernet0 FDB entries are cleared.
```

```
root@sonic:/home/admin# sonic-clear fdb vlan 100
Vlan100 FDB entries are cleared.
```

```
root@sonic:/home/admin# sonic-clear fdb port-vlan Ethernet0 100
Port Ethernet0 + Vlan100 FDB entries are cleared.
```

```
root@sonic:/home/admin# sonic-clear fdb all
Dynamic FDB entries are cleared.
```

config static-mac add

This command shown below is used to add a static mac address on the specified vlan_id and port.

Usage

```
config static-mac add <mac> <vlan_id> <port>
```

Parameter:

- <mac>: Static mac address
- <vlan_id>: Vlan ID
- <port>: The name of a physical interface

The example shown below will add a static mac address "00:10:3a:2b:05:67" with vlan 100 on port Ethernet2.

Example

```
root@sonic:/# config static-mac add 00:10:3a:2b:05:67 100 Ethernet2
```

config static-mac del

This command is used to delete a static mac address on the specified vlan_id.

Usage
<code>config static-mac del [mac] [vlan_id]</code>

Parameter:

- <mac>: Static mac address
- <vlan_id>: Vlan ID

The command shown below will delete a static mac address on vlan 100.

Example
<code>root@sonic:/# config static-mac del 00:10:3a:2b:05:67 100</code>

21 Interfaces

Table of Contents

Interface Show Commands

[show interfaces alias](#)
[show interfaces arp](#)
[show interfaces autoneg status](#)
[show interfaces breakout](#)
[show interfaces counters](#)
[show interfaces description](#)
[show interfaces diagnostic](#)
[show interfaces fec status](#)
[show interfaces link-training status](#)
[show interfaces neighbor](#)
[show interface pms status](#)
[show interfaces portchannel](#)
[show interfaces status](#)
[show interfaces tpid](#)
[show storm-control](#)

Interface Clear Counters Commands

[sonic-clear clounters](#)
[sonic-clear rifcounters](#)

Interface Configuration Commands

[config interface ip add](#)
[config interface remove](#)
[config interface ip add/remove --secondary](#)
[config interface link-training](#)
[config interface pfc priority](#)
[config interface pfc asymmetric](#)
[config interface shutdown](#)
[config interface startup](#)

[config interface speed](#)

[config interface mtu](#)

[config interface breakout](#)

[config interface storm-control](#)

[config interface autoneg](#)

[config interface advertised-speeds](#)

[config interface advertised-types](#)

[config interface type \(not supported\)](#)

[config interface tpid](#)

[config interface pms <interface_name> enabled](#)

[config interface pms <interface_name> disabled](#)

[config interface pms <interface_name> max-mac-count](#)

[config interface pms <interface_name> violation-action](#)

[config interface description](#)

[Interface Naming Mode](#)

[show interfaces naming_mode](#)

[config interface_naming_mode](#)

[Interface VRF Binding Commands](#)

[config interface vrf bind](#)

[config interface vrf unbind](#)

[Transceiver Config and Show Commands](#)

[show interfaces transceiver](#)

[show interfaces transceiver eeprom](#)

[show interfaces transceiver vdm](#)

[show interfaces transceiver pm](#)

[show interfaces transceiver status](#)

[show interfaces transceiver error-status \[-hw\]](#)

[show interfaces transceiver frequency](#)

[show interfaces transceiver lpmode](#)
[show interfaces transceiver presence](#)
[config interface transceiver application](#)
[config interface transceiver frequency](#)
[config interface transceiver tx_power](#)
[config interface transceiver lpmode](#)
[config interface transceiver reset](#)
[sfputil show eeprom](#)
[sfputil show vdm](#)
[sfputil read-eeprom](#)
[sfputil write-eeprom](#)
[sfputil lpmode](#)
[sfputil reset](#)
[sfputil show snr](#)

Table of Contents

[Interface Show Commands](#)

[show interfaces alias](#)
[show interfaces arp](#)
[show interfaces autoneg status](#)
[show interfaces breakout](#)
[show interfaces counters](#)
[show interfaces description](#)
[show interfaces diagnostic](#)
[show interfaces fec status](#)
[show interfaces link-training status](#)
[show interfaces neighbor](#)
[show interface pms status](#)
[show interfaces portchannel](#)
[show interfaces status](#)

[show interfaces tpid](#)
[show interfaces transceiver](#)
[show interfaces transceiver eeprom](#)
[show interfaces transceiver vdm](#)
[show interfaces transceiver pm](#)
[show interfaces transceiver status](#)
[show interfaces transceiver error-status \[-hw\]](#)
[show interfaces transceiver frequency](#)
[show interfaces transceiver lpmode](#)
[sfputil show eeprom](#)
[sfputil show vdm](#)
[show storm-control](#)

[Interface Clear Counters Commands](#)

[sonic-clear clounters](#)
[sonic-clear rifcounters](#)

[Interface Configuration Commands](#)

[config interface ip add](#)
[config interface remove](#)
[config interface ip add/remove --secondary](#)
[config interface link-training](#)
[config interface pfc priority](#)
[config interface pfc asymmetric](#)
[config interface shutdown](#)
[config interface startup](#)
[config interface speed](#)
[config interface transceiver application](#)
[config interface transceiver frequency](#)
[config interface transceiver tx_power](#)
[config interface transceiver lpmode](#)
[config interface transceiver reset](#)
[config interface transceiver mtu](#)
[config interface breakout](#)
[config interface storm-control](#)
[config interface autoneg](#)
[config interface advertised-speeds](#)
[config interface advertised-types](#)

[config interface type \(not supported\)](#)
[config interface tpid](#)
[config interface pms <interface_name> enabled](#)
[config interface pms <interface_name> disabled](#)
[config interface pms <interface_name> max-mac-count](#)
[config interface pms <interface_name> violation-action](#)
[config interface description](#)

[Interface Naming Mode](#)

[show interfaces naming_mode](#)
[config interface_naming_mode](#)

[Interface VRF Binding Commands](#)

[config interface vrf bind](#)
[config interface vrf unbind](#)

Interface Show Commands

This sub-section lists all the possible show commands for the interfaces available in the device. The following example gives a list of possible show commands on interfaces. Subsequent sections explain each of these commands in detail.

Example

```
admin@sonic:~$ show interfaces -?
Usage: show interfaces [OPTIONS] COMMAND [ARGS]...
  Show details of the network interfaces
Options:
  -?, -h, --help  Show this message and exit.
Commands:
  alias      Show Interface Name/Alias Mapping
  autoneg    Show interface autoneg information
  breakout   Show Breakout Mode information by interfaces
  buffer     Show interfaces buffer ...
```

```

counters    Show interface counters
description  Show interface status, protocol and description
diagnostic   Show diagnostic cable test information
fec          Show interface fec information
mpls        Show Interface MPLS status
naming_mode  Show interface naming_mode status
neighbor     Show neighbor related information
pms          Show details of the PMS
portchannel  Show PortChannel information
qos          Show interface qos information
rate-limit
scheduler
status       Show Interface status information
tpid         Show Interface tpid information
transceiver  Show SFP Transceiver information
wred

```

show interfaces alias

Shows the interface name/alias mapping.

Example

Name	Alias
Ethernet0	hundredGigE1
Ethernet4	hundredGigE2
Ethernet8	hundredGigE3
Ethernet12	hundredGigE4
... continue	

show interfaces arp

Usage

```
show interfaces arp [INTERFACENAME]
```

This command display the ARP related configuration information on the interface.

Example

```
admin@sonic:~$ show interfaces arp
Interface   Aging(sec)  Gratuitous ARP  ARP Host Route
-----
Ethernet0   1800       disabled       disabled
Vlan10      1800       disabled       disabled
admin@sonic:~$ show interfaces arp Vlan10
Interface   Aging(sec)  Gratuitous ARP  ARP Host Route
-----
Vlan10      1800       disabled       disabled
```

show interfaces autoneg status

Shows the interface auto-negotiation status.

Usage

```
show interfaces autoneg status
```

```
show interfaces autoneg status <interface_name>
```

Example

```
admin@sonic:~$ show interfaces autoneg status
Interface   Auto-Neg Mode  Oper Speed  Adv Speeds  Type  Adv Types  Oper  Admin
-----
Ethernet0   N/A           10G        1000M,10G   N/A    N/A       up    up
Ethernet1   N/A           10G        N/A         N/A    N/A       up    up
Ethernet2   N/A           10G        N/A         N/A    N/A       up    up
```

Ethernet3	N/A	10G	N/A	N/A	N/A	up	up
Ethernet4	N/A	10G	N/A	N/A	N/A	up	up
Ethernet5	N/A	10G	N/A	N/A	N/A	up	up
...							

show interfaces breakout

This command displays the port capability for all interfaces, i.e. index, lanes, default break mode (default_brkout_mode), all available breakout modes (breakout_modes), and current breakout mode (brkout_mode). To display the current breakout mode, the "current-mode" subcommand can be used. For a specific interface, provide the <interface name> in the options.

Usage

```
show interfaces breakout
show interfaces breakout current-mode
show interfaces breakout current-mode <interface_name>
```

Example

```
admin@lnos-x1-a-fab01:~$ show interfaces breakout
{
  "Ethernet0": {
    "index": "1,1,1,1",
    "default_brkout_mode": "1x100G[40G]",
    "child ports": "Ethernet0",
    "child port speed": "100G",
    "breakout_modes": "1x100G[40G],2x50G,4x25G[10G]",
    "Current Breakout Mode": "1x100G[40G]",
    "lanes": "65,66,67,68",
    "alias_at_lanes": "Eth1/1, Eth1/2, Eth1/3, Eth1/4"
```

```
}... continue
}
```

The "current-mode " option is used to display the current breakout mode for all interfaces.

Example (all interfaces)

```
admin@lnos-x1-a-fab01:~$ show interfaces breakout current-mode
```

```
+-----+-----+
| Interface | Current Breakout Mode |
+=====+=====+
| Ethernet0 | 4x25G[10G]           |
+-----+-----+
| Ethernet4 | 4x25G[10G]           |
+-----+-----+
| Ethernet8 | 4x25G[10G]           |
+-----+-----+
| Ethernet12| 4x25G[10G]           |
+-----+-----+
```

Example (specific interface)

```
admin@lnos-x1-a-fab01:~$ show interfaces breakout current-mode Ethernet0
```

```
+-----+-----+
| Interface | Current Breakout Mode |
+=====+=====+
| Ethernet0 | 4x25G[10G]           |
+-----+-----+
```

Note:

- breakout_mode: number x speed1 [speed2, speed3]
 - The parent port lanes are split equally to the number of ports denoted by the number. And, the speed for each breakout port defaults to speed1, but is changeable to speed2, speed3 etc.
 - For example: 4x25G[10G] means that all lanes are assigned to one port and are running at 25G by default, but the speed can be changed to 10G later.

show interfaces counters

This show command displays packet counters for all interfaces since the last time the counters were cleared.

Usage

```
show interfaces counters [-a|--printall] [-p|--period ]
show interfaces counters errors
show interfaces counters rates
show interfaces counters rif [-p|--period ] [-i <interface_name>]
```

Options:

- "-a" provides two additional columns - RX-PPS and TX-PPS.
- "-p" specifies the (in seconds) in which to gather counters. period
- "errors" displays the interface error counters.
- "rates" displays only the interface rates.
- "rif" displays Layer 3 counters for a of time or a specific period <interface_name>, which can include router interface, portchannel, and vlan.

Note:

- There is no facility to display counters for one specific Layer 2 interface.
- For RX_BPS and other rate calculations, smoothing is applied. For example, when clearing statistics or experiencing sudden traffic drops, the RX_OK statistics and RX_BPS data may experience temporary desynchronization.

Example (all interfaces)

```
admin@sonic:~$ show interfaces counters
IFACE      STATE      RX_OK  RX_BPS  RX_UTIL  RX_ERR  RX_DRP  RX_OVR
TX_OK  TX_BPS  TX_UTIL  TX_ERR  TX_DRP  TX_OVR
-----
Ethernet0  U 471,729,839,997 653.87 MB/s 12.77% 0 18,682 0 409,682,385,925
```

556.84 MB/s	10.88%	0	0	0					
Ethernet4	U	453,838,006,636	632.97 MB/s	12.36%	0	1,636	0	388,299,875,056	
529.34 MB/s	10.34%	0	0	0					
Ethernet8	U	549,034,764,539	761.15 MB/s	14.87%	0	18,274	0	457,603,227,659	
615.20 MB/s	12.02%	0	0	0					
Ethernet12	U	458,052,204,029	636.84 MB/s	12.44%	0	17,614	0	388,341,776,615	
527.37 MB/s	10.30%	0	0	0					
Ethernet16	U	16,679,692,972	13.83 MB/s	0.27%	0	17,605	0	18,206,586,265	
17.51 MB/s	0.34%	0	0	0					
Ethernet20	U	47,983,339,172	35.89 MB/s	0.70%	0	2,174	0	58,986,354,359	
51.83 MB/s	1.01%	0	0	0					
Ethernet24	U	33,543,533,441	36.59 MB/s	0.71%	0	1,613	0	43,066,076,370	
49.92 MB/s	0.97%	0	0	0					

Display the error counters only.

Example (error counters)

```
admin@str-s6000-ac-s-11:~$ show interface counters errors
```

IFACE	STATE	RX_ERR	RX_DRP	RX_OVR	TX_ERR	TX_DRP	TX_OVR
-----	----	-----	-----	-----	-----	-----	-----
Ethernet0	U	0	4	0	0	0	0
Ethernet4	U	0	0	0	0	0	0
Ethernet8	U	0	1	0	0	0	0
Ethernet12	U	0	0	0	0	0	0

Display the counters of rates.

Example (rate)

```
admin@str-s6000-ac-s-11:/usr/bin$ show int counters rates
```

IFACE	STATE	RX_OK	RX_BPS	RX_PPS	RX_UTIL	TX_OK	TX_BPS	TX_PPS	TX_UTIL
-----	----	-----	-----	-----	-----	-----	-----	-----	-----
Ethernet0	U	467510	N/A	N/A	N/A	466488	N/A	N/A	N/A
Ethernet4	U	469679	N/A	N/A	N/A	469245	N/A	N/A	N/A

Ethernet8	U	466660	N/A	N/A	N/A	465982	N/A	N/A	N/A
Ethernet12	U	466579	N/A	N/A	N/A	466318	N/A	N/A	N/A

Display the counters of specified interfaces

Example (specific interfaces)

```
admin@sonic:~$ show interfaces counters -i Ethernet4,Ethernet12-16
```

IFACE	STATE	RX_OK	RX_BPS	RX_UTIL	RX_ERR	RX_DRP	RX_OVR	TX_OK	TX_BPS	TX_UTIL	TX_ERR	TX_DRP	TX_OVR

Ethernet4	U	453,838,006,636	632.97 MB/s	12.36%	0	1,636	0	388,299,875,056	529.34 MB/s	10.34%	0	0	0
Ethernet12	U	458,052,204,029	636.84 MB/s	12.44%	0	17,614	0	388,341,776,615	527.37 MB/s	10.30%	0	0	0
Ethernet16	U	16,679,692,972	13.83 MB/s	0.27%	0	17,605	0	18,206,586,265	17.51 MB/s	0.34%	0	0	0

Note: The "-i" option is required when using **show interface counters** and it needs to specify the interface.

Example (rif)

```
admin@sonic:~$ show interfaces counters rif
```

IFACE	RX_OK	RX_BPS	RX_PPS	RX_ERR	TX_OK	TX_BPS	TX_PPS	TX_ERR

PortChannel0001	62,668	107.81 B/s	1.34/s	3	6	0.02 B/s	0.00/s	0
PortChannel0002	62,645	107.77 B/s	1.34/s	3	2	0.01 B/s	0.00/s	0
PortChannel0003	62,481	107.56 B/s	1.34/s	3	3	0.01 B/s	0.00/s	0
PortChannel0004	62,732	107.88 B/s	1.34/s	2	3	0.01 B/s	0.00/s	0
Vlan1000	0	0.00 B/s	0.00/s	0	0	0.00 B/s	0.00/s	0

Display the counters of a rif interface.

Example (one interface)

```
admin@sonic:~$ show interfaces counters rif PortChannel0001
```

```
PortChannel0001
```

```
RX:
```

```
3269 packets
```

```
778494 bytesq
```

```
3 error packets
```

```
292 error bytes
```

```
TX:
```

```
0 packets
```

```
0 bytes
```

```
0 error packets
```

```
0 error bytes
```

Display the counters for a period of time in seconds.

Example (a period of time)

```
admin@sonic:~$ show interfaces counters -p 5
```

```
IFACE      STATE RX_OK  RX_BPS RX_UTIL RX_ERR RX_DRP RX_OVR TX_OK
TX_BPS TX_UTIL TX_ERR TX_DRP TX_OVR
```

```
-----
```

Ethernet0	U	515	59.14 KB/s	0.00%	0	0	0	1,305	127.60 KB
/s	0.00%	0	0	0					
Ethernet4	U	305	26.54 KB/s	0.00%	0	0	0	279	39.12 KB
/s	0.00%	0	0	0					
Ethernet8	U	437	42.96 KB/s	0.00%	0	0	0	182	18.37 KB
/s	0.00%	0	0	0					
Ethernet12	U	284	40.79 KB/s	0.00%	0	0	0	160	13.03 KB
/s	0.00%	0	0	0					
Ethernet16	U	377	32.64 KB/s	0.00%	0	0	0	214	18.01 KB

```
/s 0.00% 0 0 0
Ethernet20 U 284 36.81 KB/s 0.00% 0 0 0 138 8758.25 B
/s 0.00% 0 0 0
Ethernet24 U 173 16.09 KB/s 0.00% 0 0 0 169 11.39 KB
/s 0.00% 0 0 0
```

Example (one interface)

```
admin@sonic:~$ show interfaces counters rif PortChannel0001
```

```
PortChannel0001
```

```
RX:
```

```
3269 packets
```

```
778494 bytesq
```

```
3 error packets
```

```
292 error bytes
```

```
TX:
```

```
0 packets
```

```
0 bytes
```

```
0 error packets
```

```
0 error bytes
```

Display the counters for a period of time in seconds.

Example (a period of time)

```
admin@sonic:~$ show interfaces counters -p 5
```

```
IFACE      STATE RX_OK  RX_BPS RX_UTIL RX_ERR RX_DRP RX_OVR TX_OK
TX_BPS TX_UTIL TX_ERR TX_DRP TX_OVR
```

```
-----
-----
Ethernet0  U  515 59.14 KB/s 0.00% 0 0 0 1,305 127.60 KB
/s 0.00% 0 0 0
```

```

Ethernet4    U    305 26.54 KB/s  0.00%    0    0    0    279 39.12 KB
/s  0.00%    0    0    0
Ethernet8    U    437 42.96 KB/s  0.00%    0    0    0    182 18.37 KB
/s  0.00%    0    0    0
Ethernet12   U    284 40.79 KB/s  0.00%    0    0    0    160 13.03 KB
/s  0.00%    0    0    0
Ethernet16   U    377 32.64 KB/s  0.00%    0    0    0    214 18.01 KB
/s  0.00%    0    0    0
Ethernet20   U    284 36.81 KB/s  0.00%    0    0    0    138 8758.25 B
/s  0.00%    0    0    0
Ethernet24   U    173 16.09 KB/s  0.00%    0    0    0    169 11.39 KB
/s  0.00%    0    0    0

```

show interfaces description

This command displays the key fields of interfaces, such as Operational Status, Administrative Status, Alias, and Description.

Usage

```
show interfaces description [<interface_name>]
```

Example (all interfaces)

```
admin@sonic:~$ show interfaces description
```

Interface	Oper	Admin	Alias	Description
Ethernet0	down	up	hundredGigE1/1	T0-1:hundredGigE1/30
Ethernet4	down	up	hundredGigE1/2	T0-2:hundredGigE1/30
Ethernet8	down	down	hundredGigE1/3	hundredGigE1/3
Ethernet12	down	down	hundredGigE1/4	hundredGigE1/4

Example (a specific interface)

```
admin@sonic:~$ show interfaces description Ethernet4
```

Interface	Oper	Admin	Alias	Description
Ethernet4	down	up	hundredGigE1/2	T0-2:hundredGigE1/30
Ethernet4	down	up	hundredGigE1/2	T0-2:hundredGigE1/30
Ethernet8	down	down	hundredGigE1/3	hundredGigE1/3
Ethernet12	down	down	hundredGigE1/4	hundredGigE1/4

Example (a specific interface)

```
admin@sonic:~$ show interfaces description Ethernet4
```

Interface	Oper	Admin	Alias	Description
Ethernet4	down	up	hundredGigE1/2	T0-2:hundredGigE1/30

show interfaces diagnostic

This command displays information for all the interfaces for the cable TDR(Time Domain Reflectometer) data requested or a specific interface if the optional "interface_name" is specified.

Usage

```
show interfaces diagnostic cable-test [<interface_name>]
```

Example (all interfaces)

```
admin@sonic:~$ show interfaces diagnostic cable-test
```

```
Ethernet0: cable (4 pairs, length +/- 10 meters)
```

```
    pair A Open, length 0 meters
```

```
    pair B Open, length 0 meters
```

```
    pair C Open, length 0 meters
```

```
    pair D Open, length 0 meters
```

```
Ethernet1: cable (4 pairs, length +/- 10 meters)
```

```
pair A Ok, length 9 meters
pair B Ok, length 9 meters
pair C Ok, length 10 meters
pair D Ok, length 9 meters
```

```
Ethernet2: cable (4 pairs, length +/- 10 meters)
```

```
pair A Ok, length 0 meters
pair B Ok, length 10 meters
pair C Ok, length 0 meters
pair D Ok, length 0 meters
```

```
Ethernet3: cable (4 pairs, length +/- 10 meters)
```

```
pair A Open, length 0 meters
pair B Open, length 0 meters
pair C Open, length 0 meters
pair D Open, length 0 meters
```

Example (a specific interface)

```
admin@sonic:~$ show interfaces diagnostic cable-test Ethernet12
```

```
Ethernet12: cable (4 pairs, length +/- 10 meters)
```

```
pair A Ok, length 9 meters
pair B Ok, length 9 meters
pair C Ok, length 9 meters
pair D Ok, length 5 meters
```

Example (unsupported interface)

```
admin@sonic:~$ show interfaces diagnostic cable-test Ethernet51
```

```
Error! could not perform TDR test on Ethernet51
```

show interfaces fec status

This command displays administrative and operational FEC mode mainly and along with the fields such as the operational and administrative status and operational Speed of the interfaces.

Usage

```
show interfaces fec status
```

```
show interfaces fec status <interface_name>
```

Example

```
admin@sonic:~$ show interface fec status
```

Interface	Oper	Admin	FEC	Oper FEC	Oper Speed
Ethernet0	up	up	rs	rs	100G
Ethernet8	up	up	rs	rs	100G
Ethernet16	up	up	rs	rs	100G
Ethernet24	up	up	rs	rs	100G
Ethernet32	up	up	rs	rs	100G
Ethernet40	up	up	rs	rs	100G
...					

show interfaces link-training status

Use the following command to display the link-training configuration and operational status.

Usage

```
show interfaces link-training status
```

```
show interfaces link-training status <interface_name>
```

Example

```
admin@sonic:~$ show interfaces link-training status Ethernet0
```

Interface	LT Oper	LT Admin	Oper	Admin
Ethernet0	up	up	up	up

```
Ethernet0    trained    on    up    up
```

show interfaces neighbor

This command is used to display the list of expected neighbors for all interfaces (or for a particular interface) that is configured.

Usage

```
show interfaces neighbor expected [<interface_name>]
```

Example

```
admin@sonic:~$ show interfaces neighbor expected
```

LocalPort	Neighbor	NeighborPort	NeighborLoopback	NeighborMgmt	NeighborType
Ethernet112	ARISTA01T1	Ethernet1	None	10.16.205.100	ToRRouter
Ethernet116	ARISTA02T1	Ethernet1	None	10.16.205.101	SpineRouter
Ethernet120	ARISTA03T1	Ethernet1	None	10.16.205.102	LeafRouter
Ethernet124	ARISTA04T1	Ethernet1	None	10.16.205.103	LeafRouter

show interface pms status

This command shows the configuration and status of port-mac-security on the entire interface or specified interfaces.

Usage

```
show interface pms status
```

```
show interface pms status <interface_name>
```

Example

```
admin@sonic:~$ show interface pms status
```

Interface	PMS Mode	Max Mac Count	Violation Action	Learnt Count	Violation Count
Ethernet0	enabled	1000	Protect	10	N/A
Ethernet4	enabled	2000	Restrict	2000	10
Ethernet8	enabled	10	Shutdown	10	N/A

...

```
admin@sonic:~$ show interface pms status Ethernet0
```

Interface	PMS Mode	Max Mac Count	Violation Action	Learnt Count	Violation Count
Ethernet0	enabled	1000	Protect	10	N/A

show interfaces portchannel

This command displays information regarding port-channel interfaces.

Usage

```
show interfaces portchannel
```

Example

```
admin@sonic:~$ show interfaces portchannel
```

Flags: A - active, I - inactive, Up - up, Dw - Down, N/A - not available, S - selected, D - deselected

No.	Team Dev	Protocol	Ports
24	PortChannel24	LACP(A)(Up)	Ethernet28(S) Ethernet24(S)
48	PortChannel48	LACP(A)(Up)	Ethernet52(S) Ethernet48(S)
40	PortChannel40	LACP(A)(Up)	Ethernet44(S) Ethernet40(S)

```
0 PortChannel0 LACP(A)(Up) Ethernet0(S) Ethernet4(S)
8 PortChannel8 LACP(A)(Up) Ethernet8(S) Ethernet12(S)
```

show interfaces status

This command displays some more fields such as Lanes, Speed, MTU, Type, Asymmetric PFC status and also the operational and administrative status of the interfaces.

Usage

```
show interfaces status [<interface_name>]
```

Show the status of all interfaces.

Example

```
admin@sonic:~$ show interfaces status
```

Interface	Lanes	Speed	MTU	Oper	FEC	Alias	Oper	Admin	Type	Asym	PFC
Ethernet0	49,50,51,52	100G	9100	N/A	hundredGigE1/1	down	up	N/A	off		
Ethernet4	53,54,55,56	100G	9100	N/A	hundredGigE1/2	down	up	N/A	off		
Ethernet8	57,58,59,60	100G	9100	N/A	hundredGigE1/3	down	down	N/A	off		

Show the status of a specific interface.

Example

```
admin@sonic:~$ show interface status Ethernet0
```

Interface	Lanes	Speed	MTU	Oper	FEC	Alias	Oper	Admin
Ethernet0	101,102	40G	9100	rs	fortyGigE1/1/1	up	up	

Show the status for a range of interfaces.

Example

```
admin@sonic:~$ show interfaces status Ethernet8,Ethernet168-180
```

Interface	Lanes	Speed	MTU	Oper	FEC	Alias	Oper	Admin	Type	Asym	PFC
Ethernet8	49,50,51,52	100G	9100	N/A	hundredGigE3	down	down	N/A	N/A		
Ethernet168	9,10,11,12	100G	9100	N/A	hundredGigE43	down	down	N/A	N/A		
Ethernet172	13,14,15,16	100G	9100	N/A	hundredGigE44	down	down	N/A	N/A		
Ethernet176	109,110,111,112	100G	9100	N/A	hundredGigE45	down	down	N/A	N/A		
Ethernet180	105,106,107,108	100G	9100	N/A	hundredGigE46	down	down	N/A	N/A		

```
intfutil status_ext
```

This show command displays like , but it also shows extended fields for the specific platforms. show interface status

For the AS8000, which supports PIM hotswap, the extended fields are "PIM slot" and "PIM status".

Example (all interfaces)

```
admin@sonic:~$ intfutil status_ext
```

Interface	Lanes	Speed	MTU	FEC	Alias	Vlan	Oper	Admin	Type	Asym	PFC
PIM Slot	PIM Status										
Ethernet0	5,6	100G	9100	rs	onehundredGigE0	routed	up	up	N/A	off	2
up											
Ethernet1	7,8	100G	9100	rs	onehundredGigE1	routed	up	up	N/A	off	2
up											
Ethernet2	1,2	100G	9100	rs	onehundredGigE2	routed	up	up	N/A	off	2
up											
Ethernet3	3,4	100G	9100	rs	onehundredGigE3	routed	up	up	N/A	off	2
up											
Ethernet4	37,38	100G	9100	rs	onehundredGigE4	routed	up	up	N/A	off	
2	up										
Ethernet5	39,40	100G	9100	rs	onehundredGigE5	routed	up	up	N/A	off	
2	up										

Ethernet6	33,34	100G	9100	rs	onehundredGigE6	routed	up	up	N/A	off
2	up									
Ethernet7	35,36	100G	9100	rs	onehundredGigE7	routed	up	up	N/A	off
2	up									

show interfaces tpid

This command displays the key fields of the interfaces such as Operational Status, Administrative Status, Alias and TPID.

Usage

```
show interfaces tpid [<interface_name>]
```

Display the TPID for all interfaces.

Example (a specific interface)

```
admin@sonic:~$ show interfaces tpid
```

Interface	Alias	Oper	Admin	TPID
Ethernet0	fortyGigE1/1/1	up	up	0x8100
Ethernet1	fortyGigE1/1/2	up	up	0x8100
Ethernet2	fortyGigE1/1/3	down	down	0x8100
Ethernet3	fortyGigE1/1/4	down	down	0x8100
Ethernet4	fortyGigE1/1/5	up	up	0x8100
Ethernet5	fortyGigE1/1/6	up	up	0x8100
Ethernet6	fortyGigE1/1/7	up	up	0x9200
Ethernet7	fortyGigE1/1/8	up	up	0x88A8
Ethernet8	fortyGigE1/1/9	up	up	0x8100
...				
Ethernet63	fortyGigE1/4/16	down	down	0x8100
PortChannel0001	N/A	up	up	0x8100
PortChannel0002	N/A	up	up	0x8100

PortChannel0003	N/A	up	up 0x8100
PortChannel0004	N/A	up	up 0x8100

Display the TPID for a specific interface.

Example (a specific interface)

```
admin@sonic:~$ show interfaces tpid Ethernet6
```

Interface	Alias	Oper	Admin	TPID
Ethernet6	fortyGigE1/1/7	up	up	0x9200

show storm-control

This command is used to display the current threshold rate and burst size for BUM (broadcast/unknown-multicast/unknown-unicast)

traffic on the physical interface.

Usage

```
show storm-control <command> <args>
```

```
show storm-control all
```

```
show storm-control interface <interface name>
```

Commands:

- all , Show storm-control settings for all interfaces
- interface , Show storm-control settings for a given interface

<interface name>, specify interface

Example

```
admin@sonic:~$ show storm-control all
```

```

+-----+-----+-----+-----+-----+
| Interface Name | Storm Type   |   Cir | Burst Size   |   Meter type   |
+-----+-----+-----+-----+-----+
=====+
| Ethernet0     | broadcast    |   1000 | 150          |   bytes        |
+-----+-----+-----+-----+-----+
| Ethernet1     | unknown-multicast |   1000 | 150          |   bytes        |
+-----+-----+-----+-----+-----+
| Ethernet2     | unknown-unicast |   1000 | 150          |   packets      |
+-----+-----+-----+-----+-----+
admin@sonic:~$ show storm-control interface Ethernet1
+-----+-----+-----+-----+-----+
| Interface Name | Storm Type   |   Cir | Burst Size   |   Meter type   |
+-----+-----+-----+-----+-----+
=====+
| Ethernet1     | unknown-multicast |   1000 | 150          |   bytes        |
+-----+-----+-----+-----+-----+

```

Interface Clear Counters Commands

sonic-clear clouters

Clear interface counters.

Usage

```
sonic-clear counters
```

Example

```
admin@sonic:~$ sonic-clear counters
```

sonic-clear rifcounters

Clear Layer 3 interface counters.

Usage
<code>sonic-clear rifcounters</code>

Example (clear rif counters)
<code>admin@sonic:~\$ sonic-clear rifcounters</code>

Interface Configuration Commands

Interface configuration commands cover these sub-topics:

- `ip` - To add or remove an IP address for an interface
- `pfc` - to set the PFC configuration for an interface
- `shutdown` - to administratively shut down an interface
- `speed` - to set the interface speed
- `startup` - to bring up an administratively shutdown interface
- `breakout` - to set an interface breakout mode
- `tpid` - to set interface tpid
- `pms` - to set the port mac security for an interface

config interface ip add

Configure interface IP address. Add the IP address for an interface.

Usage
<code>config interface ip add <interface_name> <ip_addr> [default_gw]</code>

Note:

- The IP address for a physical interface, portchannel, VLAN interface, or Loopback interface, can all be configured with this command.
- While configuring the IP address for the management interface "eth0", users can provide the default gateway IP address as an optional parameter.
- <interface_name>
 - interface VLAN: use "vlan<vlan-id>". For example, "vlan100: for VLAN-100.

Example (Configure interface on port)

```
admin@sonic:~$ sudo config interface ip add Ethernet63 10.11.12.13/24
admin@sonic:~$ sudo config interface ip add eth0 20.11.12.13/24 20.11.12.254
```

Example (Configure interface on vlan)

```
admin@sonic:~$ sudo config interface ip add vlan100 10.11.12.13/24
```

config interface remove

Remove an IP address from an interface.

Usage

```
config interface ip remove <interface_name> <ip_addr>
```

Example (Remove IP address from an interface - port)

```
admin@sonic:~$ sudo config interface ip remove Ethernet63 10.11.12.13/24
admin@sonic:~$ sudo config interface ip remove eth0 20.11.12.13/24
```

Example (Remove IP address from an interface - vlan)

```
admin@sonic:~$ sudo config interface ip remove vlan100 10.11.12.13/24
```

config interface ip add/remove --secondary

Since SONiC 202006 Dec. version, the IPv4 addresses for an interface are classified as the primary address and secondary. There is no primary/secondary classification for IPv6 addresses.

The principles are:

- There is only one primary address for an interface. Other addresses should be specified as secondary.
- The first added address SHOULD be the primary address. The secondary address SHOULD be added after the primary one.
- The command syntax for the addition of a primary address is like the original syntax. The syntax for addition of a secondary address is as follows:
- The primary address SHOULD be the last address to be removed from an interface. In order to remove the primary address, you must remove all secondary addresses first.
- The command syntax for the removal of a primary address is like the original syntax. The syntax for the removal of a secondary address is as follows:

Usage (Remove a secondary IPv4 address)

```
config interface <interface_name> ip remove <ip_addr> --secondary
```

config interface link-training

Once configured, use the following command to enable or disable link-training at a interface when auto-negotiation is disabled. show interfaces link-training status to check the status.

Usage

Format:

```
config interface link-training <interface_name> <mode>
```

Arguments:

interface_name: [mandatory] name of the interface to be configured. e.g: Ethernet0

mode: [mandatory] link training mode, can be either "on" or "off"

Return:

- error message if interface_name or mode is invalid
- empty upon success

Example

```
admin@sonic:~$ sudo config interface link-training Ethernet0 on
```

```
admin@sonic:~$ sudo config interface link-training Ethernet8 off
```

config interface pfc priority

This command is used to set PFC to a given priority on a given interface to either "on" or "off". Once successfully configured, it will show current loss priorities on the given interface. Otherwise, it will show error information.

Usage

```
config interface pfc priority <interface_name> <priority> (on | off)
```

Parameters:

<priority> - range in (0..7)

Example

```
admin@sonic:~$ sudo config interface pfc priority Ethernet0 3 off
Interface    Lossless priorities
-----
Ethernet0    4
admin@sonic:~$ sudo config interface pfc priority Ethernet0 8 off
Usage: pfc config priority [OPTIONS] STATUS INTERFACE PRIORITY
Error: Invalid value for "priority": invalid choice: 8. (choose from 0, 1, 2, 3, 4, 5, 6, 7)
admin@sonic:~$ sudo config interface pfc priority Ethernet101 3 off
Cannot find interface Ethernet101
admin@sonic:~$ sudo config interface pfc priority Ethernet0 3 on
Interface    Lossless priorities
-----
Ethernet0    3,4
```

config interface pfc asymmetric

This command is used for setting the asymmetric PFC for an interface to either "on" or "off". Once it is configured, use show interfaces status to check the status.

Usage

```
config interface pfc asymmetric <interface_name> (on | off)
```

Example

```
admin@sonic:~$ sudo config interface pfc asymmetric Ethernet60 on
```

config interface shutdown

This command is used to administratively shut down either a physical interface or a port-channel interface. Once configured, use `show interfaces status` to check the status.

Usage

```
config interface shutdown <interface_name>
```

Example

```
admin@sonic:~$ sudo config interface shutdown Ethernet63
```

Example (shutdown multi-interfaces)

```
admin@sonic:~$ sudo config interface shutdown Ethernet8,Ethernet16-20,Ethernet32
```

config interface startup

This command is used for administratively bringing up a physical interface or a port-channel interface. Once configured, use `show interfaces status` to check the status.

Usage

```
config interface startup <interface_name>
```

Example

```
admin@sonic:~$ sudo config interface startup Ethernet63
```

Example (startup multi-interfaces)

```
admin@sonic:~$ sudo config interface startup Ethernet8,Ethernet16-20,Ethernet32
```

config interface speed

This command is used to configure the speed for a physical interface.

The supported speed list can be changed by breakout-mode. Use `show interfaces breakout` to see the current breakout-mode for the supported speed.

Usage

```
config interface speed <interface_name> <speed_value>
```

Parameters:

- `<speed_value>`, user needs to know the interface configurable speeds
 - 40000 for 40G
 - 100000 for 100G

Example

```
admin@sonic:~$ sudo config interface speed Ethernet63 40000
```

Note:

- `breakout_mode: number x speed1 [speed2, speed3]`
 - The parent port lanes are split equally to the number of ports denoted by the number. And, the speed for each breakout port defaults to speed1, but is changeable to speed2, speed3 etc.

- For example: 1x100G[40G] means all lanes are assigned to one port and are running at 100G by default, but the speed can be changed to 40G later.

config interface mtu

This command is used to configure the MTU for a physical interface.

The MTU (Maximum Transmission Unit) size range is from 1500 to 9216 bytes. The user-configured value will add 22 bytes and be set to the chip.

Usage

```
config interface mtu <interface_name> <mtu_value>
```

Example

```
admin@sonic:~$ sudo config interface mtu Ethernet64 1500
```

config interface breakout

This command is used to set an available breakout mode for a user-specified interface.

Use a double tab (i.e. <tab><tab>) to see the available breakout options customized for each interface specified by the user.

Usage

```
config interface breakout [OPTIONS] <interface_name> <breakout_mode>
```

Options:

-f, --force-remove-dependencies

Clear all dependencies internally first.

-l, --load-predefined-config

load predefined user configuration (alias, lanes, speed etc) first.

-y, --yes

-v, --verbose

Enable verbose output

-, -h, --help

Show this message and exit.

Note:

- breakout_mode: number x speed1 [speed2, speed3]
 - The parent port lanes are split equally to the number of ports denoted by the number. And, the speed for each breakout port defaults to speed1, but is changeable to speed2, speed3 etc.
 - For example: 1x100G[40G] means that all lanes are assigned to one port and running at 100G by default, but the speed can be changed to 40G later.
 - Use `show interface breakout` to see the supported breakout mode.
- The new breakout ports are created by the default configuration, but you can predefine the port configuration by the option "--load-predefined-config". The file name of the predefined configuration must be "port_breakout_config_db.json" and the file must be placed in the directory /etc/sonic/.
- If the breakout_mode includes parentheses (), please add single quotes " for the bash parser. For example: `config interface breakout Ethernet0 '1x100G[40G](4)'`

Example

```
admin@sonic:~$ sudo config interface breakout Ethernet0 <tab><tab>
<tab provides option for breakout mode>
1x100G[40G] 2x50G 4x25G[10G]
```

```
admin@sonic:~$ sudo config interface breakout Ethernet48 4x25G -f -l -v -y
```

Running Breakout Mode : 1x100G[40G]

Target Breakout Mode : 4x25G

Ports to be deleted :

```
{
  "Ethernet48": "100000"
}
```

Ports to be added :

```
{
  "Ethernet50": "25000",
  "Ethernet51": "25000",
  "Ethernet49": "25000",
  "Ethernet48": "25000"
}
```

After running Logic to limit the impact

Final list of ports to be deleted :

```
{
  "Ethernet48": "100000"
}
```

Final list of ports to be added :

```
{
  "Ethernet50": "25000",
  "Ethernet51": "25000",
  "Ethernet49": "25000",
  "Ethernet48": "25000"
}
```

Loaded below Yang Models

```
['sonic-acl', 'sonic-extension', 'sonic-interface', 'sonic-loopback-interface', 'sonic-port', 'sonic-
portchannel', 'sonic-types', 'sonic-vlan']
```

Note: Below table(s) have no YANG models:

```
TACPLUS_SERVER, DEVICE_METADATA, BGP_PEER_RANGE, PORTCHANNEL_MEMBER,
FLEX_COUNTER_TABLE, SYSLOG_SERVER, CRM,
CONTAINER_FEATURE, BGP_NEIGHBOR, PORTCHANNEL_INTERFACE, MGMT_INTERFACE,
NTP_SERVER,
```

```
DEVICE_NEIGHBOR_METADATA, TELEMETRY, DEVICE_NEIGHBOR, FEATURE, BREAKOUT_CFG,
DHCP_SERVER, MGMT_PORT,
RESTAPI, VERSIONS, BUFFER_POOL, BUFFER_PROFILE,
Breakout process got successfully completed.
Please note loaded setting will be lost after system reboot. To preserve setting, run `config save`.
```

config interface storm-control

This command is used to add the rate and burst size for BUM (broadcast/unknown-multicast/unknown-unicast) traffic, or to threshold delete the previous setting on the physical interface.

All types of storm traffic can be configured on the interface at the same time.

Usage

```
config interface storm-control <storm_type> add <port_name> <meter_type> <cir> <burst size>

config interface storm-control <storm_type> del <port_name>
```

Parameters:

- <storm_type>: There are three types to choose from:
 - broadcast, configure broadcast storm control.
 - unknown multicast, configure unknown multicast storm control.
 - unknown unicast, configure unknown unicast storm control.
- <port_name>, specifies the interface, can only be a physical interface.
- <meter type>,select the rate limiting type bytes or packets.
- <cir>, traffic speed limit value, in kbps. When equal to 0, all the configured traffic will drop.
- <burst size>, optional. If<burst size>is not specified, when the meter type is bytes, the burst size of the TD3 device is 10 times the MTU of the application interface. Other devices are 1% of the cir, and when the meter type is packets, the burst size is ten times that of the cir.

Example

```
admin@sonic:~$ sudo config interface storm-control broadcast add Ethernet0 bytes 1000
add broadcast storm-control
admin@sonic:~$ sudo config interface storm-control unknown-multicast add bytes Ethernet0 100000 750
add unknown-multicast storm-control
```

```
admin@sonic:~$ sudo config interface storm-control unknown-unicast add Ethernet0 bytes 50000 150
```

```
add unknown-unicast storm-control
```

```
admin@sonic:~$ show storm-control all
```

Interface Name	Storm Type	Cir	Burst Size	Meter type
Ethernet0	broadcast	1000	10	bytes
Ethernet0	unknown-multicast	100000	750	bytes
Ethernet0	unknown-unicast	50000	150	bytes

```
admin@sonic:~$ sudo config interface storm-control broadcast del Ethernet0
```

```
del broadcast storm-control
```

```
admin@sonic:~$ show storm-control all
```

Interface Name	Storm Type	Cir	Burst Size	Meter type
Ethernet0	unknown-multicast	100000	750	bytes
Ethernet0	unknown-unicast	50000	150	bytes

config interface autoneg

This command enables (or disables) the interface auto-negotiation. The referred speed in negotiation is specified in the config interface advertised-speeds command. The referred interface type in negotiation is specified in the config interface advertised-types command.

Usage

```
config interface autonego <interface> { enabled | disabled }
```

Note,

- There are 3 kinds of IEEE standard to support autonego. The first one is IEEE 802.3 Clause 28, which is applicable to RJ-45 port to support BASE-T PHYs like 1000Base-T. The second is IEEE 802.3 Clause 37, which is applicable to 1000Base-X. The other one is IEEE 802.3 Clause 73, which is applicable to the port that plugged a DAC cable. Note that IEEE 802.3 Clause 73 is not applicable to the port that plugged an optical transceiver. Enable the autonego on the port which is not applicable to support autonego will cause the unpredictable result and the port may not work correctly.
- When auto-negotiation is enabled, the interface speed is negotiated, which refers to the speed list specified by the config interface advertised-speed command.
- When auto-negotiation is enabled, the interface type is negotiated, which refers to the speed list specified by the config interface advertised-types command.
- When auto-negotiation is disabled, the interface is forced to the speed specified in by the config interface speed command.

This is an example to enable (or disable) auto-negotiation on interface Ethernet0.

Example

```
admin@sonic:~$ sudo config interface autoneg Ethernet0 enabled
admin@sonic:~$ sudo config interface autoneg Ethernet0 disabled
```

config interface advertised-speeds

This command specifies a collection of speeds that are available as a linked speed after auto-negotiation. The configuration does not take effect if the interface has not been enabled for auto-negotiation using the command config interface autonego . The change to the advertised speed list takes effect immediately if the interface has auto-negotiation enabled.

Usage

```
config interface advertised-speeds <interface> { all | <speed-list> }
```

Parameters:

<interface>

the interface that applies the auto-negotiation advertised speeds.

option, user needs to specify one of the following:

all, set all the advertised-speeds that the interface can support. (default)

<speed list>, speed collection that the user wants to use in auto-negotiation.

Note:

- A user-configured speed may not be the linked speed if the peer cannot support it. For example, a user specifies 100M, 1G, and 10G in <speed list>, and then mis-configures the peer interface for 1G and 10G when it only supports 100M. The port will enter a link down state since there is no proper speed for both ends.
- The whole speed list is not accepted if it contains an invalid speed in the list.
- All advertised speeds are replaced if a user specifies a new set of speeds, even if auto-negotiation is enabled.
- When setting a new speed list, all speeds in the speed list will be examined by the following check order:
 - Supported speed check: Not supported speed in speed list
 - Supported adv-speed check: Not supported adv-speed in speed list

The following example configures an interface (Ethernet0) with a speed list (100M, 1G, 2.5G) or all. After this command, you need to use the `config interface autonego Ethernet0 enable` command to enable port auto-negotiation.

Example

```
admin@sonic:~$ sudo config interface advertised-speeds Ethernet0 100,1000,2500
admin@sonic:~$ sudo config interface advertised-speeds Ethernet0 all
```

Example (Not supported speed in speed list)

```
admin@sonic:~$ sudo config interface advertised-speeds Ethernet0 10,100000
Invalid speed specified: 10,100000
Valid speeds:1000,10000
```

Example (Not supported adv-speed in speed list)

```
admin@sonic:~$ config interface advertised-speeds Ethernet0 1000
Invalid adv-speed specified: 1000
Valid adv-speeds:10000
```

config interface advertised-types

This command specifies a collection of interface types that are available as a linked type after auto-negotiation. The configuration does not take effect if the interface has not been enabled for auto-negotiation using the command `config interface autonego` . The change to the type list takes effect immediately if the interface has auto-negotiation enabled.

Usage

```
config interface advertised-types <interface> { all | <interface_type> }
```

Parameters:

<interface>

the interface that applies the auto-negotiation interface types

option, user needs to specify one of the following:

all, set all the advertised-types that the interface can support. (default)

<interface type>, interface type collection that the user wants to use in auto-negotiation(KR, KR2, KR4, KR8, CR, CR2, CR4, CR8, and so on).

Note:

The setting is only applicable to IEEE 802.3by Clause73, which means, only applicable to the port that plugged a DAC cable.

The following example configures an interface (Ethernet0) with a interface type list (CR4, KR4) or all. After this command, you need to use the config interface autonego Ethernet0 enable command to enable port auto-negotiation.

Example

```
admin@sonic:~$ sudo config interface advertised-types Ethernet0 CR4,KR4
admin@sonic:~$ sudo config interface advertised-types Ethernet0 all
```

config interface type (not supported)

Configuring interface type takes effect only if auto negotiation is disabled. If auto negotiation is enabled, this command still saves interface type value to CONFIG_DB.

Usage

```
config interface type <interface> <interface_type>
```

Parameters:

<interface> the interface that applies the auto-negotiation interface types

<interface type>, interface type, valid value include CR4, KR4, and son on.

Note:

This configuration is only applicable to the port, which is a SFP or QSFP form factor port.

The following example configures an interface (Ethernet0) with a interface type CR4.

Example

```
admin@sonic:~$ sudo config interface type Ethernet0 CR4
admin@sonic:~$ sudo config interface type Ethernet4 KR4
```

config interface tpid

This command is used to configure the TPID for the Physical/PortChannel interface. default is 0x8100. Other allowed values if supported by HW SKU (0x9100, 0x9200, 0x88A8).

Usage

```
config interface tpid <interface_name> <tpid_value>
```

Example

```
admin@sonic:~$ sudo config interface tpid Ethernet64 0x9200
```

config interface pms <interface_name> enabled

This command enables the interface port-mac-security.

Usage

```
config interface pms <interface_name> enabled
```

Parameters:

<interface_name>: Physical interface name.

Note:

- The MAC addresses will be flushed when enabling port-mac-security.
- If the max-mac-count is not configured, the default number of MAC address can access the network through this interface will be 1 .
- If the violation-action is not configured, the default action is "protect " when the violation is occurred.

Example

```
admin@sonic:~$ sudo config interface pms Ethernet0 enabled
```

config interface pms <interface_name> disabled

This command disables the interface port-mac-security.

Usage

```
config interface pms <interface_name> disabled
```

Parameters:

<interface_name>: Physical interface name.

Note:

The MAC addresses will not be flushed when disabling port-mac-security .

If the admin state of port is down due to a violation, this command can be used to remove the violated state from the port.

Example

```
admin@sonic:~$ sudo config interface pms Ethernet0 disabled
```

config interface pms <interface_name> max-mac-count

This command specifies the maximum number of allowed MAC addresses after port-mac-security enabled.

Usage

```
config interface pms <interface_name> max-mac-count <value>
```

Parameters:

<interface_name>: Physical interface name.

<value>: maximum number of allowed MAC addresses. Minimum: 1. Maximum: 4097.

Note:

The default maximum number of allowed MAC addresses is 1 if this configuration is not set.

Example

```
admin@sonic:~$ sudo config interface pms Ethernet0 max-mac-count 1000
```

config interface pms <interface_name> violation-action

This command specifies the action to be taken when more than the allowed number of MAC addresses is attempted to be learnt on the port.

Usage

```
config interface pms <interface_name> violation-action { protect | restrict | shutdown }
```

Parameters:

<interface_name>: Physical interface name.

violation-action:

protect: The violating packets are dropped.

restrict: The violating packets are dropped, and a violation counter is incremented for each violation.

shutdown: The port is administratively shut down.

Note:

The default action is "protect" if this configuration is not set.

If a shutdown action is taken on the port, "config interface pms <interface_name> disabled" can be used to remove the violated state.

Example

```
admin@sonic:~$ sudo config interface pms Ethernet0 violation-action protect
```

config interface description

This command is used to configure the description for the Physical interface or Port channel.

Usage

```
config interface description <interface_name> <interface_description>
```

Example

```
admin@sonic:~$ sudo config interface description Ethernet0 Eth1/1
```

Interface Naming Mode

show interfaces naming_mode

This command displays the current interface naming mode.

Usage

```
show interfaces naming_mode
```

Note:

default, display all SONiC interface names in show commands and accept SONiC interface names as parameters in config commands.

alias, display all hardware vendor interface aliases in show commands and accept hardware vendor interface aliases as parameters in config commands.

Interface naming mode originally set to 'default'. Interfaces are referenced by default SONiC interface names. Users can change the naming_mode using the config interface_naming_mode command.

Example

```
admin@sonic:~$ show interfaces naming_mode
alias
admin@sonic:~$ show interfaces naming_mode
default
```

config interface_naming_mode

This command is used to change the interface naming mode.

Users can select between the default mode (SONiC interface names) or alias mode (Hardware vendor names).

The user must log out and log back in for the changes to take effect. Note that the newly-applied interface mode will affect all interface-related show/config commands.

Note: Some platforms do not support alias mapping. In such cases, this command is not applicable. Such platforms always use the same SONiC interface names.

Usage

```
config interface_naming_mode (default | alias)
```

Note: Interface naming mode is originally set to 'default'. Interfaces are referenced by default SONiC interface names.

Example

```
admin@sonic:~$ show interfaces naming_mode
default
admin@sonic:~$ show interface status Ethernet0
Interface  Lanes  Speed  MTU    Alias  Oper  Admin
-----
Ethernet0  101,102  40G   9100  fortyGigE1/1/1  up    up
admin@sonic:~$ sudo config interface_naming_mode alias
Please logout and log back in for changes take effect.
```

After the user logs out and logs in again, the interfaces are referred to by the hardware vendor alias.

Example

```
admin@sonic:~$ show interfaces naming_mode
alias
admin@sonic:~$ sudo config interface fortyGigE1/1/1 shutdown
```

```
admin@sonic:~$ show interface status fortyGigE1/1/1
Interface  Lanes  Speed  MTU      Alias  Oper  Admin
-----
Ethernet0  101,102  40G   9100  fortyGigE1/1/1  down  down
```

Interface VRF Binding Commands

By default, all L3 interfaces are bound to the default VRF. Use the `config interface vrf bind` command to bind to different VRFs.

config interface vrf bind

This command is used to bind an interface to a non default VRF.

Usage

```
config interface vrf bind <interface_name> <vrf_name>
```

Example

```
admin@sonic:~$ show vrf
VRF  Interfaces
----
admin@sonic:~$ config vrf add Vrf1
admin@sonic:~$ show vrf
VRF  Interfaces
----
Vrf1
admin@sonic:~$ config interface vrf bind PortChannel0001 Vrf1
admin@sonic:~$
```

```
admin@sonic:~$  
admin@sonic:~$ show vrf  
VRF  Interfaces  
-----  
Vrf1  PortChannel0001
```

config interface vrf unbind

Unbind an interface from a non-default VRF.

Usage

```
config interface vrf unbind <interface_name>
```

Example

```
admin@sonic:~$ config interface vrf unbind PortChannel0001  
admin@sonic:~$  
admin@sonic:~$ show vrf  
VRF  Interfaces  
-----  
Vrf1
```

Transceiver Config and Show Commands

This chapter introduces the display of optical module information and configuration instructions.

show interfaces transceiver

Usage

```
show interfaces transceiver [OPTIONS] COMMAND [ARGS]...
```

Show SFP Transceiver information

Options:

-?, -h, --help Show this message and exit.

Commands:

EEPROM Show interface transceiver EEPROM information

error-status Show transceiver error-status

frequency Show interface transceiver frequency

lpmode Show interface transceiver low-power mode status

presence Show interface transceiver presence

show interfaces transceiver eeprom

Show interface transceiver EEPROM information.

Usage

```
show interfaces transceiver eeprom [-d|--dom] [<interface_name>]
```

Parameters:

"-d" or "-- dom" display DOM (Digital Optics Monitoring) information

<interface_name> display specific interface transceiver information

Note: Without "-d", this command shows DOM capacity.

Example (eeprom info)

```
admin@sonic:~$ show interfaces transceiver eeprom
```

```
Ethernet0: SFP EEPROM detected
```

```
Application Advertisement: N/A
```

```
Connector: MPOx12
```

DOM Capability:

Rx_power_support: True

Temp_support: False

Tx_power_support: True

Voltage_support: False

Encoding: 256B257B

Extended Identifier: Power Class 3(2.5W max), CDR present in Rx Tx

Extended RateSelect Compliance: QSFP+ Rate Select Version 1

Identifier: QSFP28 or later

Length Cable Assembly(m): 50

Nominal Bit Rate(100Mbps): 255

Specification compliance:

Extended Specification compliance: 100GBASE-SR4 or 25GBASE-SR

Fibre Channel Speed: 100 Mbytes/Sec

Vendor Date Code(YYYY-MM-DD Lot): 2018-09-14

Vendor Name: Edgecore

Vendor OUI: 70-72-cf

Vendor PN: ET7402-SR4

Vendor Rev: 01

Vendor SN: J11837006041

Ethernet240: SFP EEPROM detected

Application Advertisement: N/A

Connector: MPOx12

DOM Capability:

Rx_power_support: True

Temp_support: False

Tx_power_support: True

Voltage_support: False

Encoding: 256B257B

Extended Identifier: Power Class 3(2.5W max), CDR present in Rx Tx

Extended RateSelect Compliance: QSFP+ Rate Select Version 1

Identifier: QSFP28 or later

... continue

Example (ZR transceiver with dom option)

```
root@sonic:/home/admin# show interfaces transceiver eeprom --dom
```

Ethernet160: SFP EEPROM detected

Active App Selection Host Lane 1: 1

Active App Selection Host Lane 2: 1

Active App Selection Host Lane 3: 1

Active App Selection Host Lane 4: 1

Active App Selection Host Lane 5: 1

Active App Selection Host Lane 6: 1

Active App Selection Host Lane 7: 1

Active App Selection Host Lane 8: 1

Active Firmware Version: 1.3

Application Advertisement:

1: 400GAUI-8 C2M (Annex 120E) | 400ZR, DWDM, amplified

2: 100GAUI-2 C2M (Annex 135G) | 400ZR, DWDM, amplified

CMIS Revision: 4.1

Connector: LC

Encoding: N/A

Extended Identifier: Power Class 8 (19.0W Max)

Extended RateSelect Compliance: N/A

Hardware Revision: 1.1

Host Electrical Interface: 400GAUI-8 C2M (Annex 120E)

Host Lane Assignment Options: 1

Host Lane Count: 8

Identifier: QSFP-DD Double Density 8X Pluggable Transceiver

Inactive Firmware Version: 1.3

Length Cable Assembly(m): 0.0

Media Interface Code: 400ZR, DWDM, amplified

Media Interface Technology: 1550 nm DFB

Media Lane Assignment Options: 1

Media Lane Count: 1

Nominal Bit Rate(100Mbps): 0

Specification compliance: sm_media_interface

Supported Max Laser Frequency: 196100GHz

Supported Max TX Power: -9.0dBm

Supported Min Laser Frequency: 191300GHz

Supported Min TX Power: -14.0dBm

Vendor Date Code(YYYY-MM-DD Lot): 2022-03-28

Vendor Name: MOLEX

Vendor OUI: 00-09-3a

Vendor PN: 1837240006

Vendor Rev: 10

Vendor SN: Z22120BU5

ChannelMonitorValues:

RX1Power: -40.0dBm

RX2Power: -40.0dBm

RX3Power: -40.0dBm

RX4Power: -40.0dBm

RX5Power: -40.0dBm

RX6Power: -40.0dBm

RX7Power: -40.0dBm

RX8Power: -40.0dBm

TX1Power: -40.0dBm

TX2Power: -40.0dBm

TX3Power: -40.0dBm

TX4Power: -40.0dBm

TX5Power: -40.0dBm

TX6Power: -40.0dBm

TX7Power: -40.0dBm

TX8Power: -40.0dBm

ChannelThresholdValues:

RxPowerHighAlarm : 6.0dBm

RxPowerHighWarning: 3.0dBm

RxPowerLowAlarm : -16.003dBm

RxPowerLowWarning : -14.001dBm

TxBiasHighAlarm : 0.0mA

TxBiasHighWarning : 0.0mA

```

TxBiasLowAlarm : 0.0mA
TxBiasLowWarning : 0.0mA
TxPowerHighAlarm : -2.0dBm
TxPowerHighWarning: -4.0dBm
TxPowerLowAlarm : -13.002dBm
TxPowerLowWarning : -12.007dBm
ModuleMonitorValues:
  Temperature: 31.941C
  Vcc: 3.353Volts
ModuleThresholdValues:
  TempHighAlarm : 80.0C
  TempHighWarning: 75.0C
  TempLowAlarm : -6.0C
  TempLowWarning : -3.0C
  VccHighAlarm : 3.7Volts
  VccHighWarning : 3.6Volts
  VccLowAlarm : 3.0Volts
  VccLowWarning : 3.05Volts
Ethernet192: SFP EEPROM detected
  Application Advertisement: N/A
  Connector: MPO 1x12
  DOM Capability:
    Rx_power_support: True
    Temp_support: True
    Tx_power_support: True
    Voltage_support: True
... continue

```

show interfaces transceiver vdm

Show interface transceiver versatile diagnostics monitoring for QSFP-DD.

Example

```
root@sonic:/# show interfaces transceiver vdm Ethernet504
```

```
Ethernet504:
```

Parameter	Unit	Value	Threshold	Threshold	Threshold	Threshold	Threshold	Threshold
Threshold	Threshold	Threshold	Threshold	Threshold	Threshold	Threshold	Threshold	Threshold
Crossing	Low	Low	Crossing	High	High	Alert-High	Alarm	Warning
Alert-Low	Alert-Low	Alert-Low	Alert-Low	Alert-Low	Alert-Low	Alert-Low	Alert-Low	Alert-Low
Laser Temperatur	C	52.31640625	90.0	85.0	False	5.0	8.0	False
Laser Age	%	0.0	95.0	90.0	False	0.0	0.0	False
Tx Power	dBm	-8.21	-2.0	-4.0	False	-17.0	-16.0	False
Rx Total Power	dBm	-40.0	6.0	3.0	False	-22.0	-	20.0
Rx Signal Power	dBm	-40.0	4.0	2.0	False	-22.0	-	20.0
CD-short link	ps/nm	0.0	2400.0	2280.0	False	0.0	0.0	False
CD-long link	ps/nm	0.0	50000.0	42500.0	False	-655360.0	-655360.0	False
PDL	dB	0.0	3.5	3.0	False	0.0	0.0	False
OSNR	dB	0.0	256.0	256.0	False	14.0	16.0	True
eSNR	dB	0.0	256.0	256.0	False	0.0	0.0	False
CFO	MHz	0.0	3000.0	2000.0	False	-3000.0	-	2000.0
DGD	ps	0.0	220.0	200.0	False	0.0	0.0	False
Pre-FEC BER Current Media	N/A	1.0	0.02	0.018000000000000002	True	0.0	0.0	False

Post-FEC BER Current Media	N/A	1.0	1.0	2.0	False	0.0
0.0	False					
Pre-FEC BER Current Host	N/A	1.0	1.0	2.0	False	0.0
0.0	False					
Post-FEC BER Current Host	N/A	1.0	1.00000000000000002e-06	1e-08		True
0.0	0.0	False				
MER	dB	N/A	N/A	N/A	N/A	N/A
N/A						

show interfaces transceiver pm

Show interface transceiver platform monitoring for ZR.

Example

```
root@sonic:/# show interfaces transceiver pm Ethernet240
```

Ethernet240:

Parameter	Unit	Min	Avg	Max	Threshold	Threshold	Threshold	Threshold	Threshold
Threshold	Threshold								
			High	High	Crossing	Low	Low	Crossing	
			Alarm	Warning	Alert-High	Alarm	Warning	Alert-Low	
Tx Power	dBm	-8.18	-8.17	-8.16	0.0	-2.0	False	-18.013	-16.003
False									
Rx Total Power	dBm	-64.04	-43.76	-40.0	13.0	10.0	False	-21.0	-18.0
True									
Rx Signal Power	dBm	-40.0	-40.0	-40.0	13.0	10.0	False	-21.0	-18.0
True									
CD-short link	ps/nm	0.0	0.0	0.0	-1.0	-1.0	True	0.0	0.0
PDL	dB	0.0	0.0	0.0	6553.5	6553.5	False	0.0	0.0
OSNR	dB	0.0	0.0	0.0	6553.5	6553.5	False	0.0	0.0
eSNR	dB	0.0	0.0	0.0	6553.5	6553.5	False	0.0	0.0
CFO	MHz	0.0	0.0	0.0	-1.0	-1.0	True	0.0	0.0
DGD	ps	0.0	0.0	0.0	655.35	655.35	False	0.0	0.0

SOPMD	ps^2	0.0	0.0	0.0	655.35	655.35	False	0.0	0.0
False									
SOP ROC	krad/s	0.0	0.0	0.0	N/A	N/A	N/A	N/A	N/A
Pre-FEC BER	N/A	1.0	1.0	1.0	0.00999	0.008	True	0.0	0.0
False									
Post-FEC BER	N/A	0.0	0.0	0.0	20470000000.0	20470000000.0	False	0.0	0.0
False									
EVM	%	0.0	0.0	0.0	N/A	N/A	N/A	N/A	N/A

show interfaces transceiver status

Show interface transceiver status for QSFP-DD.

Example

```
root@sonic:/home/admin# show interfaces transceiver status Ethernet240
```

Ethernet240:

```

Tx fault flag on media lane 1: False
Tx fault flag on media lane 2: False
Tx fault flag on media lane 3: False
Tx fault flag on media lane 4: False
Tx fault flag on media lane 5: False
Tx fault flag on media lane 6: False
Tx fault flag on media lane 7: False
Tx fault flag on media lane 8: False
Rx loss of signal flag on media lane 1: True
Rx loss of signal flag on media lane 2: False
Rx loss of signal flag on media lane 3: False
Rx loss of signal flag on media lane 4: False
Rx loss of signal flag on media lane 5: False
Rx loss of signal flag on media lane 6: False
Rx loss of signal flag on media lane 7: False
Rx loss of signal flag on media lane 8: False
Current module state: ModuleReady

```

Reason of entering the module fault state: No Fault detected

Datapath firmware fault: False

Module firmware fault: False

Module state changed: False

Data path state indicator on host lane 1: DataPathActivated

Data path state indicator on host lane 2: DataPathActivated

Data path state indicator on host lane 3: DataPathActivated

Data path state indicator on host lane 4: DataPathActivated

Data path state indicator on host lane 5: DataPathActivated

Data path state indicator on host lane 6: DataPathActivated

Data path state indicator on host lane 7: DataPathActivated

Data path state indicator on host lane 8: DataPathActivated

Tx output status on media lane 1: False

Tx output status on media lane 2: False

Tx output status on media lane 3: False

Tx output status on media lane 4: False

Tx output status on media lane 5: False

Tx output status on media lane 6: False

Tx output status on media lane 7: False

Tx output status on media lane 8: False

Rx output status on host lane 1: False

Rx output status on host lane 2: False

Rx output status on host lane 3: False

Rx output status on host lane 4: False

Rx output status on host lane 5: False

Rx output status on host lane 6: False

Rx output status on host lane 7: False

Rx output status on host lane 8: False

Tx loss of signal flag on host lane 1: True

Tx loss of signal flag on host lane 2: True

Tx loss of signal flag on host lane 3: True

Tx loss of signal flag on host lane 4: True

Tx loss of signal flag on host lane 5: True

Tx loss of signal flag on host lane 6: True

Tx loss of signal flag on host lane 7: True
 Tx loss of signal flag on host lane 8: True
 Tx clock and data recovery loss of lock on host lane 1: True
 Tx clock and data recovery loss of lock on host lane 2: True
 Tx clock and data recovery loss of lock on host lane 3: True
 Tx clock and data recovery loss of lock on host lane 4: True
 Tx clock and data recovery loss of lock on host lane 5: True
 Tx clock and data recovery loss of lock on host lane 6: True
 Tx clock and data recovery loss of lock on host lane 7: True
 Tx clock and data recovery loss of lock on host lane 8: True
 Rx clock and data recovery loss of lock on media lane 1: True
 Rx clock and data recovery loss of lock on media lane 2: False
 Rx clock and data recovery loss of lock on media lane 3: False
 Rx clock and data recovery loss of lock on media lane 4: False
 Rx clock and data recovery loss of lock on media lane 5: False
 Rx clock and data recovery loss of lock on media lane 6: False
 Rx clock and data recovery loss of lock on media lane 7: False
 Rx clock and data recovery loss of lock on media lane 8: False
 Configuration status for the data path of host line 1: ConfigUndefined
 Configuration status for the data path of host line 2: ConfigUndefined
 Configuration status for the data path of host line 3: ConfigUndefined
 Configuration status for the data path of host line 4: ConfigUndefined
 Configuration status for the data path of host line 5: ConfigUndefined
 Configuration status for the data path of host line 6: ConfigUndefined
 Configuration status for the data path of host line 7: ConfigUndefined
 Configuration status for the data path of host line 8: ConfigUndefined
 Data path configuration updated on host lane 1: False
 Data path configuration updated on host lane 2: False
 Data path configuration updated on host lane 3: False
 Data path configuration updated on host lane 4: False
 Data path configuration updated on host lane 5: False
 Data path configuration updated on host lane 6: False
 Data path configuration updated on host lane 7: False
 Data path configuration updated on host lane 8: False

Temperature high alarm flag: False
Temperature high warning flag: False
Temperature low warning flag: False
Temperature low alarm flag: False
Vcc high alarm flag: False
Vcc high warning flag: False
Vcc low warning flag: False
Vcc low alarm flag: False
Tx power high alarm flag on lane 1: False
Tx power high alarm flag on lane 2: False
Tx power high alarm flag on lane 3: False
Tx power high alarm flag on lane 4: False
Tx power high alarm flag on lane 5: False
Tx power high alarm flag on lane 6: False
Tx power high alarm flag on lane 7: False
Tx power high alarm flag on lane 8: False
Tx power high warning flag on lane 1: False
Tx power high warning flag on lane 2: False
Tx power high warning flag on lane 3: False
Tx power high warning flag on lane 4: False
Tx power high warning flag on lane 5: False
Tx power high warning flag on lane 6: False
Tx power high warning flag on lane 7: False
Tx power high warning flag on lane 8: False
Tx power low warning flag on lane 1: False
Tx power low warning flag on lane 2: False
Tx power low warning flag on lane 3: False
Tx power low warning flag on lane 4: False
Tx power low warning flag on lane 5: False
Tx power low warning flag on lane 6: False
Tx power low warning flag on lane 7: False
Tx power low warning flag on lane 8: False
Tx power low alarm flag on lane 1: False
Tx power low alarm flag on lane 2: False

```
Tx power low alarm flag on lane 3: False
Tx power low alarm flag on lane 4: False
Tx power low alarm flag on lane 5: False
Tx power low alarm flag on lane 6: False
Tx power low alarm flag on lane 7: False
Tx power low alarm flag on lane 8: False
...continue
```

show interfaces transceiver error-status [-hw]

Show interface transceiver error-status get from REDIS-DB. If add '-hw', then it would get from sonic-platform API.

Now only support error-status get from sonic-platform API. It would only show "OK" or "Unplugged" in REDIS-DB.

Example

```
Port      Error Status
-----
Ethernet0  OK
Ethernet8  OK
Ethernet16 Unplugged
Ethernet24 Unplugged
Ethernet32 OK
...continue
```

show interfaces transceiver frequency

Show interface transceiver frequency and space-grid for QSFP-DD. If the transceiver is not QSFP-DD, it would show 'N/A'.

Example

```
Port      Frequency  Grid space
```

```

-----
Ethernet0  N/A      N/A
Ethernet8  N/A      N/A
Ethernet16 193100GHz  75GHz
Ethernet24 N/A      N/A
Ethernet32 N/A      N/A

...continue

```

show interfaces transceiver lpmode

Show interface transceiver low-power mode status.

Example

```

Port      Low-power Mode
-----
Ethernet0  On
Ethernet4  On
Ethernet8  On
Ethernet12 On
... continue

```

show interfaces transceiver presence

Show interface transceiver presence.

Example

```

Port      Presence
-----
Ethernet0  Present
Ethernet4  Not present
Ethernet8  Not present
Ethernet12 Not present

```

... continue

show interfaces transceiver presence

This command is used to show transceiver presence status.

Example

Port	Presence
Ethernet0	Present
Ethernet4	Not present
Ethernet8	Not present
Ethernet12	Not present

... continue

config interface transceiver application

This command is used to set application for CMIS transceiver.

Need to set Vendor PN and application code.

If there is a transceiver plugged into the port, it can set application without Vendor PN, and the Vendor PN would be automatically added to CONFIG_DB.

Usage

```
config interface transceiver application <interface_name> <application code> -v <Vendor part number>
```

Parameters:

- <speed_value>, user needs to know the interface configurable speeds
 - 40000 for 40G
 - 100000 for 100G

Example

```
config interface transceiver application Ethernet0 3 -v DP04QSDD-E30-001
```

Configure application as auto to automatically select application by port speed and port lane count. If there are multiple matching applications, it would select the first one.

Usage

```
config interface transceiver application <interface_name> auto
```

Example

```
config interface transceiver application Ethernet0 auto
```

Note:

- The configured application code would be applicable if the following conditions are true.
 - The configured Vendor PN matches the transceiver Vendor PN.
 - The configured application is supported by the transceiver.

- The host lane count of the configured application matches the breakout mode. For example: The lane count per port in breakout mode 4x100G is 2, and the host lane count of the configured application should be 2.
- If there is no configured application code or there is no applicable configured application, the system would automatically select application by port speed and port lane count.
- Use the "show interfaces transceiver eeprom" to get the supported application. The pattern is "<application code>: <Host Electrical Interface> | <Media Interface>". The host electrical interface and the media interface are based on the SFF8024.

```
show interfaces transceiver eeprom
```

```
Ethernet248: SFP EEPROM detected
```

```
Active App Selection Host Lane 1: 1
```

```
Active App Selection Host Lane 2: 1
```

```
Active App Selection Host Lane 3: 1
```

```
Active App Selection Host Lane 4: 1
```

```
Active App Selection Host Lane 5: 1
```

```
Active App Selection Host Lane 6: 1
```

```
Active App Selection Host Lane 7: 1
```

```
Active App Selection Host Lane 8: 1
```

```
Active Firmware Version: 3.3
```

```
Application Advertisement:
```

```
1: 400GAUI-8 C2M (Annex 120E) | 400ZR, DWDM, amplified
```

```
2: 400GAUI-8 C2M (Annex 120E) | ZR400-OFEC-16QAM
```

```
3: CAUI-4 C2M (Annex 83E) | ZR200-OFEC-QPSK
```

```
4: CAUI-4 C2M (Annex 83E) | ZR100-OFEC-QPSK
```

- Use the "show logging CMIS" command to check the result of the configuration:

```
Configure application successfully
```

```
root@as9716-32d-2:/# show logging CMIS
```

```
Jul 7 06:16:16.380853 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G,  
lanemask=0xff, state=INSERTED, appl=1, retries=0
```

```
Jul 7 06:16:16.473915 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248 get  
configured application 2
```

```
Jul 7 06:16:19.705147 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G,  
lanemask=0xff, state=DP_DEINIT, appl=2, retries=3
```

```

Jul 7 06:16:20.945597 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G,
lanemask=0xff, state=AP_CONFIGURED, appl=2, retries=3
Jul 7 06:16:25.851871 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G,
lanemask=0xff, state=DP_INIT, appl=2, retries=3
Jul 7 06:16:25.971742 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G,
lanemask=0xff, state=DP_TXON, appl=2, retries=3
Jul 7 06:17:04.175065 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G,
lanemask=0xff, state=DP_ACTIVATION, appl=2, retries=3
Jul 7 06:17:06.494368 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: READY

```

Configure inapplicable application

```

root@as9716-32d-2:/# show logging CMIS
Jul 7 06:24:12.266125 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G,
lanemask=0xff, state=INSERTED, appl=0, retries=0
Jul 7 06:24:12.356151 as9716-32d-2 ERR pmon#xcvrd: CMIS: Ethernet248 the configred
application_code DP04QSDD-E30-001:3 doesn't applicable for current breakout mode

```

config interface transceiver frequency

This command is used to set frequency and space-grid for ZR transceiver.

If the configured frequency is not supported, the transceiver will remain on the original frequency.

Usage

```
config interface transceiver frequency <interface_name> <frequency> <grid_space:75|100>
```

Example

```

user@sonic~$ sudo config interface transceiver frequency Ethernet0 193100 75
Set frequency for port Ethernet0... OK
user@sonic~$ sudo config interface transceiver frequency Ethernet0 192900 100

```

Set frequency for port Ethernet0... OK

Note:

Use the "show logging CMIS" command to check the result of the configuration:

Configure frequency successfully

```
root@as9716-32d-2:/# show logging CMIS
Jul 7 05:55:49.769547 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G, lanemask=0xff,
state=INSERTED, appl=1, retries=0
Jul 7 05:55:50.674936 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: force Datapath reinit
Jul 7 05:55:54.142381 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G, lanemask=0xff,
state=DP_DEINIT, appl=1, retries=0
Jul 7 05:55:55.702526 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G, lanemask=0xff,
state=AP_CONFIGURED, appl=1, retries=0
Jul 7 05:56:00.560000 as9716-32d-2 NOTICE pmon#xcvrd: message repeated 9 times: [ CMIS:
Ethernet248: 400G, lanemask=0xff, state=AP_CONFIGURED, appl=1, retries=0]
Jul 7 05:56:00.560000 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248 configured laser
frequency 193200 GHz grid space 100 GHz
Jul 7 05:56:00.908286 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G, lanemask=0xff,
state=DP_INIT, appl=1, retries=0
Jul 7 05:56:01.076187 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G, lanemask=0xff,
state=DP_TXON, appl=1, retries=0
Jul 7 05:56:38.887624 as9716-32d-2 NOTICE pmon#xcvrd: message repeated 80 times: [ CMIS:
Ethernet248: 400G, lanemask=0xff, state=DP_TXON, appl=1, retries=0]
Jul 7 05:56:38.887624 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G, lanemask=0xff,
state=DP_ACTIVATION, appl=1, retries=0
Jul 7 05:56:42.157752 as9716-32d-2 NOTICE pmon#xcvrd: message repeated 5 times: [ CMIS:
Ethernet248: 400G, lanemask=0xff, state=DP_ACTIVATION, appl=1, retries=0]
Jul 7 05:56:42.157752 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: READY
```

Configure unsupported frequency

```
root@as9716-32d-2:/# show logging CMIS |tail
Jul 7 06:01:34.909414 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: 400G, lanemask=0xff,
```

```
state=INSERTED, appl=1, retries=0
```

```
Jul 7 06:01:35.614400 as9716-32d-2 ERR pmon#xcvrd: CMIS: Ethernet248 configured freq:193200 GHz  
is not supported in grid 75 GHz
```

```
Jul 7 06:01:35.614400 as9716-32d-2 NOTICE pmon#xcvrd: CMIS: Ethernet248: READY
```

config interface transceiver tx_power

This command is used to set tx power for ZR transceiver.

Usage

```
config interface transceiver tx_power <interface_name> <txpower>
```

Example

```
user@sonic~$ sudo config interface transceiver tx_power Ethernet0 -- -9  
Setting target Tx output power to -9.0 dBm on port Ethernet0
```

config interface transceiver lpmode

This command is used to enable or disable the low-power mode of an SFP transceiver.

Usage

```
config interface transceiver lpmode <interface_name> (enable | disable)
```

Example

```
user@sonic~$ sudo config interface transceiver lpmode Ethernet0 enable  
Enabling low-power mode for port Ethernet0... OK
```

```
user@sonic~$ sudo config interface transceiver lpmode Ethernet0 disable
Disabling low-power mode for port Ethernet0... OK
```

config interface transceiver reset

Resets an SFP transceiver module.

Usage

```
config interface transceiver reset <interface_name>
```

Example

```
user@sonic~$ sudo config interface transceiver reset Ethernet0
Resetting port Ethernet0... OK
```

sfputil show eeprom

This command uses `sfputil` utility to retrieve transceiver's DOM information. Transceiver maker to make sure DOM information can be read and correct in EEPROM.

Example (get transceiver eeprom DOM information)

```
admin@sonic:~$ sudo sfputil show eeprom --dom
Ethernet0: SFP EEPROM detected
    Application Advertisement: 400GAUI-8 C2M (Annex 120E) - Active Cable assembly with BER <
2.6x10^-4

    Connector: No separable connector
    Encoding: Not supported for CMIS cables
```

Extended Identifier: Power Class 2(12.0W Max)

Extended RateSelect Compliance: Not supported for CMIS cables

Identifier: QSFP-DD Double Density 8X Pluggable Transceiver

Length Cable Assembly(m): 10

Nominal Bit Rate(100Mbps): Not supported for CMIS cables

Specification compliance: Not supported for CMIS cables

Vendor Date Code(YYYY-MM-DD Lot): 2021-04-07

Vendor Name: Edgecore

Vendor OUI: 68-e8-eb

Vendor PN: ET7502-AOC-10M

Vendor Rev: 10

Vendor SN: L12115000001

ChannelMonitorValues:

RX1Power: 0.4591dBm

RX2Power: 1.1311dBm

RX3Power: 1.3440dBm

RX4Power: 1.1883dBm

RX5Power: -0.0463dBm

RX6Power: 0.7918dBm

RX7Power: 0.8052dBm

RX8Power: 0.7972dBm

TX1Bias: 6.6000mA

TX1Power: 0.6483dBm

TX2Bias: 6.6000mA

TX2Power: 1.1428dBm

TX3Bias: 6.6000mA

TX3Power: 1.1388dBm

TX4Bias: 6.6000mA

TX4Power: 1.3348dBm

TX5Bias: 6.6000mA

TX5Power: 0.7547dBm

TX6Bias: 6.6000mA

TX6Power: 1.0673dBm

TX7Bias: 6.6000mA

TX7Power: 0.9989dBm

TX8Bias: 6.6000mA

TX8Power: 1.1348dBm

ChannelThresholdValues:

RxPowerHighAlarm : 5.0dBm

RxPowerHighWarning: 4.0dBm

RxPowerLowAlarm : -9.3968dBm

RxPowerLowWarning : -8.3983dBm

TxBiasHighAlarm : 15.0mA

TxBiasHighWarning : 14.0mA

TxBiasLowAlarm : 2.0mA

TxBiasLowWarning : 3.0mA

TxPowerHighAlarm : 5.0dBm

TxPowerHighWarning: 4.0dBm

TxPowerLowAlarm : -7.5007dBm

TxPowerLowWarning : -6.4995dBm

ModuleMonitorValues:

Temperature: 36.7773C

Vcc: 3.2323Volts

ModuleThresholdValues:

TempHighAlarm : 75.0C

TempHighWarning: 70.0C

TempLowAlarm : -5.0C

TempLowWarning : 0.0C

VccHighAlarm : 3.6Volts

VccHighWarning : 3.5Volts

VccLowAlarm : 2.9Volts

VccLowWarning : 3.0Volts

Ethernet8: SFP EEPROM detected

Application Advertisement: 400GAUI-8 C2M (Annex 120E) - Active Cable assembly with BER < 2.6×10^{-4}

Connector: No separable connector

Encoding: Not supported for CMIS cables

Extended Identifier: Power Class 2(12.0W Max)

Extended RateSelect Compliance: Not supported for CMIS cables

Identifier: QSFP-DD Double Density 8X Pluggable Transceiver

...contiune

sfputil show vdm

This command uses sfp utility to retrieve transceiver's versatile diagnostics monitoring.

Example							
admin@sonic:~\$ sfputil show vdm -p Ethernet504							
Ethernet504:							
Parameter	Unit	Value	Threshold	Threshold	Threshold	Threshold	Threshold
Threshold	Threshold						
		High	High	Crossing	Low	Low	
Crossing							
		Alarm	Warning	Alert-High	Alarm	Warning	
Alert-Low							

TEC Current	%	-10.467848750267036	79.99816888943144	69.99725333414716	False		
-80.00427259132664	-70.00335703604236	False					
Laser Temperature	C	50.578125	85.0	80.0	False	-10.0	-
5.0	False						
CD high granularity, short link	ps/nm	0	2400	2280	False	0	0
False							
CD low granularity, long link	ps/nm	0	50000	42500	False	-655360	
-655360	False						
DGD	ps	0.0	220.0	200.0	False	0.0	0.0
False							
PDL	dB	0.0	3.5	3.0	False	0.0	0.0
False							
OSNR	dB	0.0	256.0	256.0	False	14.0	16.0

True							
eSNR	dB	0.0	256.0	256.0	False	0.0	0.0
False							
CFO	MHz	0	3000	2000	False	-3000	-2000
False							
EVM_modem	%	0.0	100.0	100.0	False	0.0	0.0
False							
SOP ROC	krad/s	0	80	50	False	0	0
False							
Tx Power	dBm	-8.2	-2.0	-4.0	False	-17.0	-16.0
False							
Rx Total Power	dBm	-40.0	6.0	3.0	False	-22.0	-20.0
True							
Rx Signal Power	dBm	-40.0	4.0	2.0	False	-22.0	-20.0
True							
Pre-FEC BER Minimum Media Input	N/A	1.0	0.02	0.018000000000000002	True		
0.0	0.0	False					
Pre-FEC BER Maximum Media Input	N/A	1.0	0.02	0.018000000000000002	True		
0.0	0.0	False					
Pre-FEC BER Average Media Input	N/A	1.0	0.02	0.018000000000000002	True		
0.0	0.0	False					
Pre-FEC BER Current Value Media Input	N/A	1.0	0.02	0.018000000000000002	True		
0.0	0.0	False					
Errored Frames Minimum Media Input	N/A	1.0	1.0	2.0	False	0.0	
0.0	False						
Errored Frames Maximum Media Input	N/A	1.0	1.0	2.0	False	0.0	
0.0	False						
Errored Frames Average Media Input	N/A	1.0	1.0	2.0	False	0.0	
0.0	False						
Errored Frames Current Value Media Input	N/A	1.0	1.0	2.0	False	0.0	
0.0	False						
Modulator Bias X/I	%	44.998855573357744	87.99877927824826	85.99984740978103			
False	1.9989318684672313	5.999847409781033	False				
Modulator Bias X/Q	%	43.99938963912413	87.99877927824826	85.99984740978103			
False	1.9989318684672313	5.999847409781033	False				

Modulator Bias Y/I	%	63.96734569314107	87.99877927824826	85.99984740978103		
False	1.9989318684672313	5.999847409781033	False			
Modulator Bias Y/Q	%	52.967116807812616	87.99877927824826	85.99984740978103		
False	1.9989318684672313	5.999847409781033	False			
Modulator Bias X_Phase	%	59.28282597085527	87.99877927824826	85.99984740978103		
False	1.9989318684672313	5.999847409781033	False			
Modulator Bias Y_Phase	%	53.98794537270161	87.99877927824826	85.99984740978103		
False	1.9989318684672313	5.999847409781033	False			
Laser Age	%	0	95	90	False	0 0
False						
Pre-FEC BER Minimum Host Input	N/A	1.0	1.0000000000000002e-06	1e-08	True	
0.0	0.0	False				
Pre-FEC BER Maximum Host Input	N/A	1.0	1.0000000000000002e-06	1e-08	True	
0.0	0.0	False				
Pre-FEC BER Average Host Input	N/A	1.0	1.0000000000000002e-06	1e-08	True	
0.0	0.0	False				
Pre-FEC BER Current Value Host Input	N/A	1.0	1.0000000000000002e-06	1e-08	True	
0.0	0.0	False				
Errored Frames Minimum Host Input	N/A	1.0	1.0	2.0	False	0.0
0.0	False					
Errored Frames Maximum Host Input	N/A	1.0	1.0	2.0	False	0.0
0.0	False					
Errored Frames Average Host Input	N/A	1.0	1.0	2.0	False	0.0
0.0	False					
Errored Frames Current Value Host Input	N/A	1.0	1.0	2.0	False	0.0
0.0	False					

sfputil read-eeprom

用法

```
sfputil read-eeprom -p [port] -n [page in hex] -o [offset] -s [size]
```

参数

-p [port]

-n [page in hex]
 -o [offset]
 -s [size]

示例

```
root@sonic:/home/admin# sfputil read-eeprom -p Ethernet292 -n 11 -o 128 -s 128
00000080 44 44 00 00 00 00 0f 00 00 00 00 00 00 00 00 |DD.....|
00000090 00 00 00 00 00 00 00 00 00 00 3c b9 3c 36 3a d0 |.....<.<6:.|
000000a0 3e c9 00 00 00 00 00 00 00 00 11 c6 11 c6 11 c6 |>.....|
000000b0 11 c6 00 00 00 00 00 00 00 00 35 80 32 48 31 b4 |.....5.2H1.|
000000c0 2f ce 00 00 00 00 00 00 00 00 11 11 00 00 11 11 |/.....|
000000d0 11 11 00 00 00 00 0f 00 00 00 00 00 0f 0f 77 |.....w|
000000e0 77 00 00 22 22 00 00 22 22 00 00 00 00 00 00 |w.."" .."|
000000f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
```

sfputil write-eeprom

用法

```
sfputil write-eeprom -p [port] -n [page in hex] -o [offset] -d [data in hex]
```

参数

-p [port]
 -n [page in hex]
 -o [offset]
 -d [data in hex]

示例

```
root@sonic:/home/admin# sfputil write-eeprom -p Ethernet480 -n 10 -o 128 -d ffff
root@sonic:/home/admin# sfputil read-eeprom -p Ethernet480 -n 10 -o 128 -s 128
00000080 ff ff 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
00000090 00 10 10 10 10 18 18 18 18 ff 00 00 00 00 00 00 |.....|
000000a0 ff ff 66 66 66 66 11 11 11 11 22 22 22 22 00 00 |..ffff...."""|
```

```
000000b0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
000000c0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
000000d0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
000000e0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
000000f0 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 |.....|
```

sfputil lpmode

用法

```
sfputil lpmode on/off [port]
```

参数

on/off [port]

示例

```
root@sonic:/home/admin# sfputil reset Ethernet292
Resetting port Ethernet292 ... OK
root@sonic:/home/admin# sfputil lpmode on Ethernet292
Enabling low-power mode for port Ethernet292 ... OK
root@sonic:/home/admin# sfputil lpmode off Ethernet292
Disabling low-power mode for port Ethernet292 ... OK
```

sfputil reset

用法

```
sfputil reset [port]
```

参数

[port]

示例

```
root@sonic:/home/admin# sfputil reset Ethernet292
Resetting port Ethernet292 ... OK
```

sfputil show snr

用法

```
sfputil show snr [port]
```

参数

-p [port]

示例

```
sfputil show snr -p Ethernet416
```

Ethernet416:

Parameter	Value
host_side_input_snr_measurement_supported	False
MediaSideSNRLane1	21.796875
MediaSideSNRLane2	21.796875
MediaSideSNRLane3	22.0
MediaSideSNRLane4	21.69921875
MediaSideSNRLane5	0.0
MediaSideSNRLane6	0.0
MediaSideSNRLane7	0.0
MediaSideSNRLane8	0.0

22 IP/IPv6

Table of Contents

[IP Show Commands](#)

[show ip route](#)

[show ip interfaces](#)

[show ip prefix-list](#)

[show ip protocol](#)

[IPv6 Show Commands](#)

[show ipv6 route](#)

[show ipv6 interfaces](#)

[show ipv6 prefix-list](#)

[show ipv6 protocol](#)

IP Show Commands

This sub-section explains the various IP protocol-specific show commands that are used to display the following.

1. routes
2. bgp details - Explained in the bgp section
3. IP interfaces
4. prefix-list
5. protocol

show ip route

This command displays either all the route entries from the routing table or a specific route.

Usage
<code>show ip route [vrf <vrf-name>] [<ip_address>]</code>

Example

```
admin@sonic:~$ show ip route
```

Codes: K - kernel route, C - connected, S - static, R - RIP,

O - OSPF, I - IS-IS, B - BGP, E - EIGRP, N - NHRP,

T - Table, v - VNC, V - VNC-Direct, A - Babel, D - SHARP,

F - PBR, f - OpenFabric,

> - selected route, * - FIB route, q - queued route, r - rejected route

```
S>* 0.0.0.0/0 [200/0] via 10.11.162.254, eth0
```

```
C>* 1.1.0.0/16 is directly connected, Vlan100
```

```
C>* 10.1.1.0/31 is directly connected, Ethernet112
```

```
C>* 10.1.1.2/31 is directly connected, Ethernet116
```

```
C>* 10.11.162.0/24 is directly connected, eth0
```

Optionally, specify an IP address to display routes to the particular IP address.

Example

```
admin@sonic:~$ show ip route 10.1.1.0
```

Routing entry for 10.1.1.0/31

Known via "connected", distance 0, metric 0, best

Last update 00:07:49 ago

* directly connected, Ethernet112

Specify <vrf_name> to get IPv4 routes programmed in the <vrf_name>

Example

```
admin@sonic:~$ show ip route vrf Vrf-red
```

Codes: K - kernel route, C - connected, S - static, R - RIP,

O - OSPF, I - IS-IS, B - BGP, E - EIGRP, N - NHRP,
T - Table, v - VNC, V - VNC-Direct, A - Babel, D - SHARP,
F - PBR, f - OpenFabric,
> - selected route, * - FIB route, q - queued route, r - rejected route

VRF Vrf-red:

```
C>* 11.1.1.1/32 is directly connected, Loopback11, 21:50:47
```

```
C>* 100.1.1.0/24 is directly connected, Vlan100, 03w1d06h
```

```
admin@sonic:~$ show ip route vrf Vrf-red 11.1.1.1/32
```

Routing entry for 11.1.1.1/32

Known via "connected", distance 0, metric 0, vrf Vrf-red, best

Last update 21:57:53 ago

* directly connected, Loopback11

show ip interfaces

This command displays the details about all the Layer3 IP interfaces in the device for which IP address have been assigned. The type of interfaces include the following.

1. Front panel physical ports
2. PortChannel interfaces
3. VLAN interfaces
4. Loopback interfaces
5. docker interface
6. management interface

Usage

```
show ip interfaces
```

Example

```
admin@sonic:~$ show ip interfaces
```

Interface	Master	IPv4 address/mask	Admin/Oper	BGP Neighbor	Neighbor IP Flags
Loopback0		1.0.0.1/32	up/up	N/A	N/A
Loopback11	Vrf-red	11.1.1.1/32	up/up	N/A	N/A
Loopback100	Vrf-blue	100.0.0.1/32	up/up	N/A	N/A
PortChannel01		10.0.0.56/31	up/down	DEVICE1	10.0.0.57
PortChannel02		10.0.0.58/31	up/down	DEVICE2	10.0.0.59
PortChannel03		10.0.0.60/31	up/down	DEVICE3	10.0.0.61
PortChannel04		10.0.0.62/31	up/down	DEVICE4	10.0.0.63
Vlan100	Vrf-red	1001.1.1/24	up/up	N/A	N/A
Vlan1000		192.168.0.1/27	up/up	N/A	N/A
Docker0		240.127.1.1/24	up/down	N/A	N/A
eth0		10.3.147.252/23	up/up	N/A	N/A
lo		127.0.0.1/8	up/up	N/A	N/A

show ip prefix-list

This command displays the ip prefix-list.

Usage

```
show ip prefix-list
```

Example

```
admin@sonic:~$ show ip prefix-list
BGP: ip prefix-list PL_LoopbackV4: 1 entries
seq 5 permit 10.1.0.32/32
```

show ip protocol

This command displays the route-map that is configured for the routing protocol. Refer to the routing stack Quagga Command Reference or FRR Command Reference to know more about this command.

Usage

```
show ip protocol
```

Example

```
admin@sonic:~$ show ip protocol
VRF: default
Protocol : route-map
-----
system   : none
kernel   : none
Connected : none
static    : none
rip       : none
ripng     : none
ospf      : none
ospf6     : none
isis      : none
bgp       : RM_SET_SRC
```

```
pim      : none
eigrp    : none
nhrp     : none
hsls     : none
olsr     : none
Table    : none
ldp      : none
vnc      : none
vnc-direct : none
vnc-rn   : none
bgp-direct : none
bgp-direct-to-nve-groups : none
babel    : none
sharp    : none
pbr      : none
bfd      : none
openfabric : none
vrrp     : none
wildcard : none
any      : none
```

IPv6 Show Commands

This sub-section explains the various IPv6 protocol-specific show commands that are used to display the following.

1. routes
2. IPv6 bgp details - Explained in the bgp section
3. IP interfaces
4. prefix-list

5. protocol

show ipv6 route

This command displays either all the IPv6 route entries from the routing table or a specific IPv6 route

Usage

```
show ipv6 route [vrf <vrf-name>] [<ip_address>]
```

Example

```
admin@sonic:~$ show ipv6 route
```

Codes: K - kernel route, C - connected, S - static, R - RIPng,

O - OSPFv3, I - IS-IS, B - BGP, N - NHRP, T - Table,

v - VNC, V - VNC-Direct, A - Babel, D - SHARP, F - PBR,

f - OpenFabric,

> - selected route, * - FIB route, q - queued route, r - rejected route

```
C>* 2018:2001::/126 is directly connected, Ethernet112
```

```
C>* 2018:2002::/126 is directly connected, Ethernet116
```

```
C>* fc00:2::102/128 is directly connected, eth0
```

```
C * fe80::/64 is directly connected, Vlan100
```

```
C * fe80::/64 is directly connected, Ethernet112
```

```
C * fe80::/64 is directly connected, Ethernet116
```

```
C * fe80::/64 is directly connected, Bridge
```

```
C * fe80::/64 is directly connected, PortChannel0011
```

```
C>* fe80::/64 is directly connected, eth0
```

Optionally, you can specify an IPv6 address in order to display only routes to that particular IPv6 address.

Example

```
admin@sonic:~$ show ipv6 route fc00:1::32
Routing entry for fc00:1::32/128
  Known via "connected", distance 0, metric 0, best
  Last update 00:26:02 ago
  * directly connected, lo
```

A VRF name can also be specified to see IPv6 routes configured in the VRF.

Example

```
admin@sonic:~$ show ipv6 route vrf Vrf-red
Codes: K - kernel route, C - connected, S - static, R - RIPng,
       O - OSPFv3, I - IS-IS, B - BGP, N - NHRP, T - Table,
       v - VNC, V - VNC-Direct, A - Babel, D - SHARP, F - PBR,
       f - OpenFabric,
       > - selected route, * - FIB route, q - queued route, r - rejected route
```

VRF Vrf-red:

```
C>* 1100::1/128 is directly connected, Loopback11, 21:50:47
C>* 100::/112 is directly connected, Vlan100, 03w1d06h
C>* fe80::/64 is directly connected, Loopback11, 21:50:47
C>* fe80::/64 is directly connected, Vlan100, 03w1d06h
admin@sonic:~$ show ipv6 route vrf Vrf-red 1100::1/128
Routing entry for 1100::1/128
  Known via "connected", distance 0, metric 0, vrf Vrf-red, best
  Last update 21:57:53 ago
  * directly connected, Loopback11
```

show ipv6 interfaces

This command displays the details about all the Layer3 IPv6 interfaces in the device for which IPv6 address have been assigned. The type of interfaces include the following.

1. Front panel physical ports
2. PortChannel interfaces
3. VLAN interfaces
4. Loopback interfaces
5. management interface

Usage

```
show ipv6 interfaces
```

Example

```
admin@sonic:~$ show ipv6 interfaces
```

Interface	Master	IPv6 address/mask	Admin/Oper	BGP Neighbor	Neighbor IP
Bridge		fe80::7c45:1dff:fe08:cdd%Bridge/64	up/up	N/A	N/A
Loopback11	Vrf-red	1100::1/128	up/up		
PortChannel01		fc00::71/126	up/down	DEVICE1	fc00::72
PortChannel02		fc00::75/126	up/down	DEVICE2	fc00::76
PortChannel03		fc00::79/126	up/down	DEVICE3	fc00::7a
PortChannel04		fc00::7d/126	up/down	DEVICE4	fc00::7e
Vlan100	Vrf-red	100::1/112	up/up	N/A	N/A
		fe80::eef4:bbff:fefe:880a%Vlan100/64			

eth0	fe80::eef4:bbff:fefe:880a%eth0/64	up/up	N/A	N/A
Lo	fc00:1::32/128	up/up	N/A	N/A

show ipv6 prefix-list

This command displays the IPv6 prefix-list.

Usage

```
show ipv6 prefix-list
```

Example

```
admin@sonic:~$ show ipv6 prefix-list
BGP: ipv6 prefix-list PL_LoopbackV6: 1 entries
seq 5 permit fc00:1::/64
```

show ipv6 protocol

This command displays the route-map that is configured for the IPv6 routing protocol. Refer to the routing stack Quagga Command Reference or FRR Command Reference to know more about this command.

Usage

```
show ipv6 protocol
```

Example

```
admin@sonic:~$ show ipv6 protocol
```

```
VRF: default
```

```
Protocol : route-map
```

```
-----  
system : none
```

```
kernel : none
```

```
Connected : none
```

```
static : none
```

```
rip : none
```

```
ripng : none
```

```
ospf : none
```

```
ospf6 : none
```

```
isis : none
```

```
bgp : RM_SET_SRC
```

```
pim : none
```

```
eigrp : none
```

```
nhrp : none
```

```
hsls : none
```

```
olsr : none
```

```
Table : none
```

```
ldp : none
```

```
vnc : none
```

```
vnc-direct : none
```

```
vnc-rn : none
```

```
bgp-direct : none
```

```
bgp-direct-to-nve-groups : none
```

```
babel : none
```

```
sharp : none
```

```
pbr : none
```

```
bfd : none
```

```
openfabric : none
```

```
vrrp : none
```

```
wildcard : none
```

```
any : none
```

23 Kubernetes Configuration

Table of Contents

[Kubernetes Server Setting](#)

[show the kubernetes server config](#)

[show kubernetes server status](#)

[config kubernetes server ip](#)

[config kubernetes server disable](#)

[SONiC Feature Setting](#)

[config feature owner](#)

[show feature config](#)

[show feature status](#)

Kubernetes Server Setting

show the kubernetes server config

This command displays the Kubernetes server configuration if any, otherwise it will report as not configured.

Usage

```
show kubernetes server config
```

Example

```
admin@sonic:~$ show kubernetes server config
ip      port  insecure  disable
-----  ---  -
10.250.4.167 6443  True     False
```

show kubernetes server status

This command displays the Kubernetes server status.

Usage

```
show kubernetes server status
```

Example

```
admin@sonic:~$ show kubernetes server status
ip      port  connected  update-time
-----  ---  -
10.250.4.167 6443  true       2022-4-15 18:25:05
```

config kubernetes server ip

This command is used to configure the kubernetes server address

Usage

```
sudo config kubernetes server ip [<server_ip>]
```

Example

```
admin@sonic:~$ sudo config kubernetes server ip 10.250.4.167
```

config kubernetes server disable

To enable or disable the connection between the kubernetes server.

Usage

```
sudo config kubernetes server disable [on/off]
```

Example

```
admin@sonic:~$ sudo config kubernetes server disable off
admin@sonic:~$ sudo config kubernetes server disable on
```

SONiC Feature Setting

config feature owner

Configures the owner of a feature as "local" or "kube". The "local" implies starting the feature container from local image. The "kube" implies that kubernetes server is made eligible to deploy the feature. The deployment of a feature by kubernetes is conditional based on many factors like, whether the kube server is configured or not, connected-to-kube-server or not and if that master has manifest for this feature for this switch or not and more. At some time in the future, the deployment could happen and beyond that time point the feature can run from the local image, called "fallback". The fallback is allowed by default and it could be toggled to "not allowed". When

fallback is not allowed, the feature would run only upon deployment by kubernetes master.

Usage

```
config feature owner [<feature name>] [local/kube]
```

Example

```
admin@sonic:~$ sudo config feature owner snmp kube
```

show feature config

By executing the command below, the the owner configuration of the corresponding feature can be displayed.

Usage

```
show feature config [<feature name>]
```

Example

```
admin@sonic:~$ show feature config
```

Feature	State	AutoRestart	Owner	fallback
bgp	enabled	enabled	local	
database	enabled	disabled	local	
dhcp_relay	enabled	enabled	kube	
lldp	enabled	enabled	kube	true
mgmt-framework	enabled	enabled	local	
nat	disabled	enabled	local	
pmon	enabled	enabled	kube	
radv	enabled	enabled	kube	

sflow	disabled	enabled	local
snmp	enabled	enabled	kube
swss	enabled	enabled	local
syncd	enabled	enabled	local
teamd	enabled	enabled	local
telemetry	enabled	enabled	kube

show feature status

To see some detailed status like the current owner or the remote state of the feature.

Usage

show feature status [<feature name>]

Example

```
admin@sonic:~$ show feature status
```

Feature	State	AutoRestart	SystemState	UpdateTime	ContainerId
ContainerVersion	SetOwner	CurrentOwner	RemoteState		

bgp	enabled	enabled			
up			local	local	
none					
database	enabled				
disabled				local	
dhcp_relay	enabled	enabled	up	2020-11-15 18:21:09	249e70102f55
20201230.100	kube	local			
lldp	enabled	enabled	up	2020-11-15 18:21:09	779c2d55ee12
20201230.100	kube	local			
mgmt-framework	enabled	enabled			

```

up                                local  local
none
nat      disabled
enabled                                local
pmon      enabled enabled  up      2020-11-15 18:20:27 a2b9ffa8aba3
20201230.100 kube  local
radv      enabled enabled  up      2020-11-15 18:21:05 d8ff27dcfe46
20201230.100 kube  local
sflow     disabled
enabled                                local
snmp      enabled enabled  up      2020-11-15 18:25:51 8b7d5529e306
20201230.111 kube  kube  running
swss      enabled enabled
up                                local  local
none
syncd     enabled enabled
up                                local  local
none
teamd     enabled enabled
up                                local  local
none
telemetry enabled enabled  down    2020-11-15 18:24:59
20201230.100 kube  none

```

24 LLDP

Table of Contents

[LLDP Show Commands](#)

[show lldp table](#)

[show lldp neighbors](#)

[show lldp med location](#)

[show lldp med policy](#)

[show lldp med power](#)

[show lldp dot3](#)

[show lldp global](#)

[show lldp interfaces](#)

[LLDP Config Commands](#)

[config lldp med location](#)

[config lldp med power](#)

[config lldp dot3 power](#)

[config lldp global hello_timer](#)

[config lldp global management_ip](#)

[config lldp global system_description](#)

[config lldp global system_name](#)

The Link Layer Discovery Protocol (LLDP) is used to discover basic information about neighboring devices in the local broadcast domain. LLDP is a Layer 2 protocol that uses periodic broadcasts to advertise information about the sending device. Advertised information is represented in Type Length Value (TLV) format according to the IEEE 802.1AB standard, and can include details such as device identification, capabilities, and configuration settings. LLDP also defines how to store and maintain information gathered about the neighboring network nodes it discovers.

LLDP Show Commands

show lldp table

This command displays a brief summary of all LLDP neighbors.

Usage

```
show lldp table
```

Example

```
admin@sonic:~$ show lldp table
```

Capability codes: (R) Router, (B) Bridge, (O) Other

LocalPort	RemoteDevice	RemotePortID	Capability	RemotePortDescr
-----------	--------------	--------------	------------	-----------------

Ethernet112	ARISTA01T1	Ethernet1	BR	
-------------	------------	-----------	----	--

Ethernet116	ARISTA02T1	Ethernet1	BR	
-------------	------------	-----------	----	--

eth0	00:e0:0c:00:01:05	BR		Ethernet Port on unit 1, port 8
------	-------------------	----	--	---------------------------------

Total entries displayed: 3

show lldp neighbors

This command displays more details about all LLDP neighbors or only the neighbors connected to a specific interface.

Usage

```
show lldp neighbors <interface_name>
```

Example 1: Display all neighbors on all interfaces

```
admin@sonic:~$ show lldp neighbors
```

```
LLDP neighbors:
```

```
Interface: eth0, via: LLDP, RID: 5, Time: 0 day, 00:04:12
```

```
Chassis:
```

```
ChassisID: mac 00:e0:0c:00:00:fd
```

```
SysDescr: ECS4120-28T
```

```
Capability: Bridge, on
```

```
Capability: Router, on
```

```
Port:
```

```
PortID: mac 00:e0:0c:00:01:05
```

```
PortDescr: Ethernet Port on unit 1, port 8
```

```
TTL: 120
```

```
MFS: 1522
```

```
PMD autoneg: supported: yes, enabled: yes
```

```
Adv: 10Base-T, HD: yes, FD: yes
```

```
Adv: 100Base-TX, HD: yes, FD: yes
```

```
Adv: 1000Base-T, HD: no, FD: yes
```

```
MAU oper type: 1000BaseTFD - Four-pair Category 5 UTP, full duplex mode
```

```
VLAN: 20, pvid: yes
```

```
Interface: Ethernet112, via: LLDP, RID: 1, Time: 0 day, 00:04:32
```

```
Chassis:
```

```
ChassisID: mac 52:54:00:02:b9:09
```

```
SysName: ARISTA01T1
```

```
SysDescr: Arista Networks EOS version 4.20.15M running on an Arista Networks vEOS
```

```
MgmtIP: 10.250.2.100
```

```
Capability: Bridge, on
```

```
Capability: Router, on
```

```
Port:
```

```
PortID: ifname Ethernet1
```

```
TTL: 120
```

```
MFS: 9236
```

Port is aggregated. PortAggregID: 1000001

Interface: Ethernet116, via: LLDP, RID: 3, Time: 0 day, 00:04:32

Chassis:

ChassisID: mac 52:54:00:25:75:8e

SysName: ARISTA02T1

SysDescr: Arista Networks EOS version 4.20.15M running on an Arista Networks vEOS

MgmtIP: 10.250.2.101

Capability: Bridge, on

Capability: Router, on

Port:

PortID: ifname Ethernet1

TTL: 120

MFS: 9236

Port is aggregated. PortAggregID: 1000001

Optionally, you can specify an interface name in order to display only that particular interface.

Example 2

```
admin@sonic:~$ show lldp neighbors Ethernet112
```

LLDP neighbors:

Interface: Ethernet112, via: LLDP, RID: 5, Time: 0 day, 00:05:08

Chassis:

ChassisID: mac 52:54:00:02:b9:09

SysName: ARISTA01T1

SysDescr: Arista Networks EOS version 4.20.15M running on an Arista Networks vEOS

MgmtIP: 10.250.2.100

Capability: Bridge, on

Capability: Router, on

Port:

PortID: ifname Ethernet1

TTL: 120

MFS: 9236

Port is aggregated. PortAggregID: 1000001

show lldp med location

This command displays the summary of LLDP-MED location configuration of specified port or all ports.

Usage`show lldp med location [port]`**Example**

```
admin@sonic:~$ show lldp med location
```

INTERFACE NAME	ELIN
----------------	------

Global	1234556
--------	---------

show lldp med policy

This command displays the summary of LLDP-MED policy configuration of specified port or all ports.

Usage`show lldp med policy [port]`

Example

```
admin@sonic:~$ show lldp med policy
```

INTERFACE	NAME	APPLICATION	UNKNOWN	TAGGED	VLAN	PRIORITY	DSCP
Global	voice	True	True	background	63		

show lldp med power

This command displays the summary of LLDP-MED PoE-MDI configuration of a specified port or all ports.

Usage

```
show lldp med power [port]
```

Example

```
admin@sonic:~$ show lldp med power
```

INTERFACE	NAME	TYPE	SOURCE	PRIORITY	VALUE
Global	pse	primary	unknown	100	

show lldp dot3

This command displays the summary of LLDP Dot3 PoE-MDI configuration of a specified port or all ports.

Usage

```
show lldp dot3 [port]
```

Example

```
admin@sonic:~$ show lldp dot3
INTERFACE NAME  TYPE  POWER PAIRS  SUPPORTED  ENABLED  PAIR CONTROL  CLASS  802.3
TYPE  SOURCE  PRIORITY  REQUESTED  ALLOCATED
-----
Global      pse  signal      False      False      False
```

show lldp global

This command displays the summary of LLDP global configuration.

Usage

```
show lldp global
```

Example

```
admin@sonic:~$ show lldp global
-----
LLDP Global configuration:
-----
HELLO TIMER      30
SYSTEM NAME      as7326-56x-3
SYSTEM DESCRIPTION SONiC Software Version: SONiC.autobuild_172 - HwSku:
Accton-AS7326-56X - Distribution: Debian 11.4 - Kernel: 5.10.0-8-2-amd64
MANAGEMENT IP    10.250.0.182
-----
```

show lldp interfaces

This command displays the LLDP interfaces status.

Usage

```
show lldp interfaces [port]
```

Example

```
admin@sonic:~$ show lldp interfaces Ethernet0
```

```
INTERFACE NAME  LLDP ENABLED
```

```
-----
```

```
Ethernet0      true
```

LLDP Config Commands

config lldp med location

This command is used to set the LLDP-MED location.

Usage

```
config lldp med location <--elin <elin>> [--port <port-name>]
```

Parameters:

- elin : Emergency Location Identification Number.
- port : Port name. Default is set to all ports.

Note: The configuration cannot be removed after it is configured.

The example below sets the LLDP-MED location to port Ethernet27 and emergency number to 911.

Example

```
admin@sonic:~$ sudo config lldp med location --elin 911 --port Ethernet27
```

```
config lldp med policy voice
```

This command is used to configure the specific network policy for voice applications advertised by LLDP for a given port or for all ports.

Usage

```
config lldp med policy voice [--port <port-name>] [--vlan <1-4094>] [--tagged] [--unknown] [--priority (best-effort | background | excellent-effort | critical-applications| video | voice | internetwork-control | network-control)] [--dscp <0-63>]
```

Parameters:

- port: Port name. Default is set to all ports.
- unknown: Means the network policy for voice application is currently unknown. Default is known.
- tagged: Means the IEEE 802.1Q tagged frame format is used by voice application. Default is untagged.
- vlan: The VLAN ID (the range is from 1 to 4094). Default value is 0.
- priority: IEEE 802.1p Layer 2 Priority, also known as Class of Service(CoS). Default value is best-effort.
 - best-effort (0).
 - background (1).
 - excellent-effort (2).
 - critical-applications (3).
 - video (4).
 - voice (5).
 - internetwork-control (6).
 - network-control (7).
- dscp: DSCP value to be advertised for the given network policy (the range is from 0 to 63). Default value is 0.

Note: The configuration cannot be removed after it is configured.

The example below sets the LLDP-MED policy for the voice VLAN to port Ethernet27, vlan 100 tagged, network policy unknown, priority voice, and dscp 46.

Example

```
sudo config lldp med policy voice --port Ethernet27 --vlan 100 --tagged --unknown --priority voice --dscp 46
```

config lldp med power

These commands are used to configure the LLDP-MED PoE-MDI TLV advertised on a given port or all ports.

The following command is used to configure LLDP-MED PoE-MDI TLV of power providers.

Usage

```
config lldp med power --power-type pse --source (primary | backup) --priority (unknown | critical | high | low) --value <milliwatts> [--port <port-name>]
```

The following command is used to configure LLDP-MED PoE-MDI TLV of power consumers.

Usage

```
config lldp med power --power-type pd --source (pse | local | both) --priority (unknown | critical | high | low) --value <milliwatts> [--port <port-name>]
```

Parameters:

- source: Power source.
 - primary : Primary power source.
 - backup : Backup power source.
 - pse: power source equipment.
 - local : Local power.
 - both : Both pse and local .
- priority : Power priority.
 - unknown
 - critical
 - High
 - low
- value : Total power in milliwatts required by the PD device or available by the PSE device. It shall be divisible by 100.
- port : Port name. Default is set to all ports.

Note: The configuration cannot be removed after it is configured.

The example below sets LLDP-MED PoE-MDI to port Ethernet27, power-type pse, source primary, priority high, and available power 4000 milliwatts.

Example

```
sudo config lldp med power --port Ethernet27 --power-type pse --source primary --priority high --value 4000
```

config lldp dot3 power

These commands are used to configure LLDP Dot3 PoE-MDI TLV for a given port or for all ports.

The following command is used to configure LLDP Dot3 PoE-MDI TLV of power providers.

Usage

```
config lldp dot3 power --power-type pse <--power-pairs (signal | spare)> [--port <port-name>] [--supported] [--
```

```
enabled] [--pair-control] [--power-class <0-4>] [--dot3-type (1 | 2) --source (primary | backup) --priority (unknown | critical | high | low) --requested <milliwatts> --allocated <milliwatts> ]
```

The following command is used to configure LLDP Dot3 PoE-MDI TLV of power consumers.

Usage

```
config lldp dot3 power --power-type pd <--power-pairs (signal | spare)> [--port <port-name>] [--supported] [--enabled] [--pair-control] [--power-class <0-4>] [--dot3-type (1 | 2) --source (pse | local | both) --priority (unknown | critical | high | low) --requested <milliwatts> <--allocated <milliwatts> ]
```

Parameters:

- power-pairs : Power pairs.
 - signal : Signal pair.
 - spare: Spare pair.
- port : Port name. Default is set to all ports.
- supported : Means MDI power is supported on the given port, otherwise default is not supported.
- enabled : Means MDI power is enabled, otherwise the default is disabled.
- pair-control : Means pair selection can be controlled, otherwise the default is cannot be controlled.
- power-class : Power class (the range is from 0 to 4).
- dot3-type : Type of 802.3.
 - 1 : Type 1, IEEE802.3af.
 - 2 : Type 2, IEEE802.3at.
- source: Power source.
 - primary : Primary power source.
 - backup : Backup power source.
 - pse: Power source equipment.
 - local : Local power.
 - both : Both pse and local .
- priority : Power priority.
 - unknown
 - critical
 - high
 - low

- requested : Requested power in milliwatts. It shall be divisible by 100.
- allocated : Allocated power in milliwatts. It shall be divisible by 100.

Note: The configuration cannot be removed after it is configured.

The example below sets LLDP Dot3 PoE-MDI to port Ethernet27, power-type pse, power pairs signal, power class 3, MDI power supported and enabled, 802.3at type 1, source backup, priority critical, requested 10000 milliwatts, and allocated 10000 milliwatts.

Example

```
sudo config lldp dot3 power --port Ethernet27 --power-type pse --power-pairs signal --power-class 3 --supported --enabled --dot3-type 1 --source backup --priority critical --requested 10000 --allocated 10000
```

config lldp global hello_timer

The command is used to configure the transmission frequency of LLDP PDU updates in seconds. The range is 5 to 65534 seconds.

Usage

```
config lldp global hello_timer <seconds>
```

Example

```
sudo config lldp global hello_timer 10
```

config lldp global management_ip

The command is used to configure the management address to be advertised in LLDP PDUs.

Usage

```
config lldp global management_ip <ip_str>
```

Example

```
sudo config lldp global management_ip 192.168.1.1
```

config lldp global system_description

The command is used to configure the system description to be advertised in LLDP PDUs.

Usage

```
config lldp global system_description <desc>
```

Example

```
sudo config lldp global system_description "Networks"
```

config lldp global system_name

The command is used to configure the system name to be advertised in LLDP PDUs.

Usage

```
config lldp global system_name <name>
```

Example

```
sudo config lldp global system_name "SONiC DUT"
```

25 Management VRF

Table of Contents

[Management VRF Show Commands](#)

[show mgmt-vrf](#)

[show mgmt-vrf routes](#)

[show management_interface address](#)

[Management VRF Config Commands](#)

[config vrf add mgmt](#)

[config vrf del mgmt](#)

[config in-band-mgmt](#)

Management Virtual Routing and Forwarding (VRF) supports a separate routing table for management traffic that is forwarded by out-of-band management ports on a switch. This enables management traffic to be routed across a management network and still remain secure and separate from network data traffic.

Management VRF Show Commands

show mgmt-vrf

This command displays whether the management VRF and in-band management VRF are enabled or disabled. It also displays the details about the links (eth0, mgmt, lo-m, L3 interface) that are related to the management VRF.

Usage

```
show mgmt-vrf
```

Example

```
admin@sonic:~$ show mgmt-vrf
ManagementVRF : Enabled
In-band ManagementVRF : Enabled
Management VRF interfaces in Linux:
348: mgmt: <NOARP,MASTER,UP,LOWER_UP> mtu 65536 qdisc noqueue state UP mode DEFAULT group default
qlen 1000
    link/ether f2:2a:d9:bc:e8:f0 brd ff:ff:ff:ff:ff:ff
2: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc mq master mgmt state UP mode DEFAULT
group
default qlen 1000
    link/ether 4c:76:25:f4:f9:f3 brd ff:ff:ff:ff:ff:ff
66: Ethernet104: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 9100 qdisc pfifo_fast master mgmt state UP
mode
DEFAULT group default qlen 1000
    link/ether 4c:76:25:f4:f9:f3 brd ff:ff:ff:ff:ff:ff
350: lo-m: <BROADCAST,NOARP,UP,LOWER_UP> mtu 1500 qdisc noqueue master mgmt state UNKNOWN mode
DEFAULT
group default qlen 1000
    link/ether b2:4c:c6:f3:e9:92 brd ff:ff:ff:ff:ff:ff
NOTE: The management interface "eth0" shows the "master" as "mgmt" since it is part of management VRF.
```

show mgmt-vrf routes

This command displays the routes that are present in the management VRF routing table.

Usage

```
show mgmt-vrf routes
```

Example

```
admin@sonic:~$ show mgmt-vrf
```

```
ManagementVRF : Enabled
```

```
In-band ManagementVRF : Enabled
```

Management VRF interfaces in Linux:

```
348: mgmt: <NOARP,MASTER,UP,LOWER_UP> mtu 65536 qdisc noqueue state UP mode DEFAULT group default
qlen 1000
```

```
link/ether f2:2a:d9:bc:e8:f0 brd ff:ff:ff:ff:ff:ff
```

```
2: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc mq master mgmt state UP mode DEFAULT
group
```

```
default qlen 1000
```

```
link/ether 4c:76:25:f4:f9:f3 brd ff:ff:ff:ff:ff:ff
```

```
66: Ethernet104: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 9100 qdisc pfifo_fast master mgmt state UP
mode
```

```
DEFAULT group default qlen 1000
```

```
link/ether 4c:76:25:f4:f9:f3 brd ff:ff:ff:ff:ff:ff
```

```
350: lo-m: <BROADCAST,NOARP,UP,LOWER_UP> mtu 1500 qdisc noqueue master mgmt state UNKNOWN mode
DEFAULT
```

```
group default qlen 1000
```

```
link/ether b2:4c:c6:f3:e9:92 brd ff:ff:ff:ff:ff:ff
```

NOTE: The management interface "eth0" shows the "master" as "mgmt" since it is part of management VRF.

show management_interface address

This command displays the IP addresses configured for the management interface "eth0" and the management network default gateway.

Usage

```
show management_interface address
```

Example

```
admin@sonic:~$ show management_interface address
Management IP address = 10.16.210.75/24
Management NetWork Default Gateway = 10.16.210.254
Management IP address = FC00:2::32/64
Management Network Default Gateway = fc00:2::1
```

Management VRF Config Commands

config vrf add mgmt

This command enables the management VRF in the system. This command restarts the "interfaces-config" service, which in turn regenerates the /etc/network/interfaces file and restarts the "networking" service. This creates a new interface and l3mdev CGROUP with the name as "mgmt" and enslaves the management interface "eth0" into this master interface "mgmt".

Note that the VRFName "mgmt" (or "management") is reserved for the management VRF. That is, data VRFs should not use these reserved VRF names.

Usage
<code>config vrf add mgmt</code>

Example
<code>admin@sonic:~\$ sudo config vrf add mgmt</code>

config vrf del mgmt

This command disables the management VRF in the system. This command restarts the "interfaces-config" service, which in turn regenerates the /etc/network/interfaces file and restarts the "networking" service. This deletes the interface "mgmt" and deletes the l3mdev CGROUP named "mgmt" and puts back the management interface "eth0" into the default VRF.

Note that the VRFName "mgmt" (or "management") is reserved for the management VRF. That is, data VRFs should not use these reserved VRF names.

Usage
<code>config vrf del mgmt</code>

Example:
<code>admin@sonic:~\$ sudo config vrf del mgmt</code>

config in-band-mgmt

This command is used to enable or disable the in-band management VRF in the system. Globally, in-band management VRF is disabled by default.

Usage
config in-band-mgmt <enable disable>

Example
admin@sonic:~\$ sudo config in-band-mgmt enable

26 MC LAG

Table of Contents

[MCLAG show commands](#)

[show mclag brief](#)

[show mclag interface](#)

[show mclag unique ip](#)

[MCLAG Configuration Commands](#)

[config mclag add/del](#)
[config mclag member add/del](#)
[config mclag unique-ip add/del](#)
[config mclag keepalive-interval](#)
[config mclag session-timeout](#)

This section explains all the MCLAG (Multi-Chassis Link Aggregation Group) commands that are supported in SONiC.

MCLAG show commands

show mclag brief

This command displays brief information about an MCLAG domain.

Usage

```
show mclag brief
```

Example

```
admin@sonic:~$ show mclag brief
```

```

Domain ID           : 5
Role                : Active
Session Status      : Up
Peer Link Status    : Up
Source Address      : 192.168.1.1
Peer Address        : 192.168.1.2
Peer Link           : PortChannel30
Keepalive Interval  : 1 secs
Session Timeout     : 15 secs
System MAC          : b8:6a:97:73:6c:96

```

Number of MCLAG Interfaces : 2

MCLAG Interface	Local/Remote Status
PortChannel50	Up/Up
PortChannel60	Up/Up

show mclag interface

This command displays interface information in an MCLAG domain.

Usage

```
show mclag interface <domain-id> <portchannel-name>
```

Example

```
admin@sonic:~$ show mclag interface 5 PortChannel50
```

Local/Remote Status	: Up/Up
IsolateWithPeerLink	: Yes

show mclag unique ip

This command displays the unique IP status.

Usage

```
show mclag unique-ip
```

Example

```
admin@sonic:~$ show mclag unique-ip
```

Unique IP: : Vlan200, Vlan300

MCLAG Configuration Commands

In this section, it describes how to configure a MCLAG domain, add MCLAG member, enable/disable unique IP, and configure timer for keep-alive and session timeout.

config mclag add/del

Use this command to configure MCLAG domain attributes.

Usage

```
config mclag {add | del} <domain-id> <local-ip-addr> <peer-ip-addr> [<peer-ifname>]
```

Parameters:

- domain-id - MCLAG node's unique domain ID; this domain-id should be the same as peer node.
- local-ip-addr - MCLAG node's local IPv4 address
- peer-ip-addr - MCLAG node's peer IPv4 address
- peer-ifname - MCLAG peer interface name; optional for L3 MCLAG, mandatory for L2 MCLAG config

Example

```
admin@sonic:~$ sudo config mclag add 5 192.168.1.1 192.168.1.2 PortChannel30
```

config mclag member add/del

Use this command to configure a domain's MCLAG interfaces.

Usage

```
config mclag member {add | del} <domain-id> <portchannel-name>
```

Note:

- MCLAG interfaces can be only portchannel.

Example

```
admin@sonic:~$ sudo config mclag member add 5 PortChannel50
```

config mclag unique-ip add/del

Use this command to configure the unique IP status on a specified VLAN. User may enable (or disable) unique IP on different VLANs but this configuration should be the same in both active node and standby node. When the unique IP of a VLAN is enabled, active node and standby node should use different IP addresses, that is, the assigned IP address of active node and standby node on the VLAN cannot be the same.

Usage

```
config mclag unique-ip {add | del} <Vlan-interface>n
```

Parameter:

- add - enable unique IP on the VLAN. After enabled, the active node and standby node should not assign the same IP address on the VLAN.
- del - disable unique IP on the VLAN. After disabled, the active node and standby node share the same IP address on the VLAN. Vlan-interface - VLAN interface for which a unique IP can be configured.

Before applying this command, please make sure

- The MCLAG Domain should be created.
- VLAN interface should not be bound to VRF.
- There are not any IP address on VLAN interface.

Note, this restriction is derived from following user scenario

- when enabling (or disabling) the unique IP on a VLAN, the IP address should be re-assigned after the command executed.
- the IP address re-assignment should be manually configured by user. This command would not automatically clean (or assign) the IP address.

- as the IP address is re-assigned, the routing tables of VRF should be not referred any more.
- Due to the re-assignment is manually, the command will check the MCLAG domain, IP assignment, and bound on VRF before execution.

Example

```
admin@sonic:~$ sudo config mclag unique-ip add Vlan200
```

config mclag keepalive-interval

Use this command to configure keep-alive timer.

Usage

```
config mclag keepalive-interval <domain-id> <keepalive-timer-val>
```

Note

- keepalive-timer-val - keepalive-timer in the range of 1 to 60 seconds with default value of 1 seconds.
- session-timeout should be at least greater than 3 times keepalive-timer value.

Example

```
admin@sonic:~$ sudo config mclag keepalive-interval 5 5
```

config mclag session-timeout

Use this command to configure session timeout.

Usage

```
config mclag session-timeout <domain_id> <time_in_secs>
```

Note:

- time_in_secs - session-timeout in the range of 3 to 3600 seconds with default value of 15 seconds

- session-timeout should be at least greater than 3 times keepalive-timer value.

Example

```
admin@sonic:~$ sudo config mclag session-timeout 5 20
```

27 Mirroring

Table of Contents

[Mirroring Show Commands](#)

[show mirror_session](#)

[Mirroring Configuration Commands](#)

[config mirror_session add](#)

[config mirror_session span add](#)

[config mirror_session remove](#)

Mirroring Show Commands

show mirror_session

The command `show mirror_session` displays all the mirror sessions that are configured.

Example

```
admin@sonic:~$ show mirror_session
```

ERSPAN Sessions

Name	Status	SRC IP	DST IP	GRE	DSCP	TTL	Queue	Policer	Monitor Port	SRC Port	Direction
mrr_legacy	inactive	1.2.3.4	20.21.22.23	0x88be	8	100	UC0				

SPAN Sessions

Name	Status	DST Port	SRC Port	Direction	Queue	Policer
mrr_port0	active	Ethernet0	PortChannel10	rx		

Mirroring Configuration Commands

config mirror_session add

The command `config mirror_session add` is used to add mirroring sessions. A mirror session is identified by a "session_name".

This command supports configuring both Switch Port Analyzer (SPAN) and Encapsulated Remote SPAN (ERSPAN) sessions. For a SPAN session, you can configure mirroring for a list of source ports/LAG to a destination port in ingress, egress, or both directions. For an ERSPAN session, you can configure mirroring for a list of source ports/LAG to a destination IP. Both SPAN/ERSPAN support ACL-based mirroring and can be used in ACL configurations.

The ERSPAN mirror session below command is used to create ERSPAN mirror session

Usage

```
config mirror_session erspan add <session-name> <src_ip> <dst_ip> <dscp> <ttl> [gre_type] [queue] [src_port]
[direction] [--policer policer_name>]
```

or

Usage (backward compatible, to be deprecated)

```
config mirror_session add <session_name> <src_ip> <dst_ip> <dscp> <ttl> [gre_type] [queue]
```

ERSPAN mirror session Parameters:

1. Session name
2. Source IP address
3. Destination IP address
4. DSCP (QoS) value with which mirrored packets are forwarded
5. TTL value
6. Optional - GRE type in a GRE tunnel packet. The default value is 0x88be. Valid values are:
 - a. 0x88be: ERSPAN Type I.
 - b. 0x22eb: ERSPAN Type III (Only support on Intel devices).
 - c. 0x8949: AS9746-128D supports this value only.
7. Optional - Queue in which packets shall be sent out of the device. The default value is 0. Only support to change the value on Intel devices. Valid values are 0..7.
8. Optional - List of source ports that can have both Ethernet and LAG ports.
9. Optional - Direction - Mirror session direction when configured along with source port. (Supported rx/tx/both. default direction is both.)
10. Optional - Policer that will be used to control the rate at which frames are mirrored. (refer [Policer](#))

The example below shows how to create an ERSPAN session with name mrr_legacy, source address 1.2.3.4, destination address 20.21.2.2.23, DSCP 8, TTL 100, and GRE-type 0x88be.

Example1

```
admin@sonic:~# config mirror_session add mrr_legacy 1.2.3.4 20.21.22.23 8 100 0x88be 0
admin@sonic:~# show mirror_session
```

ERSPAN Sessions

Name	Status	SRC IP	DST IP	GRE	DSCP	TTL	Queue	Policer	Monitor Port	SRC Port	Direction
mrr_legacy	inactive	1.2.3.4	20.21.22.23	0x88be	8	100	UC0				

SPAN Sessions

Name	Status	DST Port	SRC Port	Direction	Queue	Policer
------	--------	----------	----------	-----------	-------	---------

```
admin@sonic:~#
```

The example below shows how to create an ERSPAN session with name mrr_abcd, source address 1.2.3.4, destination address 20.21.22. 23, DSCP 8, TTL 100, and GRE-type 0x88be.

Example2

```
admin@sonic:~# config mirror_session erspan add mrr_abcd 1.2.3.4 20.21.22.23 8 100 0x88be 0
admin@sonic:~# show mirror_session
```

ERSPAN Sessions

Name	Status	SRC IP	DST IP	GRE	DSCP	TTL	Queue	Policer	Monitor Port	SRC Port	Direction
mrr_abcd	inactive	1.2.3.4	20.21.22.23	0x88be	8	100	UC0				

SPAN Sessions

Name	Status	DST Port	SRC Port	Direction	Queue	Policer
------	--------	----------	----------	-----------	-------	---------

```
admin@sonic:~#
```

The example below shows how to create an ERSPAN session with name mrr_port, source address [1.2.3.4](#), destination address 20.21.22. 23, DSCP 8, TTL 100, GRE-type 0x88be, and source port Ethernet0.

Example3

```
admin@sonic:~# config mirror_session erspan add mrr_port 1.2.3.4 20.21.22.23 8 100 0x88be 0 Ethernet0
```

```
admin@sonic:~# show mirror_session
```

ERSPAN Sessions

Name	Status	SRC IP	DST IP	GRE	DSCP	TTL	Queue	Policer	Monitor Port	SRC Port	Direction
mrr_port	inactive	1.2.3.4	20.21.22.23	0x88be	8	100	UC0		Ethernet0	both	

SPAN Sessions

Name	Status	DST Port	SRC Port	Direction	Queue	Policer

```
admin@sonic:~#
```

config mirror_session span add

The command is used to create a SPAN mirror session

Usage

```
config mirror_session span add <session_name> <dst_port> [src_port] [direction] [queue] [--policer <policer_name>]
```

SPAN mirror session parameters are:

1. Session name
2. Destination port
3. Optional - List of source ports- List of source ports that can have both Ethernet and LAG ports.
4. Optional - Direction - Mirror session direction when configured along with source port. (Supported rx/tx/both. Default direction is both.)

5. Optional - Queue in which packets shall be sent out of the device. The default value is 0. Only support to change the value on Intel devices. Valid values are 0..7.

6. Optional - Policer that will be used to control the rate at which frames are mirrored.

The example below shows how to create a SPAN session with name mrr_port0, destination port Ethernet0 and source ports Ethernet4, PortChannel10,Ethernet8.

Example

```
admin@sonic:~# config mirror_session span add mrr_port0 Ethernet0 Ethernet4,PortChannel10,Ethernet8
admin@sonic:~# show mirror_session
```

ERSPAN Sessions											
Name	Status	SRC IP	DST IP	GRE	DSCP	TTL	Queue	Policer	Monitor Port	SRC Port	Direction

SPAN Sessions						
Name	Status	DST Port	SRC Port	Direction	Queue	Policer

mrr_port0	active	Ethernet0	Ethernet4,PortChannel10,Ethernet8	both		UC0

```
admin@sonic:~#
```

config mirror_session remove

The command shown below is used to remove the existing mirroring sessions and requires a parameter named session name.

Usage

```
config mirror_session remove <session-name>
```

The below example shows how to remove a mirror session with session name mrr_port0.

Example

```
admin@sonic:~# show mirror_session
```

```
ERSPAN Sessions
```

Name	Status	SRC IP	DST IP	GRE	DSCP	TTL	Queue	Policer	Monitor Port	SRC Port	Direction
------	--------	--------	--------	-----	------	-----	-------	---------	--------------	----------	-----------

```
SPAN Sessions
```

Name	Status	DST Port	SRC Port	Direction	Queue	Policer
------	--------	----------	----------	-----------	-------	---------

mrr_port0	active	Ethernet0	Ethernet4,PortChannel10,Ethernet8	both		UC0
-----------	--------	-----------	-----------------------------------	------	--	-----

```
admin@sonic:~# config mirror_session remove mrr_port0
```

```
admin@sonic:~# show mirror_session
```

```
ERSPAN Sessions
```

Name	Status	SRC IP	DST IP	GRE	DSCP	TTL	Queue	Policer	Monitor Port	SRC Port
------	--------	--------	--------	-----	------	-----	-------	---------	--------------	----------

```
Direction
```

```
SPAN Sessions
```

Name	Status	DST Port	SRC Port	Direction	Queue	Policer
------	--------	----------	----------	-----------	-------	---------

28 NAT

Table of Contents

[NAT Show Commands](#)

[show nat config](#)

[show nat statistics](#)

[show nat translations](#)

[NAT Configuration Commands](#)

[config nat add static](#)

[config nat add pool](#)

[config nat add binding](#)

[config nat add interface](#)

[config nat set](#)

[config nat feature](#)

[NAT Clear Commands](#)

[sonic-clear nat translations](#)

[sonic-clear nat statistics](#)

Network Address Translation (NAT) is a standard method of mapping "internal" (private) network IP addresses to "external"(public) IP address on devices at the edge of a network. Typically, NAT not only translates the inbound and outbound IP addresses of network traffic, but also Layer 4 ports. This allows multiple internal IP addresses to "share" one public external IP address and also provides a level of security for private network hosts that remain "hidden" from the public network.

NAT Show Commands

show nat config

This command displays the NAT configuration.

Usage

```
show nat config [static | pool | bindings | globalvalues | zones]
```

With no optional arguments, the whole NAT configuration is displayed.

Example

```
admin@sonic:~$ show nat config static
```

Nat Type	IP Protocol	Global IP	Global L4 Port	Local IP	Local L4 Port	Twice-Nat Id
dnat	all	65.55.45.5	---	10.0.0.1	---	---
dnat	all	65.55.45.6	---	10.0.0.2	---	---
dnat	tcp	65.55.45.7	2000	20.0.0.1	4500	1
snat	tcp	20.0.0.2	4000	65.55.45.8	1030	1

```
admin@sonic:~$ show nat config pool
```

Pool Name	Global IP Range	Global L4 Port Range
Pool1	65.55.45.5	1024-65535
Pool2	65.55.45.6-65.55.45.8	---
Pool3	65.55.45.10-65.55.45.15	500-1000

```
admin@sonic:~$ show nat config bindings
```

Binding Name	Pool Name	Access-List	Nat Type	Twice-Nat Id
Bind1	Pool1	---	snat	---
Bind2	Pool2	1	snat	1
Bind3	Pool3	2	snat	--

```
admin@sonic:~$ show nat config globalvalues
```

```
Admin Mode : enabled
Global Timeout : 600 secs
TCP Timeout : 86400 secs
UDP Timeout : 300 secs
```

```
admin@sonic:~$ show nat config zones
```

Port	Zone
---	---

Ethernet2 0

Vlan100 1

show nat statistics

This command displays the NAT translation statistics for each entry.

Usage

```
show nat statistics
```

Example

```
admin@sonic:~$ show nat statistics
```

Protocol	Source	Destination	Packets	Bytes
all	10.0.0.1	--	802	1009280
all	10.0.0.2	--	23	5590
tcp	20.0.0.1:4500	--	110	12460
udp	20.0.0.1:4000	--	1156	789028
tcp	20.0.0.1:6000	--	30	34800
tcp	20.0.0.1:5000	65.55.42.1:2000	128	110204
tcp	20.0.0.1:5500	65.55.42.1:2000	8	3806

show nat translations

This command displays the NAT translation entries.

Usage

```
show nat translations [count]
```

Giving the optional count argument displays only the details about the number of translation entries.

Example

```
admin@sonic:~$ show nat translations
```

```
Static NAT Entries ..... 4
```

```
Static NAPT Entries ..... 2
```

```
Dynamic NAT Entries ..... 0
```

```
Dynamic NAPT Entries ..... 4
```

```
Static Twice NAT Entries ..... 0
```

```
Static Twice NAPT Entries ..... 4
```

```
Dynamic Twice NAT Entries ..... 0
```

```
Dynamic Twice NAPT Entries ..... 0
```

```
Total SNAT/SNAPT Entries ..... 9
```

```
Total DNAT/DNAPT Entries ..... 9
```

```
Total Entries ..... 14
```

```
Protocol Source      Destination    Translated Source Translated Destination
```

```
-----
```

```
all 10.0.0.1 -- 65.55.42.2 --
```

```
all -- 65.55.42.2 -- 10.0.0.1
```

```
all 10.0.0.2 -- 65.55.42.3 --
```

```
all -- 65.55.42.3 -- 10.0.0.2
```

```
tcp 20.0.0.1:4500 -- 65.55.42.1:2000 --
```

```
tcp -- 65.55.42.1:2000 -- 20.0.0.1:4500
```

```
udp 20.0.0.1:4000 -- 65.55.42.1:1030 --
```

```
udp -- 65.55.42.1:1030 -- 20.0.0.1:4000
```

```
tcp 20.0.0.1:6000 -- 65.55.42.1:1024 --
```

```
tcp -- 65.55.42.1:1024 -- 20.0.0.1:6000
```

```
tcp 20.0.0.1:5000 65.55.42.1:2000 65.55.42.1:1025 20.0.0.1:4500
```

```

tcp    20.0.0.1:4500  65.55.42.1:1025  65.55.42.1:2000  20.0.0.1:5000
tcp    20.0.0.1:5500  65.55.42.1:2000  65.55.42.1:1026  20.0.0.1:4500
tcp    20.0.0.1:4500  65.55.42.1:1026  65.55.42.1:2000  20.0.0.1:5500
admin@sonic:~$ show nat translations count
Static NAT Entries      ..... 4
Static NAPT Entries     ..... 2
Dynamic NAT Entries     ..... 0
Dynamic NAPT Entries    ..... 4
Static Twice NAT Entries ..... 0
Static Twice NAPT Entries ..... 4
Dynamic Twice NAT Entries ..... 0
Dynamic Twice NAPT Entries ..... 0
Total SNAT/SNAPT Entries ..... 9
Total DNAT/DNAPT Entries ..... 9
Total Entries           ..... 14

```

NAT Configuration Commands

config nat add static

This command adds a static NAT or NAPT entry. When configuring a static NAT entry, you have to specify the following fields with these "basic" keywords.

1. Global IP address,
2. Local IP address,
3. NAT type (snat / dnat) to be applied on the Global IP address. Default value is dnat. This is an optional argument.
4. Twice NAT Id. This is an optional argument used in the case of twice NAT configuration.

When configuring a static NAPT entry, you have to specify the following fields.

1. IP protocol type (tcp / udp)
2. Global IP address + Port
3. Local IP address + Port
4. NAT type (snat / dnat) to be applied on the Global IP address + Port. Default value is dnat. This is an optional argument.
5. Twice NAT Id. This is an optional argument used in the case of twice NAT configuration.

Usage

```
config nat add static (basic <global-ip> <local-ip> | (tcp | udp) <global-ip> <global-port> <local-ip> <local-port>) [-nat_type (snat | dnat)] [-twice_nat_id <value>]
```

To delete a static NAT or NAPT entry, use the command below. Giving the all argument deletes all the configured static NAT and NAPT entries.

Usage

```
config nat remove static (basic <global-ip> <local-ip> | (tcp | udp) <global-ip> <global-port> <local-ip> <local-port> | all)
```

Example

```
admin@sonic:~$ sudo config nat add static basic 65.55.45.1 12.12.12.14 -nat_type dnat
admin@sonic:~$ sudo config nat add static tcp 65.55.45.2 100 12.12.12.15 200 -nat_type dnat
admin@sonic:~$ show nat translations
Static NAT Entries      ..... 2
Static NAPT Entries     ..... 2
Dynamic NAT Entries     ..... 0
```

```
Dynamic NAPT Entries ..... 0
Static Twice NAT Entries ..... 0
Static Twice NAPT Entries ..... 0
Dynamic Twice NAT Entries ..... 0
Dynamic Twice NAPT Entries ..... 0
Total SNAT/SNAPT Entries ..... 2
Total DNAT/DNAPT Entries ..... 2
Total Entries ..... 4
Protocol Source      Destination    Translated Source  Translated Destination
-----
all  12.12.12.14  --      65.55.42.1  --
all  --      65.55.42.1  --      12.12.12.14
tcp  12.12.12.15:200 --      65.55.42.2:100 --
tcp  --      65.55.42.2:100 --      12.12.12.15:200
```

config nat add pool

This command creates a NAT pool used for dynamic source NAT or NAPT translations. The pool can be configured in one of the following combinations.

1. Global IP address range (or)
2. Global IP address + L4 port range (or)
3. Global IP address range + L4 port range.

Usage

```
config nat add pool <pool-name> <global-ip-range> <global-port-range>
```

To delete a NAT pool, use the following command. A pool cannot be removed if it is referenced by a NAT binding.

Using the `pools` argument removes all the configured pools.

Usage

```
config nat remove (pool <pool-name> | pools)
```

Example

```
admin@sonic:~$ sudo config nat add pool pool1 65.55.45.2-65.55.45.10
```

```
admin@sonic:~$ sudo config nat add pool pool2 65.55.45.3 100-1024
```

```
admin@sonic:~$ show nat config pool
```

Pool Name	Global IP Range	Global Port Range
pool1	65.55.45.2-65.55.45.10	---
pool2	65.55.45.3	100-1024

config nat add binding

This command creates a NAT binding between a pool and an ACL. The following fields are needed for configuring the binding.

1. ACL is an optional argument. If an ACL argument is not given, the NAT binding is applicable to match all traffic.
2. NAT type is an optional argument. Only DNAT type is supported for binding.
3. Twice NAT Id is an optional argument. This ID is used to form a twice NAT grouping with the static NAT/NAPT entry configured with the same ID.

Usage

```
config nat add binding <binding-name> [<pool-name>] [<acl-name>] [-nat_type (snat | dnat)] [-twice_nat_id
```

<value>]

To delete a NAT binding, use the following command.

Usage

```
config nat remove (binding <binding-name> | bindings)
```

Example

```
admin@sonic:~$ sudo config nat add binding bind1 pool1 acl1
```

config nat add interface

This command is used to configure a NAT zone on an L3 interface. The default value of a NAT zone on an L3 interface is 0. The valid range of zone values is 0-3 (On Intel devices, the valid values are: 0, 1).

Usage

```
config nat add interface <interface-name> -nat_zone <value>
```

To reset the NAT zone on an interface, use the command below. Using the `interfaces` argument resets the NAT zone on all L3 interfaces to 0.

Usage

```
config nat remove (interface <interface-name> | interfaces)
```

Example:

```
admin@sonic:~$ sudo config nat add interface Ethernet28 -nat_zone 1
```

```
admin@sonic:~$ show nat config zones
```

Port	Zone
Ethernet0	0
Ethernet28	1
Ethernet22	0
Vlan2091	0

config nat set

This command is used to set NAT timeout values. Different timeout values can be configured for the NAT entry timeout, NAPT TCP entry timeout, and NAPT UDP entry timeout. The range for the Global NAT entry timeout is 300 sec to 432000 sec, the default value is 600 sec. The range for the TCP NAT/NAPT entry timeout is 300 sec to 432000 sec, the default value is 86400 sec. The range for the UDP NAT/NAPT entry timeout is 120 sec to 600 sec, the default value is 300 sec.

Usage

```
config nat set (tcp-timeout <value> | timeout <value> | udp-timeout <value>)
```

To reset the timeout values to the default values, use the following command.

Usage

```
config nat reset (tcp-timeout | timeout | udp-timeout)
```

Example

```
admin@sonic:~$ sudo config nat add set tcp-timeout 3600
admin@sonic:~$ show nat config globalvalues
Admin Mode    : enabled
Global Timeout : 600 secs
TCP Timeout   : 600 secs
UDP Timeout   : 300 secs
```

config nat feature

This command is used to enable or disable the NAT feature.

Usage

```
config nat feature (enable | disable)
```

Example

```
admin@sonic:~$ sudo config nat feature enable
admin@sonic:~$ sudo config nat feature disable
```

NAT Clear Commands

sonic-clear nat translations

This command is used to clear the dynamic NAT and NAPT translation entries.

Usage

sonic-clear nat translations

sonic-clear nat statistics

This command is used to clear the statistics of all NAT and NAPT entries.

Usage
sonic-clear nat statistics

29 NDP

[NDP Show Commands](#)

[show ndp](#)

[NDP Config Command](#)

[config vlan proxy_arp](#)

[config interface nd aging](#)

[config vlan nd_host_route](#)

NDP Show Commands

show ndp

This command displays the IPv6 neighbors.

Usage

```
show ndp [-if|--iface <interface_name>] <ipv6_address>
```

Example (all IPv6 neighbors)

```
admin@sonic:~$ show ndp
```

Address	MacAddress	Iface	Vlan	Status
fe80::20c:29ff:feb8:b11e	00:0c:29:b8:b1:1e	eth0	-	REACHABLE
fe80::20c:29ff:feb8:cf0	00:0c:29:b8:cf:f0	eth0	-	REACHABLE
fe80::20c:29ff:fef9:324	00:0c:29:f9:03:24	eth0	-	REACHABLE

Total number of entries 3

Example (a specific IPv6 neighbor)

```
admin@sonic:~$ show ndp fe80::20c:29ff:feb8:b11e
```

Address	MacAddress	Iface	Vlan	Status
fe80::20c:29ff:feb8:b11e	00:0c:29:b8:b1:1e	eth0	-	REACHABLE

Total number of entries 1

Example (a specific interface)

```
admin@sonic:~$ show ndp -if eth0
```

Address	MacAddress	Iface	Vlan	Status
-----	-----	-----	-----	-----
fe80::20c:29ff:feb8:b11e	00:0c:29:b8:b1:1e	eth0	-	REACHABLE
fe80::20c:29ff:feb8:cff0	00:0c:29:b8:cf:f0	eth0	-	REACHABLE
fe80::20c:29ff:feb9:324	00:0c:29:f9:03:24	eth0	-	REACHABLE
Total number of entries 3				

NDP Config Command

config vlan proxy_arp

Usage
config vlan proxy_arp < vid > { enabled disable }

Note:

Configuring NDP proxy will also configure NDP proxy. Currently, independent configuration of NDP proxy is not supported; it can only be configured through NDP proxy settings.

NDP proxy is disabled by default and can only be configured on VLAN interfaces.

Use **show vlan brief** to show the configuration.

Usage
admin@sonic:~\$ sudo config vlan proxy_arp 10 enabled

```
admin@sonic:~$ sudo config vlan proxy_arp 10 disabled
```

config interface nd aging

Usage

```
config interface nd aging <interface_name> <interface_nd_aging>
```

Parameter:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <interface_nd_aging>: The default ND aging time is 1800s, and the configuration range is 300~86400

Note:

- If you have already learned ND, configuring ND aging time will not take effect immediately. You need to wait for ND aging before the aging time configuration will take effect.
- Use **show interfaces nd** command, you can view **NDP** aging configuration information on the interface.

Usage

```
admin@sonic:~$ sudo config interface nd aging Vlan10 10000
```

config vlan nd_host_route

Usage

```
config vlan nd_host_route < vid > { enabled | disable }
```

Note:

- ND host routing is disabled by default and can only be configured on VLAN interfaces. ND to host routing converts ND to "K" type routing.
- Use **show interfaces nd** command, you can view ND nd_host_route configuration information on the interface.

Usage

```
admin@sonic:~$ sudo config vlan nd_host_route 10 enabled
admin@sonic:~$ sudo config vlan nd_host_route 10 disabled
```

30 NTP

NTP Show Commands

show ntp

This command displays a list of NTP peers known to the server as well as a summary of their state.

Usage
show ntp

Example
<pre>admin@sonic:~\$ show ntp synchronised to NTP server (204.2.134.164) at stratum 3 time correct to within 326797 ms polling server every 1024 s remote refid st t when poll reach delay offset jitter ===== 23.92.29.245 .XFAC. 16 u -1024 0 0.000 0.000 0.000 *204.2.134.164 46.233.231.73 2 u 916 1024 377 3.079 0.394 0.128</pre>

NTP Config Commands

This sub-section of commands is used to add or remove the configured NTP servers.

config ntp add

This command is used to add an NTP server IP address to the NTP server list. Note that more than one NTP server IP address can be added in the device.

Usage
config ntp add <ip_address>

Parameters:

- <ip_address>: NTP server's IP address, IPv4 or IPv6 address.
- When the NTP service is started, it listens on eth0 by default. This means that the NTP server must be accessible from eth0.

The following example shows how to add a NTP server.

Example

```
admin@sonic:~$ sudo config ntp add 9.9.9.9
NTP server 9.9.9.9 added to configuration
Restarting ntp-config service...
admin@sonic:~$ sudo config ntp add 2000::2
NTP server 2000::2 added to configuration
Restarting ntp-config service...
```

config ntp delete

This command is used to delete a configured NTP server IP address.

Usage

```
config ntp del <ip_address>
```

Parameters:

- <ip_address>: NTP server's IP address, IPv4 or IPv6 address.

The following example shows how to remove an NTP server.

Example

```
admin@sonic:~$ sudo config ntp del 9.9.9.9
NTP server 9.9.9.9 removed from configuration
Restarting ntp-config service...
```

30.1 NTP

Table of Contents

[NTP显示指令](#)

[show ntp](#)

[show ntp global](#)

[show ntp key](#)

[show ntp server](#)

[show runningconfiguration ntp](#)

[NTP配置指令](#)

[config ntp server add](#)

[config ntp del](#)

[config ntp server state](#)

[config ntp authentication](#)

[config ntp dhcp](#)

[config ntp key add](#)

[config ntp key del](#)

[config ntp server-role](#)

[config ntp source-ip set](#)

[config ntp source-ip unset](#)

[config ntp source-interface set](#)

[config ntp source-ip unset](#)

[config ntp state](#)

[config ntp vrf](#)

NTP display command

show ntp

This command displays a list of NTP peers known to the server and a summary of their status.

Usage

```
show ntp
```

Example

```
admin@sonic:~$ show ntp
synchronised to NTP server (204.2.134.164) at stratum 3
time correct to within 326797 ms
polling server every 1024 s
      remote      refid      st t when poll reach  delay  offset jitter
=====
23.92.29.245 .XFAC.      16 u  -1024  0  0.000  0.000  0.000
*204.2.134.164 46.233.231.73  2 u  916 1024 377  3.079  0.394  0.128
```

show ntp global

This command displays the global configuration information of server NTP.

Usage

```
show ntp global
```

Example

```
admin@sonic:~$ show ntp global
State: enabled
Authentication: disabled
VRF: default
DHCP: enabled
Server Role: enabled
```

show ntp key

This command displays the NTP key for server configuration.

Usage

show ntp key

Example

admin@sonic:~\$ show ntp key

KEY ID TYPE TRUSTED

1 md5 yes

show ntp server

This command displays the NTP server configured for the server

Usage

show ntp server

Example

admin@sonic:~\$ show ntp server

SERVER STATE TYPE KEY ID VERSION IBURST TRUSTED

1.1.1.1 enabled server 1 3 on

show runningconfiguration ntp

This command displays the NTP source interface, source IP, and NTP server configured for the server.

Usage

show runningconfiguration ntp

Example

```
admin@sonic:~$ show runningconfiguration ntp
NTP source-interface   : eth0
NTP source-ip         :
NTP Servers
-----
1.1.1.1
```

NTP configuration command

This command section is used to add or remove configured NTP servers.

config ntp server add

This command is used to add the NTP server IP address to the NTP server list.

Please note that multiple NTP server IP addresses can be added to the device.

Usage

```
config ntp server add <ip_address>
```

Parameters:

- <ip_address>: NTP server's IP address, IPv4 or IPv6 address.
- When the NTP service is started, it listens on eth0 by default. This means that the NTP server must be accessible from eth0.
- t: NTP server type server | pool, default is server
- k: ntp keyID
- v: ntpd version 3|4 , default NTPv4

The following example shows how to add a NTP server.

Example

```
admin@sonic:~$ sudo config ntp server add 9.9.9.9
NTP server 9.9.9.9 added to configuration
Restarting ntp-config service...
admin@sonic:~$ sudo config ntp server add 2000::2
NTP server 2000::2 added to configuration
Restarting ntp-config service...
admin@sonic:~$ sudo config ntp server add 1.1.1.1 -k 1 -v 3
NTP server 1.1.1.1 added to configuration
Restarting ntp-config service...
```

config ntp del

This command is used to delete the configured NTP server IP address.

Usage

```
config ntp server del <ip_address>
```

Parameters:

•<ip_address>: NTP server's IP address, IPv4 or IPv6 address.

The following example shows how to delete an NTP server.

Example

```
admin@sonic:~$ sudo config ntp server del 9.9.9.9
NTP server 9.9.9.9 removed from configuration
Restarting ntp-config service...
```

config ntp server state

This command is used to modify the parameters of an added NTP server.

Usage

```
config ntp server state <ntpserver_ip_address>
```

Parameters:

- disabled: Make the specified NTP server IP invalid.
- enabled: Make the specified NTP server IP effective.
- iburst: off|on, The default is on. When the NTP service is first started, multiple NTP messages will be sent to the NTP server to quickly synchronize the time
- key-id: ntp keyID
- trusted: trust the server yes|no ,
- version: ntpd version 3|4 , default NTPV4

The following example shows how to add an NTP server.

Example

```
admin@sonic:~$ sudo config ntp server state 1.1.1.1 disabled
Configure NTP server 1.1.1.1 disabled
admin@sonic:~$ sudo config ntp server state 1.1.1.1 enabled
Configure NTP server 1.1.1.1 enabled
admin@sonic:~$ sudo config ntp server state 1.1.1.1 iburst off
Configure NTP server 1.1.1.1 iburst off
admin@sonic:~$ sudo config ntp server state 1.1.1.1 iburst on
Configure NTP server 1.1.1.1 iburst on
admin@sonic:~$ sudo config ntp server state 1.1.1.1 trusted yes
Configure NTP server 1.1.1.1 trusted yes
admin@sonic:~$ sudo config ntp server state 1.1.1.1 trusted no
Configure NTP server 1.1.1.1 trusted no
admin@sonic:~$ sudo config ntp server state 1.1.1.1 version 3
Configure NTP server 1.1.1.1 version 3
admin@sonic:~$ sudo config ntp server state 1.1.1.1 version 4
```

```
Configure NTP server 1.1.1.1 version 4
admin@sonic:~$ sudo config ntp server state 1.1.1.1 key-id 1
Configure NTP server 1.1.1.1 key id 1
```

config ntp authentication

This command is used to enable/disable NTP authentication on the device.

Usage

```
config ntp server add [OPTIONS]
```

Parameters:

disabled : Disable NTP authentication, default disabled

enabled: Enable NTP authentication

Example

```
admin@sonic:~$ sudo config ntp authentication disabled
NTP authentication is already disabled.
root@sonic:/home/admin#
admin@sonic:~$ sudo config ntp authentication enabled
Restarting ntp-config service...
root@sonic:/home/admin#
```

config ntp dhcp

This command is used to enable/disable obtaining NTP servers from DHCP servers.

Usage

```
config ntp dhcp [OPTIONS]
```

Parameters:

disabled : Disable obtaining NTP server from DHCP server

enabled: Enable obtaining NTP server from DHCP server, default enabled

Example

```
admin@sonic:~$ sudo config ntp dhcp disabled
NTP authentication is already disabled.
root@sonic:/home/admin#
admin@sonic:~$ sudo config ntp dhcp enabled
Restarting ntp-config service...
root@sonic:/home/admin#
```

config ntp key add

This command is used to add NTP key.

Usage

```
config ntp key add <key_id> <key_value>
```

Parameters:

<key_id>: key id ,value 1-65535

<key_value>: Key string

--type:Encryption method, one of [md5 | sha1 | sha256 | sha384 | sha512]

--trusted :trust [yes|no]

Example

```
admin@sonic:~$ sudo config ntp key add 1 password --type md5 --trusted yes
NTP key 1 added to configuration
Restarting ntp-config service...
```

config ntp key del

This command is used to delete NTP key.

Usage
config ntp key del <key_id>

Parameters:

<key_id>: key id

Example
admin@sonic:~\$ sudo config ntp key del 1 NTP key 1 removed from configuration Restarting ntp-config service...

config ntp server-role

This command is used to enable/disable obtaining NTP servers from DHCP servers.

Usage
config ntp server-role [OPTIONS]

Parameters:

disabled : Disable the function of acting as an NTP server.

enabled: Enable the function of acting as an NTP server, which is enabled by default.

Example
admin@sonic:~\$ sudo config ntp server-role disabled NTP server_role is already disabled. root@sonic:/home/admin#

```
admin@sonic:~$ sudo config ntp dhcp enabled
Restarting ntp-config service...
root@sonic:/home/admin#
```

config ntp source-ip set

This command is used to configure NTP source IP.

Usage

```
config ntp source-ip set <ip_address>
```

Parameters:

- **<ip_address>**: IPv4 or IPv6 address on a certain interface.

Example

```
admin@sonic:~$ sudo config ntp source-ip set 80.1.1.4
Restarting ntp-config service...
```

config ntp source-ip unset

This command is used to unconfigure the NTP source IP.

Usage

```
config ntp source-ip unset <ip_address>
```

Parameters:

- **<ip_address>**: IPv4 or IPv6 address on a certain interface.

Example

```
admin@sonic:~$ sudo config ntp source-ip unset 80.1.1.4
Restarting ntp-config service...
```

config ntp source-interface set

This command is used to configure NTP source IP.

Usage

```
config ntp source-interface set <interface_name>
```

Parameters:

- <interface_name>: a certain interface.

Example

```
admin@sonic:~$ sudo config ntp source-interface set Loopback0
Restarting ntp-config service...
```

config ntp source-ip unset

This command is used to unconfigure the NTP source IP.

Usage

```
config ntp source-ip unset <interface_name>
```

Parameters:

- <interface_name>: a certain interface.

Example

```
admin@sonic:~$ sudo config ntp source-interface unset Loopback0
Restarting ntp-config service...
```

--

config ntp state

This command is used to turn on/off NTP.

Usage

```
config ntp state [disabled|enabled]
```

Parameters:

disabled : Disable NTP function.

enabled: Enable NTP function, default enabled.

Example

```
admin@sonic:~$ sudo config ntp state disabled
admin@sonic:~$ sudo config ntp state enabled
Restarting ntp-config service...
```

config ntp vrf

This command is used to configure ntp vrf.

Usage

```
config ntp state [default|mgmt]
```

Parameters:

default:

mgmt:

Example

```
admin@sonic:~$ sudo config ntp vrf default
admin@sonic:~$ sudo config ntp vrf mgmt
```

Restarting ntp-config service...

31 PFC

Table of Contents

[PFC Show commands](#)

- [show pfc asymmetric](#)
- [show pfc priority](#)
- [show pfc counters](#)
- [show qos pfc-priority-queue](#)
- [show interface pfc config](#)

[PFC Configuration Commands](#)

- [config interface pfc asymmetric](#)
- [config interface pfc priority](#)
- [config qos pfc-priority-queue add](#)
- [config qos pfc-priority-queue update](#)
- [config qos pfc-priority-queue del](#)
- [config interface qos pfc-priority-queue bind](#)
- [config interface qos pfc-priority-queue unbind](#)

[PFC Clear Commands](#)

- [sonic-clear pfccounters](#)

PFC Show commands

show pfc asymmetric

This command displays the status of asymmetric PFC for all interfaces or a given interface.

Usage

```
show pfc asymmetric [<interface>]
```

Example: Show on factory default

```
admin@sonic:~$ show pfc asymmetric
```

```
Interface  Asymmetric
```

```
-----
```

```
Ethernet0  N/A
```

```
Ethernet4  N/A
```

Note: The factory default of asymmetric PFC is disabled and show as N/A.

Example: Show after configured

```
admin@sonic:~$ show pfc asymmetric
```

```
Interface  Asymmetric
```

```
-----
```

```
Ethernet0  on
```

```
Ethernet2  off
```

```
Ethernet4  off
```

```
Ethernet6  off
```

```
Ethernet8  off
```

```
Ethernet10 off
```

```
Ethernet12 off
```

```
Ethernet14 off
```

Example: Show on specify interface

```
admin@sonic:~$ show pfc asymmetric Ethernet0
```

```
Interface Asymmetric
```

```
-----
```

```
Ethernet0 off
```

show pfc priority

This command displays the lossless priorities for all interfaces or a given interface.

Usage

```
show pfc priority [<interface>]
```

Example

```
admin@sonic:~$ show pfc priority
```

```
Interface Lossless priorities
```

```
-----
```

```
Ethernet0 3,4
```

```
Ethernet2 3,4
```

```
Ethernet8 3,4
```

```
Ethernet10
```

```
Ethernet16 3,4
```

Example

```
admin@sonic:~$ show pfc priority Ethernet0
Interface  Lossless priorities
-----
Ethernet0  3,4
```

show pfc counters

This command displays the details of Rx and Tx priority-flow-control (PFC) for all ports.

Usage

```
show pfc counters
```

Example

```
admin@sonic:~$ show pfc counters
```

Port Rx	PFC0	PFC1	PFC2	PFC3	PFC4	PFC5	PFC6	PFC7
Ethernet0	0	0	0	0	0	0	0	0
Ethernet4	0	0	0	0	0	0	0	0
Ethernet8	0	0	0	0	0	0	0	0
Ethernet12	0	0	0	0	0	0	0	0

show qos pfc-priority-queue

This command displays the PFC-priority-to-queue mapping.

Usage

```
show qos pfc-priority-queue [<profile_name>]
```

Parameters:

- <profile_name>: Profile name.

Example

```
admin@sonic:~$ show qos pfc-priority-queue
pfc-queue policy: pfc_queue_profile
PFC Priority  Queue
-----
0            0
1            2
2            2
```

show interface pfc config

This command displays the PFC configuration for all interfaces or a given interface.

Usage

```
show interface pfc config [<interface_name>]
```

Parameters:

<interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
admin@sonic:~$ show interfaces pfc config
Ethernet88
PFC mode: Symmetric
PFC Lossless Priorities: 0,1
PFC to Queue: pfc_q_prof
PFC  Queue
----
0    2
1    2
```

PFC Configuration Commands

config interface pfc asymmetric

This command is used to set PFC asymmetric of an interface to "on"(enable) or "off"(disable).

Usage

```
config interface pfc asymmetric <interface_name> (on | off)
```

To disable PFC asymmetric on Ethernet0, use the following command:

Example

```
admin@sonic:~$ sudo config interface pfc asymmetric Ethernet0 on
```

config interface pfc priority

This command is used to enable ("on") or disable ("off") a PFC priority on an interface.

Usage

```
config interface pfc priority <interface_name> {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7} {on | off}
```

To enable PFC priority 7 on Ethernet0, use the following command.

Example

```
admin@sonic:~$ sudo config interface pfc priority Ethernet0 7 on
```

Note:

- After configuring the aforementioned two types of PFC switches with traffic ports, it is necessary to restart the syncd Docker as follows:

```
docker restart syncd
```

config qos pfc-priority-queue add

This command is used to create a profile of PFC-priority-to-queue mapping.

Usage

```
config qos pfc-priority-queue add <profile_name> --pfc-priority <pfc-priority> --queue <queue>
```

Parameters:

- <profile_name>: Profile name.
- <pfc-priority>: List of PFC priority. Minimum: 0. Maximum: 7. For example: "1", "1,2-3".
- <queue>: Queue. Minimum: 0. Maximum: 7.

Note:

- This command is only supported on the devices using Broadcom ASIC.

Example

```
sudo config qos pfc-priority-queue add pfc_queue_profile --pfc-priority 0 --queue 0
```

config qos pfc-priority-queue update

This command is used to modify an existing profile of PFC-priority-to-queue mapping.

Usage

```
config qos pfc-priority-queue update <profile_name> --pfc-priority <pfc-priority> [--queue <queue>] [--remove]
```

Parameters:

- <profile_name>: Profile name.
- <pfc-priority>: List of PFC priority. Minimum: 0. Maximum: 7. For example: "1", "1,2-3".
- <queue>: Queue. Minimum: 0. Maximum: 7.

- remove: Remove the mapping. For example: "--pfc-priority 1 --remove".

Note:

- This command is only supported on the devices using Broadcom ASIC.

Example

```
sudo config qos pfc-priority-queue update pfc_queue_profile --pfc-priority 1,2 --queue 2
```

config qos pfc-priority-queue del

This command is used to delete a profile of PFC-priority-to-queue mapping.

Usage

```
config qos pfc-priority-queue del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Note:

- This command is only supported on the devices using Broadcom ASIC.

Example

```
sudo config qos pfc-priority-queue del pfc_queue_profile
```

config interface qos pfc-priority-queue bind

This command is used to configure the PFC-priority-to-queue mapping on the specified interface.

Usage

```
config interface qos pfc-priority-queue bind <interface_name> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <profile_name>: Profile name.

Default mapping:

PFC Priority	Queue
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Any packet field value that is not specified in the configuration is assigned to a default value.

Note:

- This command is only supported on the devices using Broadcom ASIC.

Example

```
sudo config interface qos pfc-priority-queue bind Ethernet0 pfc_queue_profile
```

config interface qos pfc-priority-queue unbind

This command is used to reset the PFC-priority-to-queue mapping on the specified interface.

Usage

```
config interface qos pfc-priority-queue unbind <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Note:

- This command is only supported on the devices using Broadcom ASIC.

Example

```
sudo config interface qos pfc-priority-queue unbind Ethernet0
```

PFC Clear Commands

sonic-clear pfccounters

This command is used to clear the counters of Rx and Tx priority-flow-control for all ports.

Usage

```
sonic-clear pfccounters
```

Example

```
admin@sonic:~$ sonic-clear pfccounters  
Clear saved counters
```

32 PFC Watchdog

Table of Contents

[PFC Watchdog Configure Command](#)

[config pfcwd start](#)

[config pfcwd stop](#)

[config pfcwd interval](#)

[config pfcwd counter_poll](#)

[config pfcwd big_red_switch](#)

[\(Not supported\) config pfcwd start_default](#)

[PFC Watchdog Show Command](#)

[show pfcwd config](#)

[show pfcwd stats](#)

A detailed description of the PFC Watchdog can be found on [this wiki page](#).

PFC Watchdog Configure Command

config pfcwd start

This command starts the PFC Watchdog.

Usage

```
config pfcwd start [--action (drop | forward | alert)] [--restoration-time <ms_value>] ports (all | <PORTS>)
detection-time <ms_value>
```

Parameters

- all: All ethernet ports
- <PORTS> : <ethernet_interface_name> separate by space ' ', e.g Ethernet0 Ethernet1 Ethernet2

Example: Sef pfcwd on all ethernet port

```
admin@sonic:~$ config pfcwd start --action drop --restoration-time 400 ports all detection-time 400
```

Example: Sef pfcwd on Ethernet0

```
admin@sonic:~$ config pfcwd start --action drop --restoration-time 400 ports Ethernet0 detection-time 400
```

Example: Sef pfcwd on Ethernet0 and Ethernet4

```
admin@sonic:~$ config pfcwd start --action drop --restoration-time 400 ports Ethernet0 Ethernet4 detection-
time 400
```

config pfcwd stop

This command stops the PFC Watchdog.

Usage

```
config pfcwd stop
```

Example: Stop pfcwd on all ports

```
admin@sonic:~$ config pfcwd stop
```

config pfcwd interval

This command sets the PFC Watchdog counter polling interval (ms).

Usage

```
config pfcwd interval <interval_in_ms>
```

Example

```
admin@sonic:~$ config pfcwd interval 200
```

config pfcwd counter_poll

This command enables or disables the PFC Watchdog related counters polling.

Usage

```
config pfcwd counter_poll (enable | disable)
```

Example

```
admin@sonic:~$ config pfcwd counter_poll disable
```

config pfcwd big_red_switch

This command enables or disables the PFC Watchdog's "BIG RED SWITCH"(BRS). When enabled, the BRS PFC Watchdog will be disabled on all ports/queues it is configured for no matter whether a storm was detected or not.

Usage

```
config pfcwd big_red_switch (enable | disable)
```

Example

```
admin@sonic:~$ config pfcwd big_red_switch enable
```

(Not supported) config pfcwd start_default

This command starts the PFC Watchdog with the default settings.

Usage

```
config pfcwd start_default
```

Default values are the following:

- detection time - 200ms
- restoration time - 200ms
- polling interval - 200ms
- action - 'drop'
- Additionally, if the number of ports in the system exceeds 32, all times will be multiplied by roughly $\frac{\text{num_ports}}{32} + 1$.

Example

```
admin@sonic:~$ config pfcwd start_default
```

Note: Due to the incomplete implementation of config pfcwd start_default , this command malfunctions.

PFC Watchdog Show Command

show pfcwd config

This command shows the current PFC Watchdog configuration.

Usage

```
show pfcwd config
```

Example

```
admin@sonic:~$ show pfcwd config
```

PORT	ACTION	DETECTION TIME	RESTORATION TIME
Ethernet0	drop	400	400

show pfcwd stats

This command shows the current PFC Watchdog statistics (storms detected, packets dropped, etc).

Usage

```
show pfcwd stats
```

Example

```
admin@sonic:~$ show pfcwd stats
```

QUEUE	STATUS	STORM DETECTED/RESTORED	TX OK/DROP	RX OK/DROP	TX LAST OK/DROP	RX LAST OK/DROP

Ethernet0:3	stormed	1/0	100/300	100/300	0
/200	0/200				
Ethernet0:4	operational	2/2	100/100	100/100	0
/0	0/0				

33 Policer

Table of Contents

[Policer Show Commands](#)

[show policer](#)

[Policer Config Commands](#)

[config policer add](#)

[config policer update](#)

[config policer remove](#)

This section explains various show and configuration commands available for users.

Policer Show Commands

show policer

This command displays a summary of the policer configuration.

Usage

show policer

Example

```
admin@sonic:~$ show policer
```

Name	Type	Mode	Color	Source	CIR	CBS	PIR	PBS	Green Packet Action	YellowPacket Action	Red Packet Action
POLICER_TR_TCM	bytes	tr_tcm	blind		1500	3000	2000	4000	forward	forward	drop

SP4 Example

```
admin@sonic:~$ show policer
```

Name	Type	Mode	Color	Source	CIR	CBS	PIR	PBS	Green Packet Action	Yellow Packet Action	Red Packet Action
POLICER_TR_TCM	bytes	tr_tcm	blind		1 Mbps	1 Kib	2 Mbps	3 Kib	forward	forward	drop

Note: If the type of mellanox switch policer is bytes, the value will be converted to the corresponding unit. If the type is pakcets, it will be consistent with the display of Broadcom switches

Policer Config Commands

config policer add

This command is used to add a policer.

Usage

```
config policer add <policer_name> sr_tcm <meter_type> <color_source> [--cir <cir>] [--cbs <cbs>] [--pbs <pbs>]
[--green_packet_action <green_packet_action> | --green_set_tc <green_set_tc> | --green_set_dscp
<green_set_dscp> | --green_set_cos <green_set_cos>] [--yellow_packet_action <yellow_packet_action> | --
yellow_set_tc <yellow_set_tc> | --yellow_set_dscp <yellow_set_dscp> | --yellow_set_cos <yellow_set_cos>] [--
red_packet_action <red_packet_action> | --red_set_tc <red_set_tc> | --red_set_dscp <red_set_dscp> |
--red_set_cos <red_set_cos>]
```

```
config policer add <policer_name> tr_tcm <meter_type> <color_source> [--cir <cir>] [--cbs <cbs>] [--pir <pir>] [--
pbs <pbs>] [--green_packet_action <green_packet_action> | --green_set_tc <green_set_tc> | --
green_set_dscp <green_set_dscp> | --green_set_cos <green_set_cos>] [--yellow_packet_action
<yellow_packet_action> | --yellow_set_tc <yellow_set_tc> | --yellow_set_dscp <yellow_set_dscp> | --
yellow_set_cos <yellow_set_cos>] [--red_packet_action <red_packet_action> | --red_set_tc <red_set_tc>
| --red_set_dscp <red_set_dscp> | --red_set_cos <red_set_cos>]
```

```
config policer add <policer_name> storm_control <meter_type> <color_source> [--cir <cir>] [--cbs <cbs>] [--
green_packet_action <green_packet_action> | --green_set_tc <green_set_tc> | --green_set_dscp
<green_set_dscp> | --green_set_cos <green_set_cos>] [--red_packet_action <red_packet_action> | --
red_set_tc <red_set_tc> | --red_set_dscp <red_set_dscp> | --red_set_cos <red_set_cos>]
```

Parameters:

- **policer_name:** Policer name. The maximum length is 16.
- **meter_type:** The unit of metering. Valid options are the following:
 - bytes
 - packets, packets mode is only supported on Broadcom switches.
- **color_source:** Be aware of or ignore the [pre-coloring](#) of packets.
 - aware
 - blind
- **cir:** Bandwidth limit for guaranteed traffics. It ranges from:

- 1000 to 12500000000 in bytes mode,
 - 1 to 148809523 in packets mode.
- cbs: Maximum packet size permitted for bursts of data that exceed the c ir. It ranges from:
 - 2000 to 256000000 in bytes mode,
 - 1 to 536576 in packets mode.
- pir: Bandwidth limit for peak traffics. It ranges from:
 - 1000 to 12500000000 in bytes mode,
 - 1 to 148809523 in packets mode.
- pbs: Maximum packet size permitted for bursts of data that exceed the pir. It ranges from:
 - 2000 to 256000000 in bytes mode,
 - 1 to 536576 in packets mode.
- green_packet_action: Specifies the action for green packets. Valid options are as follows:
 - forward
 - drop, drop mode is only supported on Broadcom switches.
- yellow_packet_action: Specifies the action for yellow packets. Valid options are the following:
 - forward
 - drop, drop mode is only supported on Broadcom switches.
- red_packet_action: Specifies the action for red packets. Valid options are the following:
 - forward
 - drop
- green_set_cos: Enables changing the VLAN PCP value for green packets. The valid range is 0 to 7. This action is only available for ACL. (Supported only on Broadcom switches.)
- yellow_set_cos: Enables changing the VLAN PCP value for yellow packets. Valid range is 0 to 7. This action is only available for ACL. (Supported only on Broadcom switches.)
- red_set_cos: Enables changing the VLAN PCP value for red packets. Valid range is 0 to 7. This action is only available for ACL. (Supported only on Broadcom switches.)
- green_set_dscp: Enables changing the DSCP for green packets. Valid range is 0 to 63. This action is only available for ACL. (Supported only on Broadcom switches.)
- yellow_set_dscp: Enables changing the DSCP for yellow packets. Valid range is 0 to 63. This action is only available for ACL. (Supported only on Broadcom switches.)

- **red_set_dscp:** Enables changing the DSCP for red packets. Valid range is 0 to 63. This action is only available for ACL. (Supported only on Broadcom switches.)
- **green_set_tc:** Enables changing the Traffic Class (TC) for green packets. Valid range is 0 to 7. This action is only available for ACL. (Supported only on Broadcom switches.)
- **yellow_set_tc:** Enables changing the Traffic Class (TC) for yellow packets. Valid range is 0 to 7. This action is only available for ACL. (Supported only on Broadcom switches.)
- **red_set_tc:** Enables changing the Traffic Class (TC) for red packets. Valid range is 0 to 7. This action is only available for ACL. (Supported only on Broadcom switches.)

The following example shows how to create a policer named "POLICER_TR_TCM" with tr_tcm mode, meter type "bytes", color source "blind", cir = 1000, cbs = 2000, pir = 2000, pbs = 4000, which drops packets marked red by the meter.

Example

```
admin@sonic:~$ sudo config policer add POLICER_TR_TCM tr_tcm bytes blind --cir 1000 --cbs 2000 --pir 2000 --pbs 4000 --green_packet_action forward --yellow_packet_action forward --red_packet_action drop
```

The following example shows how to create a policer named "POLICER_TR_TCM" with the "tr_tcm" mode, meter type "bytes", color source "blind", cir = 1000, cbs = 2000, pir = 2000, pbs = 4000, which remarks IP DSCP by the meter's marked color: green to 8, yellow to 16, and red to 24.

Example

```
admin@sonic:~$ sudo config policer add POLICER_TR_TCM tr_tcm bytes blind --cir 1000 --cbs 2000 --pir 2000 --pbs 4000 --green_set_dscp 8 --yellow_set_dscp 16 --red_set_dscp 24
```

config policer update

This command is used to update an existing policer.

Usage

```
config policer update <policer_name> [--cir <cir>] [--cbs <cbs>] [--pir <pir>] [--pbs <pbs>]
```

Parameters:

- **cir:** Bandwidth limit for guaranteed traffics. It ranges from:
 - 1000 to 12500000000 in bytes mode,
 - 1 to 148809523 in packets mode.
- **cbs:** Maximum packet size permitted for bursts of data that exceed the c ir. It ranges from:
 - 2000 to 256000000 in bytes mode,
 - 1 to 536576 in packets mode.
- **pir:** Bandwidth limit for peak traffics. It ranges from:
 - 1000 to 12500000000 in bytes mode,
 - 1 to 148809523 in packets mode.
- **pbs:** Maximum packet size permitted for bursts of data that exceed the pir. It ranges from:
 - 2000 to 256000000 in bytes mode,
 - 1 to 536576 in packets mode

The following example updates a policer named POLICER_TR_TCM with cir = 1500, cbs = 3000.

Example

```
admin@sonic:~$ sudo config policer update POLICER_TR_TCM --cir 1500 --cbs 3000
```

config policer remove

This command is used to remove a policer.

Usage

```
config policer remove <policer_name>
```

The following example removes a policer named POLICER_TR_TCM.

Example

```
admin@sonic:~$ sudo config policer remove POLICER_TR_TCM
```

34 Port Channels

[Port Channel Show Commands](#)

[show interfaces portchannel](#)

[Port Channel Config Commands](#)

[config portchannel](#)

[config portchannel member](#)

This section includes port channel creation, addition (or removal) of members, and deletion.

While creating a port channel, the user may specify whether the port channel is static (manually configured) or dynamic (running LACP protocol) which should be consistent with the peer switch.

Port Channel Show Commands

show interfaces portchannel

The **show interfaces portchannel** command displays all the port channels that are configured in the device and their status.

Example

```
admin@sonic:~$ show interfaces portchannel
```

Flags: A - active, I - inactive, Up - up, Dw - Down, N/A - not available,

S - selected, D - deselected, * - not synced,

M - mixed speed

No.	Team	Dev	Protocol	Ports	Oper Key	Admin Key	Fast Rate
System ID	System	Priority	Dev Number	Max Ports			
0	PortChannel0	LACP(A)(Up)	Ethernet0(S)	Ethernet4(S)	1	1	false
N/A	N/A	N/A	64				
2	PortChannel2	NONE(-)(Up)	Ethernet2(S)	Ethernet1(S)	N/A	N/A	N/A
N/A	N/A	N/A	64				
5	PortChannel5	LACP(A)(Dw)	N/A		N/A	auto	false
N/A	N/A	N/A	64				
8	PortChannel8(M)	LACP(A)(Up)	Ethernet8(S)	Ethernet12(S)	8	8	ture
N/A	N/A	N/A	64				
24	PortChannel24	LACP(A)(Up)	Ethernet28(S)	Ethernet24(S)	124	auto	false
N/A	N/A	N/A	64				
40	PortChannel40	LACP(A)(Up)	Ethernet44(S)	Ethernet40(S)	40	40	false
N/A	N/A	N/A	64				
48	PortChannel48	LACP(A)(Up)	Ethernet52(S)	Ethernet48(S)	48		
N/A	N/A	N/A	64				

The parameters are as below:

- Protocol
 - LACP protocol mode, active (A) or inactive(I) on the port channel.
 - LACP(A) means LACPDU frames are sent along the configured links periodically .

- LACP(I) means the port channel is not in an active negotiating state. It acts as "speak when spoken to", does respond to incoming LACP packets.
 - The 'NONE(-)' keyword means static port channel.
 - The port channel state, (Up) or (Dw).
- Ports
 - S - selected, the port is already attached to the port channel and ready to transmit and receive.
 - D - deselected, the port is not attached to the port channel yet.
 - * - not synced, the port is not synchronized. It is currently not in the right aggregation.
- Oper Key and Admin Key
 - The Admin Key is specified value in "--lacp-key" option of config portchannel add command.
 - The Oper Key is value of actually participating in the LACP protocol.
 - The Admin Key and Oper Key are always N/A for static port channel.
- Fast Rate
 - It is used to set the rate at which the LACP control packets are sent from partner.
 - true means LACP fast rate mode, request partner to transmit LACPDUs every 1 second
 - false means LACP slow rate mode, request partner to transmit LACPDUs every 30 seconds N/A, it is meaningless for static port channel.
- Mix Speed
 - M - Show which portchannel is in mixed speed mode.
 - In mixed speed mode, it is allowed to combine ports with different speeds into a single port channel.

Note

- If user creates a LACP port channel, and sets lacp-key as "auto", the "Oper Key" value will be generated automatically after first port channel member is added to port channel.

Port Channel Config Commands

This sub-section explains how to configure a port channel and its member ports.

config portchannel

The command `config portchannel` is used to add or delete a port channel. User can specify some attributes of

the port channel when adding the port channel name.

Usage

```
config portchannel add <portchannel_name> [--min-links <num_min_links>] [--fallback {true | false}] [--lacp-key {auto | <num_lacp_key>}] [--static {true | false}] [--fast-rate (true | false)] [--mix-speed (true | false)] [--system-id <system_id_value>] [--system-priority <system_priority_value>] [--dev-num <dev_num_value>] [--mode {active | passive}] [--max-ports <num_max_ports>]
```

```
config portchannel del <portchannel_name>
```

Parameters:

- **add** , add a new port-channel name in the system.
 - default attributes: LACP protocol, if no options specified or if the option " --static" not specified.
- **del** , delete the port-channel name from the system. User doesn't need to specify any options.
- **<portchannel_name>** , the port channel name to be added or deleted.
 - The syntax of port channel name is "PortChannel"<suffix> where <suffix> range is 0..9999
 - For example, <suffix> uses "200", the name could be "PortChannel200".
- **--min-links <num_min_links>** , minimum number of links in the LACP port channel before the LACP port channel can be brought up and active.
 - The default value is 1.
 - The range from 1 to 1024.
- **--fallback** option , LACP fallback feature can be enabled/disabled.
 - **true** , enable LACP fallback, which keep the port channel stays in "up" before receiving any LACP PDUs from peer DUT.
 - **false** , disable LACP fallback, turn the port channel state to down when it does not receive the LACP PDUs from peer DUT.
 - The default value is false.
- **--lacp-key** , specify the exchanged lacp-key in LACP protocol, either auto or <num_lacp_key>
 - **auto** , it concatenates "1"<suffix> as the key. For example, <suffix> uses "200", the lacp_key would be "1200" .
 - **<num_lacp_key>** , the range of given number from 1 to 65535.
 - The default value is auto.
- **--lacp-system-id** - Specifies the LACP system ID in the format of xxxx.xxxx.xxxx. If not specified, it will be the MAC of the DUT.

- --lacp-system-priority - Configures the LACP system priority. The value ranges from 0 to 65535. The default value is 65535.
- --dev-number - It's used to extended the actor port id, the formula for calculating the extended port id is: $\text{port} + (\text{dev-number} - 1) * 10000$. The value ranges from 1 to 6. The default value is 1.
- --static , specify the port channel type, either true for static port channel or false for dynamic LACP port channel.
- --fast-rate , specify LACP rate mode.
 - true, LACP fast rate mode, request partner to transmit LACPDU every 1 second. LACP timeout is 3 seconds.
 - false, LACP slow rate mode, request partner to transmit LACPDU every 30 seconds. LACP timeout is 90 seconds.
 - the default value is false.
- --mix-speed , specify whether the port channel is allowed to combine ports with different speeds into a single port channel. Default is false.
- --mode, specifies the operation mode of the port within the aggregation group, which is divided into two modes: active and passive. The default is active.
 - active , in active mode, the device will proactively send LACP packets to establish link aggregation.
 - passive , in passive mode, the device does not proactively send LACP packets but can respond to LACP packets sent from the peer to establish link aggregation.
- --max-ports, specifies the maximum number of ports in the aggregation group. The default is 64, with a range from 1 to 64.

Note

1. The member of a portchannel cannot be added into another portchannel.

If any port is already a member of a port channel and a user tries to add the same port to another port channel (without first deleting it from the current port channel), the command fails and error message is printed. In such cases, remove the member port from the current port channel and then add it to new port channel.

2. Portchannel cannot be deleted if there is any configured member.

A port channel can be deleted only if it does not have any members or the members are already deleted. When a user tries to delete a port channel and the port channel still has one or more members that exist, the deletion of port channel is blocked.

3. Refer to https://github.com/Azure/SONiC/blob/master/doc/lag/LACP_Fallback_Feature_for_SONiC_v0.5.md for more details about the fallback feature.
4. Only --static option is required when adding static port channel. Extra option, such as lacp_key, min_link, fast_rate, fallback or mode, would cause an error.
5. The attributes of created port channel cannot be modified or changed.

If port channel is already created and user tries to specify options to change port channel attributes, the command fails and error message is printed.

Example of creating a LACP port channel with the name: "PortChannel200".

Example 1

```
admin@sonic:~$ sudo config portchannel add PortChannel200
```

Example of creating a static port channel with the name "PortChannel300" and specify "--static true".

Example 2

```
admin@sonic:~$ sudo config portchannel add PortChannel300 --static true
```

Example of creating a mixed speed port channel with the name "PortChannel300", and specify "--mix speed".

Example 3

```
admin@sonic:~$ sudo config portchannel add PortChannel300 --mix-speed true
```

Example of deleting a port channel with the name "PortChannel200".

Example 4

```
admin@sonic:~$ sudo config portchannel del PortChannel200
```

config portchannel member

The command `config portchannel` adds or deletes a member port to/from the existing port channel.

Usage

```
config portchannel member {add | del} <portchannel_name> <member_portname>
```

Example: add interface Ethernet4 as a member of port channel "PortChannel200".

Example

```
admin@sonic:~$ sudo config portchannel member add PortChannel200 Ethernet4
```

35 Port Rate Limit

Table of Contents

[Port Rate Limit Show Commands](#)

[show interface rate-limit](#)

[Port Rate Limit Configuration Commands](#)

[config interface rate-limit add](#)

[config interface rate-limit del](#)

This section explains the commands of limiting the rate of transmission. It could be counted in bytes or packets.(Only supported on Broadcom switches of this chapter.)

Port Rate Limit Show Commands

show interface rate-limit

To display the rate limit configuration on an interface, use `show interface rate-limit` command.

Usage

```
show interface rate-limit [<interface_name>]
```

Parameters:

- `<interface_name>`: Physical interface name. For example: "Ethernet0".

Example

```
admin@sonic:~$ show interface rate-limit
```

Interface	Meter Type	Rate	Burst Size
Ethernet0	bytes	100 kbps	1 Kib

Port Rate Limit Configuration Commands

config interface rate-limit add

To enable to limit the incoming traffic rate on a port, use config interface rate-limit add command.

Usage

```
config interface rate-limit add <interface_name> --meter-type {bytes|packets} --rate <rate> [--burst-size
<burst_size>]
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- meter-type: Meter type. Valid values are:
 - bytes : Meter type as bytes mode.
 - packets : Meter type as packets mode.
- <rate>: Maximum rate of ingress traffic in kilo-bits/second (kbps) or packet/second (pps). Valid values are:
 - If meter-type is bytes :
 - The format is a decimal number or a decimal number followed by the abbreviation k (1,000), m (1,000,000), or g (1,000,000,000). Minimum: 8 kbps (32 kbps for AS8000 and AS9746-32D). Maximum: 400,000,000 kbps. For example: "10", "10k".
 - If meter-type is packets :
 - Minimum: 1 pps. Maximum: 148,809,523 pps.
- <burst_size>: The burst size in bytes or packets. If burst size is not given, the default value of bytes mode and packet mode are <rate> × 10 and <rate> ÷ 8 × 10 milliseconds respectively. Valid values are:
 - If meter-type is bytes :
 - The format is a decimal number or a decimal number followed by the abbreviation k (210), or m (220). Minimum: 2,000 bytes. Maximum: 256,000,000 bytes. For example: "100", "100k".
 - If meter-type is packets :
 - Minimum: 1 pps. Maximum: 536,576 pps.

Example

```
sudo config interface rate-limit add Ethernet0 --meter-type bytes --rate 10g --burst-size 9100
```

config interface rate-limit del

Disable to limit the incoming traffic rate on a port, use config interface rate-limit del command.

Usage

```
config interface rate-limit del <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
sudo config interface rate-limit del Ethernet0
```

36 PVST

Table of Contents

[PVST show commands](#)

[show spanning-tree](#)

[show spanning-tree bpdu_guard](#)

[show spanning-tree root_guard](#)

[show spanning-tree statistics](#)

[PVST configuration commands](#)

[config spanning-tree](#)

[config spanning-tree forward_delay](#)

[config spanning-tree hello](#)

[config spanning-tree max_age](#)

[config spanning-tree priority](#)

[config spanning-tree root_guard_timeout](#)

[config spanning-tree vlan](#)

[config spanning-tree vlan interface cost](#)

[config spanning-tree interface](#)

[config spanning-tree interface root_guard](#)

[config spanning-tree interface bpdu_guard](#)

[config spanning-tree interface portfast](#)

[config spanning-tree interface uplink_fast](#)

[config spanning-tree interface priority](#)

[configure spanning-tree interface cost](#)

[PVST debug commands](#)

[debug spanning-tree](#)

[PVST clear commands](#)

[sonic-clear spanning-tree](#)

This section describes PVST (STP) feature and commands which are supported in SONiC.

PVST (Per VLAN Spanning Tree) is a feature in SONiC, [SONiC_PVST_HLD](#), which planned in 202106 branch. It supports STP (802.1D Spanning Tree) for those ports, assigned to un tagged VLAN1, but there is an issue - dual root bridge when interacts with 802.1D switch.

To resolve this, MX SONiC adding stp mode in config spanning-tree command, which runs a single spanning tree instance for all portswich is a member of any VLAN, and disables other instances in PVST.

PVST show commands

show spanning-tree

This command displays spanning tree information .

Note:

- VLAN related settings cannot be displayed when spanning-tree mode is stp.

Usage

```
show spanning-tree
show spanning-tree vlan <vlanid>
show spanning-tree vlan <vlanid> interface <ifname>
```

Example

```
admin@sonic:~$ show spanning-tree vlan 100
Spanning-tree Mode: PVST
VLAN 100 - STP instance 3
-----
STP Bridge Parameters:
Bridge      Bridge Bridge Bridge Hold LastTopology Topology
Identifier  MaxAge Hello FwdDly Time Change Change
hex        sec  sec  sec  sec  sec  cnt
8000002438eefbc3 20  2  15  1  0  0
RootBridge  RootPath DesignatedBridge RootPort Max Hel Fwd
Identifier  Cost  Identifier Age lo Dly
hex        hex          sec sec sec
8000002438eefbc3 0  8000002438eefbc3 Root  20 2 15
STP Port Parameters:
Port  Prio Path Port Uplink State Designated Designated Designated
Name  rity Cost Fast Fast Cost Root Bridge
Ethernet13 128 4 Y N FORWARDING 0 8000002438eefbc3 8000002438eefbc3
```

show spanning-tree bpduguard

This command displays the interfaces which are BPDU guard enabled and also the state if the interface is disabled due to BPDU guard.

Usage

```
show spanning-tree bpduguard
```

Example

```
admin@sonic:~$ show spanning-tree bpduguard
```

PortNum	Shutdown	Port shut
	Configured	due to BPDU guard

Ethernet1	Yes	Yes
Ethernet2	Yes	No
Port-Channel2	No	NA

show spanning-tree rootguard

This command displays the interfaces where root guard is active and the pending time for root guard timer expiry

Usage

```
show spanning-tree rootguard
```

Example

```
admin@sonic:~$ show spanning-tree rootguard
```

```
Root guard timeout: 120 secs
Port    VLAN    Current State
-----
Ethernet1  1      Inconsistent state (102 seconds left on timer)
Ethernet8  100    Consistent state
```

show spanning-tree statistics

show spanning-tree statistics vlan <vlanid>

This command displays the spanning-tree bpdu statistics. Statistics will be synced to APP DB every 10 seconds

Usage

```
show spanning-tree statistics
show spanning-tree statistics vlan <vlanid>
```

Example

```
admin@sonic:~$ show spanning-tree statistics vlan 100
VLAN 100 - STP instance 3
```

```
-----
PortNum      BPDU Tx   BPDU Rx   TCN Tx   TCN Rx
Ethernet13    10        4         3         4
PortChannel15 20        6         4         1
```

PVST configuration commands

config spanning-tree

This command enables/disables the spanning tree mode for the device. pvst and stp are exclusive. User's configuration should be one of (pvst, stp, disable).

Usage

```
config spanning-tree {enable|disable} {pvst | stp}
```

option

- pvst: Per VLAN Spanning Tree mode. When enabled, it enables multi-spanning tree instances for first 255 VLANs. The first
- instance is for VLAN 1 and delivers BPDU for untagged member interface.
- stp: (802.1D) Spanning Tree mode. When enabled, it enables 1st spanning tree instance with system id (0) and disable other instance. All ports which is member of VLAN, either tagged or untagged, are joined the instance.

Note:

- Only one mode can be enabled at any given time. That is, the configuration should be one of (disable, pvst, stp).
- When switching the mode, eg pvst to stp, it will stop pvst and then start stp.

Example

```
admin@sonic:~$ sudo config spanning-tree enable pvst
```

config spanning-tree forward_delay

This command allows configuring the forward delay time in seconds (default = 15), range 4-30.

Note:

- $2 * (\text{forward_delay} - 1) \geq \text{max_age} \geq 2 * (\text{hello_time} + 1)$.
- The specified value on the global level command will also apply to value on these VLAN if original per-VLAN value is same as the global one.

Usage

```
config spanning-tree forward_delay <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree forward_delay 30
```

config spanning-tree hello

This command allow configuring the hello interval in secs for transmission of bpdus (default = 2), range 1-10.

Note:

- $2 * (\text{forward_delay} - 1) \geq \text{max_age} \geq 2 * (\text{hello_time} + 1)$.
- The specified value on the global level command will also apply to value on these VLAN if original per-VLAN value is same as the global one.

Usage

```
config spanning-tree hello <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree hello 10
```

config spanning-tree max_age

This command allows configuring the maximum time to listen for root bridge in seconds (default = 20), range 6-40.

Note:

- $2 * (\text{forward_delay} - 1) \geq \text{max_age} \geq 2 * (\text{hello_time} + 1)$.
- The specified value on the global level command will also apply to value on these VLAN if original per-VLAN value is same as the global one.

Usage

```
config spanning-tree max_age <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree max_age 40
```

config spanning-tree priority

This command allows configuring the bridge priority in increments of 4096 (default = 32768), range 0-61440.

Note:

- The specified value on the global level command will also apply to value on these VLAN if original per-VLAN value is same as the global one.

Usage

```
config spanning-tree priority <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree priority 61440
```

config spanning-tree root_guard_timeout

This command allows configuring a root guard timeout value. Once superior BPDUs stop coming on the port, device will wait for a

period until root guard timeout before moving the port to forwarding state(default = 30 secs), range 5-600.

Usage

```
config spanning-tree root_guard_timeout <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree root_guard_timeout 600
```

config spanning-tree vlan

This command allows enabling or disabling spanning-tree on a VLAN.

Note:

- VLAN related settings cannot be configured when spanning-tree mode is stp.

Usage

```
config spanning-tree vlan {enable|disable} <vlan>
```

Example

```
admin@sonic:~$ sudo config spanning-tree vlan enable 1
```

Below commands are similar to the global level commands but allow configuring on per VLAN basis.

Usage

```
config spanning-tree vlan forward_delay <vlan> <fwd-delay-value>
config spanning-tree vlan hello <vlan> <hello-value>
config spanning-tree vlan max_age <vlan> <max-age-value>
config spanning-tree vlan priority <vlan> <priority-value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree vlan priority 1 61440
```

config spanning-tree vlan interface cost

This command allows to configure the port level cost value for a VLAN, range 1 - 200000000

Usage

```
config spanning-tree vlan interface cost <vlan> <ifname> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree vlan interface cost 1 Ethernet0 10
```

config spanning-tree vlan interface priority

This command allows to configure the port level priority value for a VLAN, range 0 - 240 (default 128)

Usage

```
config spanning-tree vlan interface priority <vlan> <ifname> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree vlan interface priority 1 Ethernet0 240
```

config spanning-tree interface

This command allows enabling or disabling of STP on an interface, by default STP will be enabled on the interface if global STP mode is configured.

Usage

```
config spanning-tree interface {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface enable Ethernet0
```

config spanning-tree interface root_guard

This command allow enabling or disabling of root guard on an interface.

Usage

```
config spanning-tree interface root_guard {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface root_guard enable Ethernet0
```

config spanning-tree interface bpdu_guard

Below command allows enabling or disabling of bpdu guard on an interface.

Usage

```
config spanning-tree interface bpduguard {enable|disable} <ifname>
```

By default, BPDU guard will only generate a syslog indicating the condition, for taking an action like disabling the port below

command can be used with shutdown option

Usage

```
config spanning-tree interface bpduguard {enable|disable} <ifname> [--shutdown | -s]
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface bpduguard enable Ethernet0
```

config spanning-tree interface portfast

Below command allows enabling or disabling of portfast on an interface.

Usage

```
config spanning-tree interface portfast {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface portfast enable Ethernet0
```

config spanning-tree interface uplink_fast

Usage

```
config spanning-tree interface uplink_fast {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface uplink_fast enable Ethernet0
```

config spanning-tree interface priority

This command allows to configure the port level priority value, range 0 - 240 (default 128)

Usage

```
config spanning-tree interface priority <ifname> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface priority Ethernet0 240
```

configure spanning-tree interface cost

This command allows to configure the port level cost value, range 1 - 2000000000

Usage

```
config spanning-tree interface cost <ifname> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface cost Ethernet0 1000
```

PVST debug commands

debug spanning-tree

Following debug commands will be supported for enabling additional logging which can be viewed in /var/log/stpd.log, orchagent related logs can be viewed in /var/log/syslog.

Usage

```
debug spanning-tree
debug spanning-tree bpdu [tx|rx]
debug spanning-tree event
debug spanning-tree interface <ifname>
debug spanning-tree verbose
debug spanning-tree vlan <id>
```

Note

- This "debug spanning-tree" command must be enabled for logs to be written to log file, after enabling any of the below commands.

Example

```
admin@sonic:~$ debug spanning-tree
Command: sudo stpctl dbg enable
admin@sonic:~$ debug spanning-tree bpdu tx
Command: sudo stpctl dbg bpdu tx-on
admin@sonic:~$ debug spanning-tree event
Command: sudo stpctl dbg event on
admin@sonic:~$ debug spanning-tree verbose
Command: sudo stpctl dbg verbose on
admin@sonic:~$ debug spanning-tree vlan 1
Command: sudo stpctl dbg vlan 1 on
admin@sonic:~$ debug spanning-tree interface Ethernet3
```

Command: `sudo stpctl dbg port Ethernet3 on`

To disable the debugging controls enabled '-d' or '--disable' option can be used, an example of disabling bpdu debugging is shown below.

Usage

`debug spanning-tree bpdu -d`

Example

`admin@sonic:~$ debug spanning-tree bpdu -d`

Command: `sudo stpctl dbg bpdu off`

Follow commands can be used to reset and display the debugging controls enabled respectively

Usage

`debug spanning-tree reset`

`debug spanning-tree show`

Example

`admin@sonic:~$ debug spanning-tree bpdu -d`

Command: `sudo stpctl dbg bpdu off`

`admin@sonic:~$ debug spanning-tree show`

Command: `sudo stpctl dbg show`

STP Debug Parameters

STP debugging is : ON

Verbose : ON

Event : ON

BPDU-RX : OFF

BPDU-TX : OFF

Ports: 3

VLANs: 1

Following debug commands will be supported for displaying internal data structures

Usage

```
debug spanning-tree dump global
```

```
debug spanning-tree dump vlan <vid>
```

```
debug spanning-tree dump interface <vid> <ifname>
```

Example

```
admin@sonic:~$ debug spanning-tree dump interface 2 Ethernet3
```

```
Command: sudo stpctl port 2 Ethernet3
```

```
PORT CLASS - VLAN 2 PORT 3(Ethernet3)
```

```
=====
```

```
port_id          = 8 3
```

```
state            = FORWARDING
```

```
path_cost        = 2000
```

```
designated_root   = 0x800268215f8101b6
```

```
designated_cost   = 0
```

```
designated_bridge = 0x800268215f8101b6
```

```
designated_port   = Pri-8, Num-3
```

```
topology_change_acknowledge = 0
```

```
config_pending   = 0
```

```
change_detection_enabled = 1
```

```
self_loop        = 0
```

```
auto_config      = 1
```

```
message_age_timer = INACTIVE 0
```

```
forward_delay_timer = INACTIVE 0
```

```
hold timer          = INACTIVE 0
root_protect_timer  = INACTIVE 0
forward_transitions = 1
rx_config_bpdu      = 0
tx_config_bpdu      = 266
rx_tcn_bpdu         = 0
tx_tcn_bpdu         = 0
```

PVST clear commands

sonic-clear spanning-tree

Following clear commands will be supported

Usage

```
sonic-clear spanning-tree statistics
sonic-clear spanning-tree statistics vlan <vid>
sonic-clear spanning-tree statistics vlan-interface <vid> <ifname>
sonic-clear spanning-tree statistics interface <ifname>
```

Example

```
admin@sonic:~$ sonic-clear spanning-tree statistics
All stats cleared
admin@sonic:~$ sonic-clear spanning-tree statistics vlan 1
Stats cleared for VLAN 1
admin@sonic:~$ sonic-clear spanning-tree statistics vlan-interface 1 Ethernet0
Stats cleared for VLAN 1 Ethernet0
admin@sonic:~$ sonic-clear spanning-tree statistics interface Ethernet0
Stats cleared for Ethernet0
```

37 QoS

Table of Contents

[Qos Classification](#)

[Classification Show Commands](#)

[show qos dot1p-tc](#)

[show qos dscp-tc](#)

[show qos tc-pg](#)

[show qos tc-queue](#)

[show interface qos](#)

[QoS Classification Configuration Commands](#)

[config qos dot1p-tc add](#)

[config qos dot1p-tc update](#)

[config qos dot1p-tc del](#)

[config interface qos dot1p-tc bind](#)

[config interface qos dot1p-tc unbind](#)

[config qos dscp-tc add](#)

[config qos dscp-tc update](#)

[config qos dscp-tc del](#)

[config interface qos dscp-tc bind](#)

[config interface qos dscp-tc unbind](#)

[config qos tc-pg add](#)

[config qos tc-pg update](#)

[config qos tc-pg del](#)
[config interface qos tc-pg bind](#)
[config interface qos tc-pg unbind](#)
[config qos tc-queue add](#)
[config qos tc-queue update](#)
[config qos tc-queue del](#)
[config interface qos tc-queue bind](#)
[config interface qos tc-queue unbind](#)

Qos Marking

QoS Marking Show Commands

[show qos remark dot1p](#)
[show qos remark dscp](#)

QoS Marking Configuration Commands

[config qos remark dot1p add](#)
[config qos remark dot1p update](#)
[config qos remark dot1p del](#)
[config interface qos remark dot1p bind](#)
[config interface qos remark dot1p unbind](#)
[config qos remark dscp add](#)
[config qos remark dscp update](#)
[config qos remark dscp del](#)
[config interface qos remark dscp bind](#)
[config interface qos remark dscp unbind](#)

Qos Configuration Commands

[config qos clear](#)
[config qos reload](#)

Qos Classification

Classification Show Commands

show qos dot1p-tc

This command is used to display the Dot1p-to-TC profile(s).

Usage

```
show qos dot1p-tc [<profile_name>]
```

Parameters:

- <profile_name>: Profile name.

Example

```
admin@sonic:~$ show qos dot1p-tc
dot1p-tc policy: dot1p_to_tc_profile
Dot1p  TC
-----
0  2
1  3
2  4
dot1p-tc policy: dot1p_to_tc_profile2
Dot1p  TC
-----
2  3
3  3
4  3
5  3
```

show qos dscp-tc

This command is used to display the DSCP-to-TC profile(s).

Usage

```
show qos dscp-tc [<profile_name>]
```

Parameters:

- <profile_name>: Profile name.

Example

```
admin@sonic:~$ show qos dscp-tc
dscp-tc policy: dscp_to_tc_profile
```

DSCP	TC
0	0
8	1
16 24	2

show qos tc-pg

This command is used to display the TC-to-PG profile(s).

Usage
show qos tc-pg [<profile_name>]

Parameters:

- <profile_name>: Profile name.

Example
admin@sonic:~\$ show qos tc-pg
tc-pg policy: tc_pg_prof1
TC PG

2 3
3 3
4 3
5 3

show qos tc-queue

This command is used to display the Tc-to-queue profile(s).

Usage
show qos tc-queue [<profile_name>]

Parameters:

- <profile_name>: Profile name.

Example

```
admin@sonic:~$ show qos tc-queue
tc-queue policy: tc_to_queue_profile
  TC  Queue
  ---  -----
  0    0
  1    2
  2    2
```

SP4 Example

```
admin@sonic:~$ show qos tc-queue
tc-queue policy: tc_to_queue_profile
  TC  Queue
  ---  -----
  0  [0]
  1  [2]
  2  [2]
```

show interface qos

This command is used to display the QoS configuration for all interfaces or a given interface.

Usage

```
show interface qos [<interface_name>]
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
admin@sonic:~$ show interface qos
Ethernet0:
TC to Queue: tc_to_queue_profile
Ethernet16:
```

```
Dot1p to TC: AZURE
PFC to Queue: AZURE
TC to PG: AZURE
TC to Queue: AZURE
Ethernet18:
pfc-priority: 0
PFC to Queue: AZURE
```

Example

```
admin@sonic:~$ show interface qos Ethernet0
TC to Queue: tc_to_queue_profile
```

QoS Classification Configuration Commands

config qos dot1p-tc add

This command is used to create a Dot1p-to-TC profile.

Usage

```
config qos dot1p-tc add <profile_name> --dot1p <dot1p> --tc <tc>
```

Parameters:

- <profile_name>: Profile name.
- <dot1p>: List of dot1p. Minimum: 0. Maximum: 7. For example: "1", "1,2-3".
- <tc>: Traffic Class. Minimum: 0. Maximum: 7.

Example

```
sudo config qos dot1p-tc add dot1p_to_tc_profile --dot1p 0,1,2,3 --tc 0
```

config qos dot1p-tc update

This command is used to modify an existing Dot1p-to-TC profile.

Usage

```
config qos dot1p-tc update <profile_name> --dot1p <dot1p> [--tc <tc>] [--remove]
```

Parameters:

- <profile_name>: Profile name.
- <dot1p>: List of dot1p. Minimum: 0. Maximum: 7. For example: "1", "1,2-3".
- <tc>: Traffic Class. Minimum: 0. Maximum: 7.
- remove: Remove the mapping. For example: "--dot1p 1 --remove".

Example

```
sudo config qos dot1p-tc update dot1p_to_tc_profile --dot1p 0 --tc 1
```

```
sudo config qos dot1p-tc update dot1p_to_tc_profile --dot1p 4 --tc 0
```

```
sudo config qos dot1p-tc update dot1p_to_tc_profile --dot1p 1 --tc 0 --remove
```

config qos dot1p-tc del

This command is used to delete a Dot1p-to-TC profile.

Usage

```
config qos dot1p-tc del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config qos dot1p-tc del dot1p_to_tc_profile
```

config interface qos dot1p-tc bind

This command is used to configure Dot1p-to-TC mapping on the specified interface.

Usage

```
config interface qos dot1p-tc bind <interface_name> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

- <profile_name>: Profile name.

Default mapping: The following table shows the default mapping on Broadcom platform.

DOT1P	TC
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Any packet field value that is not specified in the configuration is assigned to a default value.

Example

```
sudo config interface qos dot1p-tc bind Ethernet0 dot1p_to_tc_profile
```

config interface qos dot1p-tc unbind

This command is used to reset Dot1p-to-TC mapping on the specified interface.

Usage

```
config interface qos dot1p-tc unbind <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
sudo config interface qos dot1p-tc unbind Ethernet0
```

config qos dscp-tc add

This command is used to create a DSCP-to-TC profile.

Usage

```
config qos dscp-tc add <profile_name> --dscp <dscp> --tc <tc>
```

Parameters:

- <profile_name>: Profile name.
- <dscp>: List of DSCP. Minimum: 0. Maximum: 63. For example: "1", "1,2-3".
- <tc>: Traffic Class. Minimum: 0. Maximum: 7.

Example

```
sudo config qos dscp-tc add dscp_to_tc_profile --dscp 0,1,2,3 --tc 0
```

config qos dscp-tc update

This command is used to modify an existing DSCP-to-TC profile.

Usage

```
config qos dscp-tc update <profile_name> --dscp <dscp> [--tc <tc>] [--remove]
```

Parameters:

- <profile_name>: Profile name.
- <dscp>: List of DSCP. Minimum: 0. Maximum: 63. For example: "1", "1,2-3".
- <tc>: Traffic Class. Minimum: 0. Maximum: 7.
- remove: Remove the mapping. For example: "--dscp 1 --remove".

Example

```
sudo config qos dot1p-tc update dot1p_to_tc_profile --dot1p 0 --tc 1
sudo config qos dot1p-tc update dot1p_to_tc_profile --dot1p 4 --tc 0
sudo config qos dot1p-tc update dot1p_to_tc_profile --dot1p 1 --tc 0 --remove
```

config qos dscp-tc del

This command is used to delete a DSCP-to-TC profile.

Usage

```
config qos dscp-tc del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config qos dscp-tc del dscp_to_tc_profile
```

config interface qos dscp-tc bind

This command is used to configure the DSCP-to-TC mapping on the specified interface.

Usage

```
config interface qos dscp-tc bind <interface_name> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <profile_name>: Profile name.

Default mapping:

DSCP	TC
0 ~ 63	0

Any packet field value that is not specified in the configuration is assigned to a default value.

Example

```
sudo config interface qos dscp-tc bind Ethernet0 dscp_to_tc_profile
```

config interface qos dscp-tc unbind

This command is used to reset the DSCP-to-TC mapping on the specified interface.

Usage

```
config interface qos dscp-tc unbind <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
sudo config interface qos dscp-tc unbind Ethernet0
```

config qos tc-pg add

This command is used to create a TC-to-PG profile.

Usage

```
config qos tc-pg add <profile_name> --tc <tc> --pg <pg>
```

Parameters:

- <profile_name>: Profile name.
- <tc>: the TC (Traffic Class), or switch-priority, the value could be a list that is comma separated, valid range is 0 to 7. <pg>: the priority group value, valid range is 0 to 7 for Broadcom platform, 1 to 5 for Intel platform.

Example

```
sudo config qos tc-pg add tc_to_pg_profile --tc 0,1,2,3 --pg 0
```

config qos tc-pg update

This command is used to modify an existing TC-to-PG profile.

Usage

```
config qos tc-pg update <profile_name> --tc <tc> --pg <pg> [--remove]
```

Parameters:

- <profile_name>: Profile name.
- <tc>: the TC (Traffic Class), or switch-priority, the value could be a list that is comma separated, valid range is 0 to 7. <pg>: the priority group value, valid range is 0 to 7 for Broadcom platform, 1 to 5 for Intel platform.
- remove: Remove the mapping. For example: "--tc 1 --remove".

Example

```
sudo config qos tc-pg update tc_to_pg_profile -tc 0 -pg 1
sudo config qos tc-pg update tc_to_pg_profile -tc 4 -pg 0
sudo config qos tc-pg update tc_to_pg_profile -tc 1 -pg 0 --remove
```

config qos tc-pg del

This command is used to delete a TC-to-PG profile.

Usage

```
config qos tc-pg del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config qos tc-pg del tc_to_pg_profile
```

config interface qos tc-pg bind

This command is used to configure the TC-to-PG mapping on the specified interface.

Usage

```
config interface qos tc-pg bind {<interface_name> | all} <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.
- <profile_name>: Profile name.

Default mapping:

The following table shows the default mapping on Broadcom Trident2plus, Trident3, Tomahawk and Tomahawk2 switches.

TC	PG
0 ~ 7	7

The following table shows the default mapping on Broadcom Trident4, Tomahawk3, and Tomahawk4 switches.

TC	PG
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

The following table shows the default mapping on Intel platform.

TC	PG
0 ~ 7	0

Any packet field value that is not specified in the configuration is assigned to a default value.

Example

```
sudo config interface qos tc-pg bind Ethernet0 tc_to_pg_profile
```

config interface qos tc-pg unbind

This command is used to reset the TC-to-PG mapping on the specified interface.

Usage

```
config interface qos tc-pg unbind {<interface_name> | all}
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.

Example

```
sudo config interface qos tc-pg unbind Ethernet0
```

config qos tc-queue add

This command is used to create a TC-to-queue profile.

Usage

```
config qos tc-queue add <profile_name> --tc <tc> --queue <queue>
```

SP4 Usage

```
config qos tc-queue add <profile_name> --tc <tc> --uc-queue <queue>
```

Parameters:

- <profile_name>: Profile name.
- <tc>: the TC (Traffic Class), or switch-priority, the value could <queue>: the queue value, valid range is 0 to 7.

Note:

- On the devices using Intel ASIC, it only supports one profile per system. The configuration is applied immediately after profile is added. Any packet field value that is not specified in the configuration is assigned to a default value.

Example

```
sudo config qos tc-queue add tc_to_queue_profile --tc 0,1,2,3 --queue 0
```

Sp4 Example

```
sudo config qos tc-queue add tc_to_queue_profile --tc 0,1,2,3 --uc-queue 0
```

config qos tc-queue update

This command is used to modify an existing TC-to-queue profile. The configuration is applied immediately after profile is updated on Intel platform.

Usage

```
config qos tc-queue update <profile_name> --tc <tc> --queue <queue> [--remove]
```

Sp4 Usage

```
config qos tc-queue update <profile_name> --tc <tc> --uc-queue <queue> [--remove]
```

Parameters:

- <profile_name>: Profile name.
- <tc>: the TC (Traffic Class), or switch-priority, the value could be a list that is comma separated, valid range is 0 to 7.
- <queue>: the queue value, valid range is 0 to 7.
- remove: Remove the mapping. For example: "--tc 1 --remove".

Note:

- On the devices using Intel ASIC, it only supports one profile per system. The configuration is applied immediately after profile is added. Any packet field value that is not specified in the configuration is assigned to a default value.

Example

```
sudo config qos tc-queue update tc_to_queue_profile --tc 0 --queue 1
sudo config qos tc-queue update tc_to_queue_profile --tc 4 --queue 2
sudo config qos tc-queue update tc_to_queue_profile --tc 1 --queue 2 --remove
```

Sp4 Example

```
sudo config qos tc-queue update tc_to_queue_profile --tc 0 --uc-queue 1
sudo config qos tc-queue update tc_to_queue_profile --tc 4 --uc-queue 2
sudo config qos tc-queue update tc_to_queue_profile --tc 1 --uc-queue 2 --remove
```

config qos tc-queue del

This command is used to delete a TC-to-queue profile.

Usage

```
config qos tc-queue del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config qos tc-queue del tc_to_queue_profile
```

config interface qos tc-queue bind

This command is used to configure the TC-queue mapping on the specified interface. This command is not supported on Intel platform because configuration is applied immediately after profile is added or updated.

Usage

```
config interface qos tc-queue bind {<interface_name> | all} <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.
- <profile_name>: Profile name.

Default mapping:

The following table shows the default mapping on Broadcom platform.

TC	Queue
0	0
1	1
2	2
3	3
4	4
5	5
6	6

7	7
---	---

Any packet field value that is not specified in the configuration is assigned to a default value.

Note:

- This command is only supported on the devices using Broadcom ASIC.

Example

```
sudo config interface qos tc-queue bind Ethernet0 tc_to_queue_profile
```

config interface qos tc-queue unbind

This command is used to reset the TC-to-queue mapping on the specified interface.

Usage

```
config interface qos tc-queue unbind {<interface_name> | all}
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.

Note:

- This command is only supported on the devices using Broadcom ASIC.

Example

```
sudo config interface qos tc-queue unbind Ethernet0
```

Qos Marking

QoS Marking Show Commands

show qos remark dot1p

This command is used to display the dot1p remarking profile(s).

Usage

```
show qos remark dot1p [<profile_name>]
```

Parameters:

- <profile_name>: Profile name.

Example

```
admin@sonic:~$ show qos remark dot1p
dot1p policy: remark_dot1p_profile
  TC  Dot1p
----
  0   0
  1   1
  2   2
```

show qos remark dscp

This command is used to display the DSCP remarking profile(s).

Usage

```
show qos remark dscp [<profile_name>]
```

Parameters:

- <profile_name>: Profile name.

Example

```
admin@sonic:~$ show qos remark dscp
dscp policy: remark_dscp_profile
  TC  DSCP
----
  0   2
  1   9
  2  17
```

QoS Marking Configuration Commands

config qos remark dot1p add

This command is used to create a Dot1p remarking profile.

Usage

```
config qos remark dot1p add <profile_name> --tc <tc> --dot1p <dot1p>
```

Parameters:

- <profile_name>: Profile name.
- <tc>: List of Traffic Class. Minimum: 0. Maximum: 7. For example: "1", "1,2-3"
- <dot1p>: Dot1p. Minimum: 0. Maximum: 7.

Example

```
sudo config qos remark dot1p add remark_dot1p_profile --tc 0 --dot1p 0
```

config qos remark dot1p update

This command is used to modify an existing Dot1p remarking profile.

Usage

```
config qos remark dot1p update <profile_name> --tc <tc> [--dot1p <dot1p>] [--remove]
```

Parameters:

- <profile_name>: Profile name.
- <tc>: List of Traffic Class. Minimum: 0. Maximum: 7. For example: "1", "1,2-3".
- <dot1p>: Dot1p. Minimum: 0. Maximum: 7
- remove: Remove the mapping. For example: "--tc 1 --remove".

Example

```
sudo config qos remark dot1p update remark_dot1p_profile --tc 1 --dot1p 1
```

config qos remark dot1p del

This command is used to delete a Dot1p remarking profile.

Usage

```
config qos remark dot1p del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config qos remark dot1p del remark_dot1p_profile
```

config interface qos remark dot1p bind

This command is used to enable Dot1p remarking on the specified interface.

Usage

```
config interface qos remark dot1p bind <interface_name> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <profile_name>: Profile name.

Default mapping:

TC	Dot1p
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Any TC value that is not specified in the configuration is assigned to a default Dot1p value for rewriting.

Example

```
sudo config interface qos remark dot1p bind Ethernet0 remark_dot1p_profile
```

config interface qos remark dot1p unbind

This command is used to disable Dot1p remarking on the specified interface.

Usage

```
config interface qos remark dot1p unbind <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
sudo config interface qos remark dot1p unbind Ethernet0
```

config qos remark dscp add

This command is used to create a DSCP remarking profile.

Usage

```
config qos remark dscp add <profile_name> --tc <tc> --dscp <dscp>
```

Parameters:

- <profile_name>: Profile name.
- <tc>: List of Traffic Class. Minimum: 0. Maximum: 7. For example: "1", "1,2-3".
- <dscp>: DSCP. Minimum: 0. Maximum: 63.

Example

```
sudo config qos remark dscp add remark_dscp_profile --tc 0 --dscp 2
```

config qos remark dscp update

This command is used to modify an existing DSCP remarking profile.

Usage

```
config qos remark dscp update <profile_name> --tc <tc> [--dscp <dscp>] [--remove]
```

Parameters:

- <profile_name>: Profile name.
- <tc>: List of Traffic Class. Minimum: 0. Maximum: 7. For example: "1", "1,2-3"
- <dscp>: DSCP. Minimum: 0. Maximum: 63.
- remove: Remove the mapping. For example: "--tc 1 --remove".

Example

```
sudo config qos remark dscp update remark_dscp_profile --tc 1 --dscp 9
sudo config qos remark dscp update remark_dscp_profile --tc 2 --dscp 17
```

config qos remark dscp del

This command is used to delete a DSCP remarking profile.

Usage

```
config qos remark dscp del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config qos remark dscp del remark_dscp_profile
```

config interface qos remark dscp bind

This command is used to enable DSCP remarking on the specified interface.

Usage

```
config interface qos remark dscp bind <interface_name> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <profile_name>: Profile name.

Default mapping:

TC	DSCP
0 ~ 7	0

Any TC value that is not specified in the configuration is assigned to a default DSCP value for rewriting.

Example

```
sudo config interface qos remark dscp bind Ethernet0 remark_dscp_profile
```

config interface qos remark dscp unbind

This command is used to disable DSCP remarking on the specified interface.

Usage

```
config interface qos remark dscp unbind <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
sudo config interface qos remark dscp unbind Ethernet0
```

Qos Configuration Commands

config qos clear

This command is used to clear all the QoS configuration from all the following QOS Tables in ConfigDB.

1. TC_TO_PRIORITY_GROUP_MAP
2. MAP_PFC_PRIORITY_TO_QUEUE
3. TC_TO_QUEUE_MAP
4. DSCP_TO_TC_MAP
5. DOT1P_TO_TC_MAP
6. MPLS_TC_TO_TC_MAP
7. SCHEDULER
8. PFC_PRIORITY_TO_PRIORITY_GROUP_MAP
9. PORT_QOS_MAP
10. WRED_PROFILE

- 11. QUEUE
- 12. CABLE_LENGTH
- 13. BUFFER_POOL
- 14. BUFFER_PROFILE
- 15. BUFFER_PG
- 16. BUFFER_QUEUE

Usage
config qos clear

Example
admin@sonic:~\$ sudo config qos clear

config qos reload

This command is used to clear and load the predefined lossless buffer configuration. The config qos clear command is issued by this command to clear all the QoS configuration. After this command, use config save command to save the configuration file, then use reboot command to restart the switch to take the change effect.

Usage
config qos reload

Example
admin@sonic:~\$ sudo config qos reload Running command: /usr/local/bin/sonic-cfggen -d -t /usr/share/sonic/device/x86_64-dell_z9100_c2538-r0 /Force10-Z9100-C32/buffers.json.j2 >/tmp/buffers.json Running command: /usr/local/bin/sonic-cfggen -d -t /usr/share/sonic/device/x86_64-dell_z9100_c2538-r0

```
/Force10-Z9100-C32/qos.json.j2 -y /etc/sonic/sonic_version.yml >/tmp/qos.json
Running command: /usr/local/bin/sonic-cfggen -j /tmp/buffers.json --write-to-db
Running command: /usr/local/bin/sonic-cfggen -j /tmp/qos.json --write-to-db
In this example, it uses the buffers.json.j2 file and qos.json.j2 file from platform specific folders.
When there are no changes in the platform specific configuration files, they internally use the file
"/usr
/share/sonic/templates/buffers_config.j2" and "/usr/share/sonic/templates/qos_config.j2" to
generate the
configuration.
```

38 Rate

Rate Config Commands

config rate smoothing-interval

This command is used to change the window size of exponential moving average to make the rates and utilization values more smooth in the output of "show interface counters"

Usage

```
config rate smoothing-interval <interval>
```

Parameter:

- <interval>: The window size of exponential moving average.(The range is from 1 to 1000)

Example

```
admin@sonic:~$ sudo config rate smoothing-interval 20
```

39 Routing Stack

The SONiC software is agnostic of the routing software that is being used in the device. For example, users can use either the Quagga or FRR routing stack as per their requirement. A separate shell (vtysh) is provided to configure such routing stacks. Once users enter v tysh , they can use the routing stack specific commands as given in the following example.

Example (FRR Routing Stack)

```
admin@sonic:~$ vtysh
Hello, this is FRRouting (version 7.2.1-sonic).
Copyright 1996-2005 Kunihiro Ishiguro, et al.
sonic# show route-map
ZEBRA:
route-map: RM_SET_SRC Invoked: 82595
```

permit, sequence 10 Invoked 82595

Match clauses:

Set clauses:

src 10.1.0.32

Call clause:

Action:

Exit routemap

Refer to the routing stack [Quagga Command Reference](#) or [FRR Command Reference](#) to know more about about the routing stack configuration.

40 SAG

Table of Contents

[SAG Show Commands](#)

[show sag](#)

[show sag ip](#)

[show sag ipv6](#)

[SAG Configuration Commands](#)

[config sag mac_address add/del](#)

[config sag ipv4 enable/disable](#)

[config sag ipv6 enable/disable](#)

[config sag interface sag ip add/del](#)

SAG Show Commands

show sag

This command displays the global SAG configuration.

Usage

show sag

Example

```
admin@sonic:~#show sag
Static Anycast Gateway Information
MacAddress    IPv4  IPv6
-----
00:11:22:33:44:55  enable  enable
```

show sag ip

This command displays the configured SAG IPv4 addresses.

Usage

show sag ip

Example

```
admin@sonic~#show sag ip
Vlan Interface Name  IPv4 address/mask
-----
Vlan100              1.1.1.254/24
```

show sag ipv6

This command displays the configured SAG IPv6 addresses.

Usage

```
show sag ipv6
```

Example

```
admin@sonic~#show sag ipv6
Vlan Interface Name  IPv6 address/mask
-----
Vlan100              2001:1000::FE/64
```

SAG Configuration Commands

config sag mac_address add/del

This command is used to add/delete the SAG MAC address.

This setting is global and only a single MAC address is allowed.

Usage

```
config sag mac_address <add|del> <mac-address>
```

Parameters:

- **mac-address:** Specifies the MAC address used for SAG interface.

Example

```
admin@sonic:~# sudo config sag mac_address add 00:11:22:33:44:55
admin@sonic:~# sudo config sag mac_address del 00:11:22:33:44:55
```

config sag ipv4 enable/disable

This command is used to enable/disable the IPv4 address on the SAG interface.

Usage

```
config sag ipv4 <enable|disable>
```

Example

```
admin@sonic:~# sudo config sag ipv4 enable
admin@sonic:~# sudo config sag ipv4 disable
```

config sag ipv6 enable/disable

This command is used to enable/disable the IPv6 address on the SAG interface.

Usage

```
config sag ipv6 <enable|disable>
```

Example

```
admin@sonic:~# sudo config sag ipv6 enable
admin@sonic:~# sudo config sag ipv6 disable
```

config sag interface sag ip add/del

This command is used to add/del the IPv4/IPv6 address on the SAG interface, and the VLAN interface that the SAG interface is based on.

Usage

```
config interface sag ip <add|del> <vlan-name> <ip-address>
```

Parameters:

- **vlan-name:** Specifies the SAG's parent VLAN interface name.
- **ip-address:** Specifies the IPv4/IPv6 address used on the SAG interface.

Example

```
admin@sonic:~# sudo config interface sag ip add Vlan1 192.168.1.1/24
admin@sonic:~# sudo config interface sag ip del Vlan1 192.168.1.1/24
```

41 Scheduling & Shaping

Table of Contents

[Scheduling & Shaping Show Commands](#)

[show scheduler](#)

[show interface scheduler](#)

[Scheduling & Shaping Configuration Commands](#)

[config scheduler add](#)

[config scheduler update](#)
[config scheduler del](#)
[config interface scheduler bind queue](#)
[config interface scheduler unbind queue](#)
[config interface scheduler bind port](#)
[config interface scheduler unbind port](#)

This section explain the commands for queue scheduling and shaping, either in bytes or packets.

Scheduling & Shaping Show Commands

show scheduler

This command is used to display the scheduler profile(s).

Usage

```
show scheduler [<profile_name>]
```

Parameters:

- <profile_name>: Profile name.

Example

```
admin@as5835-54t-2:~$ show scheduler
```

Name	Scheduling Type	Weight	Shaper Type	Bandwidth
scheduler_profile_queue0	WRR	20 bytes		10 Gbps

show interface scheduler

This command is used to display the scheduling and shaping for all interfaces or a given interface.

Usage

```
show interface scheduler [<interface_name>]
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
admin@sonic:~$ show interface scheduler
```

```
Ethernet0
```

Type	Queue	Profile	Scheduling Mode	Weight	Shaper Type	Bandwidth
Port	N/A	egress_port_shaper_profile	DWRR	N/A	bytes	10 Gbps
Queue	0	scheduler_profile_queue0	WRR	20	bytes	20 Gbps

Scheduling & Shaping Configuration Commands

User may create a schedule profile and bind/unbind the profile with port or egress queue of a port.

config scheduler add

This command is used to create a scheduler profile.

Usage

```
config scheduler add <profile_name> [--sched_type {WRR | DWRR | STRICT}] [--weight <weight>] [--shaper_type {bytes | packets}] [--bandwidth <bandwidth>]
```

Parameters:

- profile_name>: Profile name
- sched-type: Scheduling mode. Valid values are:
 - WRR : Weighted Round Robin.

- note : mode WRR is not supported in Intel ASIC; for example Wedge100BF-32X/32QS/65X or AS9516-32D.
- note: mellanox chips do not support the WRR mode. For example, AS9746-128D.
- DWRR : Deficit Weighted Round Robin.
 - Default value for Intel ASIC.
- STRICT : Strict mode.
- <weight>: Weight of the mode; in the range (1..100)
 - Default: 1.
- shaper-type: Shaper type of shaping. Valid values are:
 - bytes : Bytes mode.
 - packets : Packets mode. (mellanox chips do not support this parameter.)
- <bandwidth>: Maximum rate of traffic can pass through in kilo-bits/second (kbps) or packet/second (pps). Valid values are:
 - If meter-type is bytes :
 - The format is a decimal number or a decimal number followed by the abbreviation k (1000), m (1,000,000), or g (1,000,000,000). Minimum: 8 kbps (32 kbps for AS8000 and AS9746-32D). Maximum: 400,000,000 kbps. For example: "10", "10k".
 - If meter-type is packets :
 - Minimum: 1 pps (2 pps for AS9746-32D). Maximum: 148,809,523 pps (67,108,608 pps for AS9746-32D).

Example

```
sudo config scheduler add scheduler_profile_queue0 --sched_type DWRR --weight 10 --meter_type bytes --bandwidth 1250000
```

config scheduler update

This command is used to modify an existing scheduler profile.

Usage

```
config scheduler update <profile_name> [--sched-type {WRR | DWRR | STRICT}] [--weight <weight>] [--shaper-
```

```
type {bytes | packets}] [--bandwidth <bandwidth>] [--no-shaping]
```

Parameters:

- <profile_name>: Profile name
- sched-type: Scheduling mode. (This parameter is required for Intel platform) Valid values are:
 - WRR : Weighted Round Robin.
 - note : mode WRR is not supported in Intel ASIC; for example Wedge100BF-32X/32QS/65X or AS9516-32D.
 - DWRR : Deficit Weighted Round Robin.
 - Default value for Intel ASIC.
 - STRICT : Strict mode.
- <weight>: Weight of the mode; in the range (1..100)
 - Default: 1..
- shaper-type: Shaper type of shaping. Valid values are:
 - bytes : Bytes mode.
 - packets : Packets mode.
- <bandwidth>: Maximum rate of traffic can pass through in kilo-bits/second (kbps) or packet/second (pps). Valid values are:
 - If meter-type is bytes :
 - The format is a decimal number or a decimal number followed by the abbreviation k (1000), m (1,000,000), or g (1,000,000,000). Minimum: 8 kbps (32 kbps for AS8000 and AS9746-32D). Maximum: 400,000,000 kbps. For example:"10", "10k".
 - If meter-type is packets :
 - Minimum: 1 pps (2 pps for AS8000 and AS9746-32D). Maximum: 148,809,523 pps (67,108,608 pps for AS8000 and AS9746-32D).
- no-shaping: Disable the traffic shaping.

Example

```
sudo config scheduler update scheduler_profile_queue0 --sched_type WRR --weight 20 --meter_type bytes --bandwidth 2500000
```

config scheduler del

This command is used to delete a scheduler profile.

Usage

```
config scheduler del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config scheduler del scheduler_profile_queue0
```

config interface scheduler bind queue

This command is used to configure the scheduling and shaping setting on the specified queue.

Usage

```
config interface scheduler bind queue <interface_name> <queue> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <queue>: Queue. Minimum: 0. Maximum: 7.
- <profile_name>: Profile name.

Example

```
sudo config interface scheduler bind queue Ethernet0 0 scheduler_profile_queue0
```

config interface scheduler unbind queue

This command is used to reset the scheduling and shaping setting on the specified queue.

Usage

```
config interface scheduler unbind queue <interface_name> <queue>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <queue>: Queue. Minimum: 0. Maximum: 7.

Example

```
sudo config interface scheduler unbind queue Ethernet0 0
```

config interface scheduler bind port

This command is used to configure the shaping setting on the specified interface.

Usage

```
config interface scheduler bind port <interface_name> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <profile_name>: Profile name.

Note :

- This command is only supported on Intel switches.

Example

```
sudo config interface scheduler bind port Ethernet0 egress_port_shaper_profile
```

config interface scheduler unbind port

This command is used to reset the shaping setting on the specified interface.

Usage

```
config interface scheduler unbind port <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- <profile_name>: Profile name.

Note :

- This command is only supported on Intel switches.

Example

```
sudo config interface scheduler unbind port Ethernet0
```

42 sFlow

Table of Contents

[sFlow Show Commands](#)

[show sflow](#)

[show sflow interface](#)

[sFlow Config Commands](#)

[config sflow collector add](#)

[config sflow collector del](#)

[config sflow agent-id add](#)

[config sflow agent-id del](#)

[config sflow enable](#)

[config sflow interface](#)

[config sflow interface sample-rate](#)

[config sflow polling-interval](#)

Sampled flow, or sFlow, collects sampled packets and counters from traffic at a predefined sampling rate, encapsulates the data in sFlow packets, and then delivers them to remote collectors. This section describes the sFlow command syntax and usage.

sFlow Show Commands

show sflow

This command displays the global sFlow configuration that includes the admin state, collectors, the Agent ID, and counter polling interval.

Usage
show sflow

Example
admin@sonic:~# show sflow sFlow Global Information: sFlow Admin State: up sFlow Polling Interval: default sFlow AgentID: lo 2 Collectors configured: Name: collector_A IP addr: 10.11.46.2 UDP port: 6343 Name: collector_lo IP addr: 127.0.0.1 UDP port: 6343

show sflow interface

This command displays each interface's sFlow admin status and the sampling rate.

Usage

```
show sflow interface
```

Example

```
admin@sonic:~# show sflow interface
```

sFlow interface configurations

```
+-----+-----+-----+
| Interface | Admin State | Sampling Rate |
+=====+=====+=====+
| Ethernet0 | up         | 4000 |
+-----+-----+-----+
| Ethernet1 | up         | 4000 |
+-----+-----+-----+
...
+-----+-----+-----+
| Ethernet61 | up        | 4000 |
+-----+-----+-----+
| Ethernet62 | up        | 4000 |
+-----+-----+-----+
| Ethernet63 | up        | 4000 |
+-----+-----+-----+
```

sFlow Config Commands

config sflow collector add

This command adds an sFlow collector.

Usage

```
config sflow collector add <collector-name> {<ipv4-address | ipv6-address>} [--port <number>] [--vrf {default | mgmt}]
```

Parameters:

- <collector-name>, a unique name for the collector, max length is 16. The maximum number of collectors that can be configured is 2.
- <ipv4-address>, IPv4 address of the collector in dotted decimal format.
- <ipv6-address>, IPv6 address of the collector in x: x: x: x::x format, where :: notation specifies successive hexadecimal fields of zeros.
- port (OPTIONAL), specifies the UDP port of the collector.
 - valid range is from 0 to 65535. (default is 6343)
- vrf (OPTIONAL), specifies the VRF of the collector. (default is default)
 - default , connects using the default VRF.
 - mgmt , connects using the mgmt VRF. If the mgmt VRF doesn't be created yet, the default VRF will be used to connect to server.

The following example configures a collector "collect_A" whose IP address is 10.11.46.2.

Example

```
admin@sonic:~# sudo config sflow collector add collector_A 10.11.46.2
```

config sflow collector del

This command deletes an sFlow collector whose name is specified.

Usage

```
config sflow collector del <collector-name>
```

Parameters:

- <collector-name>, the collector to be removed.

This example deletes a collector "collector_A".

Example

```
admin@sonic:~# sudo config sflow collector del collector_A
```

config sflow agent-id add

This command configures an interface as the sampling agent ID.

Usage

```
config sflow agent-id add <interface-name>
```

Parameters:

- <interface-name>, the interface whose IPv4 or IPv6 address is to be used as the agent address in sFlow packets.

Note:

- This setting is global and applied to configured collector(s).
- If there is a configured agent ID, you need to delete it before adding a new one.

This example specifies interface lo as the agent ID.

Example

```
admin@sonic:~# sudo config sflow agent-id add lo
```

config sflow agent-id del

This command removes the current agent ID.

Usage

```
config sflow agent-id del
```

Example

```
admin@sonic:~# sudo config sflow agent-id del
```

config sflow enable

Enables (or disables) sFlow sampling, which starts (or stops) the sFlow daemon monitoring the traffic on the interface(s).

Usage

```
config sflow {enable | disable}
```

This example starts sFlow monitoring.

Example

```
admin@sonic:~# sudo config sflow enable
```

config sflow interface

Enables/disables sFlow monitoring for sampling on an interface or all interfaces.

Usage

```
config sflow interface {enable | disable} {<interface-name> | all}
```

Parameters:

- <interface-name>, the interface on which the flow is monitored. It can be enabled or disabled individually.
all, apply this configuration to all interfaces.

Note:

- To enable sFlow sampling correctly, you need to configure COPP. Here is a sample configuration that is appended to /usr/share /sonic/templates/copp_cfg.j2 .

copp_cfg.j2

```
{
  "COPP_GROUP": {
    "queue2_group1": {
      "cbs": "1000",
      "cir": "1000",
      "genetlink_mcgrp_name": "packets",
      "genetlink_name": "psample",
      "meter_type": "packets",
      "mode": "sr_tcm",
      "queue": "2",
      "red_action": "drop",
      "trap_action": "trap",
      "trap_priority": "1"
    }
  },
  "COPP_TRAP": {
    "sflow": {
      "trap_group": "queue2_group1",
      "trap_ids": "sample_packet"
    }
  }
}
```

The following example shows how to disable flow sampling on Ethernet40.

Example

```
admin@sonic:~# sudo config sflow interface disable Ethernet40
```

config sflow interface sample-rate

Configure the sampling rate of an interface.

Usage

```
config sflow interface sample-rate <interface-name> <value>
```

Parameters:

- <interface-name>, the interface on which the sampling rate is applied.
- <value>, sampling rate. Valid range: (100..8388608)
 - The value is the average number of packets skipped before the sample is taken. "The sampling rate specifies random sampling probability as the ratio of packets observed to samples generated. For example, a sampling rate of 256
 - specifies that, on average, 1 sample will be generated for every 256 packets observed."
- default sampling rates for link speeds

	link speed	sampling rate
1	1G	100
2	10G	1,000
3	40G	4,000
4	50G	5,000
5	100G	10,000
6	400G	40,000

Note:

- The Broadcom MAC chip supports a maximum of 4 different sampling rates per switch. It is recommended to use the default sampling rate unless it is a MUST.

The following example shows to how set a sampling rate of 1000 on interface Ethernet32.

Example

```
admin@sonic:~# sudo config sflow interface sample-rate Ethernet32 1000
```

config sflow polling-interval

This command is used to set the counter polling interval.

Usage

```
config sflow polling-interval <value>
```

Parameters:

- <value>, polling interval
 - valid range: 0, 5 to 300 seconds.
 - 0: disable counter polling
 - default: 20 seconds.

The following example shows how to set the polling interval to 30 seconds.

Example

```
admin@sonic:~# sudo config sflow polling-interval 30
```

43 Shared Buffer

Table of Contents

[Shared Buffer Show Commands](#)

- [show buffer pool](#)
- [show buffer profile](#)
- [show interface buffer priority-group](#)
- [show interface buffer queue](#)
- [show buffer_pool](#)
- [show headroom-pool](#)

[Shared Buffer Configuration Commands](#)

- [config buffer pool add](#)
- [config buffer pool del](#)
- [config buffer profile add](#)
- [config buffer profile update](#)
- [config buffer profile del](#)
- [config interface buffer bind priority-group](#)
- [config interface buffer unbind priority-group](#)
- [config interface buffer bind queue](#)
- [config interface buffer unbind queue](#)

[Queue and Priority-Group](#)

[Queue and Priority-Group Show Commands](#)

- [show queue counters](#)
- [show queue watermark](#)
- [show priority-group watermark](#)

[Queue and Priority-Group Clear Commands](#)

- [sonic-clear queuecounters](#)
- [sonic-clear queue watermark](#)
- [sonic-clear priority-group watermark](#)

Shared buffer is used to buffer the ingress packets, process, and insert into egress queue before transmitting out from the device.

In some applications, it needs trigger notification to send (back pressure) pause frame to inform transmitting device slow down, user needs to adjust the threshold on ingress or egress.

Shared Buffer Show Commands

show buffer pool

This command is used to display the buffer pool configuration.

Usage

```
show buffer pool <[pool_name]>
```

Parameters:

- <pool_name>: Pool name.

Example

```
admin@sonic:~$ show buffer pool
```

Pool	Type	Size	Xoff
egress_lossless_pool	egress	6,383,104 Bytes	
egress_lossy_pool	egress	6,383,104 Bytes	
ingress_lossless_pool	ingress	1,148,959 Bytes	5,744,794 Bytes
ingress_lossy_pool	ingress	5,872,456 Bytes	

show buffer profile

This command is used to display the buffer profile configuration.

Usage

```
show buffer profile <[profile_name]>
```

Parameters:

- <profile_name>: Profile name.

Example

```
admin@sonic:~$ show buffer profile
```

Profile	Pool	Size	Shared Mode	Shared Size	Xoff
Xon	Xon-offset				

```
egress_lossless_profile egress_lossless_pool 0 Bytes dynamic 66%
egress_lossy_profile egress_lossy_pool 0 Bytes dynamic 66%
ingress_lossless_profile ingress_lossless_pool 0 Bytes dynamic 66% 5,744,794 Bytes 18
KiB
ingress_lossy_profile ingress_lossy_pool 0 Bytes dynamic 66%
```

show interface buffer priority-group

This command is used to display the buffer configuration of the priority-group (PG) for all interfaces or a given interface.

Usage

```
show interface buffer priority-group <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
admin@sonic:~$ show interface buffer priority-group
Interface PG Profile
-----
Ethernet0 0-2 buffer_prof1
```

show interface buffer queue

This command is used to display the buffer configuration for the queue for all interfaces or a given interface.

Usage

```
show interface buffer queue <interface_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
admin@sonic:~$ show interface buffer queue
```

Interface	Queue	Profile
Ethernet0	0	buffer_prof2

show buffer_pool

This command is used to display the watermark of shared buffer for buffer pools.

Usage
show buffer_pool {watermark persistent-watermark}

Parameters:

- watermark: show how user watermark for buffer pools.
- persistent-watermark: show persistent watermark for buffer pools.

Example
<pre>admin@sonic:~\$ show buffer_pool watermark Shared pool maximum occupancy: Pool Bytes ----- egress_lossless_pool 982320 egress_lossy_pool 0 ingress_lossless_pool 919680 ingress_lossy_pool 0 admin@sonic:~\$ admin@sonic:~\$ show buffer_pool persistent-watermark Shared pool maximum occupancy: Pool Bytes ----- egress_lossless_pool 982320 egress_lossy_pool 0 ingress_lossless_pool 919680 ingress_lossy_pool 0</pre>

show headroom-pool

This command is used to display the watermark of shared buffer for headroom pools.

Usage

```
show headroom-pool {watermark | persistent-watermark}
```

Parameters:

- watermark: show how user watermark for headroom pools.
- persistent-watermark: show persistent watermark for headroom pools.

Example

```
admin@sonic:~$ show headroom-pool watermark
```

Headroom pool maximum occupancy:

Pool	Bytes
ingress_lossless_pool	197866

```
admin@sonic:~$ show headroom-pool persistent-watermark
```

Headroom pool maximum occupancy:

Pool	Bytes
ingress_lossless_pool	197866

Shared Buffer Configuration Commands

config buffer pool add

This command is used to create a buffer pool profile.

Usage

```
config buffer pool add {pool_name} --type {ingress | egress} --size <size> [--xoff-size <xoff-size>]
```

Parameters:

- <pool_name>: Pool name.
- type: Stage. Valid values are:
 - ingress : Ingress stage.
 - egress: Egress stage.
- <size>: The size of the shared buffer in bytes.

- **<xoff-size>**: The size of the shared headroom in bytes. Available only for ingress stage.

Note: If changed the buffer pool setting, it is needed to restart the switch for the setting to take effect .

Example

```
sudo config buffer pool add ingress_pool --type ingress --size 9600000 --xoff-size 300000
```

Example

```
sudo config buffer pool add egress_pool --type egress --size 8400000
```

config buffer pool del

This command is used to delete a buffer pool profile.

Usage

```
config buffer pool del {pool_name}
```

Parameters:

- **<pool_name>**: Pool name.

Note: If changed the buffer pool setting, it is needed to restart the switch for the setting to take effect .

Example

```
sudo config buffer pool del ingress_pool
sudo config buffer pool del egress_pool
```

config buffer profile add

This command is used to create a buffer profile.

Usage

```
config buffer profile add <profile_name> --pool <buffer_pool_name> [--size <size>] [--shared-size
<shared_size> | --shared-percent <shared_percent>] [--xoff <xoff_size> --xon <xon_size> --xon-offset <xon_offset>]
```

Parameters:

- <profile_name>: Profile name.
- <buffer_pool_name>: Pool name.
- <size>: Reserved size in bytes.
- <shared_size>: Shared size in bytes.
- <shared_percent>: Shared size in percentage. The shared size is "the free size of buffer pool × shared percentage". Valid values are:
 - 0.78: 0.78% (alpha: 1/128) (only available on Broadcom platform).
 - 1.5: 1.5% (alpha: 1/64).
 - 3: 3% (alpha: 1/32).
 - 6: 6% (alpha: 1/16).
 - 11: 11% (alpha: 1/8).
 - 20: 20% (alpha: 1/4).
 - 33: 33% (alpha: 1/2).
 - 50: 50% (alpha: 1).
 - 66: 66% (alpha: 2).
 - 80: 80% (alpha: 4).
 - 89: 89% (alpha: 8) (only available on Broadcom platform).
- <xoff_size>: Headroom size in bytes. Only for ingress lossless profile.
- <xon_size>: Resume size in bytes. Only for ingress lossless profile.
- <xon_offset_size>: Resume offset size in bytes. Only for ingress lossless profile. This size doesn't support on Intel platform.

Example

```
sudo config buffer profile add ingress_profile_lossy --pool ingress_pool --shared_percent 1 --size 0
```

config buffer profile update

This command is used to modify an existing buffer profile.

Usage

```
config buffer profile update <profile_name> [--shared-percent <shared_percent>] [--xon <xon_size>]
```

Parameters:

- <profile_name>: Profile name.
- <shared_percent>: Shared size in percentage. The shared size is "the free size of buffer pool × shared percentage". Valid values are:
 - 0.78: 0.78% (alpha: 1/128) (only available on Broadcom platform).
 - 1.5: 1.5% (alpha: 1/64).
 - 3: 3% (alpha: 1/32).
 - 6: 6% (alpha: 1/16).

- 11: 11% (alpha: 1/8).
- 20: 20% (alpha: 1/4).
- 33: 33% (alpha: 1/2).
- 50: 50% (alpha: 1).
- 66: 66% (alpha: 2).
- 80: 80% (alpha: 4).
- 89: 89% (alpha: 8) (only available on Broadcom platform).
- <xon_size>: Resume size in bytes. Only for ingress lossless profile.

Example

```
sudo config buffer profile update ingress_profile_lossy --pool ingress_pool --shared_percent 66 --size 100
```

config buffer profile del

This command is used to delete a buffer profile.

Usage

```
config buffer profile del <profile_name>
```

Parameters:

- <profile_name>: Profile name.

Example

```
sudo config buffer profile del ingress_profile_lossy
```

config interface buffer bind priority-group

This command is used to bind the buffer profile to the ingress priority group.

Usage

```
config interface buffer bind priority-group {<interface_name> | all} <pg> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.
- <pg>: Priority Group. Valid values are:
 - Minimum: 0. Maximum: 7. (Broadcom platform)
 - Minimum: 1. Maximum: 5. (Intel platform)

- <profile_name>: Profile name.

Example

```
sudo config interface buffer bind priority-group Ethernet0 0 ingress_profile_lossy
```

config interface buffer unbind priority-group

This command is used to unbind the buffer profile from the ingress priority group.

Usage

```
config interface buffer unbind priority-group {<interface_name> | all} <pg>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.
- <pg>: Priority Group.

Here is an example for unbinding profile "ingress_profile_lossy" from interface "Ethernet0" pg 0.

Example

```
sudo config interface buffer unbind priority-group Ethernet0 0
```

config interface buffer bind queue

This command is used to bind the buffer profile to the egress queue.

Usage

```
config interface buffer bind queue {<interface_name> | all} <queue> <profile_name>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.
- <queue>: Queue. Minimum: 0. Maximum: 7.
- <profile_name>: Profile name.

Example

```
sudo config interface buffer bind queue Ethernet0 0 egress_profile
```

config interface buffer unbind queue

This command is used to unbind the buffer profile from the egress queue.

Usage

```
config interface buffer unbind queue {<interface_name> | all} <queue>
```

Parameters:

- <interface_name>: Physical interface name. For example: "Ethernet0".
- all: All physical interfaces.
- <queue>: Queue. Minimum: 0. Maximum: 7.

Example

```
sudo config interface buffer unbind queue Ethernet0 0
```

Queue and Priority-Group

This sub-section describes some queue and priority-group parameters. It can be displayed in show queue commands or show priority-group commands.

queue counters

queue watermark

priority-group

Queue and Priority-Group Show Commands

show queue counters

This command displays packet and byte counters for all queues of all ports or one specific-port specified as an argument.

Display packet and byte counters of interface(s).

Usage

```
show queue counters [<interface_name>]
```

Parameters:

- <interface name>: The interface of associated counter. Without this, it shows all ports.

Example

```
admin@sonic:~$ show queue counters
```

Port	TxQ	Counter/pkts	Counter/bytes	Drop/pkts	Drop/bytes
Ethernet0	UC0	0	0	0	0
Ethernet0	UC1	0	0	0	0
Ethernet0	UC2	0	0	0	0
Ethernet0	UC3	0	0	0	0
Ethernet0	UC4	0	0	0	0
Ethernet0	UC5	0	0	0	0
Ethernet0	UC6	0	0	0	0
Ethernet0	UC7	0	0	0	0
Ethernet0	UC8	0	0	0	0
Ethernet0	UC9	0	0	0	0
Ethernet0	MC0	0	0	0	0
Ethernet0	MC1	0	0	0	0
Ethernet0	MC2	0	0	0	0
Ethernet0	MC3	0	0	0	0
Ethernet0	MC4	0	0	0	0
Ethernet0	MC5	0	0	0	0
Ethernet0	MC6	0	0	0	0
Ethernet0	MC7	0	0	0	0
Ethernet0	MC8	0	0	0	0
Ethernet0	MC9	0	0	0	0
Port	TxQ	Counter/pkts	Counter/bytes	Drop/pkts	Drop/bytes
Ethernet4	UC0	0	0	0	0
Ethernet4	UC1	0	0	0	0
Ethernet4	UC2	0	0	0	0
Ethernet4	UC3	0	0	0	0
Ethernet4	UC4	0	0	0	0
Ethernet4	UC5	0	0	0	0
Ethernet4	UC6	0	0	0	0

Ethernet4	UC7	0	0	0	0
Ethernet4	UC8	0	0	0	0
Ethernet4	UC9	0	0	0	0
Ethernet4	MC0	0	0	0	0
Ethernet4	MC1	0	0	0	0
Ethernet4	MC2	0	0	0	0
Ethernet4	MC3	0	0	0	0
Ethernet4	MC4	0	0	0	0
Ethernet4	MC5	0	0	0	0
Ethernet4	MC6	0	0	0	0
Ethernet4	MC7	0	0	0	0
Ethernet4	MC8	0	0	0	0
Ethernet4	MC9	0	0	0	0
...					

Optionally, you can specify an interface name in order to only display the particular interface.

Example

```
admin@sonic:~$ show queue counters Ethernet72
```

Port	TxQ	Counter/pkts	Counter/bytes	Drop/pkts	Drop/bytes
Ethernet72	UC0	0	0	0	0
Ethernet72	UC1	0	0	0	0
Ethernet72	UC2	0	0	0	0
Ethernet72	UC3	0	0	0	0
Ethernet72	UC4	0	0	0	0
Ethernet72	UC5	0	0	0	0
Ethernet72	UC6	0	0	0	0
Ethernet72	UC7	0	0	0	0
Ethernet72	UC8	0	0	0	0
Ethernet72	UC9	0	0	0	0
Ethernet72	MC0	0	0	0	0
Ethernet72	MC1	0	0	0	0
Ethernet72	MC2	0	0	0	0
Ethernet72	MC3	0	0	0	0

Ethernet72	MC4	0	0	0	0
Ethernet72	MC5	0	0	0	0
Ethernet72	MC6	0	0	0	0
Ethernet72	MC7	0	0	0	0
Ethernet72	MC8	0	0	0	0
Ethernet72	MC9	0	0	0	0

Note: Queue counters can be cleared by using the following command: sonic-clear queuecounters

show queue watermark

This command displays the user watermark or persistent-watermark for unicast or multicast queues (egress shared pool occupancy per queue) for all ports.

Usage

```
show queue {watermark | persistent-watermark} {multicast | unicast|all}
```

Parameters:

- watermark , the highest watermark after the last clean command.
- persistent-watermark , the highest watermark after system bring up.
- The 'all' designation refers to a specific queue type, it does not signify a merging of multicast and unicast.

Note: Both "user watermark" and "persistent watermark" can be cleared by the user.

Example: show for unicast of watermark

```
admin@sonic:~$ show queue watermark unicast
```

Egress shared pool occupancy per unicast queue:

Port	UC0	UC1	UC2	UC3	UC4	UC5	UC6	UC7	UC8	UC9
Ethernet0	0	0	0	0	0	0	0	0	0	0
Ethernet4	416	0	0	0	0	0	0	0	0	0
Ethernet8	416	0	0	0	0	0	0	0	0	0
Ethernet12	416	0	0	0	0	0	0	0	0	0

Example: show for multicast of watermark

```
admin@sonic:~$ show queue watermark multicast
```

Egress shared pool occupancy per multicast queue:

Port	MC10	MC11	MC12	MC13	MC14	MC15	MC16	MC17	MC18	MC19
Ethernet0	0	0	0	0	0	0	0	0	0	0
Ethernet4	416	0	0	0	0	0	0	0	0	0
Ethernet8	416	0	0	0	0	0	0	0	0	0
Ethernet12	416	0	0	0	0	0	0	0	0	0
Ethernet16	416	0	0	0	0	0	0	0	0	0

Example: show for unicast of persistent-watermark

```
admin@sonic:~$ show queue persistent-watermark unicast
```

Egress shared pool occupancy per unicast queue:

Port	UC0	UC1	UC2	UC3	UC4	UC5	UC6	UC7	UC8	UC9
Ethernet0	0	0	0	0	0	0	0	0	0	0
Ethernet4	416	0	0	0	0	0	0	0	0	0
Ethernet8	416	0	0	0	0	0	0	0	0	0

Example: show for multicast of persistent-watermark

```
admin@sonic:~$ show queue persistent-watermark multicast
```

Egress shared pool occupancy per multicast queue:

Port	MC10	MC11	MC12	MC13	MC14	MC15	MC16	MC17	MC18	MC19
Ethernet0	0	0	0	0	0	0	0	0	0	0
Ethernet4	0	0	0	0	0	0	0	0	0	0
Ethernet8	0	0	0	0	0	0	0	0	0	0

show priority-group watermark

This command displays the user watermark or persistent-watermark for the Ingress "headroom" or "shared pool occupancy" per priority-group for all ports.

Usage

```
show priority-group {watermark | persistent-watermark} {headroom | shared}
```

Parameters:

- watermark , the highest watermark after the last clean command.
- persistent-watermark , the highest watermark after system bring up.
- headroom , the max size of headroom has been used.
- shared , the max size has been used in shared pool.

Note: Both "user watermark" and "persistent watermark" can be cleared by the user.

Example

```
admin@sonic:~$ show priority-group watermark shared
```

Ingress shared pool occupancy per PG:

Port	PG0	PG1	PG2	PG3	PG4	PG5	PG6	PG7
Ethernet0	0	0	0	0	0	0	0	0
Ethernet4	0	0	0	0	0	0	0	0
Ethernet8	0	0	0	0	0	0	0	0
Ethernet12	0	0	0	0	0	0	0	0

Example (Ingress headroom per PG)

```
admin@sonic:~$ show priority-group watermark headroom
```

Ingress headroom per PG:

Port	PG0	PG1	PG2	PG3	PG4	PG5	PG6	PG7
Ethernet0	0	0	0	0	0	0	0	0
Ethernet4	0	0	0	0	0	0	0	0
Ethernet8	0	0	0	0	0	0	0	0

Example (Ingress shared pool occupancy per PG)

```
admin@sonic:~$ show priority-group persistent-watermark shared
```

Ingress shared pool occupancy per PG:

Port	PG0	PG1	PG2	PG3	PG4	PG5	PG6	PG7
Ethernet0	0	0	0	0	0	0	0	0
Ethernet4	0	0	0	0	0	0	0	0
Ethernet8	0	0	0	0	0	0	0	0

Example (Ingress headroom per PG)

```
admin@sonic:~$ show priority-group persistent-watermark headroom
```

Ingress headroom per PG:

Port	PG0	PG1	PG2	PG3	PG4	PG5	PG6	PG7
Ethernet0	0	0	0	0	0	0	0	0
Ethernet4	0	0	0	0	0	0	0	0
Ethernet8	0	0	0	0	0	0	0	0

Queue and Priority-Group Clear Commands

sonic-clear queuecounters

This command will clear the packet and byte counters for all queues of all ports.

Usage

```
sonic-clear queuecounters
```

Example

```
admin@sonic:~$ sonic-clear queuecounters
```

Clear and update saved counters for Ethernet0

Clear and update saved counters for Ethernet1

Clear and update saved counters for Ethernet2

Clear and update saved counters for Ethernet3

sonic-clear queue watermark

This command will clear the user watermark or persistent-watermark for unicast or multicast queues (egress shared pool occupancy per queue) for all ports.

The 'all' designation refers to a specific queue type, it does not signify a merging of multicast and unicast.

Usage

```
sonic-clear queue {watermark | persistent-watermark} {unicast | multicast|all}
```

Example: clear unicast of user watermark

```
admin@sonic:~$ sudo sonic-clear queue watermark unicast
```

Example: clear multicast of user watermark

```
admin@sonic:~$ sudo sonic-clear queue watermark multicast
```

Example: clear unicast of persistent-watermark

```
admin@sonic:~$ sudo sonic-clear queue persistent-watermark unicast
```

Example: clear multicast of persistent-watermark

```
admin@sonic:~$ sudo sonic-clear queue persistent-watermark multicast
```

sonic-clear priority-group watermark

This command will clear the user watermark or persistent-watermark for the Ingress "headroom" or "shared pool occupancy" per priority-group for all ports.

Usage

```
sonic-clear priority-group {watermark | persistent-watermark} {headroom | shared}
```

Parameters:

- watermark , the highest watermark after the last clean command.
- persistent-watermark , the highest watermark after system bring up.
- headroom , the max size of headroom has been used.
- shared , the max size has been used in shared pool.

Example: clear headroom of user watermark

```
admin@sonic:~$ sudo sonic-clear priority-group watermark headroom
```

Example: clear shared pool occupancy of user watermark

```
admin@sonic:~$ sudo sonic-clear priority-group watermark shared
```

Example: clear headroom of persistent-watermark

```
admin@sonic:~$ sudo sonic-clear priority-group persistent-watermark headroom
```

Example: clear shared pool occupancy of persistent-watermark

```
admin@sonic:~$ sudo sonic-clear priority-group persistent-watermark shared
```

44 SNMP

Table of Contents

[SNMP Show commands](#)

- [show runningconfiguration snmp](#)
- [show runningconfiguration snmp location](#)
- [show runningconfiguration snmp contact](#)
- [show runningconfiguration snmp community](#)
- [show snmp snmpagentaddress](#)

[SNMP Config commands](#)

- [config snmp location modify](#)
- [config snmp location del](#)
- [config snmp contact add](#)
- [config snmp contact modify](#)
- [config snmp contact del](#)
- [config snmp community add](#)
- [config snmp community replace](#)
- [config snmp community del](#)
- [config snmpagentaddress add](#)
- [config snmpagentaddress del](#)

SNMP Show commands

show runningconfiguration snmp

This command displays the global SNMP configuration that includes the location, contact, and community settings.

Usage
show runningconfiguration snmp

Example

```
admin@sonic:~$ show runningconfiguration snmp
Location
-----
Emerald City
SNMP_CONTACT  SNMP_CONTACT_EMAIL
-----
joe          joe@contoso.com
Community String  Community Type
-----
Jack          RW
```

show runningconfiguration snmp location

This command displays the SNMP location setting.

Usage

```
show runningconfiguration snmp location [--json]
```

Parameters:

- **json:** Display the output in JSON format.

Example

```
admin@sonic:~$ show runningconfiguration snmp location
Location
Emerald City
```

Example with json format

```
admin@sonic:~$ show runningconfiguration snmp location --json
{'Location': 'Emerald City'}
```

show runningconfiguration snmp contact

This command displays the SNMP contact setting.

Usage

```
show runningconfiguration snmp contact [--json]
```

Parameters:

- json: Display the output in JSON format.

Example

```
admin@sonic:~$ show runningconfiguration snmp contact
```

Contact	Contact Email
joe	joe@contoso.com

Example with json format

```
admin@sonic:~$ show runningconfiguration snmp contact --json
```

```
{'joe': 'joe@contoso.com'}
```

show runningconfiguration snmp community

This command displays the SNMP community setting.

Usage

```
show runningconfiguration snmp community [--json]
```

Parameters:

- json: Display the output in JSON format.

Example

```
admin@sonic:~$ show runningconfiguration snmp community
Community String  Community Type
-----
Jack             RW
```

Example with json format

```
admin@sonic:~$ show runningconfiguration snmp community --json
{'Jack': {'TYPE': 'RW'}}
```

show snmp snmpagentaddress

This command displays the SNMP agent address setting.

Usage

```
show snmp snmpagentaddress
```

Example

```
admin@sonic:~$ show snmpagentaddress
ListenIP  ListenPort  ListenVrf
-----
10.0.0.60
```

SNMP Config commands

config snmp location modify

This command is used to modify the SNMP location.

Usage

```
config snmp location modify <location>
```

Parameters:

- <location>: SNMP location, default value is "public".

Example

```
admin@as7326-56x:~$ sudo config snmp location modify USA
```

config snmp location del

This command is used to restore the SNMP location.

Usage

```
config snmp location del <location>
```

Parameters:

- <location>: SNMP location, default value is "public".

Example

```
admin@as7326-56x:~$ sudo config snmp location del USA
```

config snmp contact add

This command is used to add the SNMP contact.

Usage

```
config snmp contact add <contact_name> <contact_email>
```

Parameters:

- <contact_name>: SNMP contact.
- <contact_email>: SNMP contact email.

Example

```
admin@sonic:~$ sudo config snmp contact add joe joe@contoso.com
```

config snmp contact modify

This command is used to modify the SNMP contact.

Usage

```
config snmp contact modify <contact> <contact_email>
```

Parameters:

- <contact>: SNMP contact.
- <contact_email>: SNMP contact email.

Example

```
admin@sonic:~$ sudo config snmp contact modify test test@contoso.com
```

config snmp contact del

This command is used to delete the SNMP contact.

Usage

```
config snmp contact del <contact>
```

Parameters:

- <contact>: SNMP contact.

Example

```
admin@sonic:~$ sudo config snmp contact del test
```

config snmp community add

This command is used to add the SNMP community.

Usage

```
config snmp community add <snmp_community> <access_type>
```

Parameters:

- <snmp_community>: SNMP community.
- <access_type>: one of the following:
 - RO : Read-only community.
 - RW : Read-write community.

Example

```
admin@sonic:~$ sudo config snmp community add testcomm ro
```

config snmp community replace

This command is used to replace the SNMP community.

Usage

```
config snmp community replace <current_community_string> <new_community_string>
```

Parameters:

- <current_community_string>: current SNMP community.
- <new_community_string>: new SNMP community.

Example

```
admin@sonic:~$ sudo config snmp community replace testcomm newtestcomm
```

config snmp community del

This command is used to delete the SNMP community.

Usage

```
config snmp community del <snmp_community>
```

Parameters:

- <snmp_community>: SNMP community.

Example

```
admin@sonic:~$ sudo config snmp community del newtestcomm
```

config snmpagentaddress add

This command is used to add the SNMP agent address.

Usage

```
config snmpagentaddress add <agent_address> [-p|--port <port>] [-v|--vrf <vrf_name>]
```

Parameters:

- <agent_address>: IP address of SNMP agent.
- <port>: Port number of SNMP agent. Default value is 161.
- <vrf_name>: VRF name. Indicates that the SNMP agent is part of the VRF.

Example

```
admin@as7326-56x:~$ sudo config snmpagentaddress add 10.0.0.60
```

config snmpagentaddress del

This command is used to delete the SNMP agent address.

Usage

```
config snmpagentaddress del <agent_address> [-p|--port <port>] [-v|--vrf <vrf_name>]
```

Parameters:

- <agent_address>: IP address of SNMP agent.
- <port>: Port number of SNMP agent. Default value is 161.
- <vrf_name>: VRF name. Indicates that the SNMP agent is part of the VRF.

Example

```
admin@as7326-56x:~$ sudo config snmpagentaddress del 10.0.0.60
```

45 SNMP Traps

Table of Contents

[SNMP Trap Show Commands](#)

[show snmptrap](#)

[SNMP Trap Config Commands](#)

[config snmptrap modify](#)

[config snmptrap del](#)

SNMP Trap Show Commands

show snmptrap

This command displays the configured SNMP trap server IP addresses.

Usage

```
show snmptrap
```

Example

```
admin@sonic:~$ show snmptrap
Version TrapReceiverIP  Port VRF  Community
-----
      2 31.31.31.31      456 mgmt  public
```

SNMP Trap Config Commands

config snmptrap modify

This command configures the trap server IP address and some options for the traps.

Usage

```
config snmptrap modify <snmp version> [-p <port>] [-v <vrf name>] [-c <community>] <trap server ip>
```

Parameters:

- <snmp version>: SNMP version. Each SNMP version can be configured with one trap server IP address.
 - 1

- 2
- 3
- <port>: the port to receive the SNMP traps. (default: 162)
- <vrf name>: VRF name; using this VRF name, the SNMP agent sends the trap through the <vrf name> domain. The option can be one of following VRF types:
 - mgmt, the keyword to specify management VRF
 - none , the keyword to clear the VRF specified before
 - <name> , specifies the name of one data VRF
- <community>
- <trap server ip>: The server IP address that receives the trap

Note:

- The configuration is stored in snmpd.conf ,
- The SNMP service is restarted to take the configuration effect.

Example

```
admin@sonic:~$ sudo config snmptrap modify 2 -p 456 -v mgmt 21.21.21.21
trap2sink 21.21.21.21:456%mgmt public
```

In this example, a user configures a trap server address (21.21.21.21) for SNMP version 2, changes the port (456), and specifies the management VRF domain. This configuration is stored in /etc/snmp/snmpd.conf inside of the SNMP docker.

In the output information, the "%mgmt" would not be present if the "-v" option is not specified.

In the case of SNMPv1, "trapsink" will be updated, and in the case of v2, "trap2sink" will be updated.

config snmpinform del

This command deletes the trap server configuration of the specified SNMP version. This configuration is removed from snmpd.conf and the SNMP service restarted to make this configuration effective in the SNMP agent.

Usage

```
config snmpinform del <snmp_version>
```

Parameters:

<snmp version>, the version to be deleted.

Example

```
admin@sonic:~$ sudo config snmpinform del 2
```

45.1 SNMP inform

Table of Contents

[SNMP Inform 显示指令](#)

[show snmpInform](#)

[SNMP Inform配置指令](#)

[config snmpInform modify](#)

[config snmpInform del](#)

SNMP Inform show commands

show snmpinform

This command displays the configured SNMP trap server IP address.

Usage

```
show snmpinform
```

Example

```
admin@sonic:~$ show snmpinform
Version TrapReceiverIP  Port  VRF  Community
-----
2 31.31.31.31          456 mgmt  public
```

SNMP Inform Config Commands

config snmpinform modify

This command configures the IP address of the inform server and some options for the inform.

Usage
config snmptrap modify <snmp version> [-p <port>] [-v <vrf name>] [-c <community>] <inform server ip>

Parameters:

- < snmp version > : SNMP version. SNMPv2 and SNMPv3 version can be configured with one inform server IP address.
 - 2
 - 3
- <port>: the port to receive the SNMP inform. (default: 162)
- <vrf名称>: VRF name; using this VRF name, the SNMP agent sends the trap through the <vrf name> domain. The option can be one of following VRF types:
 - mgmt, the keyword to specify management VRF
 - none , the keyword to clear the VRF specified before
 - <name>, specifies the name of one data VRF
- <community>
 - default value public
 - When configuring the SNMPv3 version, the username should be SNMPv3

•<inform server ip>: The server IP address that receives the inform

Note:

- The configuration is stored in snmpd.conf ,
- The SNMP service is restarted to take the configuration effect.

Example

```
admin@sonic:~$ sudo config snmpinform modify 2 -p 456 -v mgmt 21.21.21.21
informsink 21.21.21.21:456%mgmt public
```

In this example, a user configures a trap server address (21.21.21.21) for SNMP version 2, changes the port (456), and specifies the management VRF domain. This configuration is stored in /etc/snmp/snmpd.conf inside of the SNMP docker.

In the output information, the "%mgmt" would not be present if the "-v" option is not specified.

In the case of SNMPv1, "trapsink" will be updated, in the case of v2, "trap2sink" will be updated, and in the case of v3, "trapssess" will be updated.

Example

```
admin@sonic:~$ sudo config snmpinform modify 3 -p 456 21.21.21.21 -c myuser
```

The configuration file/etc/snmp/snmpd.conf will generate the following configuration

```
trapssess -Ci -v 3 -l authPriv -e 0x80001f888069061b0e86e4b66700000000 21.21.21.21:456 -u myuser
```

In this example, a user configures a inform server address (21.21.21.21) for SNMP version 3, changes the port (456), specifies the management VRF domain, and set the SNMPv3 user. This configuration is stored in /etc/snmp/snmpd.conf inside of the SNMP docker.

In the output information, the "%mgmt" would not be present if the "-v" option is not specified.

In the case of SNMPv2, "trap2sink" will be updated, and in the case of v3, "trapssess" will be updated.

config snmpinform del

This command deletes the trap server configuration for the specified SNMP version.

This configuration will be removed from snmpd.conf and the SNMP service will restart for this configuration to take effect in the SNMP agent.

Usage
config snmpinform del <snmp_version>

参数:

<snmp version>, the version to be deleted.

Example
admin@sonic:~\$ sudo config snmpinform del 2

46 Software Installation and Management

Table of Contents

[SONiC Installer](#)

- [sonic-installer list](#)
- [sonic-installer install](#)
- [sonic-installer set-default](#)
- [sonic-installer set-nex-boot](#)
- [sonic-installer remove](#)
- [sonic-installer cleanup](#)
- [sonic_installer binary_version \(not supported\)](#)
- [sonic_installer rollback_docker \(not supported\)](#)
- [sonic_installer upgrade_docker \(not supported\)](#)

The SONiC software can be installed by two methods; using the "sonic_installer" tool or "ONIE Installer".

SONiC Installer

This is a command line tool available as part of the SONiC software; If the device is already running the SONiC software, this tool can be used to install an alternate image in the partition. This tool has the facility to install an alternate image, list the available images, and set the next reboot image. This command requires elevated (root) privileges to run.

sonic-installer list

This command displays information about currently installed images. It displays a list of installed images, the currently running image, and the image set to be loaded at the next reboot.

Usage:
sonic-installer list

Example:

```
admin@tor:~$ sudo sonic-installer list
Current: SONiC_20220819_084543_202111_184
Next: SONiC_20220819_084543_202111_184
Available:
SONiC_20220819_084543_ec202111_184
SONiC_20220526_081320_ec202111_117
```

This output can be obtained without root privileges by running the show boot command.

sonic-installer install

This command is used to install a new image in the alternate image partition. This command takes a path to an installable SONiC image or URL and installs the image.

Usage:

```
sonic-installer install [OPTIONS] <image_file_path>
```

Options:

- -y, --yes, When prompted 'yes/no', select 'yes' directly
- -f, --force, Forces installation of an image of a type that differs from that of the currently running image
- --skip-platform-check, Force installation of an image of a type which is not of the same platform
- --skip_migration, Do not migrate current configuration to the newly installed image
- --skip-package-migration, Do not migrate current packages to the newly installed image
- --skip-setup-swap, Skip setup temporary SWAP memory used for installation
- --swap-mem-size <INTEGER> , SWAP memory space size [default: (1024MiB)] NOTE: this argument is mutually exclusive with arguments: skip_setup_swap

- --total-mem-threshold <INTEGER> ,If system total memory is lower than threshold, setup SWAP memory [default:(2048 MiB)] NOTE: this argument is mutually exclusive with arguments:skip_setup_swap
- --available-mem-threshold <INTEGER> , If system available memory is lower than threshold, setup SWAP memory [default:(1200 MiB)] NOTE: this argument is mutually exclusive with arguments: skip_setup_swap

Note

- By default, the current configuration will be migrated to the newly installed image. The option "--skip_migration" can be applied to omit the migration of configuration.
- If a kernel panic has ever occurred on the running of the current image, there will be dmesg files in "/sys/fs/pstore/", which can be used for debugging. It is strongly recommended to have a backup before installing a new image. Also, remember to note down the current image version so the dmesg files can be correlated to the correct image version.
- The format of files in the "/sys/fs/pstore/" may not be compatible with all Linux kernel versions, which could result in error logs that read "pstore: crypto comp decompress failed, ret = -22!" when the system boots. These files will be deleted after the first boot with the freshly loaded image to prevent them from showing harmless error logs that can confuse users.

Example:

```
admin@sonic:~$ sudo sonic-installer install https://sonic-jenkins.westus.cloudapp.azure.com/job/xxxx/job/buildimage-xxxx-all/xxx/artifact/target/sonic-xxxx.bin
New image will be installed, continue? [y/N]: y
Downloading image...
...100%, 480 MB, 3357 KB/s, 146 seconds passed
Command: /tmp/sonic_image
Verifying image checksum ... OK.
Preparing image archive ... OK.
ONIE Installer: platform: XXXX
onie_platform:
Installing SONiC in SONiC
Installing SONiC to /host/image-xxxx
Directory /host/image-xxxx/ already exists. Cleaning up...
Archive: fs.zip
creating: /host/image-xxxx/boot/
```

```
inflating: /host/image-xxxx/boot/vmlinuz-3.16.0-4-amd64
inflating: /host/image-xxxx/boot/config-3.16.0-4-amd64
inflating: /host/image-xxxx/boot/System.map-3.16.0-4-amd64
inflating: /host/image-xxxx/boot/initrd.img-3.16.0-4-amd64
creating: /host/image-xxxx/platform/
extracting: /host/image-xxxx/platform/firsttime
inflating: /host/image-xxxx/fs.squashfs
inflating: /host/image-xxxx/dockerfs.tar.gz
Log file system already exists. Size: 4096MB
Installed SONiC base image SONiC-OS successfully
Command: cp /etc/sonic/minigraph.xml /host/
Command: grub-set-default --boot-directory=/host 0
Done
```

sonic-installer set-default

This command is used to change the image that can be loaded by default in all the subsequent reboots.

Usage:

```
sonic-installer set-default <image_name>
```

Example:

```
admin@sonic:~$ sudo sonic-installer set-default SONiC-OS-HEAD.XXXX
```

sonic-installer set-nex-boot

This command is used to change the image that can be loaded in the next reboot only. Note that following the next reboot, it will always fall back to the current image.

Usage:

```
sonic-installer set-next-boot <image_name>
```

Example:

```
admin@sonic:~$ sudo sonic-installer set-next-boot SONiC-OS-HEAD.XXXX
```

sonic-installer remove

This command is used to remove the unused SONiC image from the disk. Note that it's not allowed to remove the currently running image.

Usage:

```
sonic-installer remove [y|yes] <image_name>
```

Example:

```
admin@sonic:~$ sudo sonic-installer remove SONiC-OS-HEAD.YYYY
Image will be removed, continue? [y/N]: y
Updating GRUB...
Done
Removing image root filesystem
Done
Command: grub-set-default  boot-directory=/host 0
Image removed
```

sonic-installer cleanup

This command removes all unused images from the device, leaving only the currently active image and the image that will be booted next (if different). If there are no images that can be removed, the command will output "No image(s) to remove".

Usage:

```
sonic-installer cleanup [y|-yes]
```

Example:

```
admin@sonic:~$ sudo sonic-installer cleanup
Remove images which are not current and next, continue? [y/N]: y
No image(s) to remove
```

sonic_installer binary_version (not supported)

This command is used to get the version from the local binary image file.

sonic_installer rollback_docker (not supported)

This command is used to rollback the docker image to a previous version.

sonic_installer upgrade_docker (not supported)

This command is used to upgrade a docker image from a local binary or URL.

47 Startup & Running Configuration

Table of Contents

[Startup Configuration](#)

[show startupconfiguration bgp](#)

[Running Configuration](#)

[show runningconfiguration bgp](#)

[show runningconfiguration interfaces](#)

[show runningconfiguration ntp](#)

[show runningconfiguration snmp](#)

[show runningconfiguration all](#)

[show runningconfiguration acl](#)

[show runningconfiguration ports](#)

[show runningconfiguration syslog](#)

Startup Configuration

show startupconfiguration bgp

This command is used to display the startup configuration for the BGP module.

Usage
show startupconfiguration bgp

Example
admin@sonic:~\$ show startupconfiguration bgp Routing-Stack is: frr ! ! template: bgpd/bgpd.conf.j2 !

```
!  
! ===== Managed by sonic-cfggen DO NOT edit manually! =====  
! generated by templates/quagga/bgpd.conf.j2 with config DB data  
! file: bgpd.conf  
!  
!  
! template: common/daemons.common.conf.j2  
!  
hostname as5812-54x  
password zebra  
enable password zebra  
!  
log syslog informational  
log facility local4  
!  
! end of template: common/daemons.common.conf.j2!  
agentx  
!  
!  
!  
! template: bgpd/bgpd.main.conf.j2  
!  
! bgp multiple-instance  
!  
! BGP configuration  
!  
! TSA configuration  
!  
ip prefix-list PL_LoopbackV4 permit 10.1.0.32/32  
!  
ipv6 prefix-list PL_LoopbackV6 permit fc00:1::/64  
!  
!  
!
```

```
router bgp 65100
!
bgp log-neighbor-changes
no bgp default ipv4-unicast
!
bgp bestpath as-path multipath-relax
!
bgp graceful-restart restart-time 240
bgp graceful-restart
bgp graceful-restart preserve-fw-state
...
```

Running Configuration

This sub-section explains the show commands for displaying the running configuration for the following modules.

1. BGP
2. Interfaces
3. NTP
4. SNMP
5. ALL
6. ACL
7. Ports
8. Syslog

show runningconfiguration bgp

This command displays the running configuration of the BGP module.

Usage

```
show runningconfiguration bgp
```

Example

```
admin@sonic:~$ show runningconfiguration bgp
Building configuration...
Current configuration:
!
fr version 7.2.1-sonic
fr defaults traditional
hostname as5812-54x
log syslog informational
log facility local4
agentx
no service integrated-vtysh-config
!
enable password zebra
password zebra
!
ip route 0.0.0.0/0 10.250.0.1 200
!
router bgp 65100
bgp router-id 10.1.0.32
bgp log-neighbor-changes
no bgp default ipv4-unicast
bgp graceful-restart restart-time 240
bgp graceful-restart
bgp graceful-restart preserve-fw-state
bgp bestpath as-path multipath-relax
neighbor PEER_V4 peer-group
```

...

show runningconfiguration interfaces

This command displays the running configuration for the interfaces.

Usage

```
show runningconfiguration interfaces
```

Example

```
admin@sonic:~$ show runningconfiguration interfaces
```

```
{
  "Ethernet0": {},
  "Ethernet1": {},
  "Ethernet2": {},
  "Ethernet3": {},
  "Ethernet4": {},
  "Ethernet5": {},
  "Ethernet6": {},
  "Ethernet7": {},
  "Ethernet8": {},
  "Ethernet9": {},
  "Ethernet10": {},
  "Ethernet11": {},
  "Ethernet12": {},
  "Ethernet13": {},
  "Ethernet14": {},
  "Ethernet15": {},
  "Ethernet16": {},
  "Ethernet17": {},
```

```
"Ethernet18": {},
"Ethernet19": {},
"Ethernet20": {},
"Ethernet21": {},
"Ethernet22": {},
"Ethernet23": {},
"Ethernet24": {},
"Ethernet25": {},
"Ethernet26": {},
"Ethernet27": {},
"Ethernet28": {},
"Ethernet29": {},
"Ethernet30": {},
"Ethernet31": {},
"Ethernet0| 10.0.0.0/31": {},
"Ethernet0|FC00::1/126": {},
"Ethernet1| 10.0.0.2/31": {},
"Ethernet1|FC00::5/126": {},
"Ethernet2| 10.0.0.4/31": {},
```

...

show runningconfiguration ntp

This command displays the running configuration of the NTP module.

Usage

```
show runningconfiguration ntp
```

Example

```
admin@sonic:~$ show runningconfiguration ntp
NTP Servers
    1.1.1.1
    2.2.2.2
```

show runningconfiguration snmp

This command displays the running configuration of the SNMP module.

Usage

```
show runningconfiguration snmp
```

Example

```
admin@sonic:~$ show runningconfiguration snmp
#####
# Managed by sonic-config-engine
#####
#
# EXAMPLE.conf:
# An example configuration file for configuring the Net-SNMP agent ('snmpd')
# See the 'snmpd.conf(5)' man page for details
#
# Some entries are deliberately commented out, and will need to be explicitly activated
#
#####
#
# AGENT BEHAVIOUR
#
# Listen for connections on all ip addresses, including eth0, ipv4 lo
#
```

```
agentAddress udp:161
agentAddress udp6:161
#####
#
# ACCESS CONTROL
#
# system + hrSystem groups only
view systemonly included .1.3.6.1.2.1.1
view systemonly included .1.3.6.1.2.1.25.1
# Default access to basic system info
rocommunity public
rocommunity6 public
#####
#
# SYSTEM INFORMATION
#
# Note that setting these values here, results in the corresponding MIB objects being 'read-only'
# See snmpd.conf(5) for more details
sysLocation public
sysContact Azure Cloud Switch vteam <linuxnetdev@microsoft.com>
# Application + End-to-End layers
sysServices 72
...
```

show runningconfiguration all

This command displays the entire running configuration.

Usage

```
show runningconfiguration all
```

Example

```
admin@sonic:~$ show runningconfiguration all
```

```
{
  "ACL_TABLE": {
    "DATAACL": {
      "policy_desc": "DATAACL",
      "ports": [
        "Ethernet16",
        "Ethernet0",
        "Ethernet17",
        "Ethernet1",
        "Ethernet18",
        "Ethernet2",
        "Ethernet19",
        "Ethernet3",
        "Ethernet20",
        "Ethernet4",
        "Ethernet21",
        "Ethernet5",
        "Ethernet22",
        "Ethernet6",
        "Ethernet23",
        "Ethernet7",
        "Ethernet24",
        "Ethernet8",
        "Ethernet25",
        "Ethernet9",
        "Ethernet26",
        "Ethernet10",
        "Ethernet27",
        "Ethernet11",
        "Ethernet28",
        "Ethernet12",
```

```
        "Ethernet29",
        "Ethernet13",
        "Ethernet30",
        "Ethernet14",
        "Ethernet31",
        "Ethernet15"
    ],
    "stage": "ingress",
    "type": "L3"
},
"EVERFLOW": {
    "policy_desc": "EVERFLOW",
    "ports": [
        "Ethernet10",
        "Ethernet9",
        "Ethernet16",
        "Ethernet15",
        "Ethernet14",
        "Ethernet13",
        "Ethernet12",
        "Ethernet11",
        "Ethernet18",
        "Ethernet17",
        "Ethernet2",
        "Ethernet1",
        "Ethernet0",
        "Ethernet6",
        "Ethernet5",
        "Ethernet4",
        "Ethernet3",
        "Ethernet8",
        "Ethernet7",
        "Ethernet21",
        "Ethernet22",
```

```

        "Ethernet19",
        "Ethernet20",
        "Ethernet25",
        "Ethernet26",
        "Ethernet23",
        "Ethernet24",
        "Ethernet27",
        "Ethernet28",
        "Ethernet30",
        "Ethernet29",
        "Ethernet31"
    ],
    "stage": "ingress",
    "type": "MIRROR"
},
...

```

show runningconfiguration acl

This command displays the running configuration of the ACLs.

Usage

```
show runningconfiguration acl
```

Example

```

root@sonic:~# show runningconfiguration acl
{
    "TEST1|DEFAULT_RULE": {
        "ETHER_TYPE": "2048",
        "PACKET_ACTION": "DROP",

```

```
"PRIORITY": "1"
},
"TEST1|RULE_1": {
  "PACKET_ACTION": "FORWARD",
  "PRIORITY": "9999",
  "SRC_IP": "20.0.0.2/32"
}
}
```

show runningconfiguration ports

This command displays the running configuration of the Ports.

Usage

```
show runningconfiguration ports [<portname>]
```

Example

```
admin@sonic:~$ show runningconfiguration ports
{
  "Ethernet0": {
    "admin_status": "up",
    "alias": "tenGigE1",
    "description": "ARISTA01T2:Ethernet1",
    "index": "1",
    "lanes": "13",
    "mtu": "9100",
    "pfc_asym": "off",
    "speed": "10000"
  },
  "Ethernet1": {
```

```

    "admin_status": "up",
    "alias": "tenGigE2",
    "description": "ARISTA02T2:Ethernet1",
    "index": "2",
    "lanes": "14",
    "mtu": "9100",
    "pfc_asym": "off",
    "speed": "10000"
  },
  "Ethernet2": {
...

admin@sonic:~$ show runningconfiguration ports Ethernet0
{
  "Ethernet0": {
    "index": "1",
    "lanes": "13",
    "description": "ARISTA01T2:Ethernet1",
    "admin_status": "up",
    "mtu": "9100",
    "alias": "tenGigE1",
    "pfc_asym": "off",
    "speed": "10000"
  }
}

```

show runningconfiguration syslog

This command displays the running configuration of the Syslog module.

Usage

```
show runningconfiguration syslog
```

Example

```
admin@sonic:~$ show runningconfiguration syslog  
Syslog Servers  
    [10.250.1.44]
```

Note

- For all "show startupconfiguration" and "show runningconfiguration" commands, only the partial output is shown here. In the realtime, all the configuration information is displayed.

48 Syslog

Table of Contents

[Syslog Configuration Commands](#)

[config syslog add](#)

[config syslog delete](#)

Syslog Configuration Commands

The `config syslog` command is used to add or remove the configured syslog servers.

config syslog add

This command is used to add a new syslog server to the Syslog server list. Note that more than one syslog server can be added to the list.

Usage

```
config syslog add <ipv4-address | ipv6-address> [--source <ipv4-address | ipv6-address>] [--port <number>] [--vrf {default | mgmt}]
```

Parameters:

- `ipv4-address` : IP address of the collector in dotted decimal format for IPv4
- `ipv6-address` : `x:x:x:x::x` format for IPv6 address of the collector (where `::` notation specifies successive hexadecimal fields of zeros)
- `source(OPTIONAL)` : IP address of specific source IP, the source IP must exist in default vrf or mgmt vrf.
- `port (OPTIONAL)`, specifies the UDP port of the collector.
 - valid range is from 0 to 65535. (default is 6343)
- `vrf (OPTIONAL)`, specifies the VRF of the collector. (default is default)
 - `default` , connects using the default VRF.
 - `mgmt` , connects using the mgmt VRF. If the mgmt VRF doesn't be created yet, the default VRF will be used to connect to server.

The following example shows how to add a remote syslog server with the ip address 1.1.1.1.

Example

```
admin@sonic:~$ sudo config syslog add 1.1.1.1 --source 192.168.8.231
```

```
Running command: systemctl reset-failed rsyslog-config rsyslog
```

```
Running command: systemctl restart rsyslog-config
```

config syslog delete

This command is used to delete a configured syslog server.

Usage

```
config syslog del <ipv4-address | ipv6-address>
```

Parameters:

- **ipv4-address** : IP address of the collector in dotted decimal format for IPv4
- **ipv6-address** : x:x:x:x::x format for IPv6 address of the collector (where :: notation specifies successive hexadecimal fields of zeros)

The following example shows how to delete a remote syslog server with the ip address 1.1.1.1.

Example

```
admin@sonic:~$ sudo config syslog del 1.1.1.1
Syslog server 1.1.1.1 removed from configuration
Restarting rsyslog-config service...
```

Note

- The format of the syslog messages sent to configured syslog servers is defined in RFC3164. The following packet opened in Wireshark is an example. At the header of the syslog message, the facility and severity levels are encoded and placed between angle brackets ("**<**" and "**>**").

No.	Time	Source	Destination	Protocol	Length	Info
1	0.000000	10.250.0.168	10.250.2.44	Syslog	307	USER.INFO: Mar 9 10:48:33.458161 as7726-32x-4 INFO syncd#/supervisors

> Frame 1: 307 bytes on wire (2456 bits), 307 bytes captured (2456 bits) > Ethernet II, Src: Edgecore_21:ac:0f (90:3c:b3:21:ac:0f), Dst: ae:41:e1:45:ff:95 (ae:41:e1:45:ff:95) > Internet Protocol Version 4, Src: 10.250.0.168, Dst: 10.250.2.44 > User Datagram Protocol, Src Port: 60998, Dst Port: 514 > [truncated]Syslog message: USER.INFO: Mar 9 10:48:33.458161 as7726-32x-4 INFO syncd#/supervisors: syncd 0: bcm_esw_linkscan_thread: LINKSCAN interval more than						
--	--	--	--	--	--	--

0020	02 2c ee 46 02 02 01 11 2d e5 3c 31 34 3e 4d 61	..F....-<14>Ma
0030	72 20 20 39 20 31 30 3a 34 38 3a 33 33 2e 34 35	r 9 10: 48:33.45
0040	38 31 36 31 20 61 73 37 37 32 36 2d 33 32 78 2d	8161 as7 726-32x-

49 Subport

Subport Show commands

show subinterfaces status

This command display the Subport configuration and status.

Usage

```
show subinterfaces status
```

Example

```
admin@sonic:~# show subinterfaces status
```

Sub port interface	Speed	MTU	Vlan	Admin	Parent admin	Type
Ethernet4.10	100G	9100	10	up	up	802.1q-encapsulation
Ethernet4.4094	100G	9100	4094	up	up	802.1q-encapsulation

Subport Configuration commands

A subport interface is added (or removed) when it's configured with IP address ("config interface ip") or bound on a VRF ("config interface vrf"). If user does not specify the <vrf name>, the L3 configuration on subport interface is bound on default VRF.

User should be careful in configuring sequence of "config interface vrf" and "config interface ip". (please refer example.)

config interface ip add/remove

Configuring IP address on subport is the same as config interface ip add/remove command.

This command will automatically add (or remove) subport interface if the subport interface does not exist (or already existed).

The VLAN ID in subport interface name specifies the 802.1q Vlan tagging. The ingress and egress packets of subport interface should be tagged with the VLAN ID. For example, for sub port interface Ethernet4.20, Vlan 20 is used for 802.1q Vlan tagging.

Usage
config interface ip {add remove} <sub_port_interface_name> <ip_addr>

Parameters

- sub_port_interface_name: specify subport to add (or remove) subport interface

Example
admin@sonic:~# sudo config interface ip add Ethernet4.20 192.169.1.1/24 admin@sonic:~# sudo config interface ip remove Ethernet4.20 192.169.1.1/24

50 System State

Table of Contents

[Processes](#)

[show processes cpu](#)

[show processes memory](#)

[show processes summary](#)

[Services & Memory](#)

[show services](#)

[show system-memory](#)

[show mmu \(Not Supported\)](#)

[show line \(Not Supported\)](#)

[System-Health](#)

[show system-health detail](#)

[show system-health monitor-list](#)

[show system-health summary](#)

Processes

This command is used to determine the CPU utilization. It also lists the active processes along with their

corresponding process ID and other relevant parameters.

This sub-section explains the various "processes" specific data that includes the following.

- `cpu` Show processes CPU info
- `memory` Show processes memory info
- `summary` Show processes info

The "show processes" commands provide a wrapper over Linux's "top" command.

The "show process cpu" command sorts the processes being displayed by cpu-utilization, whereas "show process memory" does it for processes' memory-utilization.

show processes cpu

This command displays the current CPU usage by process. This command uses Linux's "top -bn 1 -o %CPU" command to display the output.

Usage
show processes cpu

Tip : Users can pipe the output to "head" to display only the "n" number of lines (e.g., `show processes cpu | head -n 10`).

Example
<pre>admin@sonic:~\$ show processes cpu top - 23:50:08 up 1:18, 1 user, load average: 0.25, 0.29, 0.25</pre>

Tip : Advanced users can view individual processes using variations of the `ps` command (e.g., `ps -ax | grep <process name>`).

show processes memory

This command displays the current memory usage by processes. This command uses Linux's "top -bn 1 -o %MEM" command to display the output.

Usage

show processes memory

Note:

- the pipe option can be used using " | head -n" to display only the "n" number of lines

Example

```
admin@sonic:~$ show processes memory
top - 23:41:24 up 7 days, 39 min, 2 users, load average: 1.21, 1.19, 1.18
Tasks: 191 total, 2 running, 189 sleeping, 0 stopped, 0 zombie
%Cpu(s): 2.8 us, 20.7 sy, 0.0 ni, 76.3 id, 0.0 wa, 0.0 hi, 0.2 si, 0.0 st
KiB Mem : 8162264 total, 5720412 free, 945516 used, 1496336 buff/cache
KiB Swap: 0 total, 0 free, 0 used. 6855632 avail Mem
  PID USER  PR  NI  VIRT  RES  SHR S %CPU %MEM    TIME+  COMMAND
18051 root   20   0 851540 274784 8344 S  0.0  3.4   0:02.77 syncd
17760 root   20   0 1293428 259212 58732 S  5.9  3.2   96:46.22 syncd
  508 root   20   0 725364 76244 38220 S  0.0  0.9   4:54.49 dockerd
30853 root   20   0 96348 56824 7880 S  0.0  0.7   0:00.98 show
17266 root   20   0 509876 49772 30640 S  0.0  0.6   0:06.36 docker
24891 admin  20   0 515864 49560 30644 S  0.0  0.6   0:05.54 docker
17643 admin  20   0 575668 49428 30628 S  0.0  0.6   0:06.29 docker
23885 admin  20   0 369552 49344 30840 S  0.0  0.6   0:05.57 docker
18055 root   20   0 509076 49260 30296 S  0.0  0.6   0:06.36 docker
17268 root   20   0 371120 49052 30372 S  0.0  0.6   0:06.45 docker
 1227 root   20   0 443284 48640 30100 S  0.0  0.6   0:41.91 docker
23785 admin  20   0 443796 48552 30128 S  0.0  0.6   0:05.58 docker
17820 admin  20   0 435088 48144 29480 S  0.0  0.6   0:06.33 docker
  506 root   20   0 1151040 43140 23964 S  0.0  0.5   8:51.08 containerd
18437 root   20   0 84852 26388 7380 S  0.0  0.3   65:59.76 python3.6
```

show processes summary

This command displays the current summary information about all the processes.

Usage
show processes summary

Example

admin@sonic:~\$ show processes summary

PID	PPID	CMD	%MEM	%CPU
1	0	/sbin/init	0.0	0.0
2	0	[kthreadd]	0.0	0.0
3	2	[ksoftirqd/0]	0.0	0.0
5	2	[kworker/0:0H]	0.0	0.0

Services & Memory

These commands are used to know the services that are running and the memory that is currently utilized.

show services

This command displays the state of all the SONiC processes running inside a docker container. This helps to identify the status of SONiC's critical processes.

Usage
show services

Example

```
admin@sonic:~$ show services
```

```
dhcp_relay  docker
```

```
-----
UID    PID PPID C STIME TTY      TIME CMD
root    1   0 0 05:26 ?    00:00:12 /usr/bin/python /usr/bin/supervi
root   24   1 0 05:26 ?    00:00:00 /usr/sbin/rsyslogd -n
nat  docker
```

```
-----
USER    PID PPID C STIME TTY      TIME CMD
root    1   0 0 05:26 ?    00:00:12 /usr/bin/python /usr/bin/supervisord
root   18   1 0 05:26 ?    00:00:00 /usr/sbin/rsyslogd -n
root   23   1 0 05:26 ?    00:00:01 /usr/bin/natmgrd
root   34   1 0 05:26 ?    00:00:00 /usr/bin/natsyncd
snmp  docker
```

```
-----
UID    PID PPID C STIME TTY      TIME CMD
root    1   0 0 05:26 ?    00:00:16 /usr/bin/python /usr/bin/supervi
root   24   1 0 05:26 ?    00:00:02 /usr/sbin/rsyslogd -n
Debian+ 29   1 0 05:26 ?    00:00:04 /usr/sbin/snmpd -f -LS4d -u Debi
root   31   1 1 05:26 ?    00:15:10 python3.6 -m sonic_ax_impl
syncd  docker
```

```
-----
UID    PID PPID C STIME TTY      TIME CMD
root    1   0 0 05:26 ?    00:00:13 /usr/bin/python /usr/bin/supervi
root   12   1 0 05:26 ?    00:00:00 /usr/sbin/rsyslogd -n
root   17   1 0 05:26 ?    00:00:00 /usr/bin/dsserve /usr/bin/syncd
root   27  17 22 05:26 ?    04:09:30 /usr/bin/syncd --diag -p /usr/sh
root   51  27 0 05:26 ?    00:00:01 /usr/bin/syncd --diag -p /usr/sh
swss  docker
```

```
-----
UID    PID PPID C STIME TTY      TIME CMD
root    1   0 0 05:26 ?    00:00:29 /usr/bin/python /usr/bin/supervi
```

```

root    25    1 0 05:26 ?    00:00:00 /usr/sbin/rsyslogd -n
root    30    1 0 05:26 ?    00:00:13 /usr/bin/orchagent -d /var/log/s
root    42    1 1 05:26 ?    00:12:40 /usr/bin/portsyncd -p /usr/share
root    45    1 0 05:26 ?    00:00:00 /usr/bin/intfsyncd
root    48    1 0 05:26 ?    00:00:03 /usr/bin/neighsyncd
root    59    1 0 05:26 ?    00:00:01 /usr/bin/vlanmgrd
root    92    1 0 05:26 ?    00:00:01 /usr/bin/intfmgrd
root   3606    1 0 23:36 ?    00:00:00 bash -c /usr/bin/arp_update; sle
root   3621  3606 0 23:36 ?    00:00:00 sleep 300

```

...

show system-memory

This command displays the system-wide memory utilization information – just a wrapper over the Linux native "free" command.

Usage

```
show system-memory
```

Example

```
admin@sonic:~$ show system-memory
```

```
Command: free -m -h
```

```

      total    used    free   shared  buffers   cached
Mem:    3.9G    2.0G    1.8G    33M    324M    791M
-/+ buffers/cache:    951M    2.9G
Swap:      0B      0B      0B

```

show mmu (Not Supported)

This command displays the virtual address to physical address translation status of the Memory Management Unit (MMU).

Usage

show mmu

Example

```
admin@sonic:~$ show mmu
Pool: ingress_lossless_pool
--- -----
xoff 4194112
type ingress
mode dynamic
size 10875072
--- -----
Pool: egress_lossless_pool
--- -----
type egress
mode static
size 15982720
--- -----
Pool: egress_lossy_pool
--- -----
type egress
mode dynamic
size 9243812
--- -----
Profile: egress_lossy_profile
-----
dynamic_th 3
```

```

pool    [BUFFER_POOL|egress_lossy_pool]
size    1518
-----
Profile: pg_lossless_100000_300m_profile
-----

xon_offset 2288
dynamic_th -3
xon       2288
xoff      268736
pool      [BUFFER_POOL|ingress_lossless_pool]
size      1248
-----

Profile: egress_lossless_profile
-----

static_th 3995680
pool      [BUFFER_POOL|egress_lossless_pool]
size      1518
-----

Profile: pg_lossless_100000_40m_profile
-----

xon_offset 2288
dynamic_th -3
xon       2288
xoff      177632
pool      [BUFFER_POOL|ingress_lossless_pool]
size      1248
-----

Profile: ingress_lossy_profile
-----

dynamic_th 3
pool      [BUFFER_POOL|ingress_lossless_pool]
size      0
-----

Profile: pg_lossless_40000_40m_profile

```

```

-----
xon_offset 2288
dynamic_th -3
xon      2288
xoff     71552
pool     [BUFFER_POOL|ingress_lossless_pool]
size     1248
-----

```

show line (Not Supported)

This command displays the serial port or a virtual network connection status. This command is used only when SONiC is used as a console switch. This command is not applicable when SONiC used as a regular switch.

Note: This command is not working. It crashes as follows. A bug ticket is opened for this issue.

Usage
show line
Example
admin@sonic:~\$ show line

System-Health

System health monitor is intended to monitor both critical services/processes and peripheral device status and leverage system log, system status LED to and CLI command output to indicate the system status.

show system-health detail

This command displays the system-health detail information.

Usage

```
show system-health detail
```

Example

```
admin@wedge100bf-32x-1:~$ sudo show system-health detail
```

System status summary

System status LED

Services:

Status: OK

Hardware:

Status: Not OK

Reasons: Invalid temperature data for PSU 2, temperature=N/A, threshold=N/A

PSU 1 is out of power

System services and devices monitor list

Name	Status	Type
wedge100bf-32x-1	OK	System
rsyslog	OK	Process
root-overlay	OK	Filesystem
var-log	OK	Filesystem
routeCheck	OK	Program
diskCheck	OK	Program
container_checker	OK	Program
vnetRouteCheck	OK	Program
container_memory_telemetry	OK	Program
telemetry:telemetry	OK	Process
telemetry:dialout	OK	Process
snmp:snmpd	OK	Process
snmp:snmp-subagent	OK	Process
sflow:sflowmgrd	OK	Process
lldp:lldpd	OK	Process

lldp:lldp-syncd	OK	Process
lldp:lldpmgrd	OK	Process
nat:natmgrd	OK	Process
nat:natsyncd	OK	Process
syncd:syncd	OK	Process
teamd:teammgrd	OK	Process
teamd:teamsyncd	OK	Process
teamd:tlm_teamd	OK	Process
p4rt:p4rt	OK	Process
swss:orchagent	OK	Process
swss:portsyncd	OK	Process
swss:neighsyncd	OK	Process
swss:fdbsyncd	OK	Process
swss:vlanmgrd	OK	Process
swss:intfmgrd	OK	Process
swss:portmgrd	OK	Process
swss:buffermgrd	OK	Process
swss:vrfmgrd	OK	Process
swss:nbrmgrd	OK	Process
swss:vxlanmgrd	OK	Process
swss:coppmgrd	OK	Process
swss:tunnelmgrd	OK	Process
swss:esmgrd	OK	Process
bgp:zebra	OK	Process
bgp:staticd	OK	Process
bgp:bgpd	OK	Process
bgp:fpmsyncd	OK	Process
bgp:essyncd	OK	Process
bgp:bgpcfgd	OK	Process
database:redis	OK	Process
PSU 1	Not OK	PSU
PSU 2	Not OK	PSU
counter-rotating-fan-1	OK	Fan
counter-rotating-fan-2	OK	Fan

```
counter-rotating-fan-3  OK   Fan
counter-rotating-fan-4  OK   Fan
counter-rotating-fan-5  OK   Fan
System services and devices ignore list
Name  Status  Type
-----
```

show system-health monitor-list

This command displays system-health monitored services and devices name list.

Usage

```
show system-health monitor-list
```

Example

```
admin@wedge100bf-32x-1:~$ sudo show system-health monitor-list
```

System services and devices monitor list

```
Name           Status  Type
-----
wedge100bf-32x-1  OK     System
rsyslog          OK     Process
root-overlay     OK     Filesystem
var-log          OK     Filesystem
routeCheck       OK     Program
diskCheck        OK     Program
container_checker OK     Program
vnetRouteCheck   OK     Program
container_memory_telemetry OK     Program
telemetry:telemetry OK     Process
telemetry:dialout OK     Process
```

snmp:snmpd	OK	Process
snmp:snmp-subagent	OK	Process
sflow:sflowmgrd	OK	Process
lldp:lldpd	OK	Process
lldp:lldp-syncd	OK	Process
lldp:lldpmgrd	OK	Process
nat:natmgrd	OK	Process
nat:natsyncd	OK	Process
syncd:syncd	OK	Process
teamd:teammgrd	OK	Process
teamd:teamsyncd	OK	Process
teamd:tlm_teamd	OK	Process
p4rt:p4rt	OK	Process
swss:orchagent	OK	Process
swss:portsyncd	OK	Process
swss:neighsyncd	OK	Process
swss:fdbsyncd	OK	Process
swss:vlanmgrd	OK	Process
swss:intfmgrd	OK	Process
swss:portmgrd	OK	Process
swss:buffermgrd	OK	Process
swss:vrfmgrd	OK	Process
swss:nbrmgrd	OK	Process
swss:vxlanmgrd	OK	Process
swss:coppmgrd	OK	Process
swss:tunnelmgrd	OK	Process
swss:esmgrd	OK	Process
bgp:zebra	OK	Process
bgp:staticd	OK	Process
bgp:bgpd	OK	Process
bgp:fpmsyncd	OK	Process
bgp:essyncd	OK	Process
bgp:bgpcfgd	OK	Process
database:redis	OK	Process

PSU 1	Not OK	PSU
PSU 2	Not OK	PSU
counter-rotating-fan-1	OK	Fan
counter-rotating-fan-2	OK	Fan
counter-rotating-fan-3	OK	Fan
counter-rotating-fan-4	OK	Fan
counter-rotating-fan-5	OK	Fan

show system-health summary

This command displays system-health summary information.

Usage

```
show system-health summary
```

Example

```
admin@wedge100bf-32x-1:~$ sudo show system-health summary
System status summary
System status LED
Services:
    Status: OK
Hardware:
    Status: Not OK
    Reasons: Invalid temperature data for PSU 2, temperature=N/A, threshold=N/A
             PSU 1 is out of power
```

51 Troubleshooting

Table of Contents

[Collect techsupport information](#)

[show techsupport](#)

[Usage of "logger"](#)

[Example demonstration](#)

[Example 1: Collect the device information along with the log files](#)

[Example 2: Collect the device information and log files separately](#)

Collect techsupport information

show techsupport

In field service, there is limited time to gather information for troubleshooting and debugging. The command gathers show techsupport relevant information about the state of the device; information as diverse as syslog entries, database state, routing-stack state, etc. It then compresses the information into an archive file. This archived file can then be sent to the SONiC development team for examination.

Usage
show techsupport [--since=<time_specifier>]
show techsupport [--nolog]

Options:

- --since Collect logs and core files since a given date.
- --silent Run techsupport in silent mode.
- --nolog Collect system information without syslog to reduce the archive file size.

Note

- The archive file is stored in /var/dump/<DEVICE_HOST_NAME>_YYYYMMDD_HHMMSS.tar.gz
- The location and name of the archive file will be displayed at the end of the execution of the command "show techsupport "

This command can generate a large dump file after the SONiC system has been running for a long time and there are exhaustive system resources. When the log files are specified for a certain period (by using the " --since" option) or are not been included (by using the " --no log" option), the dump file size can be reduced to MB level and the time to collect the data is also reduced relatively.

Example

```
admin@sonic:~$ show techsupport --since=yesterday # Will collect syslog and core files for the last 24
hours
admin@sonic:~$ show techsupport --since='hour ago' # Will collect syslog and core files for the last one
hour
admin@sonic:~$ show techsupport --nolog          # Will not collect syslog and core files
```

Usage of "logger"

Use the 'logger' command to add a marker to make it simple to find associated Syslog entries for a reported issue.

If there is a way to reproduce an issue by a specific procedure, it would be very helpful to execute a logger command to add a special mark into the syslog before and after reproducing the issue.

For example, execute the first logger command before recreating the issue, and then execute the second command after recreating the issue as shown below. Using this marker, you can grep the syslog to know which part of the syslog is related to the reported issue. The related syslog content will be the messages between "==== test start====" and "==== test finish====".

```
logger ==== test start====
logger ==== test finish====
```

Example demonstration

Examples of collecting device information and log files, and sending them to a remote host using the "show techsupport" command.

It is known that a large number of log files will be generated if the device has been running for a long time.

Therefore, it will consume more time to process those files into an archive file.

Example 1: Collect the device information along with the log files

Step 1: Execute the show techsupport command with "--since" option.

Example

```
admin@as5835-54x-3:~$ show techsupport --since='hour ago'
main
mkdir: created directory '/var/dump/sonic_dump_as5835-54x_20210129_071517'
'/var/dump/sonic_dump_as5835-54x_20210129_071517/generate_dump' -> '/usr/bin/generate_dump'
sonic_dump_as5835-54x_20210129_071517/
sonic_dump_as5835-54x_20210129_071517/generate_dump
mkdir: created directory '/var/dump/sonic_dump_as5835-54x_20210129_071517/proc'
...
(skipped)
...
/var/dump/sonic_dump_as5835-54x_20210129_071517.tar.gz
```

Step 2: Use the scp command to copy the archive file from the local device (File generated from step 1) to a remote site.

Example

```
admin@as5835-54x:~$ sudo scp /var/dump/sonic_dump_as5835-54x_20210129_071517.tar.gz
sonic@10.250.2.44:/home
/sonic/tmp_dennis/
sonic@10.250.2.44's password:
sonic_dump_as5835-54x_20210129_071517.tar.gz 100% 3111KB 86.4MB/s 00:00
```

Example 2: Collect the device information and log files separately

Step 1: Execute the `show techsupport` command with "--no log" option to collect the device information.

Example

```
admin@as5835-54x-3:~$ show techsupport --nolog
main
mkdir: created directory '/var/dump/sonic_dump_as5835-54x-3_20210129_082320'
'/var/dump/sonic_dump_as5835-54x-3_20210129_082320/generate_dump' -> '/usr/bin/generate_dump'
sonic_dump_as5835-54x-3_20210129_082320/
sonic_dump_as5835-54x-3_20210129_082320/generate_dump
mkdir: created directory '/var/dump/sonic_dump_as5835-54x-3_20210129_082320/proc'
...
(skipped)
...
/var/dump/sonic_dump_as5835-54x-3_20210129_082320.tar.gz
```

Step 2: Use the `scp` command to copy the archive file from the local device to a remote site.

Example

```
admin@as5835-54x-3:~$ sudo scp /var/dump/sonic_dump_as5835-54x-3_20210129_082320.tar.gz
sonic@10.250.2.44:
/home/sonic/tmp_dennis/
sonic@10.250.2.44's password:
sonic_dump_as5835-54x-3_20210129_082320.tar.g 100% 2007KB 81.7MB/s 00:00
```

Step 3: Use the `scp` to copy the log (ex:syslog) file from the local device to a remote site.

Example

```
admin@as5835-54x-3:~$ sudo scp /var/log/syslog*
sonic@10.250.2.44:/home/sonic/tmp_dennis/sonic_log/
sonic@10.250.2.44's password:
syslog 100% 20KB 11.4MB/s 00:00
```

```
syslog.1 100% 2056KB 79.5MB/s 00:00
syslog.2.gz 100% 162KB 58.4MB/s 00:00
syslog.3.gz 100% 160KB 59.7MB/s 00:00
syslog.4.gz 100% 170KB 65.7MB/s 00:00
...
(skipped)
...
syslog.4.gz 100% 170KB 65.7MB/s 00:00
```

52 TFTP

53 VLAN

Table of Contents

[VLAN Show Commands](#)

[show vlan brief](#)

[show vlan brief --mtu](#)

[show vlan config](#)

[show vlan brief --mac](#)

[VLAN Config Commands](#)

[config vlan add/del](#)

[config vlan member add/del](#)

[config vlan mtu](#)

[config vlan mac_address](#)

VLAN Show Commands

show vlan brief

This command displays brief information about all the VLANs configured on the device. It displays the VLAN ID, IP address (if configured for the VLAN), list of VLAN member ports, whether the port is tagged or in un tagged mode, and the DHCP Helper Address.

Usage

```
show vlan brief
```

Example

```
admin@sonic:~$ show vlan brief
```

```
+-----+-----+-----+-----+-----+-----+
+-----+
```

```

+-----+-----+-----+-----+-----+-----+
| VLAN ID | IP Address   | Ports   | Port Tagging | Proxy ARP | DHCP Helper | DHCP Source |
+-----+-----+-----+-----+-----+-----+
|          |              |         |              |           |             |             |
|          |              |         |              |           |             |             |
|          |              |         |              |           |             |             |
|          |              |         |              |           |             |             |
|          |              |         |              |           |             |             |
|          |              |         |              |           |             |             |
|          |              |         |              |           |             |             |
|          |              |         |              |           |             |             |
+-----+-----+-----+-----+-----+-----+
| 100 | 1.1.2.2/16 | Ethernet0 | tagged      | disabled  | 192.0.0.1   |
|      |             |          |             |           |             |
|      |             |          |             |           |             |
|      |             | Ethernet4 | tagged      |           | 192.0.0.2   |
|      |             |          |             |           |             |
|      |             |          |             |           | 192.0.0.3   |
|      |             |          |             |           |             |
+-----+-----+-----+-----+-----+-----+
|          |              |         |              |           |             |
+-----+-----+-----+-----+-----+-----+

```

show vlan brief -mtu

This command is used to display the VLAN ID, VLAN MTU, list of VLAN member ports and mtu of member ports.

Example

```
admin@sonic:~$ show vlan brief --
```

mtu

+

VLAN ID	VLAN MTU	Ports	Port MTU
---------	----------	-------	----------

1

100	1500	Ethernet0	1500
-----	------	-----------	------

	Ethernet4	1500
--	-----------	------

1

show vlan config

This command displays all the VLAN configuration.

Usage

```
show vlan config
```

Example

```
admin@sonic:~$ show vlan config
```

Name	VID	Member	Mode
Vlan100	100	Ethernet0	tagged
Vlan100	100	Ethernet4	tagged

show vlan brief --mac

Example

```
admin@sonic:~$ show vlan brief --mac
```

VLAN ID	Ports	VLAN MAC
200	Ethernet64	80:a2:35:88:88:89

VLAN Config Commands

This sub-section explains how to configure a VLAN and its member ports.

config vlan add/del

This command is used to add or delete a VLAN.

Usage

```
config vlan (add | del) <vlan_id>
```

Example (Create the VLAN "Vlan100" if it does not already exist)

```
admin@sonic:~$ sudo config vlan add 100
```

config vlan member add/del

This command is used to add or delete a member port to/from an already created VLAN.

Usage

```
config vlan member add/del [-u|--untagged] <vlan_id> <member_portname>
```

Note :

- Adding the -u or --untagged flag will set the port member in "untagged" mode.
- It is not allowed to add an Ethernet port / port channel with a L3 configuration to a VLAN.
- An Ethernet port / port channel could only be added to one VLAN in un tagged mode.

Example (Add Ethernet0 as member of the vlan 100)

```
admin@sonic:~$ sudo config vlan member add 100 Ethernet0
```

Example (Add Ethernet4 as member of the vlan 100)

```
admin@sonic:~$ sudo config vlan member add 100 Ethernet4
```

config vlan mtu

This command is used to config vlan mtu. (default mtu of vlan is 9100)

Usage

```
config vlan mtu <vlan_id> <mtu>
```

Example

```
admin@sonic:~$ sudo config vlan mtu 100 1500
```

Note:

- The update of vlan mtu would not change the mtu of port.
- User needs to handle the port mtu when changing vlan mtu which is different from port MTU.
- sag interface and vrrp interface is created from vlan interface. The mtu of sag interface and vrrp interface would also changed as the same value as vlan mtu if v lan mtu is changed.
- The VLAN MTU refers to the data length at the L3 layer, not the total length of the entire packet. For packets with the same VLAN MTU, whether they are tagged (TAG) or untagged (non-TAG), the data length at the L3 layer can be different.

config vlan mac_address

Example

```
admin@sonic:~$ sudo config vlan add 200
admin@sonic:~$ sudo config vlan member add 200 -u Ethernet64
admin@sonic:~$ sudo config interface ip add Vlan200 200.1.1.200/24
admin@sonic:~$ sudo config vlan mac_address 200 80:a2:35:88:88:89
admin@sonic:~$ sudo ifconfig Vlan200
Vlan200: flags=4099<UP,BROADCAST,MULTICAST> mtu 9100
    inet 200.1.1.200 netmask 255.255.255.0 broadcast 200.1.1.255
```

```
ether 80:a2:35:88:88:89 txqueuelen 1000 (Ethernet)
RX packets 0 bytes 0 (0.0 B)
RX errors 0 dropped 0 overruns 0 frame 0
TX packets 0 bytes 0 (0.0 B)
TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

54 VLAN Stacking

Table of Contents

[VLAN Stacking Show Commands](#)

[show vlan-stacking](#)

[VLAN Stacking Config Commands](#)

[config vlan-stacking add](#)

[config vlan-stacking del](#)

[Caveat](#)

VLAN Stacking Show Commands

show vlan-stacking

This command displays the information about all the VLAN stacking rule configured on the device.

Usage

```
show vlan-stacking
```

Example

```
admin@sonic:~$ show vlan-stacking
```

Interface	Stage	Match VLAN	Action	Apply VLAN
Ethernet0	egress	200	pop	
Ethernet0	ingress	100	push	200
Ethernet4	egress	200	swap	100
Ethernet4	ingress	100	swap	200

VLAN Stacking Config Commands

This sub-section explains how to add(or delete) a VLAN stacking rule to(or from) the specified interface.

config vlan-stacking add

This command is used to add a VLAN stacking rule to interface.

Usage

```
config vlan-stacking add <interface_name> <stage> <match_vlan> <action> <apply_vlan>
```

Parameter:

<interface_name>: The name of physical interface or PortChannel, e.g. "Ethernet0" or "PortChannel0001".

<stage> : The traffic direction of the packet, e.g. "ingress" or "egress".

<match_vlan> : The VLAN ID on the packet which expected to match the rule(The range is from 1 to 4094).

<action> : The action applied to the packet when it matched the rule, e.g. "push", "pop" or "swap".

push: insert an <apply_vlan> (or SVLAN, outer VLAN) to the frame

pop: remove the <match_vlan> (or outer VLAN) from the frame

swap: replace the <match_vlan> (matched outer VLAN) with <apply_vlan>

<apply_vlan> : The VLAN ID applied to the packet according to the action field(The range is from 1 to 4094).

Example: Add vlan id 200, SVLAN, when ingress packet's vlan id is matched 100 on Ethernet0

Example

```
admin@sonic:~$ sudo config vlan-stacking add Ethernet0 ingress 100 push 200
```

config vlan-stacking del

This command is used to delete a VLAN stacking rule from interface.

Usage

```
config vlan-stacking del <interface_name> <stage> <match_vlan>
```

Parameter:

<interface_name>: The name of physical interface or PortChannel, e.g. "Ethernet0" or "PortChannel0001".

<stage> : The traffic direction of the packet, e.g. "ingress" or "egress".

<match_vlan> : The VLAN ID on the packet which expected to match the rule(The range is from 1 to 4094).

Example: Delete the configuration applied to egress packet which matched vlan id 200 on Ethernet0.

Example

```
admin@sonic:~$ sudo config vlan-stacking del Ethernet0 egress 200
```

Caveat

Do not support on DCS8500-128D, AS9746-128D, AS9817-640C, AS9736-64D.

55 VRF Configuration

Table of Contents

[VRF Show Commands](#)

[show vrf](#)

[VRF Config Commands](#)

[config vrf add](#)

[config vrf del](#)

[config vrf add_vrf_vni_map](#)

[config vrf del_vrf_vni_map](#)

VRF Show Commands

show vrf

This command displays all VRFs configured on the system along with interface binding to the VRF. If `vrf-name` is also provided as part of the command, when the VRF is created it will display all interfaces binding to the VRF. If the VRF is not created, nothing will be displayed.

Usage

```
show vrf [<vrf_name>]
```

Example

```
admin@sonic:~$ show vrf
```

VRF	Interfaces
-----	------------

-----	-----
-------	-------

Vrf-red	Vlan100
---------	---------

	Loopback11
--	------------

Vrf-blue	Loopback100
----------	-------------

	Loopback102
--	-------------

Note: You may refer to Interfaces for binding a VRF and interface.

VRF Config Commands

config vrf add

This command creates a VRF in the SONiC system with the provided VRF name.

Note: The vrf-name should always start with the keyword "Vrf".

Usage
config vrf add <vrf-name>

config vrf del

This command deletes the VRF with the name vrf-name .

Usage
config vrf del <vrf-name>

config vrf add_vrf_vni_map

This command creates VRF-VNI mapping in the SONiC system.

Note: The show command is in the VxLAN CLI guide.

Usage
config vrf add_vrf_vni_map <vrf-name> <vni>

Example
config vrf add Vrf1

```
config vxlan add vtep 10.1.0.32
config vxlan evpn_nvo add evpnvo vtep
config vrf add_vrf_vni_map Vrf1 20000
```

config vrf del_vrf_vni_map

This command deletes VRF-VNI mapping from the SONiC system.

Usage
config vrf del_vrf_vni_map <vrf-name>

56 VRF Route Leaking

The CLI configuration for VRF route leaking uses the vtysh command to configure static and dynamic route leaks.

For dynamic route leaking, BGP is used as an example.

Static VRF Route Leaking

The following command creates a static route that leaks the next hop into a specified VRF.

Usage

```
ip route <A.B.C.D/M> <A.B.C.D> nexthop-vrf <vrf-name>
```

Example

```
admin@sonic:~# vtysh
sonic# configure
sonic(config)# vrf Vrf1
sonic(config-vrf)# ip route 2.2.2.2/32 10.0.0.59 nexthop-vrf Vrf2
sonic(config-vrf)# end
sonic# exit
admin@sonic:~#
admin@sonic:~# show ip route vrf Vrf1
Codes: K - kernel route, C - connected, S - static, R - RIP,
       O - OSPF, I - IS-IS, B - BGP, E - EIGRP, N - NHRP,
       T - Table, v - VNC, V - VNC-Direct, A - Babel, D - SHARP,
       F - PBR, f - OpenFabric,
       > - selected route, * - FIB route, q - queued route, r - rejected route
VRF Vrf1:
S>* 2.2.2.2/32 [1/0] via 10.0.0.59, PortChannel0002(vrf Vrf2), 01:34:15
C>* 10.0.0.56/31 is directly connected, PortChannel0001, 01:40:04
```

Dynamic VRF Route Leaking

Basic Configuration

The following command configures a dynamic VRF route leak that automatically imports routes between VRFs. In this example, the routes in the default VRF are imported to Vrf1.

Usage

```
import vrf <vrf-name>
```

Note:

- `import vrf <vrf-name>` is shortcut syntax for specifying automatic leaking from `vrf-name` to the current VRF. In the other words, you do not need to consider that the underlying mechanism relies on the BGP constructs of Route Distinguisher (RD) and Route Targets (RTs), because they are automatically derived when you enable route leaking.

Example

```
admin@sonic:~# vtysh
sonic# configure
sonic(config)# router bgp 65200 vrf Vrf1
sonic(config-router)# address-family ipv4 unicast
sonic(config-router-af)# import vrf default
sonic(config-router-af)# end
sonic# exit
admin@sonic:~#
admin@sonic:~# show ip route vrf Vrf1 193.11.248.128
Routing entry for 193.11.248.128/25
Known via "bgp", distance 200, metric 0, vrf Vrf1, best
Last update 00:03:47 ago
* 10.0.0.59, via PortChannel0002(vrf default)
* 10.0.0.61, via PortChannel0003(vrf default)
* 10.0.0.63, via PortChannel0004(vrf default)
```

Combine with route-map and prefix-list

You can also decide to select certain prefixes from being imported. The match rule must be configured in a route map.

Usage

```
import vrf route-map <name of route-map>
```

Note: Our test environment is a t0 topology, so the default VRF will get 6440 routes from peers.

Example

```
admin@sonic:~# vtysh
sonic# configure
sonic(config)# ip prefix-list test_vrf_route_leak seq 5 deny 193.11.248.0/25
sonic(config)# ip prefix-list test_vrf_route_leak seq 10 permit 193.11.240.128/25
sonic(config)# route-map VRF_ROUTE_LEAK permit 5
sonic(config-route-map)# match ip address prefix-list test_vrf_route_leak
sonic(config-route-map)# exit
sonic(config)# router bgp 65200 vrf Vrf1
sonic(config-router)# address-family ipv4 unicast
sonic(config-router-af)# import vrf route-map VRF_ROUTE_LEAK
sonic(config-router-af)# import vrf default
sonic(config-router-af)# end
```

57 VxLAN (includes EVPN and EVPN-MH)

Table of Contents

[VxLAN Show Commands](#)

[show vxlan tunnel](#)
[show vxlan name <vxlanname>](#)
[show vxlan interface](#)
[show vxlan vlanvni](#)
[show vxlan vrfvni](#)
[show vxlan remote_mac <remoteip/esi/all>](#)
[show vxlan remote_vni <remoteip/all>](#)
[show vxlan remotevtep](#)
[show vxlan evpn es](#)
[show neigh-suppress](#)

[VxLAN Configuration Commands](#)

[config vxlan add <vtepname> <src_ipv4>](#)
[config vxlan evpn_nvo add <nvoname> <vtepname>](#)
[config vxlan map add <vtepname> <vlanid> <vnid>](#)
[config vxlan evpn_es add <portchannelname> <esid> \[<sysmac>\]](#)
[config vxlan del <vtepname>](#)
[config vxlan evpn_nvo del <nvoname>](#)
[config vxlan map del <vtepname> <vlanid> <vnid>](#)
[config vxlan evpn_es del <portchannelname>](#)
[config neigh-suppress vlan](#)

VxLAN Show Commands

show vxlan tunnel

This command displays brief information about VxLANs configured in the device. It displays VxLAN tunnel name, source IP address, destination IP address and VLAN VNI tunnel mappings.

Usage

```
show vxlan tunnel
```

Example

```
admin@sonic:~$ show vxlan tunnel
vxlan tunnel name  source ip  destination ip  tunnel map name  tunnel map mapping(vni -> vlan)
-----
vtep               1.1.1.1        map_3000_Vlan30  3000 -> Vlan30
```

show vxlan name <vxlanname>

This command displays brief information for a specified VxLAN tunnel. It displays VxLAN tunnel name, source IP address, destination IP address and VLAN VNI tunnel mappings.

Usage

```
show vxlan name <vxlanname>
```

Example

```
admin@sonic:~$ show vxlan name vtep
vxlan tunnel name  source ip  destination ip  tunnel map name  tunnel map mapping(vni -> vlan)
-----
vtep               1.1.1.1        map_3000_Vlan30  3000 -> Vlan30
```

show vxlan interface

This command displays brief VTEP information.

Usage

```
show vxlan interface
```

Example

```
admin@sonic:~$ show vxlan interface
```

VTEP Information:

VTEP Name : vtep, SIP : 1.1.1.1

NVO Name : nvo, VTEP : vtep

Source interface : Loopback0

show vxlan vlanvni

This command displays all the VLAN VNI mappings.

Usage

```
show vxlan vlanvni
```

Example

```
admin@sonic:~$ show vxlan vlanvni
```

```
+-----+-----+
| VLAN  | VNI  |
+-----+-----+
| Vlan30 | 3000 |
+-----+-----+
Total count : 1
```

show vxlan vrfvni

This command displays all the VRF VNI mappings.

Note: The config commands are in the VRF CLI guide.

Usage

```
show vxlan vrfvni
```

Example

```
admin@sonic:~$ show vxlan vrfvni
```

```

+-----+-----+
| VRF   | VNI   |
+=====+=====+
| Vrf-1 | 104   |
+-----+-----+
Total count : 1

```

show vxlan remote_mac <remoteip/esi/all>

This command displays all MACs learnt from a specified remote VTEP IP, from a specified ESI, or from all of the remote VTEP IPs for all VNIs.

Usage

```
show vxlan remote_mac <remoteip/esi/all>
```

Example

```
admin@sonic:~$ show vxlan remotemac 2.2.2.2
```

```

+-----+-----+-----+-----+-----+
| VLAN   | MAC           | RemoteVTEP | ESI   | VNI | Type |
+=====+=====+=====+=====+=====+
| Vlan1000 | 00:12:34:56:78:90 | 2.2.2.2   |      | 100 | dynamic |
+-----+-----+-----+-----+-----+
Total count : 1

```

```
admin@sonic:~$ show vxlan remotemac 03:00:11:22:33:44:55:00:00:a8
```

```

+-----+-----+-----+-----+-----+
| VLAN   | MAC           | RemoteVTEP | ESI           | VNI | Type |
+=====+=====+=====+=====+=====+
| Vlan1000 | 00:55:66:77:88:AA | 03:00:11:22:33:44:55:00:00:a8 | 100 | dynamic |
+-----+-----+-----+-----+-----+
Total count : 1

```

```
admin@sonic:~$ show vxlan remotemac all
```

```

+-----+-----+-----+-----+-----+
| VLAN   | MAC           | RemoteVTEP | ESI           | VNI | Type |
+=====+=====+=====+=====+=====+
=====+
| Vlan1000 | 00:12:34:56:78:90 | 2.2.2.2   |               | 100 | dynamic |
+-----+-----+-----+-----+-----+
| Vlan1000 | 00:55:66:77:88:AA |           | 03:00:11:22:33:44:55:00:00:a8 | 100 | dynamic |
+-----+-----+-----+-----+-----+

Total count : 2

```

show vxlan remote_vni <remoteip/all>

This command displays all the VNIs learnt from the specified remote VTEP, or all the VNIs learnt from all of the remote VTEPs.

Usage

```
show vxlan remote_vni <remoteip/all>
```

Example

```
admin@sonic:~$ show vxlan remote_vni 3.3.3.3
```

```

+-----+-----+-----+
| VLAN   | RemoteVTEP | VNI |
+=====+=====+=====+
| Vlan101 | 3.3.3.3   | 1001 |
+-----+-----+-----+

Total count : 1

```

show vxlan remotevtep

This command displays all remote VTEPs (a.k.a. VxLAN tunnels) learnt by EVPN/VxLAN.

Usage

```
show vxlan remotevtep
```

Example

```
admin@sonic:~$ show vxlan remotevtep
```

```
+-----+-----+-----+-----+
| SIP    | DIP    | Creation Source | OperStatus |
+=====+=====+=====+=====+
| 11.11.11.11 | 22.22.22.22 | EVPN           | oper_up    |
+-----+-----+-----+-----+
Total count : 1
```

show vxlan evpn es

This command display all Ethernet Segments. The 'status' field indicates the operation status of the corresponding PortChannel interface.

Usage

```
show vxlan evpn es
```

Example

```
admin@sonic:~$ show vxlan evpn es
```

Type: L local, R remote, N non-DF

```
+-----+-----+-----+-----+-----+
| ESI                | Type | ES Interface | status | VTEPS  |
+=====+=====+=====+=====+=====+
| 03:44:38:39:ab:cd:01:00:00:01 | LRN  | PortChannel0001 | down   | 1.1.1.1 |
|                               |      |                  |        | 2.2.2.2 |
|                               |      |                  |        | 3.3.3.3 |
|                               |      |                  |        | 4.4.4.4 |
```

```

|          |          |          | 5.5.5.5 |
+-----+-----+-----+-----+
| 03:44:38:39:ab:cd:01:00:00:02 | L   | PortChannel0002 | up   |          |
+-----+-----+-----+-----+
| 03:44:38:39:ab:cd:01:00:00:03 | RN   |          | 172.0.0.24 |
|          |          |          | 172.0.0.25 |
|          |          |          | 172.0.0.26 |
+-----+-----+-----+-----+
Total count : 3

```

show neigh-suppress

This command display neighbor suppression status.

Usage

```
show neigh-suppress { all | vlan <vlan-id> }
```

Example

```
root@sonic:/home/admin# show neigh-suppress all
```

```

+-----+-----+-----+
| VLAN   | STATUS   | ASSOCIATED_NETDEV |
+=====+=====+=====+
| Vlan500 | Configured | vtep-500          |
+-----+-----+-----+
| Vlan600 | Configured | vtep-600          |
+-----+-----+-----+

```

Total count : 2

```
root@sonic:/home/admin#
```

VxLAN Configuration Commands

config vxlan add <vtepname> <src_ipv4>

This command is for VTEP Source IP configuration. The vtepname is a string, and src_ipv4 is an IPV4 address in dotted notation A.B.C.D .

Usage

```
config vxlan add <vtepname> <src_ipv4>
```

Example

```
sudo config vxlan add vtep 1.1.1.1
```

config vxlan evpn_nvo add <nvname> <vtepname>

This command is for NVO configuration.

Usage

```
config vxlan evpn_nvo add <nvname> <vtepname>
```

Example

```
sudo config vxlan evpn_nvo add nvo vtep
```

config vxlan map add <vtepname> <vlanid> <vnid>

This command creates VLAN-VNI mapping on the VTEP with name vtepname .

Usage

```
config vxlan map add <vtepname> <vlanid> <vnid>
```

Example

```
sudo config vxlan map add vtep 30 3000
```

config vxlan evpn_es add <portchannelname> <esid> [<sysmac>]

This command creates an Ethernet Segment on specified PortChannel interface.

Usage

```
config vxlan evpn_es add <portchannelname> <esid> [<sysmac>]
```

Example

#type 0

```
sudo config vxlan evpn_es add PortChannel0001 00:11:22:33:44:55:66:77:88:99
```

#type 3

```
sudo config vxlan evpn_es add PortChannel0001 168 00:11:22:33:ab:cd
```

config vxlan del <vtepname>

This command deletes a VTEP with name vtepname .

Usage

```
config vxlan del <vtepname>
```

Example

```
sudo config vxlan del vtep
```

config vxlan evpn_nvo del <nvname>

This command deletes NVO with name nvname .

Usage

```
config vxlan evpn_nvo del <nvname>
```

Example

```
sudo config vxlan evpn_nvo del nvo
```

config vxlan map del <vtepname> <vlanid> <vnid>

This command deletes specific VLAN-VNI mapping on the VTEP with name vtepname .

Usage

```
config vxlan map del <vtepname> <vlanid> <vnid>
```

Example

```
sudo config vxlan map del vtep 30 3000
```

config vxlan evpn_es del <portchannelname>

This command deletes the Ethernet Segment on specified PortChannel interface.

Usage

```
config vxlan evpn_es del <portchannelname>
```

Example

```
sudo config vxlan evpn_es del PortChannel0001
```

config neigh-suppress vlan

This command will suppress both ARP & ND flooding over the tunnel when Vlan is extended.

Usage

```
config neigh-suppress vlan <vlan-id> <"on"/"off">
```

Note: vlan-id represents the VLAN

ID and on/off is enabled or disabled. By default ARP/ND suppression is disabled.

Example
config neigh-suppress vlan 600 on

58 Warm Reboot

Warm Reboot Configuration Commands

warm-reboot

This command initiates a warm reboot of the device. The command does not require setting a warm restart configuration, it sets up everything needed to perform a warm reboot. This command requires root privilege.

Usage
warm-reboot \[-h -? -v -f -r -k -x -c <control plane assistant IP list> -s\]

Parameters:

- -h,-? : get this help
- -v : turn on verbose mode
- -f : force execution
- -r : reboot with /sbin/reboot
- -k : reboot with /sbin/kexec -e \[default\]
- -x : execute script with -x flag
- -c : specify control plane assistant IP list
- -s : strict mode: do not proceed without:
 - - control plane assistant IP list.

Example

```
admin@sonic:~$ sudo warm-reboot -v
Tue Oct 22 23:20:53 UTC 2019 Pausing orchagent ...
Tue Oct 22 23:20:53 UTC 2019 Stopping radv ...
Tue Oct 22 23:20:54 UTC 2019 Stopping bgp ...
Tue Oct 22 23:20:54 UTC 2019 Stopped bgp ...
Tue Oct 22 23:20:57 UTC 2019 Initialize pre-shutdown ...
Tue Oct 22 23:20:58 UTC 2019 Requesting pre-shutdown ...
Tue Oct 22 23:20:58 UTC 2019 Waiting for pre-shutdown ...
Tue Oct 22 23:20:59 UTC 2019 Pre-shutdown succeeded ...
Tue Oct 22 23:20:59 UTC 2019 Backing up database ...
Tue Oct 22 23:21:00 UTC 2019 Stopping teamd ...
Tue Oct 22 23:21:00 UTC 2019 Stopped teamd ...
Tue Oct 22 23:21:00 UTC 2019 Stopping syncd ...
Tue Oct 22 23:21:11 UTC 2019 Stopped syncd ...
Tue Oct 22 23:21:11 UTC 2019 Stopping all remaining containers ...
Tue Oct 22 23:21:13 UTC 2019 Stopped all remaining containers ...
Tue Oct 22 23:21:15 UTC 2019 Rebooting with /sbin/kexec -e to SONiC-OS-20191021.01 ...
```

59 Warm Restart

Table of Contents

[Warm Restart Show Commands](#)

[show warm_restart config](#)

[show warm_restart state](#)

[Warm Restart Config Commands](#)

[config warm_restart bgp_timer \(Not Supported\)](#)

[config warm_restart enable/disable](#)

[config warm_restart neighsyncd_timer \(Not Supported\)](#)

[config warm_restart bgp_timer \(Not Supported\)](#)

[config warm_restart teamsyncd_timer \(Not Supported\)](#)

Besides a device-level warm reboot, SONiC also provides a docker-based warm restart. This feature is currently supported by the following dockers: BGP, teamD, and SWSS. A user can manage to restart a particular docker with no interruption on packet forwarding and no effect on other services. This helps to reduce operational costs as well as development efforts. For example, to fix a bug in the BGP routing stack, only the BGP docker image needs to be built, tested, and upgraded.

To achieve uninterrupted packet forwarding during the restarting stage and database reconciliation at the post starting stage, warm restart enables dockers with adjacency state machine to facilitate standardized protocols.

For example, a BGP restarting switch must have BGP "Graceful Restart" enabled, and its BGP neighbors must be "Graceful Restart Helper Capable", as specified in [IETF RFC4724](https://tools.ietf.org/html/rfc4724).

Before executing a warm restart for the BGP docker, the following BGP commands should be enabled:

```
bgp graceful-restart
bgp graceful-restart preserve-fw-state
```

In the current SONiC release, the above two commands are enabled by default.

You should be aware that during a warm restart, certain BGP fast convergence features and black hole avoidance features should either be disabled or set to a lower preference to avoid conflicts with the BGP graceful restart.

For example, BGP BFD could be disabled via:

```
no neighbor <A.B.C.D|X:X::X:X|WORD> bfd
```

otherwise, the fast failure detection would cause packet drop during the warm reboot.

Another commonly deployed blackhole avoidance feature: dynamic route priority adjustment, could be disabled to avoid large routes churn during BGP restart. Use the following command.

```
no bgp max-med on-peerup
```

Warm Restart Show Commands

show warm_restart config

This command displays all the configuration related to a warm restart.

Usage

```
show warm_restart config
```

Example

```
admin@sonic:~$ show warm_restart config
name enable timer_name timer_duration
```

show warm_restart state

This command displays the warm restart state.

Usage

```
show warm_restart state
```

Example

```
admin@sonic:~$ show warm_restart state
name restore_count state
  orchagent 0
  vlanmgrd 0
  bgp 1 reconciled
  portsyncd 0
  teammgrd 1
  neighsyncd 0
  teamsyncd 1
  syncd 0
  natsyncd 0
```

Warm Restart Config Commands

This sub-section explains the various configurations related to the warm restart feature. The following parameters can be configured using this command.

1. `bgp_timer`
2. `disable`
3. `enable`
4. `neighsyncd_timer`
5. `teamsyncd_timer`

Each of these sub-commands are explained in the following section.

Users can use an optional parameter `-s` to use the unix domain socket for communicating with the RedisDB which will be faster when compared to using the default network sockets. All these commands have the following option.

Options: `-s, --redis-unix-socket-path TEXT` unix socket path for redis connection.

config warm_restart bgp_timer (Not Supported)

This command is used to set the BGP timer value for warm restart of the BGP service. `bgp_timer` holds the time interval utilized by `fpm syncd` during warm-restart episodes. During this interval, `fpmsyncd` will recover all the routing states previously pushed to AppDB, as well as all new states coming from `zebra/bgpd`. Upon expiration of this timer, `fpmsyncd` will execute the reconciliation logic to eliminate all the stale entries from AppDB. This timer should match the BGP-GR restart-timer configured within the elected routing- stack.

Usage
<code>config warm_restart [-s --redis-unix-socket-path <socket_path>] bgp_timer <seconds></code>

Parameters:

seconds: Range from 1 to 3600

Example

```
admin@sonic:~$ sudo config warm_restart bgp_timer 1000
```

config warm_restart enable/disable

This command is used to enable or disable the warm restart for a particular service that supports warm reboot. The following four services support warm reboot. When a user restarts the particular service using `systemctl restart <service_name>`, this configured value will be checked for whether it is enabled or disabled. If this configuration is enabled for that service, it will perform a warm reboot for that service. Otherwise, it will do a cold restart of the service.

Usage

```
config warm_restart [-s|--redis-unix-socket-path <socket_path>] enable [<module_name>]
```

Parameters:

module_name: Can be either `system`, `swss`, `bgp`, or `teamd`. If the `module_name` argument is not specified, it will enable the system module.

Example (Set warm_restart as "enable" for the "system" service)

```
admin@sonic:~$ sudo config warm_restart enable
```

Example (Set warm_restart as "enable" for the "swss" service. When user does "systemctl restart swss", it will perform warm reboot instead of cold reboot)

```
admin@sonic:~$ sudo config warm_restart enable swss
```

Example (Set warm_restart as "enable" for the "teamd" service. When user does "systemctl restart teamd", it will perform warm reboot instead of cold reboot)

```
admin@sonic:~$ sudo config warm_restart enable teamd
```

config warm_restart neighsyncd_timer (Not Supported)

This command is used to set the neighsyncd_timer value for a warm restart of the swss service. The neighsyncd_timer is the timer used for swss (neighsyncd) service during the warm restart. The timer is started after the neighborTable is restored to internal data structures.

Then, neighborsyncd starts to read all Linux kernel entries and mark the entries in the data structures accordingly. Once the timer is expired, reconciliation is done and the delta is pushed to appDB Valid value is 1-9999. 0 is invalid.

Usage

```
config warm_restart [-s|--redis-unix-socket-path <socket_path>] neighsyncd_timer <seconds>
```

Parameters:

- seconds: Range from 1 to 9999

Example

```
admin@sonic:~$ sudo config warm_restart neighsyncd_timer 2000
```

config warm_restart bgp_timer (Not Supported)

This command is used to set the bgp_timer value for a warm restart of the bgp service. The bgp_timer is the timer used for the bgp service during the warm restart. The timer is started after the BGP table is restored to internal data structures. BGP services then start to read all Linux kernel entries and mark the entries in the data structures accordingly. Once the timer is expired, reconciliation is done and the delta is pushed to appDB Valid value is 1-9999. 0 is invalid.

Usage

```
config warm_restart [-s|--redis-unix-socket-path <socket_path>] bgp_timer <seconds>
```

Parameters:

- seconds: Range from 1 to 9999

Example

```
admin@sonic:~$ sudo config warm_restart bgp_timer 2000
```

config warm_restart teamsyncd_timer (Not Supported)

This command is used to set the teamsyncd_timer value for a warm restart of the teamd service. The teamsyncd_timer holds the time interval utilized by teamsyncd during warm-restart episodes. The timer is started when teamsyncd starts. During the timer interval, teamsyncd will preserve all LAG interface changes, but it will not apply them. The changes will only be applied when the timer expires. When the changes are applied, the stale LAG entries will be removed, the new LAG entries will be created. Supported range: 1-9999. 0 is invalid.

Usage

```
config warm_restart teamsyncd_timer <seconds>
```

Parameters:

- seconds: Range from 1 to 9999

Example

```
admin@sonic:~$ sudo config warm_restart teamsyncd_timer  
3000
```

60 Watermark

Watermark Show Commands

show watermark telemetry interval

This command displays the configured interval for the telemetry.

Usage
show watermark telemetry interval

Example
admin@sonic:~\$ show watermark telemetry interval Telemetry interval 120 second(s)

Watermark Config Commands

config watermark telemetry interval

This command is used to configure the interval for telemetry. The default interval is 120 seconds. There is no regulation on the valid range of values; it leverages the Linux timer.

Usage
config watermark telemetry interval <value>

Example

```
admin@sonic:~$ sudo config watermark telemetry interval 999
```

61 WRED & ECN

Table of Contents

[WRED & ECN Show Commands](#)

[show wred](#)

[show interface wred](#)

[WRED & ECN Configuration Commands](#)

[config wred add](#)

[config wred update](#)

[config wred del](#)

[config interface wred bind queue](#)

[config interface wred unbind queue](#)

[ECN Show Commands](#)

[show ecn](#)

[ECN Config Commands](#)

[config ecn](#)

This section explains all the Explicit Congestion Notification (ECN) show commands and ECN configuration

options that are supported in SONiC.

WRED & ECN Show Commands

show wred

This command is used to display the WRED profile.

Usage

```
show wred [<profile_name>]
```

Parameters:

<profile_name>: Profile name.

Example

```
admin@sonic:~$ show wred
```

Profile: ecn_prof

Color	Mode	Min Threshold	Max Threshold	Drop Probability
Green	ECN	100	10000	25
Yellow	ECN	200	20000	50
Red	ECN	400	40000	75

show interface wred

This command is used to display the WRED configuration for all interfaces or a given interface.

Usage

```
show interface wred <interface_name>
```

Parameters:

<interface_name>: Physical interface name. For example: "Ethernet0".

Example

```
admin@as9516-32d-2:~$ show interface wred
Ethernet0
Queue: 0
ECN/WRED: ecn_prof2
Color  Mode    Min Threshold  Max Threshold  Drop Probability
Green  ECN         5000          10000          100
Yellow ECN
Red    ECN
```

WRED & ECN Configuration Commands

config wred add

This command is used to create a WRED profile.

Usage

```
config wred add <profile> --mode={ecn|wred} [--gmin <gmin> --gmax <gmax> --gdrop <gdrop>] [--ymin
<ymin> --ymax <ymax> --ydrop <ydrop>] [--rmin <rmin> --rmax <rmax> --rdrop <rdrop>]
```

Note: On mellano switches, the command distinguishes between ecn and wred through mode, and other parameters are shared.

Parameters:

- <profile_name>: Profile name.
- mode: ECN or WRED mode.
 - ecn: Enable ECN marking.
 - wred : Enable WRED dropping.

- <gmin>: Minimum threshold in bytes to start WRED dropping or ECN marking for green packet.
- <gmax>: Maximum threshold in bytes for WRED dropping or ECN marking for green packet.
- <gdrop>: Maximum dropping or marking probability for green packet. Minimum: 0. Maximum: 100.
- <ymin>: Minimum threshold in bytes to start WRED dropping or ECN marking for yellow packet.
- <ymin>: Maximum threshold in bytes for WRED dropping or ECN marking for yellow packet.
- <ydrop>: Maximum dropping or marking probability for yellow packet. Minimum: 0. Maximum: 100.
- <rmin>: Minimum threshold in bytes to start WRED dropping or ECN marking for red packet.
- <rmax>: Maximum threshold in bytes for WRED dropping or ECN marking for red packet.
- <rdrop>: Maximum dropping or marking probability for red packet. Minimum: 0. Maximum: 100.

Note:

The devices using the Broadcom ASIC, the maximum drop probability supports one of [0~10, 25, 50, 75, 100] in hardware.

- If the user configuration value is from 0 to 10, takes the same value as hardware configuration.
- If the user configuration value is from 10 to 24, takes 10 as hardware configuration.
- If the user configuration value is from 25 to 49, takes 25 as hardware configuration.
- If the user configuration value is from 50 to 74, takes 50 as hardware configuration.
- If the user configuration value is from 75 to 99, takes 75 as hardware configuration.
- If user configuration value exceeds 100, takes 100 is used for hardware configuration.

The following table shows the maximum threshold per switch.

Switch	Maximum Threshold (bytes)
AS5835-54X AS7326-56X AS7726-32X	67,108,608
AS9746-32D AS9736-64D	133,168,898
AS9746-128d	158,220,288

Example

```
sudo config wred add ecn_profile --mode ecn --gmin 5000 --gmax 10000 --gdrop 100
```

config wred update

This command is used to modify an existing WRED profile.

Usage

```
config wred update <profile> [--mode={ecn|wred}] [--gmin <gmin> --gmax <gmax> --gdrop <gdrop>] [--ymin <ymin> --ymax <ymax> --ydrop <ydrop>] [--rmin <rmin> --rmax <rmax> --rdrop <rdrop>] [--no-green] [--no-yellow] [--no-red]
```

Parameters:

- <profile_name>: Profile name.
- mode: ECN or WRED mode.
 - ecn: Enable ECN marking.
 - wred : Enable WRED dropping.
- <gmin>: Minimum threshold in bytes to start WRED dropping or ECN marking for green packet.
- <gmax>: Maximum threshold in bytes for WRED dropping or ECN marking for green packet.
- <gdrop>: Maximum dropping or marking probability for green packet. Minimum: 0. Maximum: 100.
- <ymin>: Minimum threshold in bytes to start WRED dropping or ECN marking for yellow packet.
- <ymax>: Maximum threshold in bytes for WRED dropping or ECN marking for yellow packet.
- <ydrop>: Maximum dropping or marking probability for yellow packet. Minimum: 0. Maximum: 100.
- <rmin>: Minimum threshold in bytes to start WRED dropping or ECN marking for red packet.
- <rmax>: Maximum threshold in bytes for WRED dropping or ECN marking for red packet.
- <rdrop>: Maximum dropping or marking probability for red packet. Minimum: 0. Maximum: 100.
- no-green: Remove the green setting from the profile.
- no-yellow : Remove the yellow setting from the profile.
- no-red : Remove the red setting from the profile.

Note:

The devices using the Broadcom ASIC, the maximum drop probability supports one of [0~10, 25, 50, 75, 100] in hardware.

- If the user configuration value is from 0 to 10, takes the same value as hardware configuration.

- If the user configuration value is from 10 to 24, takes 10 as hardware configuration.
- If the user configuration value is from 25 to 49, takes 25 as hardware configuration.
- If the user configuration value is from 50 to 74, takes 50 as hardware configuration.
- If the user configuration value is from 75 to 99, takes 75 as hardware configuration.
- If user configuration value exceeds 100, takes 100 is used for hardware configuration.

Example

```
sudo config wred update ecn_profile --mode ecn --gmin 10000 --gmax 20000 --gdrop 50
```

The following example shows how to remove the yellow setting from an existing profile.

Example

```
sudo config wred update ecn_profile --no-yellow
```

config wred del

This command is used to delete a WRED profile.

Usage

```
config wred del <profile>
```

Parameters:

<profile_name>: Profile name.

Example

```
sudo config wred del ecn_profile
```

config interface wred bind queue

This command is used to configure the WRED thresholds on the specified queue.

Usage

```
config interface wred bind queue <interface_name> <queue> <profile_name>
```

Parameters:

<interface_name>: Physical interface name. For example: "Ethernet0".

<queue>: Queue. Minimum: 0. Maximum: 7.

<profile_name>: Profile name.

Example

```
sudo config interface wred bind queue Ethernet0 0 ecn_profile
```

config interface wred unbind queue

This command is used to reset the WRED thresholds on the specified queue.

Usage

```
config interface wred unbind queue <interface_name> <queue>
```

Parameters:

<interface_name>: Physical interface name. For example: "Ethernet0".

<queue>: Queue. Minimum: 0. Maximum: 7.

Example

```
sudo config interface wred unbind queue Ethernet0 0
```

ECN Show Commands

This sub-section contains the ECN show commands that are supported.

show ecn

Note

- this command can be replaced by "show wred" command.

This command displays all the WRED profiles that are configured in the device.

Usage

```
show ecn
```

Example: show the existed profile

```
admin@sonic:~$ show ecn
Profile: AZURE_LOSSLESS
-----
red_max_threshold    2097152
red_drop_probability  5
yellow_max_threshold 2097152
ecn                  ecn_all
green_min_threshold  1048576
red_min_threshold    1048576
wred_yellow_enable   true
yellow_min_threshold 1048576
green_max_threshold  2097152
green_drop_probability 5
wred_green_enable    true
yellow_drop_probability 5
```

```
wred_red_enable      true
```

```
Profile: wredprofileabcd
```

```
red_max_threshold 100
```

ECN Config Commands

This sub-section contains the configuration commands that can configure the WRED profiles.

config ecn

Note

- this command can be replaced by "config wred add" and "config wred update" commands.

This command configures the possible fields in a particular WRED profile that is specified using the "-profile <profilename>" argument. The list of the WRED profile fields that are configurable is listed below.

Usage(This configuration is only supported on Broadcom switches.)

```
config ecn -profile <profile_name> [-rmax <red_threshold_max>] [-rmin <red_threshold_min>] [-ymax
<yellow_threshold_max>] [-ymin <yellow_threshold_min>] [-gmax <green_threshold_max>] [-gmin
<green_threshold_min>] [-v|--verbose]
```

Parameters:

- profile_name Profile name.
- red_threshold_max Set the red max threshold.
- red_threshold_min Set the red min threshold.
- yellow_threshold_max Set the yellow max threshold.
- yellow_threshold_min Set the yellow min threshold.
- green_threshold_max Set the green max threshold.

- green_threshold_min Set the green min threshold.

Note

- The command can only be used to configure an existing WRED profile that is bound to a queue. It does not support creating a WRED profile and only limited fields can be configured.

Firstly, create a json file (here named ecn.json as an example) that includes a WRED profile (e.g., AZURE_LOSSLESS) and bind it to Ethernet0 queue 3 and Ethernet 4 queue4.

ecn.json

```
"WRED_PROFILE": {
  "AZURE_LOSSLESS": {
    "wred_green_enable": "true",
    "green_min_threshold": "1248",
    "green_max_threshold": "1872",
    "green_drop_probability": "25",
    "wred_yellow_enable": "true",
    "yellow_min_threshold": "1456",
    "yellow_max_threshold": "1872",
    "yellow_drop_probability": "50",
    "wred_red_enable": "true",
    "red_max_threshold": "2097152",
    "red_min_threshold": "2097152",
    "red_drop_probability": "75",
    "ecn": "ecn_all"
  }
},
"QUEUE": {
  "Ethernet0|3": {
    "wred_profile": "[WRED_PROFILE|AZURE_LOSSLESS]"
  },
  "Ethernet4|4": {
    "wred_profile": "[WRED_PROFILE|AZURE_LOSSLESS]"
  }
}
```

And then, use the `sonic-cfggen` command to load the json file that creates a WRED profile and applies it to queues.

Example

```
admin@sonic:~$ sudo sonic-cfggen -w -j ecn.json
```

The following example shows how to set a red max threshold 100 for the profile `AZURE_LOSSLESS`.

Example: Modify the red max threshold in profile 'AZURE_LOSSLESS'

```
admin@sonic:~$ sudo config ecn -profile AZURE_LOSSLESS -rmax 100
```

62 ZTP

Table of Contents

[ZTP Show Commands](#)

[show ztp status](#)

[ZTP Configuration Commands](#)

[config ztp enable](#)

[config ztp disable](#)

[config ztp run](#)

This section explains all the Zero Touch Provisioning (ZTP) commands that are supported in SONiC.

ZTP Show Commands

show ztp status

This command displays the current ZTP configuration of the switch. It also displays detailed information about current state of a ZTP session. It displays information related to all configuration sections as defined in the switch provisioning information discovered in a particular ZTP session.

Usage

```
show ztp status
```

```
show ztp status --verbose
```

Example

```
root@B1-SP1-7712:/home/admin# show ztp status
```

```
ZTP Admin Mode : True
```

```
ZTP Service : Inactive
```

```
ZTP Status : SUCCESS
```

```
ZTP Source : dhcp-opt67 (eth0)
```

```
Runtime : 05m 31s
```

```
Timestamp : 2019-09-11 19:12:24 UTC
```

```
ZTP Service is not running
```

```
01-configdb-json: SUCCESS
```

```
02-connectivity-check: SUCCESS
```

Use the verbose option to display more detailed information.

Example

```
root@B1-SP1-7712:/home/admin# show ztp status --verbose
```

```
Command: ztp status --verbose
```

```
=====
```

```
ZTP
```

```
=====
```

```
ZTP Admin Mode : True
```

```
ZTP Service : Inactive
```

```
ZTP Status : SUCCESS
```

```
ZTP Source : dhcp-opt67 (eth0)
```

```
Runtime : 05m 31s
```

```
Timestamp : 2019-09-11 19:12:16 UTC
```

```
ZTP JSON Version : 1.0
```

```
ZTP Service is not running
```

```
-----
```

```
01-configdb-json
```

```
-----
```

```
Status : SUCCESS
```

```
Runtime : 02m 48s
```

```
Timestamp : 2019-09-11 19:11:55 UTC
```

```
Exit Code : 0
```

```
Ignore Result : False
```

```
-----
```

```
02-connectivity-check
```

```
-----
```

```
Status : SUCCESS
```

```
Runtime : 04s
```

```
Timestamp : 2019-09-11 19:12:16 UTC
```

```
Exit Code : 0
```

```
Ignore Result : False
```

Description:

- ZTP AdminMode - Displays if the ZTP feature is administratively enabled or disabled. Possible values are True or False. This value is configurable using the `config z tp enabled` and `config z tp disable` commands.
- ZTP Service - Displays the ZTP service status. The following are possible values this field can display:

- Active Discovery: ZTP service is operational and is performing DHCP discovery to learn switch provisioning information.
- Inactive: ZTP service is not running.
- Processing: ZTP service has discovered switch provisioning information and is processing it.
- ZTP Status - Displays the current state and result of ZTP session. The following are possible values this field can display:
 - IN-PROGRESS: ZTP session is currently in progress. ZTP service is processing switch provisioning information.
 - SUCCESS: ZTP service has successfully processed the switch provisioning information.
 - FAILED: ZTP service has failed to process the switch provisioning information.
 - Not Started: ZTP service has not started processing the discovered switch provisioning information.
- ZTP Source - Displays the DHCP option and then interface name from which switch provisioning information has been discovered.
- Runtime - Displays the time taken for ZTP process to complete from start to finish. For individual configuration sections it indicates the time taken to process the associated configuration section.
- Timestamp - Displays the date/time stamp when the status field has last changed.
- ZTP JSON Version - Version of ZTP JSON file used for describing switch provisioning information.
- Status - Displays the current state and result of a configuration section. The following are possible values this field can display:
 - IN-PROGRESS: Corresponding configuration section is currently being processed.
 - SUCCESS: Corresponding configuration section was processed successfully.
 - FAILED: Corresponding configuration section failed to execute successfully.
 - Not Started: ZTP service has not started processing the corresponding configuration section.
 - DISABLED: Corresponding configuration section has been marked as disabled and will not be processed.
- Exit Code - Displays the program exit code of the configuration section executed. Non-zero exit code indicates that the configuration section has failed to execute successfully.

- **Ignore Result** - If this value is True, the result of the corresponding configuration section is ignored and not used to evaluate the overall ZTP result.
- **Activity String** - In addition to above information an activity string is displayed indicating the current action being performed by the ZTP service and how much time it has been performing the mentioned activity. Below is an example.
 - (04m 12s) Discovering provisioning data

ZTP Configuration Commands

This sub-section explains the list of configuration options available for ZTP.

config ztp enable

Use this command to enable ZTP administrative mode.

Usage
config ztp enable

Example
<pre>root@sonic:/home/admin# config ztp enable</pre> Running command: ztp enable

config ztp disable

Use this command to disable ZTP administrative mode. This command can also be used to abort a current ZTP session and load the

factory default switch configuration.

Usage

```
config ztp disable  
config ztp disable -y
```

Example

```
root@sonic:/home/admin# config ztp disable  
Active ZTP session will be stopped and disabled, continue? [y/N]: y  
Running command: ztp disable -y
```

config ztp run

Use this command to manually restart a new ZTP session. This command deletes the existing /etc/sonic/config_db.json file and starts the ZTP service. It also erases the previous ZTP session data. ZTP configuration is loaded on the switch and ZTP discovery is performed.

Usage

```
config ztp run  
config ztp run -y
```

Example

```
root@sonic:/home/admin# config ztp run  
ZTP will be restarted. You may lose switch data and connectivity, continue? [y/N]: y  
Running command: ztp run -y
```

63 Reloading Configuration

config reload

This command stops all services before clearing the configuration and restarts those services. The execution of the config reload takes some time since it restarts many services currently running on the device.

When users do "config reload", the newly loaded config may or may not have a management IP address. If there is a management IP in the newly loaded config file, it might be different or identical to the previously defined value.

Usage

```
config reload [-y|--yes] [-l|--load-sysinfo] [<filename>] [-n|--no-service-restart] [-f|--force]
```

The Parameters are as below:

- "-y" or "--yes" : This forces the loading without prompting the user for confirmation. If the argument is not specified, it prompts the user to confirm whether the user wants to load this configuration file.
- "-n" or "--no-service-restart" : This clears and loads the configuration without restarting dependent services running on the device. One use case for this option is during boot time when the config-setup service loads the existing old configuration and no services are running on the device.
- "-f" or "--force": This option ignores the system sanity checks. By default, a list of sanity checks is performed and if one of the checks fails, the command will not execute. The checks include making sure the system status is not starting, all the essential services are up and swss is in a ready state.
- "<filename>" : Names of configuration file(s) to load, separated by comma with no spaces in between.

Example

```
admin@sonic:~$ sudo config reload
Clear current config and reload config from the file /etc/sonic/config_db.json? [y/N]: y
Running command: systemctl stop dhcp_relay
Running command: systemctl stop swss
Running command: systemctl stop snmp
Warning: Stopping snmp.service, but it can still be activated by:
snmp.timer
Running command: systemctl stop lldp
Running command: systemctl stop pmon
Running command: systemctl stop bgp
Running command: systemctl stop teamd
Running command: /usr/local/bin/sonic-cfggen -H -k Force10-Z9100-C32 --write-to-db
Running command: /usr/local/bin/sonic-cfggen -j /etc/sonic/config_db.json --write-to-db
Running command: systemctl restart hostname-config
Running command: systemctl restart interfaces-config
Timeout, server 10.11.162.42 not responding.
```

64 Linux Kernel Dump

Table of Contents

[Linux Kernel Dump show commands](#)

[show kdump config](#)

[show kdump files](#)

[show kdump logging<file_name> <num_of_lines>](#)

[Linux Kernel Dump config commands](#)

[config kdump](#)

Linux Kernel Dump show commands

show kdump config

This command shows the configuration of Linux kernel dump.

Usage
show kdump config

Example
<pre>admin@sonic:~\$ show kdump config Kdump administrative mode: Enabled Kdump operational mode: Ready after reboot Kdump memory reservation: 0M-2G:256M,2G-4G:320M,4G-8G:384M,8G-:448M Maximum number of Kdump files: 3</pre>

Field Description:

- "Kdump administrative mode" show the user configuration.
- "Kdump operational mode" show the current state.
- "Kdump memory reservation" show the reserved memory for the capture kernel.
- "Maximum number of Kdump files" indicate the the maximum files number will be kept in the system.

Note

- When Kdump is enabled through CLI for the first time, a system reboot should be applied to make kdump take effect.
- From the output of "show kdump config", a hint "Ready after reboot" also show in the field: Kdump operational mode.
- "0M-2G:256M,2G-4G:320M,4G-8G:384M,8G-:448M" is the default value for the memory allocated for the capture kernel.

RAM size	Crash kernel parameter
<= 2GB	256 MB
<= 4GB	320 MB
<= 8GB	384 MB
> 8GB	448 MB

show kdump files

This command shows the Linux kernel core dump files and dmesg files which are generated by kernel dump tool.

Usage

```
show kdump files
```

Example

```
admin@sonic:~$ show kdump files
```

Kernel core dump files

Kernel dmesg files

```
-----
/var/crash/202212191136/kdump.202212191136 /var/crash/202212191136/dmesg.202212191136
/var/crash/202212191119/kdump.202212191119 /var/crash/202212191119/dmesg.202212191119
```

show kdump logging<file_name> <num_of_lines>

By default, this command will show the last 10 lines of latest dmesg file. This command can also accept a specific file name and number of lines as arguments.

Usage

```
show kdump logging
```

Example: showing the last 10 lines of latest dmesg file

```
admin@sonic:~$ show kdump logging
[ 313.984453] do_syscall_64+0x33/0x80
[ 313.988444] entry_SYSCALL_64_after_hwframe+0x44/0xa9
[ 313.994092] RIP: 0033:0x7f82818b58f3
[ 313.998089] Code: 8b 15 a1 25 0e 00 f7 d8 64 89 02 48 c7 c0 ff ff ff ff eb b7 0f 1f 00 64 8b 04 25 18 00 00
00 85 c0 75 14 b8 01 00 00 00 0f 05 <48> 3d 00 f0 ff ff 77 55 c3 0f 1f 40 00 48 83 ec 28 48 89 54 24 18
[ 314.019077] RSP: 002b:00007ffdce0e0278 EFLAGS: 00000246 ORIG_RAX: 0000000000000001
[ 314.027545] RAX: ffffffffda RBX: 0000000000000002 RCX: 00007f82818b58f3
[ 314.035514] RDX: 0000000000000002 RSI: 0000555e300c52f0 RDI: 0000000000000001
[ 314.043491] RBP: 0000555e300c52f0 R08: 000000000000000a R09: 0000000000000001
[ 314.051468] R10: 0000555e300b4180 R11: 0000000000000246 R12: 0000000000000002
[ 314.059445] R13: 00007f82819996a0 R14: 0000000000000002 R15: 00007f8281994880
```

Example: specifying a file name and number of lines

```
admin@sonic:~$ show kdump logging dmesg.202212191119 -l 20
[ 156.711753] Call Trace:
[ 156.714498] dump_stack+0x6b/0x83
[ 156.718211] panic+0x12d/0x303
[ 156.721625] ? printk+0x58/0x6f
[ 156.725141] sysrq_handle_crash+0x16/0x20
```

```
[ 156.729626] __handle_sysrq.cold+0x43/0x113
[ 156.734304] write_sysrq_trigger+0x24/0x40
[ 156.738885] proc_reg_write+0x51/0x90
[ 156.742980] vfs_write+0xc0/0x260
[ 156.746684] ksys_write+0x5f/0xe0
[ 156.750395] do_syscall_64+0x33/0x80
[ 156.754398] entry_SYSCALL_64_after_hwframe+0x44/0xa9
[ 156.760047] RIP: 0033:0x7fa51a6918f3
[ 156.764045] Code: 8b 15 a1 25 0e 00 f7 d8 64 89 02 48 c7 c0 ff ff ff ff eb b7 0f 1f 00 64 8b 04 25 18 00
00 00 85 c0 75 14 b8 01 00 00 00 0f 05 <48> 3d 00 f0 ff ff 77 55 c3 0f 1f 40 00 48 83 ec 28 48 89 54 24 18
[ 156.785044] RSP: 002b:00007ffef637c018 EFLAGS: 00000246 ORIG_RAX: 0000000000000001
[ 156.793514] RAX: ffffffffda RBX: 0000000000000002 RCX: 00007fa51a6918f3
[ 156.801491] RDX: 0000000000000002 RSI: 000055f5684cabb0 RDI: 0000000000000001
[ 156.809467] RBP: 000055f5684cabb0 R08: 000000000000000a R09: 0000000000000001
[ 156.817449] R10: 000055f5683c8a70 R11: 0000000000000246 R12: 0000000000000002
[ 156.825427] R13: 00007fa51a7756a0 R14: 0000000000000002 R15: 00007fa51a770880
```

Linux Kernel Dump config commands

config kdump

Administrative state of kdump is stored in ConfigDB.

The variable USE_KDUMP in the file /etc/default/kdump-tools is set to 0 to disable kdump, and set to 1 to enable kdump.

Since this command might require changing the kernel parameters to specify the amount of memory reserved for the capture kernel (the kernel parameters which are exported through /proc/cmdline), a reboot is necessary.

The command displays a message showing that kdump functionality will be either enabled or disabled following the next reboot.

Usage

```
admin@sonic:~$ sudo config kdump
Usage: config kdump [OPTIONS] COMMAND [ARGS]...
    Configure the KDUMP mechanism
Options:
  -h, -?, --help  Show this message and exit.
Commands:
  disable  Disable the KDUMP mechanism
  enable   Enable the KDUMP mechanism
  memory   Configure the memory for KDUMP mechanism
  num_dumps Configure the maximum dump files of KDUMP mechanism.
```

Example

```
admin@sonic:~$ sudo config kdump enable
KDUMP configuration changes may require a reboot to take effect.
Save SONiC configuration using 'config save' before issuing the reboot command.
admin@sonic:~$ sudo config kdump disable
KDUMP configuration changes may require a reboot to take effect.
Save SONiC configuration using 'config save' before issuing the reboot command.
admin@sonic:~$ sudo config kdump num_dumps 2
admin@sonic:~$ sudo config kdump memory 512M
KDUMP configuration changes may require a reboot to take effect.
Save SONiC configuration using 'config save' before issuing the reboot command.
```

65 XSTP

Table of Contents

[STP show commands](#)

- [show spanning-tree](#)
- [show spanning-tree brief](#)
- [show spanning-tree mst instance](#)
- [show spanning-tree mst brief](#)
- [show spanning-tree mst interface](#)
- [show spanning-tree mst configuration](#)

[STP configuration commands](#)

- [config spanning-tree](#)
- [config spanning-tree forward_delay](#)
- [config spanning-tree hello](#)
- [config spanning-tree max_age](#)
- [config spanning-tree priority](#)
- [config spanning-tree mst max_hops](#)
- [config spanning-tree mst name](#)
- [config spanning-tree mst revision](#)
- [config spanning-tree mst priority](#)
- [config spanning-tree mst vlan add/del](#)
- [config spanning-tree interface](#)
- [config spanning-tree interface bpdu_filter](#)
- [config spanning-tree interface root_guard](#)
- [config spanning-tree interface bpdu_guard](#)
- [config spanning-tree interface edge_port](#)
- [config spanning-tree interface priority](#)
- [config spanning-tree interface cost](#)
- [config spanning-tree interface mst priority](#)
- [config spanning-tree interface mst cost](#)
- [config spanning-tree interface loopback_detection](#)
- [config spanning-tree interface loopback_detection action](#)
- [config spanning-tree transmission_limit\(next phase\)](#)
- [config spanning-tree pathcost method \(next phase\)](#)
- [config spanning-treeinterface link_type\(next phase\)](#)
- [config spanning-tree interface tc_prop_stop \(next phase\)](#)
- [config spanning-tree interface protocol_migration \(nextphase\)](#)

This section describes MSTP feature and commands which are supported in SONiC.

STP show commands

show spanning-tree

This command displays spanning tree information .

Usage

show spanning-tree

Example

<pre>admin@sonic:~\$ show spanning-tree show spanning-tree</pre>
--

Spanning Tree Information

Spanning Tree Mode	: RSTP
Spanning Tree Enabled/Disabled	: Enabled
Instance	: 0
VLANs Configured	: 1-4094
Priority	: 32768
Bridge Hello Time (sec.)	: 2
Bridge Max. Age (sec.)	: 20
Bridge Forward Delay (sec.)	: 15
Root Hello Time (sec.)	: 2
Root Max. Age (sec.)	: 20
Root Forward Delay (sec.)	: 15
Max. Hops	: 20
Remaining Hops	: 20
Designated Root	: 32768.04F8F86AFA91
Current Root Port	: 0
Current Root Cost	: 0
Number of Topology Changes	: 0
Last Topology Change Time (sec.):	1415
Transmission Limit	: 3

Path Cost Method : Long

Ethernet0 Information

Admin Status : Enabled
 Role : Designate
 State : Forwarding
 Admin Path Cost : 0
 Oper Path Cost : 400
 Priority : 128
 Designated Cost : 0
 Designated Port : 128.1
 Designated Root : 32768.04F8F86AFA91
 Designated Bridge : 32768.04F8F86AFA91
 Forward Transitions : 2
 Admin Edge Port : Auto
 Oper Edge Port : Enabled
 Admin Link Type : Auto
 Oper Link Type : Point-to-point
 Loopback Detection Status : Disabled
 Loopback Detection Release Mode : Auto
 Loopback Detection Action : Block
 Spanning-Tree Status : Enabled
 Root Guard Status : Disabled
 BPDU Guard Status : Disabled
 BPDU Guard Auto Recovery : Disabled
 BPDU Guard Auto Recovery Interval : 300
 BPDU Filter Status : Disabled
 TC Propagate Stop : Disabled

show spanning-tree brief

This command displays the brief information.

Usage

```
show spanning-tree brief
```

Example

```
admin@sonic:~$ show spanning-tree brief
```

```
Spanning Tree Mode      : RSTP
```

```
Spanning Tree Enabled/Disabled : Enabled
```

```
Designated Root        : 32768.04F8F86AFA91
```

```
Current Root Port      : 0
```

```
Current Root Cost      : 0
```

Interface	Pri	Designated	Designated Oper	STP	Role	State	Oper
Bridge ID	Port ID	Cost	Status	Edge			

Ethernet0	128	32768.04F8F86AFA91	128.1	400	EN	DESG	FWD	Yes
Ethernet1	128	32768.04F8F86AFA91	128.2	400	EN	DISB	BLK	No
Ethernet2	128	32768.04F8F86AFA91	128.3	400	EN	DISB	BLK	No
Ethernet3	128	32768.04F8F86AFA91	128.4	400	EN	DISB	BLK	No
Ethernet4	128	32768.04F8F86AFA91	128.5	400	EN	DESG	FWD	Yes

```
.....
```

show spanning-tree interface

This command displays the information of specified interface.

Usage

```
show spanning-tree interface <interface_name>
```

Example

```
admin@sonic:~$ show spanning-tree interface Ethernet0
```

```
Ethernet0 Information
```

```
-----
```

Admin Status	: Enabled
Role	: Designate
State	: Forwarding
Admin Path Cost	: 0
Oper Path Cost	: 400
Priority	: 128
Designated Cost	: 0
Designated Port	: 128.1
Designated Root	: 32768.04F8F86AFA91
Designated Bridge	: 32768.04F8F86AFA91
Forward Transitions	: 2
Admin Edge Port	: Auto
Oper Edge Port	: Enabled
Admin Link Type	: Auto
Oper Link Type	: Point-to-point
Loopback Detection Status	: Disabled
Loopback Detection Release Mode	: Auto
Loopback Detection Action	: Block
Spanning-Tree Status	: Enabled
Root Guard Status	: Disabled
BPDU Guard Status	: Disabled
BPDU Guard Auto Recovery	: Disabled
BPDU Guard Auto Recovery Interval	: 300
BPDU Filter Status	: Disabled
TC Propagate Stop	: Disabled

show spanning-tree mst instance

This command displays information of the specified MST instance.

Usage
show spanning-tree mst instance <instance_id>

Note: A port becomes a member of the MSTI instance if it is added to a VLAN that is mapped to that MSTI.

Example

```
admin@sonic:~$ show spanning-tree mst instance 1
```

Spanning Tree Information

```
-----
Spanning Tree Mode      : MSTP
Spanning Tree Enabled/Disabled : Enabled
Instance                : 1
VLANs Configured        : 10
Priority                 : 32768
Bridge Hello Time (sec.) : 2
Bridge Max. Age (sec.)   : 20
Bridge Forward Delay (sec.) : 15
Root Hello Time (sec.)   : 2
Root Max. Age (sec.)     : 20
Root Forward Delay (sec.) : 15
Max. Hops                : 20
Remaining Hops           : 20
Designated Root          : 32768.1.04F8F86AFA91
Current Root Port        : 0
Current Root Cost        : 0
Number of Topology Changes : 0
Last Topology Change Time (sec.): 64
Transmission Limit       : 3
Path Cost Method         : Long
-----
```

Ethernet0 Information

```
-----
Admin Status           : Enabled
Role                   : Designate
State                  : Forwarding
External Admin Path Cost : 0
Internal Admin Path Cost : 0
External Oper Path Cost : 400
Internal Oper Path Cost : 400
Priority                : 128
-----
```

Designated Cost	: 0
Designated Port	: 128.1
Designated Root	: 32768.1.04F8F86AFA91
Designated Bridge	: 32768.1.04F8F86AFA91
Forward Transitions	: 1
Admin Edge Port	: Auto
Oper Edge Port	: Enabled
Admin Link Type	: Auto
Oper Link Type	: Point-to-point
Loopback Detection Status	: Disabled
Loopback Detection Release Mode	: Auto
Loopback Detection Action	: Block
Spanning-Tree Status	: Enabled
Root Guard Status	: Disabled
BPDU Guard Status	: Disabled
BPDU Guard Auto Recovery	: Disabled
BPDU Guard Auto Recovery Interval	: 300
BPDU Filter Status	: Disabled
TC Propagate Stop	: Disabled
.....	

show spanning-tree mst brief

This command displays brief information of the specified MST instance.

Usage

```
show spanning-tree mst brief <instance_id>
```

Example

```
admin@sonic:~$ show spanning-tree mst brief 1
Spanning tree brief for instance 1
Spanning Tree Mode      : MSTP
Spanning Tree Enabled/Disabled : Enabled
Designated Root        : 32768.01.04F8F86AFA91
```

```

Current Root Port      : 0
Current Root Cost      : 0
Interface Pri Designated      Designated Oper  STP  Role State Oper
      Bridge ID      Port ID  Cost  Status      Edge
-----
Ethernet0 128 32768.01.04F8F86AFA91 128.1      400 EN  DESG FWD  Yes

```

show spanning-tree mst interface

This command displays the information of specified interface on a mst instance.

Usage

```
show spanning-tree mst interface <instance_id> <interface_name>
```

Example

```
admin@sonic:~$ show spanning-tree mst interface 1 Ethernet0
```

Ethernet0 Information

```

-----
Admin Status      : Enabled
Role              : Designate
State             : Forwarding
External Admin Path Cost      : 0
Internal Admin Path Cost      : 0
External Oper Path Cost       : 400
Internal Oper Path Cost       : 400
Priority           : 128
Designated Cost      : 0
Designated Port      : 128.1
Designated Root      : 32768.1.04F8F86AFA91
Designated Bridge     : 32768.1.04F8F86AFA91
Forward Transitions    : 1
Admin Edge Port       : Auto
Oper Edge Port        : Enabled
Admin Link Type       : Auto

```

```

Oper Link Type          : Point-to-point
Loopback Detection Status : Disabled
Loopback Detection Release Mode : Auto
Loopback Detection Action : Block
Spanning-Tree Status    : Enabled
Root Guard Status       : Disabled
BPDU Guard Status       : Disabled
BPDU Guard Auto Recovery : Disabled
BPDU Guard Auto Recovery Interval : 300
BPDU Filter Status      : Disabled
TC Propagate Stop       : Disabled
  
```

show spanning-tree mst configuration

This command displays the configuration of the multiple spanning tree

Usage

```
show spanning-tree mst configuration
```

Example

```

admin@sonic:~$ show spanning-tree mst configuration
MSTP Configuration Information
-----
Configuration Name : 04 F8 F8 6A FA 91
Revision Level    : 0
Instance VLANs
-----
 0  1-9,11-4094
 1  10
  
```

STP configuration commands

config spanning-tree

This command enables/disables the spanning tree mode for the device.

Usage

```
config spanning-tree enable {mstp | rstp | stp}
config spanning-tree disable
```

option

- mstp: Multiple Spanning Tree (IEEE 802.1s)
- rstp: Rapid Spanning Tree Protocol (IEEE 802.1w)
- stp : Spanning Tree Protocol (IEEE 802.1D). This option uses RSTP set to STP forced compatibility mode. It uses RSTP for the internal state machine, but sends only 802.1D BPDUs.

Note:

- Only one mode can be enabled at any given time. That is, the configuration should be one of (mstp, rstp, stp) during enabling spanning tree.
- When switching the mode, eg stp to mstp, it will stop stp and then start mstp.
- Please exercise caution when switching between spanning tree modes. It is important to note that hanging modes will halt all spanning-tree instances from the previous mode and initiate a system restart in the new mode. This process may result in a temporary disruption of user traffic.
- When disabling spanning tree, spanning mode will be changed to default rstp.

Example

```
admin@sonic:~$ sudo config spanning-tree enable mstp
```

config spanning-tree forward_delay

This command allows configuring the forward delay time in seconds (default = 15), range 4-30 seconds.

Note:

$2 * (\text{forward_delay} - 1) \geq \text{max_age} \geq 2 * (\text{hello_time} + 1)$.

The timer is used to control the timing of the various states in the spanning tree process.

Usage

```
config spanning-tree forward_delay <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree forward_delay 30
```

config spanning-tree hello

This command allow configuring the hello interval in seconds for transmission of bpdus (default = 2), range 1-10 seconds.

Note:

$$2 * (\text{forward_delay} - 1) \geq \text{max_age} \geq 2 * (\text{hello_time} + 1)$$

The timer is used to control the frequency of sending BPDUs in a network.

Usage

```
config spanning-tree hello <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree hello 10
```

config spanning-tree max_age

This command allows configuring the maximum time to listen for root bridge in seconds (default = 20), range 6-40 seconds.

Note:

$$2 * (\text{forward_delay} - 1) \geq \text{max_age} \geq 2 * (\text{hello_time} + 1)$$

The timer is used to determine the maximum duration during which a bridge can consider a received BPDU as valid.

Usage

```
config spanning-tree max_age <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree max_age 40
```

config spanning-tree priority

This command allows configuring the bridge priority in increments of 4096. The default is 32768 and range is 0-61440.

Note:

The device with the highest priority, indicated by a lower numeric value, becomes the root bridge of the Spanning Tree.

Usage

```
config spanning-tree priority <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree priority 61440
```

config spanning-tree mst max_hops

This command allows configuring the maximum number of hops in the region before a BPDU is discarded. The default is 20 and range is 1-40.

Note:

Each spanning tree instance within a region, including the internal spanning tree (IST) that interconnects these instances, employs a hop count to determine the maximum number of bridges that can forward a BPDU. As the BPDU is propagated, each bridge reduces the hop count by one. Once the hop count reaches zero, the bridge discards the BPDU.

Usage

```
config spanning-tree mst max_hops <value>
```

Example

<pre>admin@sonic:~\$ sudo config spanning-tree mst max_hops 10</pre>
--

config spanning-tree mst name

This command allows configuring the name for the multiple spanning tree region in which this switch is located (default = mac address), max string length is 32.

Note:

The MST region name and revision number are utilized to identify a unique MST region. A bridge, such as this switch, can only be a part of one MST region, and all bridges within the same region must be configured with same MST instances.

Usage

<pre>config spanning-tree mst name <string></pre>

Example

<pre>admin@sonic:~\$ sudo config spanning-tree mst name testlab</pre>

config spanning-tree mst revision

This command allows configuring the revision number for this multiple spanning tree configuration of this switch. The default is 0 and range is 0-65535.

Note:

The MST region name and revision number are utilized to identify a unique MST region. A bridge, such as this switch, can only be a part of one MST region, and all bridges within the same region must be configured with same MST instances.

Usage

```
config spanning-tree mst revision <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree mst revision 1
```

config spanning-tree mst priority

This command allows configuring the priority of a spanning tree instance in increments of 4096. The default is 32768 and range is 0-61440.

Note:

- The device with the highest priority, indicated by a lower numeric value, becomes the root bridge of the Spanning Tree.
- MST priority is used in selecting the root bridge the specified instance. The device with the highest priority, indicated by a lower numeric value becomes the root bridge of the MSTI instance.

Usage

```
config spanning-tree mst priority <id> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree mst priority 1 61440
```

config spanning-tree mst vlan add/del

This command allows configuring VLANs to a spanning tree instance, range 1-4094.

Note: The maximum number of MST instances allowed is 64.

Usage

```
config spanning-tree mst vlan {add|del} <id> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree mst vlan add 1 10
admin@sonic:~$ sudo config spanning-tree mst vlan del 1 10
```

config spanning-tree interface

This command allows enabling or disabling of STP on an interface, by default STP will be enabled on the interface if global STP mode is configured.

Usage

```
config spanning-tree interface {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface enable Ethernet0
```

config spanning-tree interface bpdu_filter

This command allow enabling or disabling of bpdu filter on an interface.

Usage

```
config spanning-tree interface bpdu_filter {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface bpdu_filter enable Ethernet0
```

config spanning-tree interface root_guard

This command allow enabling or disabling of root guard on an interface.

Usage

```
config spanning-tree interface root_guard {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface root_guard enable Ethernet0
```

config spanning-tree interface bpdu_guard

Below command allows enabling or disabling of bpdu guard on an interface.

Note: To reactivate a port that has been shut down due to a BPDU guard trigger, user can use the "config spanning-tree interface bpdu_guard disable <ifname>" command or specify "auto-recovery " value when enabling bpdu_guard.

Usage

```
config spanning-tree interface bpdu_guard {enable|disable} <ifname>
```

By default, BPDU guard will shutdown port, to take an action such as enabling the port after a specified timer has expired, the following command can be used with the auto-recovery option:

Usage

```
config spanning-tree interface bpdu_guard enable <ifname> [--auto-recovery <value>]
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface bpdu_guard enable Ethernet0
```

config spanning-tree interface edge_port

Below command allows enabling, disabling, or automatically determining whether an interface is an edge port.

Usage

```
config spanning-tree interface edge_port {enable|disable|auto} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface portfast enable Ethernet0
```

config spanning-tree interface priority

This command allows to configure the port level priority value in increments of 16 (default = 128), range 0-240.

Usage

```
config spanning-tree interface priority <ifname> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface priority Ethernet0 240
```

config spanning-tree interface cost

This command allows to configure the port level cost value, range 1-200000000 (default value depend port type and speed).

Note: Default port cost on Ethernet and PortChannel port.

Port Type	Speed	Default Port Cost
Ethernet Port	10M (half-duplex)	2000000
	10M (full-duplex)	1000000
	100M (half-duplex)	200000
	100M (full-duplex)	100000
	1G (half-duplex)	20000
	1G (full-duplex)	10000
	10G (half-duplex)	2000
	10G (full-duplex)	1000

	25G (half-duplex)	800
	25G (full-duplex)	400
	40G (half-duplex)	500
	40G (full-duplex)	250
	100G (half-duplex)	200
	100G (full-duplex)	100
PortChannel Port	10M	500000
	100M	50000
	1G	5000
	10G	500
	25G	400
	40G	125
	100G	50

Usage

```
config spanning-tree interface cost <ifname> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface cost Ethernet0 1000
```

config spanning-tree interface mst priority

This command allows to configure the port level priority value on a spanning instance, range 0-240 (default = 128).

Usage

```
config spanning-tree interface mst priority <ifname> <id> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface mst priority Ethernet0 1 240
```

config spanning-tree interface mst cost

This command allows to configure the port level cost value on a spanning instance , range 1-200000000 (default value depend port type and speed).

Note: Default port cost on Ethernet and PortChannel port.

Port Type	Speed	Default Port Cost
Ethernet Port	10M (half-duplex)	2000000
	10M (full-duplex)	1000000
	100M (half-duplex)	200000
	100M (full-duplex)	100000
	1G (half-duplex)	20000
	1G (full-duplex)	10000
	10G (half-duplex)	2000
	10G (full-duplex)	1000
	25G (half-duplex)	800
	25G (full-duplex)	400
	40G (half-duplex)	500
	40G (full-duplex)	250
	100G (half-duplex)	200
	100G (full-duplex)	100
PortChannel Port	10M	500000

	100M	50000
	1G	5000
	10G	500
	25G	400
	40G	125
	100G	50

Usage

```
config spanning-tree interface mst cost <ifname> <id> <value>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface mst cost Ethernet0 1 1000
```

config spanning-tree interface loopback_detection

This command allow enabling or disabling loopback-detection on an interface.

Usage

```
config spanning-tree interface loopback_detection {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface loopback_detection enable Ethernet0
```

config spanning-tree interface loopback_detection action

This command allow configuring the action of loopback_detection on an interface.

Note:

1. If the action is set to "block", the selected interface, which has been in discarding due to loopback detection, will release

detected loopback state under the following conditions:

- Configure to disable loopback-detection on the port, or
- The port receives any other BPDU excluding its own, or
- The port is link down and link up again, or
- The port stops receiving its own BPDU in a forward delay interval for non-edge port or migration time for auto edge port.

2. If the action is set to "shutdown," the selected interface, which has been shutdown due to loopback detection, will be

automatically reactivated under the following conditions:

- Configure to disable loopback-detection on the port, or
- After the shutdown interval time has expired.

Usage

```
config spanning-tree interface loopback_detection action {block|shutdown} <ifname> [--shutdown-interval <value>]
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface loopback_detection action block Ethernet0
admin@sonic:~$ sudo config spanning-tree interface loopback_detection action shutdown Ethernet0 --shutdown-interval 90
```

config spanning-tree transmission_limit(next phase)

This command allows configuring the minimum interval between the transmission of consecutive RSTP/MSTP BPDUs. The default is 3 and range is 1-10.

Usage

```
config spanning-tree transmission_limit <count>
```

Example

```
admin@sonic:~$ sudo config transmission-limit 4
```

config spanning-tree pathcost method (next phase)

This command allows configuring the path cost method used for Rapid Spanning Tree and Multiple Spanning Tree

Usage

```
config spanning-tree pathcost method {long | short}
```

Example

```
admin@sonic:~$ sudo config spanning-tree pathcost method long
```

config spanning-tree interface link_type (next phase)

Below command allows configuring the link type for Rapid Spanning Tree and Multiple Spanning Tree

Usage

```
config spanning-tree interface link-type {auto|point-to-point|shared} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface link-type auto Ethernet0
```

config spanning-tree interface tc_prop_stop (next phase)

This command allows to stop the propagation of topology change notifications (TCN)

Usage

```
config spanning-tree interface tc-prop-stop {enable|disable} <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface tc-prop-stop enable Ethernet0
```

config spanning-tree interface protocol_migration (nextphase)

This command allows to re-check the appropriate BPDU format to send on the selected interface

Usage

```
config spanning-tree interface protocol_migration <ifname>
```

Example

```
admin@sonic:~$ sudo config spanning-tree interface protocol_migration Ethernet0
```

66 Hardware-Reset

Hardware Reset Commands

hardware-reset

This command is used to reset the devices through the CLI without performing a power cycle. The device gets reset immediately after the command is executed. This command requires root privilege.

Usage
hardware-reset [options]

Parameters

-h,-? : get this help

Example
admin@sonic:~\$ sudo hardware-reset

67 Object Track

Table of Contents

[Object Track Terminology](#)

[Tracked Object](#)

[Downlink Interfaces](#)

[Object Track Configuration Commands](#)

[config obj-track add](#)

[config obj-track del](#)

[config obj-track track-obj-type interface add](#)

[config obj-track track-obj-type interface del](#)
[config obj-track track-obj-type bgp-neighbor ip add](#)
[config obj-track track-obj-type bgp-neighbor ip del](#)
[config obj-track track-obj-type bgp-neighbor ipv6add](#)
[config obj-track track-obj-type bgp-neighbor ipv6 del](#)
[config obj-track track-obj-type bgp-neighbor interface add](#)
[config obj-track track-obj-type bgp-neighbor interface del](#)
[config obj-track downlink interface add](#)
[config obj-track downlink interface del](#)
[config obj-track admin](#)
[config obj-track guard-time](#)

[Object Track Show Commands](#)

[show obj-track](#)

[Object Track Guidelines](#)

[General Use Case](#)

[Port Track Use Case](#)

[Port Track Use Example](#)

[BGP Neighbor Track Use Case](#)

[Port Track and BGP Neighbor Track Use Case](#)

[Advanced Use Case](#)

[Port-Channel](#)

[Caveat](#)

Object Track Terminology

Tracked Object

- The object to be tracked in the object track session. It determines the tracked object status of a object traced session.
- If the tracked object meets the specific condition, the downlink interfaces will be shut down. Take the case when trackedobjects are ports or port channels as an example, the downlink interfaces are shut down when the link operation status of the ports or port channels in the tracked object list are all down.
- The first type of the tracked object can be physical ports or port channels such as Ethernet0,PortChannel0001.

- The second type of the tracked object can be BGP neighbors. If all BGP neighbors configured by the command are down, the downlink interfaces are shutdown.
- When both BGP neighbor tracked objects and physical ports/port channels tracked objects exists in the same session, the rule to determine the tracked object status is slightly different from the case that only has one type of tracked objects. The tracked object status is evaluated as up only when at least one BGP neighbor tracked object and one physical port/port channel are up at the same time.

Downlink Interfaces

- The downlink interfaces must be shut down if all of the tracked objects are down.
- Down link Interfaces must be physical ports or port channels, such as Ethernet0,PortChannel0001.

Object Track Configuration Commands

config obj-track add

This command is used to create an object track session by the session_name.

- Can not create exist obj-track session.
- Add session_name check. Only allow a-z, A-Z, 0-9 and hyphen "-" for session_name. And hyphen can't be the first or the last one.
- The length of session_name must be in the range from 1 to 32 characters.
- User can create 30 sessions at most.

After creation:

- Tracked objects: None
- Downlink Ports: None
- Admin status: Disabled
- GuardTime: 180 seconds

Usage

```
config obj-track add <session-name>
```

Parameter:

<session-name>: The name of obj-track session.

Example

```
admin@sonic:~$ config obj-track add Session1
```

config obj-track del

This command is used to destroy an obj-track session by the session name.

Can not destroy non-exist obj-track session.

Usage

```
config obj-track del <session-name>
```

Parameter:

<session-name>: The name of obj-track session.

Example

```
admin@sonic:~$ config obj-track del Session1
```

config obj-track track-obj-type interface add

This command is used to add interfaces to tracked objects in the specified session.

- Can not add the interface that has been added to downlink in the specified session.
- Can not add tracked objects to a non-exist session.
- If all of the tracked interfaces configured by this command are down, the configured downlinks are shut down.

Usage

```
config obj-track track-obj-type interface add <session-name> <interface_name>
```

Parameter:

<session-name>: The name of obj-track session.

<interface_name>: The name of physical interface or PortChannel, e.g. "Ethernet0" or "PortChannel0001".

Example

```
admin@sonic:~$ config obj-track track-obj-type interface add Session1 Ethernet0
admin@sonic:~$ config obj-track track-obj-type interface add Session1 PortChannel0001
```

config obj-track track-obj-type interface del

This command is used to remove interfaces from the tracked objects in the specified obj-track session.

- Can not remove the interfaces that are not in the tracked objects in the specified session.
- Can not remove tracked objects from a non-exist session.

Usage

```
config obj-track track-obj-type interface del <session-name> <interface_name>
```

Parameter:

<session-name>: The name of obj-track session.

<interface_name>: The name of a physical interface or a port channel, e.g. "Ethernet0" or "PortChannel0001".

Example

```
admin@sonic:~$ config obj-track track-obj-type interface del Session1 Ethernet0
admin@sonic:~$ config obj-track track-obj-type interface del Session1 PortChannel0001
```

config obj-track track-obj-type bgp-neighbor ip add

This command is used to add BGP neighbors to tracked objects in the specified session.

- Can not add tracked objects to a non-exist session.
- If all of the tracked BGP neighbors configured by this command are down, the configured downlinks are shut down.

Usage

```
config obj-track track-obj-type bgp-neighbor ip add <session-name> <ip_addr>
```

Parameter:

<session-name>: The name of obj-track session.

<ip_addr>: The IPv4 address of the specified BGP neighbor.

Example

```
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor ip add Session1 10.11.12.13
```

config obj-track track-obj-type bgp-neighbor ip del

This command is used to remove BGP neighbors from the tracked objects in the specified obj-track session.

- Can not remove the BGP neighbors that are not in the tracked objects in the specified session.
- Can not remove tracked objects from a non-exist session.

Usage

```
config obj-track track-obj-type bgp-neighbor ip del <session-name> <ip_addr>
```

Parameter:

<session-name>: The name of obj-track session.

<ip_addr>: The IPv4 address of the specified BGP neighbor.

Example

```
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor ip del Session1 10.11.12.13
```

config obj-track track-obj-type bgp-neighbor ipv6add

This command is used to add BGP neighbors to tracked objects in the specified session.

- Can not add tracked objects to a non-exist session.
- If all of the tracked BGP neighbors configured by this command are down, the configured downlinks are shut down.

Usage

```
config obj-track track-obj-type bgp-neighbor ipv6 add <session-name> <ipv6_addr>
```

Parameter:

<session-name>: The name of obj-track session.

<ipv6_addr>: The IPv6 address of the specified BGP neighbor.

Example

```
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor ipv6 add Session1 fc00:1::32
```

config obj-track track-obj-type bgp-neighbor ipv6 del

This command is used to remove BGP neighbors from the tracked objects in the specified obj-track session.

- Can not remove the BGP neighbors that are not in the tracked objects in the specified session.
- Can not remove tracked objects from a non-exist session.

Usage

```
config obj-track track-obj-type bgp-neighbor ipv6 del <session-name> <ipv6_addr>
```

Parameter:

<session-name>: The name of obj-track session.

<ipv6_addr>: The IPv6 address of the specified BGP neighbor.

Example

```
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor ipv6 del Session1 fc00:1::32
```

config obj-track track-obj-type bgp-neighbor interface add

This command is used to add BGP-unnumbered neighbors to tracked objects in the specified session.

- Can not add the interface of the BGP-unnumbered neighbor that has been added to downlink in the specified session.
- Can not add tracked objects to a non-exist session.
- If all of the tracked BGP neighbors configured by this command are down, the configured downlinks are shut down.

Usage

```
config obj-track track-obj-type bgp-neighbor interface add <session-name> <interface_name>
```

Parameter:

<session-name>: The name of obj-track session.

<interface_name>: The name of physical interface or PortChannel, e.g. "Ethernet0" or

"PortChannel0001", which is associated with the BGP-unnumbered neighbor.

Example

```
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor interface add Session1 Ethernet1
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor interface add Session1 PortChannel0002
```

config obj-track track-obj-type bgp-neighbor interface del

This command is used to remove BGP-unnumbered neighbors from the tracked objects in the specified obj-track session.

- Can not remove the BGP neighbors that are not in the tracked objects in the specified session.

- Can not remove BGP neighbors from a non-exist session.

Usage

```
config obj-track track-obj-type bgp-neighbor interface del <session-name> <interface_name>
```

Parameter:

<session-name>: The name of obj-track session.

<interface_name>: The name of physical interface or PortChannel, e.g. "Ethernet0" or

"PortChannel0001", which is associated with the BGP-unnumbered neighbor.

Example

```
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor interface del Session1 Ethernet1
admin@sonic:~$ config obj-track track-obj-type bgp-neighbor interface del Session1 PortChannel0002
```

config obj-track downlink interface add

This command is used to add interfaces to downlink to the specified obj-track session.

- Can not add the interface that has been added to the object tracked list in the specified session. Note that it includes the interface of the tracked object which is associated with BGP-unnumbered neighbors
- Can not add downlink interfaces to a non-exist session.
- If the tracked object status is evaluated as down, the downlink interfaces configured by the command are shut down.

Usage

```
config obj-track downlink interface add <session-name> <interface_name>
```

Parameter:

<session-name>: The name of obj-track session.

<interface_name>: The name of physical interface or PortChannel, e.g. "Ethernet0" or "PortChannel0001".

Example

```
admin@sonic:~$ config obj-track downlink interface add Session1 Ethernet1
admin@sonic:~$ config obj-track downlink interface add Session1 PortChannel0002
```

config obj-track downlink interface del

This command is used to remove the interfaces from the downlink interfaces in the specified obj-track session.

- Can not remove the interfaces that have not been added to the downlink interfaces in the specified session.
- Can not remove down links from a non-exist session.

Usage

```
config obj-track downlink interface del <session-name> <interface_name>
```

Parameter:

<session-name>: The name of obj-track session.

<interface_name>: The name of a physical interface or a port channel, e.g. "Ethernet0" or "PortChannel0001".

Example

```
admin@sonic:~$ config obj-track downlink interface del Session1 Ethernet1
admin@sonic:~$ config obj-track downlink interface del Session1 PortChannel0002
```

config obj-track admin

This command is used to enable/disable a obj-track session by the session_name.

- Can not set on non-exist obj-track session.

Usage

```
config obj-track admin <session-name> <admin-status>
```

Parameter:

<session-name>: The name of a obj-track session.

<admin-status>: The valid settings are enabled and disabled.

Example

```
admin@sonic:~$ config obj-track admin Session1 enabled
admin@sonic:~$ config obj-track admin Session1 disabled
```

config obj-track guard-time

This command is used to configure the recover guard time by session_name.

- Can not set on non-exist obj-track session.
- The guard time should be in the range between 0 ~ 300 seconds.
- Guard time only takes effect when physical ports/port channels tracked objects exist in the same session.
In other words, guard time will not take effect when only BGP neighbor tracked objects exist in the same session.

Usage

```
config obj-track guard-time <session-name> <guard_time>
```

Parameter:

<session-name>: The name of obj-track session

<guard-time>: The guard time in seconds(0~300 seconds, 60 seconds by default)

Example

```
admin@sonic:~$ config obj-track guard-time Session1 60
```

Object Track Show Commands

show obj-track

This command is used to show the obj-track session information.

Usage

```
show obj-track <session-name>
```

Parameter:

<session-name>: The name of obj-track session

Example

```
admin@sonic:~$ show obj-track
Obj-Track Session Information:
Name: Session1
Admin Status: enabled
Track-obj-type:
Interfaces: Ethernet0(up), PortChannel0001(down)
```

```
BGP nbrs: 10.11.12.13 (up), fc00:1::32(up)
BGP-unnumbered nbrs: Ethernet2(up), PortChannel0003(down)
Downlink:
Interfaces: Ethernet1(up), PortChannel0002(up)
GuardTime: 180 seconds
Operation Status:
Tracked Status: up
Oper Status: up
Obj-Track Session Information:
Name: Session2
Admin Status: enabled
Track-obj-type:
Interfaces: Ethernet2(down), PortChannel0003(down)
BGP nbrs: 10.11.12.13 (up), fc00:1::32(up)
BGP-unnumbered nbrs: Ethernet3(up), PortChannel0004(up)
Downlink:
Interfaces: Ethernet1(down), PortChannel0002(down)
GuardTime: 180 seconds
Operation Status:
Tracked Status: down
Oper Status: shutdown
```

Object Track Guidelines

Object Track uses the information from the tracked objects to determine the link status of the downlinks. If the condition from the tracked objects to shut down is matched, all the downlink interfaces are shut down. Otherwise, all the downlink interfaces are restored after the guard time expires.

General Use Case

1. The user must create an object track session first.
2. After the session is created, the user must add tracked objects and downlinks to that session.
3. Note that users must not add downlinks to tracked objects to prevent from recursive dependencies.
4. Then enable the object track session to monitor the tracked objects.

5. When the tracked objects meet the expected condition, all the downlinks are shut down. Otherwise, all the downlinks are restored after the guard time.

Port Track Use Case

1. The user must create an object track session that add port or port channels as tracked objects first
2. After the session is created, the user must add ports or port channels to the tracked object list and downlink interfaces to that session.
3. Note that users must not add downlink interfaces to the tracked object list to prevent from recursive dependencies.
4. Then enable the port track session to monitor the tracked interfaces.
5. When the interfaces in the object tracked list are all down, all the downlink interfaces are shut down. Otherwise, all the downlink interfaces are restored after the guard time.

Port Track Use Example

Create an object track session named as "PortTrack".

Example

```
admin@sonic:~$ config obj-track add PortTrack
```

Add tracked interfaces and downlinks.

Example

```
admin@sonic:~$ config obj-track track-obj-type interface add PortTrack Ethernet0
admin@sonic:~$ config obj-track track-obj-type interface add PortTrack PortChannel0001
admin@sonic:~$ config obj-track downlink interface add PortTrack Ethernet1
admin@sonic:~$ config obj-track downlink interface add PortTrack PortChannel0002
```

Enable the object track session "PortTrack".

Example

```
admin@sonic:~$ config obj-track admin PortTrack enabled
```

When Ethernet0 and PortChannel0001 are all down, the interfaces named as Ethernet1 and PortChannel0002 will be shut down.

When Ethernet0 or PortChannel0001 is up, the downlinks, Ethernet1 and PortChannel0002 will be restored after the guard time.

BGP Neighbor Track Use Case

1. The user must create an object track session that add BGP neighbors as tracked objects first.
2. After the session is created, the user must add BGP neighbors to the tracked object list and downlink interfaces to that session.
3. Note that users must not add downlink interfaces to the tracked object list to prevent from recursive dependencies.
4. Then enable the session to monitor the tracked BGP neighbors.
5. When the BGP neighbors in the object tracked list are all down, all the downlink interfaces are shut down. Otherwise, all the downlink interfaces are immediately restored. Note that the guard time configuration does not take effect when only BGP neighbor tracked objects exist.

Port Track and BGP Neighbor Track Use Case

1. The user must create an object track session first.
2. After the session is created, the user must add BGP neighbors, ports, or port channels to the tracked object list and downlink interfaces to that session.
3. Note that users must not add downlink interfaces to the tracked object list to prevent from recursive dependencies.
4. Then enable the session to monitor the tracked BGP neighbors.
5. When all the BGP neighbors in the object tracked list are down, or when all the interfaces in the object tracked list are down, all the downlink interfaces are shut down.
6. When at least one BGP neighbor in the tracked list is up and at least one interface in the tracked list is up, all the downlink interfaces are restored after the guard time.

Advanced Use Case

There are 2 group of ports. Port 1 ~ Port 2 are in the group 1. PortChannel1 ~ PortChannel2 are in the group 2.

The downlinks are Port3, PortChannel3.

Users want to shut down downlinks if group 1 or group 2 are down.

1. Create 2 object track sessions, session_1 and session_2.
2. Add group 1 ports to tracked objects to session_1.
3. Add downlinks to session_1.
4. Add group 2 ports to tracked objects to session_2.
5. Add downlinks to session_2.
6. Enable session_1 and session_2.

Users want to shut down downlinks if group 1 and group 2 are down.

Create 1 object track session, session_1.

1. Add group 1 ports to tracked objects session_1.
2. Add group 2 ports to tracked objects session_1.
3. Add downlinks to session_1.
4. Enable session_1.

Port-Channel

If the downlink port is a port-channel, there is something different on the way to shutdown a port-channel when it is shut down by object track and by admin-down command.

- shutdown port-channel by admin-down command(the command is executed by a user):
 - Only set admin-down to port-channel(shutdown at layer 3).
 - The tx/rx of member ports shall be disabled.
 - The physical link status may be up or down.
- shutdown port-channel by obj-track:
 - Set admin-down to port-channel.
 - The admin status of member ports shall be set to disabled.
 - The physical link status shall be down.

Caveat

Given a topology shown below.

Sonic Switch -----(Ethernet0)----- (BGP neighbor).

Configuration:

- The user tracks only one BGP unnumbered neighbor which is established via Ethernet0 by an object-track session. · The user adds Ethernet0 as the downlink interface in the same session. CLI will not forbid this operation.
- When the session is activated when BGP neighbor status is up, the tracked object status is evaluated as up. However, as long as the tracked BGP neighbor status is changed to down, the downlink interface Ethernet0 will be shut down. Ethernet0 will never be up so the BGP neighbor will never be present. Ethernet0 can only be up again until the session is disabled.

This is not a reasonable use case.

68 Port Protocol Down

Table of Contents

[Port Protocol Down Show Commands](#)

[show protocol-down brief](#)

[show protocol-down status](#)

[Interface Show Command](#)

[show interfaces status](#)

[Port Protocol Down Guidelines](#)

[Port Protocol Down Use Example](#)

[Setup an Object Track Session](#)

[Given that the Port Link Operation Status of Ethernet4 is Down](#)

[Given that the Port Link Operation Status of Ethernet4 is Changed from Down to Up](#)

Port Protocol Down Show Commands

show protocol-down brief

This command is used to show protocol down brief information for each port.

Usage

```
show protocol-down brief [port]
```

Parameter:

port is the name of the interface like: Ethernet0, Ethernet1

The brief status of all ports will be displayed when 'port' is not specified.

Example output of "show protocol-down brief"

```
admin@sonic:~$ show protocol-down brief
Interface  ProtoDown  Admin  Effective Admin
-----
Ethernet0   False     Up      Up
Ethernet4   True      Down    Down
Ethernet8   True      Up      Down
...
```

Only the brief status of the specified port will be displayed when 'port' is specified.

Example output of "show protocol-down brief Ethernet0"

```
admin@sonic:~$ show protocol-down brief Ethernet0
Interface  ProtoDown  Admin  Effective Admin
-----
```

Ethernet0	False	Up	Up
-----------	-------	----	----

show protocol-down status

This command is used to show protocol down status.

Usage

```
show protocol-down status [port]
```

Parameter:

port is the name of the interface like: Ethernet0, Ethernet1

The protocol down status of all ports will be displayed when 'port' is not specified.

Example output of "show protocol-down status"

```
admin@sonic:~$ show protocol-down status
```

Interface	EVPN	OBJTRK	PMS	STP	ProtoDown	Admin	Effective Admin
Ethernet0	False	False	False	False	False	Up	Up
Ethernet4	True	True	False	False	True	Down	Down
Ethernet8	True	False	False	False	True	Up	Down
...							
PortChannel101	False	False	False	True	True	Down	Down

Only the protocol down status of the specified port will be displayed when 'port' is specified.

Example output of "show protocol-down status Ethernet0"

```
admin@sonic:~$ show protocol-down status Ethernet0
```

Interface	EVPN	OBJTRK	PMS	STP	ProtoDown	Admin	Effective Admin
Ethernet0	False	False	False	False	False	Up	Up

Interface Show Command

show interfaces status

This command is used to show interface status.

Usage

```
show interfaces status [port]
```

Parameter:

port is the name of the interface like: Ethernet0, Ethernet1

The interface status of all ports will be displayed when 'port' is not specified. Note that the fields "Porto Down" and "Eff Admin" are new added fields by this new design.

Example output of "show interfaces status"

```
admin@sonic:~$ show interfaces status

Interface      Lanes   Speed  MTU  Oper FEC      Alias      Vlan  Oper
Admin  Proto Down  Eff Admin  Type  Asym PFC
-----
Ethernet0      49,50,51,52  100G  9100   rs  Eth1(Port1)  trunk
down  up    True    down  N/A    off
Ethernet4      53,54,55,56  100G  9100   rs  Eth2(Port2)  trunk
up    up    False   up    N/A    off
...
Ethernet100    129,130,131,132  100G  9100   rs  Eth29(Port29)  PortChannel101
up    up    False   up    N/A    off
```

Only the interface status of the specified port will be displayed when 'port' is specified.

Example output of "show interfaces status Ethernet0"

```
admin@sonic:~$ show interfaces status Ethernet0
```

Interface	Lanes	Speed	MTU	Oper	FEC	Alias	Vlan	Oper	Admin	Proto
Down	Eff Admin	Type	Asym PFC							
Ethernet0	49,50,51,52	100G	9100	N/A	Eth1(Port1)	trunk	down	up		
True	down	N/A	off							

Port Protocol Down Guidelines

Protocol down is a state for each port. For the feature that has the functionality to shutdown a port under some certain conditions, the feature needs to set the protocol down state of its own feature. So each feature is responsible to maintain the protocol down state of its own feature on each port. The effective admin state of a port will be determined by the state of the protocol down and the admin state. In usual, the effective admin state is the same as admin state. The port protocol commands can be used to find out the cause when the effective admin state is down.

Port Protocol Down Use Example

The effective admin state of a port might be changed by protocol down reasons managed by process/program. The following example demonstrates the procedures to configure object track settings and the effect on the protocol down status.

Setup an Object Track Session

Example commands to setup object track

```
admin@sonic:~$ config obj-track add PortTrack (1)
```

```
admin@sonic:~$ config obj-track track-obj-type interface add PortTrack Ethernet0 (2)
admin@sonic:~$ config obj-track downlink interface add PortTrack Ethernet4 (3)
admin@sonic:~$ config obj-track admin PortTrack enabled (4)
```

The description for above commands:

- (1) Create a object tracked session named "PortTrack".
- (2) Add a tracked object "Ethernet0", which is a port interface, into the session "PortTrack".
- (3) Add a downlink interface "Ethernet4" into the session "PortTrack".
- (4) Enable the object tracked session "PortTrack".

With the object-tracked settings shown above, the protocol down reason of the object track on Ethernet0 will be "True" when the port link operational status of Ethernet4 is down. The protocol down reason of the object track on Ethernet0 will be "False" when the portlink operational status of Ethernet4 is up.

Given that the Port Link Operation Status of Ethernet4 is Down

Here is the excerpted output of "show interface status". Note that the "Proto Down" of Ethernet0 is "True". The "Eff Admin"(Effective Admin) state is down, which is a resolved result according to "Admin" and Proto Down".

Example output of "show interfaces status"

```
admin@sonic:~$ show interfaces status
```

Interface	Lanes	Speed	MTU	Oper	FEC	Alias	Vlan	Oper	Admin	Proto
Ethernet0	49,50,51,52	100G	9100	N/A	Eth1(Port1)	trunk	down	up	True	down
Ethernet4	53,54,55,56	100G	9100	N/A	Eth2(Port2)	trunk	up	up	False	up

...

Here is the output of "show protocol-down brief Ethernet0".

Example output of "show protocol-down brief Ethernet0"

```
admin@sonic:~$ show protocol-down brief Ethernet0
```

Interface	ProtoDown	Admin	Effective Admin
Ethernet0	True	Up	Down

Here is the output of "show protocol-down status Ethernet0". Note that the "OBJTRK" field is true, which means the protocol down is set as True due to "OBJTRK" is true.

Example output of "show protocol-down status Ethernet0"

```
admin@sonic:~$ show protocol-down status Ethernet0
```

Interface	EVPN	OBJTRK	PMS	LAG	ProtoDown	Admin	Effective Admin
Ethernet0	False	True	False	False	True	Up	Down

Given that the Port Link Operation Status of Ethernet4 is Changed from Down to Up

Here is the excerpted output of "show interface status". Note that the "Proto Down" of Ethernet0 is changed to "False". The "EffAdmin"(Effective Admin) state is changed to up. The port link operation status of Ethernet0 is also changed to up.

Example output of "show interfaces status"

```
admin@sonic:~$ show interfaces status
```

Interface	Lanes	Speed	MTU	Oper	FEC	Alias	Vlan	Oper	Admin	Proto
Down	Eff Admin	Type	Asym	PFC						
Ethernet0	49,50,51,52	100G	9100	N/A	Eth1(Port1)	trunk	up	up		
False	up	N/A	off							
Ethernet4	53,54,55,56	100G	9100	N/A	Eth2(Port2)	trunk	up	up		
False	up	N/A	off							
...										

Here is the output of "show protocol-down brief Ethernet0".

Example output of "show protocol-down brief Ethernet0"

```
admin@sonic:~$ show protocol-down brief Ethernet0
```

Interface	ProtoDown	Admin	Effective Admin
Ethernet0	False	Up	Up

Here is the output of "show protocol-down status Ethernet0". Note that the "OBJTRK" field is changed to false, which means the protocol down is set as false because EVPN, OBJTRK and PMS's protocol down statuses are false.

Example output of showprotocol-downstatusEthernet0

```
admin@sonic:~$ show protocol-down status Ethernet0
```

Interface	EVPN	OBJTRK	PMS	LAG	ProtoDown	Admin	Effective Admin
Ethernet0	False	False	False	False	True	Up	Up

69 DHCP Snooping

Table of Contents

[DHCP Snooping show commands](#)

[show dhcp-snoop](#)

[show dhcp-snoop vlan](#)

[show dhcp-snoop trust](#)

[show dhcp-snoop bind](#)

[DHCP Snooping config commands](#)

[config dhcp snoop feature enable/disable](#)

[config dhcp snoop ipv4 enable/disable](#)

[config dhcp snoop trust vlan enable/disable](#)

[config dhcp snoop trust port add/del](#)

These commands are used to add or remove DHCP Snooping configuration.

DHCP Snooping show commands

show dhcp-snoop

This command is used to display dhcp snooping configuration

Usage

```
show dhcp-snoop
```

Example

```
admin@sonic:~# show dhcp-snoop
DHCP Snooping Information
IPv4   IPv6
-----
disable N/A
```

show dhcp-snoop vlan

This command is used to display vlan for dhcp snooping

Usage

```
show dhcp-snoop vlan
```

Example

```
admin@sonic:~# show dhcp-snoop vlan
```

Vlan Interface Name	Status
---------------------	--------

Vlan100	enable
---------	--------

show dhcp-snoop trust

This command is used to display trusted port for dhcp snooping

Usage

```
show dhcp-snoop trust
```

Example

```
admin@sonic:~# show dhcp-snoop trust
```

Interface Name	Status
----------------	--------

Ethernet0	enable
-----------	--------

show dhcp-snoop bind

This command is used to display binding table for dhcp snooping

Usage

```
show dhcp-snoop bind
```

Example

```
admin@sonic:~# show dhcp-snoop bind
```

Mac address	IP address	Interface Name	Vlan	Interface Name	Lease Time	Remain Time
00:11:22:33:44:55	10.10.100.1	Ethernet0	Vlan100		86400	86010

DHCP Snooping config commands

config dhcp snoop feature enable/disable

This command is used to enable/disable dhcp snooping feature

Usage

```
config feature state dhcp_snoop <enabled|disabled>
```

Example

```
admin@sonic:~# sudo config feature state dhcp_snoop enabled
```

```
admin@sonic:~# sudo config feature state dhcp_snoop disabled
```

config dhcp snoop ipv4 enable/disable

This command is used to enable/disable ipv4 for DHCP snooping

Usage

```
config dhcp-snoop ipv4 <enabled|disabled>
```

Example

```
admin@sonic:~# sudo config dhcp-snoop ipv4 enable
admin@sonic:~# sudo config dhcp-snoop ipv4 disable
```

config dhcp snoop trust vlan enable/disable

This command is used to enable/disable vlan for DHCP snooping

Usage

```
config dhcp-snoop vlan <enable|disable> <vlan-id>
```

Parameters:

vlan-id: Specifies the v lan id to enable/disable dhcp snooping

Example

```
admin@sonic:~# sudo config dhcp-snoop vlan enable 100
admin@sonic:~# sudo config dhcp-snoop vlan disable 100
```

config dhcp snoop trust port add/del

This command is used to add/del trust port for DHCP snooping

Usage
<code>config dhcp-snoop trusted <add del> <port-name></code>

Parameters:

port-name: Specifies Ethernet or PortChannel to add/del as trust port for dhcp snooping

Example
<pre>admin@sonic:~# sudo config dhcp-snoop trusted add Ethernet0 admin@sonic:~# sudo config dhcp-snoop trusted del Ethernet0 admin@sonic:~# sudo config dhcp-snoop trusted add PortChannel1 admin@sonic:~# sudo config dhcp-snoop trusted del PortChannel1</pre>

70 IGMP Snooping

Table of Contents

[IGMP Snooping Configuration Commands](#)

- [config igmp snooping](#)
- [config igmp snooping mrouter-port-expire-time](#)
- [config igmp snooping mrouter-port-forward-mode](#)
- [config igmp snooping querier](#)
- [config igmp snooping version](#)
- [config igmp snooping vlan](#)
- [config igmp snooping vlan immediate-leave](#)
- [config igmp snooping vlan last-member-query-count](#)
- [config igmp snooping vlan last-member-query-interval](#)
- [config igmp snooping vlan mrouter-port](#)
- [config igmp snooping vlan query-interval](#)
- [config igmp snooping vlan query-response-interval](#)
- [config igmp snooping vlan static-group](#)
- [config igmp snooping vlan version](#)
- [sonic-clear igmp snooping dynamic groups](#)
- [sonic-clear igmp snooping statistics](#)

[IGMP Snooping Show Commands](#)

- [show igmp snooping](#)
- [show igmp snooping groups](#)
- [show igmp snooping mrouter](#)
- [show igmp snooping querier status](#)
- [show igmp snooping statistics](#)
- [show igmp snooping vlan](#)

IGMP Snooping Configuration Commands

This sub-section of commands is used to configure IGMP Snooping.

config igmp snooping

This command is used to enable/disable IGMP Snooping.

Usage

```
config igmp snooping (enable|disable)
```

Example

```
admin@sonic:~$ sudo config igmp snooping enable
admin@sonic:~$ sudo config igmp snooping disable
```

config igmp snooping mrouter-port-expire-time

This command is used to set the mrouter port expire time.

Usage

```
config igmp snooping mrouter-port-expire-time <1-65535>
```

Example

```
admin@sonic:~$ sudo config igmp snooping mrouter-port-expire-time 300
```

The expire time is in seconds. The default value is 300 seconds.

config igmp snooping mrouter-port-forward-mode

This command is used to set the multicast forward mode for the mrouter port. If the mode is set to 'dynamic', the IP multicast stream won't be forwarded to mrouter ports unless this mrouter port has group joined. If the mode is set to 'forward', all the IP multicast stream will be forwarded to mrouter ports. By default, the mode is set to 'forward'.

Usage

```
config igmp snooping mrouter-port-forward-mode (dynamic|forward)
```

Example

```
admin@sonic:~$ sudo config igmp snooping mrouter-port-forward-mode dynamic
```

The default value is 'forward'.

config igmp snooping querier

This command is used to enable or disable the Querier function.

Usage

```
config igmp snooping querier (enabled|disabled)
```

Example

```
admin@sonic:~$ sudo config igmp snooping querier enabled  
admin@sonic:~$ sudo config igmp snooping querier disabled
```

config igmp snooping version

This command is used to set the IGMP version.

Usage

```
config igmp snooping version <1-3>
```

Example

```
admin@sonic:~$ sudo config igmp snooping version 2
```

The default value is 2.

config igmp snooping vlan

This command is used to enable/disable IGMP Snooping on a VLAN.

Usage

```
config igmp snooping vlan (enable|disable) <vid>
```

Example

```
admin@sonic:~$ sudo config igmp snooping vlan enable 100
admin@sonic:~$ sudo config igmp snooping vlan disable 100
```

The default value is 'enable'.

config igmp snooping vlan immediate-leave

This command is used to enable or disable the Immediate Leave function on a VLAN.

Usage

```
config igmp snooping vlan immediate-leave (enabled|disabled) <vid>
```

Example

```
admin@sonic:~$ sudo config igmp snooping vlan immediate-leave enabled 100
admin@sonic:~$ sudo config igmp snooping vlan immediate-leave disabled 100
```

The default value is 'disable'.

config igmp snooping vlan last-member-query-count

This command is used to set the Last Member Query Count for a VLAN.

Usage

```
config igmp snooping vlan last-member-query-count <vid> <count>
```

Example

```
admin@sonic:~$ sudo config igmp snooping vlan last-member-query-count 100 2
```

The default value is 2.

config igmp snooping vlan last-member-query-interval

This command is used to set the Last Member Query Interval for a VLAN.

Usage

```
config igmp snooping vlan last-member-query-interval <vid> <interval>
```

The interval is in seconds. The default value is 1 second.

Example

```
admin@sonic:~$ sudo config igmp snooping vlan last-member-query-interval 100 1
```

The default value is 1 second.

config igmp snooping vlan mrouter-port

This command is used to set the IGMP Snooping Multicast Router Port for a VLAN.

Usage

```
config igmp snooping vlan mrouter-port (add|remove) <vid> <port>
```

Example

```
admin@sonic:~$ sudo config igmp snooping vlan mrouter-port add 100 Ethernet0  
admin@sonic:~$ sudo config igmp snooping vlan mrouter-port remove 100 Ethernet0
```

config igmp snooping vlan query-interval

This command is used to set the IGMP Query Interval for a VLAN. The Query Interval should be greater than the Query Response Interval.

Usage

```
config igmp snooping vlan query-interval <vid> <interval>
```

Example

```
admin@sonic:~$ sudo config igmp snooping vlan query-interval 100 10
```

Please note loaded setting will be lost after system reboot. To preserve setting, run `config save`.

config igmp snooping vlan query-response-interval

This command is used to set the IGMP Query Response Interval for a VLAN.

Usage

```
config igmp snooping vlan query-response-interval <vid> <interval>
```

The interval is in seconds. The default value is 10 seconds.

Example

```
admin@sonic:~$ sudo config igmp snooping vlan query-response-interval 100 10
```

config igmp snooping vlan static-group

This command is used to add or remove a static group for a VLAN.

Usage

```
config igmp snooping vlan static-group (add|remove) <vid> <ip_addr> <port>
```

Example

```
admin@sonic:~$ sudo config igmp snooping vlan static-group add 100 224.1.1.1 Ethernet0
```

```
admin@sonic:~$ sudo config igmp snooping vlan static-group remove 100 224.1.1.1 Ethernet0
```

config igmp snooping vlan version

This command is used to set the IGMP version for a VLAN.

Usage

```
config igmp snooping vlan version <vid> <1-3>
```

Example

```
admin@sonic:~$ sudo config igmp snooping vlan version 100 2
```

The default value is 2.

sonic-clear igmp snooping dynamic groups

This command is used to clear the dynamic groups.

Usage

```
sonic-clear igmp snooping dynamic groups
```

Example

```
admin@sonic:~$ sudo sonic-clear igmp snooping dynamic groups
```

sonic-clear igmp snooping statistics

This command is used to clear the statistics of IGMP Snooping packets.

Usage

```
sonic-clear igmp snooping statistics <interface_name>
```

Example

```
admin@sonic:~$ sudo sonic-clear igmp snooping statistics Ethernet0
```

IGMP Snooping Show Commands

This sub-section lists all the possible show commands for the IGMP Snooping available in the device. Following example gives the list of possible shows on IGMP Snooping. Subsequent pages explain each of these commands in detail.

Example

```
admin@sonic:~$ show igmp snooping -?
Show IGMP Snooping information
Options:
  -?, -h, --help Show this message and exit.
Commands:
  groups      Show IGMP Snooping groups information
  mrouter     Show IGMP Snooping mrouter information
  querier     Show IGMP Snooping querier information
  statistics  Show IGMP Snooping statistics
  vlan       Show IGMP Snooping vlan information
  ...
```

show igmp snooping

This command is used to display IGMP Snooping information.

Usage

```
show igmp snooping
```

Example

```
admin@sonic:~$ show igmp snooping
IGMP Snooping           : Disabled
Router Port Expire Time   : 300 s
Router Port Mode         : Forward
Version                 : 2
Querier                 : Enabled
VLAN 1:
-----
```

```

IGMP Snooping           : Disabled
IGMP Snooping Running Status : Inactive
Version                 : Using global Version (2)
Immediate Leave         : Disabled
Last Member Query Interval : 10 (unit: 1/10s)
Last Member Query Count   : 2
Query Interval          : 125
Query Response Interval   : 100 (unit: 1/10s)
VLAN Static Group  Port
-----
1 225.1.1.1   Ethernet 6
  
```

show igmp snooping groups

This command is used to display IGMP Snooping Groups information.

Usage

```
show igmp snooping groups [vid]
```

Example

```

admin@sonic:~$ show igmp snooping groups
Bridge Multicast Forwarding Entry Count:1
Flag: R - Router port, M - Group member port
  H - Host counts (number of hosts joined to group on this port).
  P - Port counts (number of forwarding ports).
Uptime: Group elapsed time; Expire: Group remain time.
VLAN Group      Source      Port      Up time  Expire Count
-----
1 224.1.1.1    *                00:00:00:03  1(P)
                Ethernet 1(M)      0(H)
                Ethernet 2(M) 00:00:00:03 00:03  3(H)
                Ethernet 1(R)
2 224.1.1.2    *                00:03      1(P)
                Ethernet 1(R)
  
```

```
admin@sonic:~$ show igmp snooping groups 1
Bridge Multicast Forwarding Entry Count:1
Flag: R - Router port, M - Group member port
  H - Host counts (number of hosts joined to group on this port).
  P - Port counts (number of forwarding ports).
Uptime: Group elapsed time; Expire: Group remain time.
VLAN Group      Source      Port      Up time  Expire Count
-----
1 224.1.1.1      *              00:00:00:03      1(P)
                  Ethernet 1(M)      0(H)
                  Ethernet 2(M) 00:00:00:03 00:03      3(H)
                  Ethernet 1(R)
```

show igmp snooping mrouter

This command is used to display IGMP Snooping Multicast Router Port information.

Usage

```
show igmp snooping mrouter [vid]
```

Example

```
admin@sonic:~$ show igmp snooping mrouter
VLAN M'cast Router Port Type  Expire
-----
1 Ethernet 1      Static
2 Ethernet 2      Dynamic 00:00:03
admin@sonic:~$ show igmp snooping mrouter 1
VLAN M'cast Router Port Type  Expire
-----
1 Ethernet 1      Static
...
```

show igmp snooping querier status

This command is used to display IGMP Snooping Querier status information.

Usage

```
show igmp snooping querier status
```

Example

```
admin@sonic:~$ show igmp snooping querier status
VLAN 1
Other Querier      : None
Other Querier Expire : 0(m):0(s)
Other Querier Uptime : 0(h):0(m):0(s)
Self Querier       : None
Self Querier Expire  : 0(m):0(s)
Self Querier Uptime  : 0(h):0(m):0(s)
General Query Received : 0
General Query Sent    : 0
Specific Query Received : 0
Specific Query Sent    : 0
```

show igmp snooping statistics

This command is used to display IGMP Snooping Statistics information. The statistics only count the packet that is handled by the IGMP Snooping supported interfaces.

Usage

```
show igmp snooping statistics (input|output) <interface name>
```

Example

```
admin@sonic:~$ show igmp snooping statistics input
Input Statistics:
Interface Report Leave G Query G(-S)-S Query Drop Join Succ Group
```

```

-----
Ethernet 1 0    0    0    0    0    0    0
VLAN   1 0    0    0    0    0    0    0
admin@sonic:~$ show igmp snooping statistics output
Output Statistics:
Interface  Report  Leave  G Query  G(-S)-S Query Drop  Group
-----
Ethernet 1 0    0    0    0    0    0
Ethernet 2 0    0    0    0    0    0

```

show igmp snooping vlan

This command is used to display IGMP Snooping VLAN information.

Usage

```
show igmp snooping vlan <vid>
```

Example

```

admin@sonic:~$ show igmp snooping vlan 1
VLAN 1:
-----
IGMP Snooping           : Disabled
IGMP Snooping Running Status : Inactive
Version                 : Using global version (2)
Immediate Leave         : Disabled
Last Member Query Interval : 10 (unit: 1/10s)
Last Member Query Count   : 2
Query Interval          : 125
Query Response Interval   : 100 (unit: 1/10s)
VLAN Static Group  Port
-----
1  225.1.1.1    Ethernet 6

```

71 Policy-Based Routing (PBR)

Table of Contents

[PBR Config Commands](#)

[config pbr {add|del} map <pbr-map-name> <sequence-number> {permit|deny}](#)
[config pbr map <pbr-map-name> <sequence-number> match {add|del}](#)
[config pbr map <pbr-map-name> <sequence-number> action {add|del}](#)
[config interface pbr bind/unbind](#)

[PBR Show Commands](#)

[show pbr map](#)
[show pbr interface](#)

PBR Config Commands

config pbr {add|del} map <pbr-map-name> <sequence-number> {permit|deny}

This command add or delete a pbr map rule entry.

Usage

```
config pbr {add|del} map <pbr-map-name> <sequence-number> {permit|deny}
```

Example

```
admin@sonic:~$ sudo config pbr add map pmap1 10 permit
admin@sonic:~$ sudo config pbr del map pmap1 10 permit
```

config pbr map <pbr-map-name> <sequence-number> match {add|del}

This command add or delete the match attributes of a pbr map rule entry.

Usage

```
config pbr map <pbr-map-name> <sequence-number> match {add|del} --src_ip <ipv4/v6> --dst_ip <ipv4/v6> --
src_port <0-65535> --dst_port <0-65535> --ip_proto <0-255>
```

Example

```
admin@sonic:~$ sudo config pbr map pmap1 10 match add --src_ip 1.1.1.1
```

config pbr map <pbr-map-name> <sequence-number> action {add|del}

This command add or delete the action attributes of a pbr map rule entry.

Note: There is no action for 'deny' type

Usage

```
config pbr map <pbr-map-name> <sequence-number> action {add|del} --nexthop <ipv4/v6> --dscp <0-63>
```

Example

```
admin@sonic:~$ sudo config pbr map pmap1 10 action add --nexthop 192.169.2.2
```

config interface pbr bind/unbind

This command bind or unbind the packet incoming interface with pbr map, supporting Vlan, Ethernet, and PortChannel interface binding PBR.

Usage

```
config interface pbr bind <interface_name> <pbr-map-name>
```

```
config interface pbr unbind <interface_name>
```

Example

```
admin@sonic:~$ sudo config interface pbr bind Ethernet1 pmap1
```

```
admin@sonic:~$ sudo config interface pbr unbind Ethernet1
```

PBR Show Commands

show pbr map

This command shows which set of next-hops are active.

Usage

```
show pbr map [<pbr-map-name>]
```

Example

```
admin@sonic:~$ show pbr m
```

```
+ +-----+-----+-----+-----+
| Map | Sequence | Type | Match      | Action set      |
+=====+=====+=====+=====+=====+
| pmap1 | 10 | permit | src_ip:1.1.1.1 | nexthop:192.169.2.2 |
+-----+-----+-----+-----+
| pmap1 | 20 | permit | src_ip:2.2.2.2 | nexthop:192.169.3.2 |
+-----+-----+-----+-----+
```

show pbr interface

This command shows the interface bound with pbr

Usage

```
show pbr interface [<interface_name>] [--detail]
```

Example

```
admin@sonic:~$ show pbr interface
```

```
Interface  Map
```

```
-----
```

```
Ethernet1  pmap1
```

```
Ethernet2  pmap1
```

```
admin@sonic:~$ show pbr interface --detail
```

```
Interface  Map  Seq  Status
```

```
-----
```

```
Ethernet1  pmap1  10  Inactive
```

```
Ethernet1  pmap1  20  Inactive
```

```
Ethernet2  pmap1  10  Inactive
```

Ethernet2 pmap1 20 Inactive

72 VRRP

Virtual router redundancy protocol is as known backup router mechanism to prevent traffic broken suddenly while a router with some problems. The election happen between these routers , which takes part in VRRP group. Highest priority routers as master is responsible for forwarding traffic, another as backup.

VRRP interface command

Use config interface vrrp command to create or delete VRRP interface.

Note

The VRRP interface name always starts with "Vrrp" and combines with the group ID and v4 or v6.

VRRP interface needs to designate a parent interface name, for instance, you want to create a VRRP interface on Vlan1000, you need to type Vlan1000 as the last parameter

Use config interface vrrp ip command to set or remove IPv4/IPv6 address on VRRP interface.

Note

This command automatically derives the virtual MAC address from the VRRP interface name and IP address

Example

```
admin@sonic:~$ config interface vrrp add Vrrp5-v4 Vlan1000
admin@sonic:~$ config interface vrrp ip add Vrrp5-v4 10.0.2.16/24
admin@sonic:~$ config interface vrrp ip del Vrrp5-v4
admin@sonic:~$ config interface vrrp add Vrrp5-v6 Vlan1000
admin@sonic:~$ config interface vrrp ipv6 add Vrrp5-v6 2001:db8::370:7334/64
admin@sonic:~$ config interface vrrp ipv6 del Vrrp5-v6
```

VRRP group command

Configure VRRP group through FRR command. Note that Vlan1000 is parent interface.

Example

```
admin@sonic:~$ vtysh
sonic# configure
sonic(config)# interface Vlan1000
sonic(config-if)# vrrp 5 version 3
sonic(config-if)# vrrp 5 ip 10.0.2.16
sonic(config-if)# vrrp 5 ipv6 2001:0db8::0370:7334
sonic(config-if)# no vrrp 5
```

VRRP show command

Use show vrrp command to display all of VRRP status.

Use show vrrp interface command to display VRRP group associated the interface.

Use show vrrp summary command to display the brief information.

Example

```
admin@sonic:~$ show vrrp
Virtual Router ID      5
Protocol Version      3
Autoconfigured        No
Shutdown              No
Interface              eth0
VRRP interface (v4)   None
VRRP interface (v6)   None
Primary IP (v4)
Primary IP (v6)       ::
Virtual MAC (v4)      00:00:5e:00:01:05
Virtual MAC (v6)      00:00:5e:00:02:05
Status (v4)           Initialize
Status (v6)           Initialize
Priority               100
Effective Priority (v4) 100
Effective Priority (v6) 100
Preempt Mode          Yes
Accept Mode           Yes
Advertisement Interval 1000 ms
Master Advertisement Interval (v4) 0 ms
Master Advertisement Interval (v6) 0 ms
Advertisements Tx (v4) 0
Advertisements Tx (v6) 0
Advertisements Rx (v4) 0
Advertisements Rx (v6) 0
Gratuitous ARP Tx (v4) 0
Neigh. Adverts Tx (v6) 0
State transitions (v4) 0
State transitions (v6) 0
Skew Time (v4)        0 ms
```

Skew Time (v6)	0 ms
Master Down Interval (v4)	0 ms
Master Down Interval (v6)	0 ms
IPv4 Addresses	0
IPv6 Addresses	0
admin@sonic:~\$ show vrrp interface Vlan1000	
Virtual Router ID	5
Protocol Version	3
Autoconfigured	No
Shutdown	No
Interface	Vlan1000
VRRP interface (v4)	None
VRRP interface (v6)	None
Primary IP (v4)	
Primary IP (v6)	::
Virtual MAC (v4)	00:00:5e:00:01:05
Virtual MAC (v6)	00:00:5e:00:02:05
Status (v4)	Initialize
Status (v6)	Initialize
Priority	100
Effective Priority (v4)	100
Effective Priority (v6)	100
Preempt Mode	Yes
Accept Mode	Yes
Advertisement Interval	1000 ms
Master Advertisement Interval (v4)	0 ms
Master Advertisement Interval (v6)	0 ms
Advertisements Tx (v4)	0
Advertisements Tx (v6)	0
Advertisements Rx (v4)	0
Advertisements Rx (v6)	0
Gratuitous ARP Tx (v4)	0
Neigh. Adverts Tx (v6)	0
State transitions (v4)	0

State transitions (v6)	0
Skew Time (v4)	0 ms
Skew Time (v6)	0 ms
Master Down Interval (v4)	0 ms
Master Down Interval (v6)	0 ms
IPv4 Addresses	0
IPv6 Addresses	0

admin@sonic:~\$ show vrrp summary

Interface	VRID	Priority	IPv4	IPv6	State (v4)	State (v6)

Vlan1000	5	100	0	0	Backup	Backup

73 Isolation-myself

During the convergence of the routing protocol, some Layer 3 traffic may have the same ingress and egress interfaces, resulting in a temporary loop. By enabling the "isolation-myself" function, Layer 3 forwarding traffic with the same ingress and egress interfaces will be discarded at the egress interface, thereby preventing loops.

Isolation-myself Show Commands

show isolation-myself all

This command is used to display isolation-myself configuration.

Example

```
root@sonic:/home/admin# show isolation-myself all
```

```
+-----+-----+
| Interface Name | Status |
+=====+=====+
| Ethernet0     | disable |
```

```

+-----+-----+
| Ethernet1    | disable |
+-----+-----+
| Ethernet2    | disable |
+-----+-----+
| Ethernet3    | disable |
+-----+-----+
| Ethernet4    | disable |
+-----+-----+
| Ethernet5    | disable |
+-----+-----+
| Ethernet6    | disable |
+-----+-----+

```

show isolation-myself interface <interface_name>

This command is used to display isolation-myself configuration for a specified port.

Example

```

root@sonic:/home/admin# show isolation-myself interface Ethernet7
+-----+-----+
| Interface Name | Status |
+=====+=====+
| Ethernet7     | enable |
+-----+-----+

```

Isolation-myself Config Commands

config interface isolation-myself enable <interface_name>

config interface isolation-myself disable <interface_name>

The default port does not have isolation-myself, and only supports Ethernet interface configuration.

Example

```
root@sonic:/home/admin# config interface isolation-myself enable Ethernet6
root@sonic:/home/admin# config interface isolation-myself disable Ethernet6
```

74 Static DNS

Table of Contents

[Static DNS display command](#)

[show dns nameserver](#)

[Static DNS configuration command](#)

[config dns nameserver add](#)

[config dns nameserver del](#)

Static DNS display command

show dns nameserver

This command is used to display static DNS configuration

Example

```
admin@sonic:~$ show dns nameserver
Nameserver
-----
172.21.170.178
```

Static DNS configuration command

config dns nameserver add

This command is used to add static DNS configuration

Example

```
admin@sonic:~$ sudo config dns nameserver add 172.21.170.178
admin@sonic:~$ sudo config dns nameserver add 172.21.170.177
admin@sonic:~$ sudo config dns nameserver add 2001::1
admin@sonic:~$ sudo config dns nameserver add 2001::2
Usage: config dns nameserver add [OPTIONS] <ip_address>
Try "config dns nameserver add -h" for help.
```

Error: The maximum number (3) of nameservers exceeded.

```
admin@sonic:~$ show dns nameserver
```

Nameserver

172.21.170.177

172.21.170.178

2001::1

config dns nameserver del

This command is used to delete static DNS configuration

Example

```
admin@sonic:~$ sudo config dns del 172.21.170.178
```

75 Hash

Table of Contents

[Hash Show Commands](#)

[show switch-hash global](#)

[Hash Config Commands](#)

[config switch-hash global ecmp/lag hash](#)

[config switch-hash global ecmp/lag hash algorithm](#)

[config switch-hash global ecmp/lag hash seed](#)

This section explains the various show and configuration commands available for user.

Hash Show Commands

This subsection explains how to display switch hash configuration.

show switch-hash global

This command displays switch hash global configuration.

Usage

```
show switch-hash global
```

Options:

-j, -json Display in JSON format

Example

```
root@sonic:/home/admin# show switch-hash global
```

```
+-----+-----+
| Hash   | Configuration          |
+=====+=====+
| ECMP   | +-----+-----+-----+ |
```

```

|      || Hash Field | Algorithm | Seed ||
|      ||-----+-----+-----||
|      || IP_PROTOCOL | CRC_32HI | 10  ||
|      || DST_IP      |         |     ||
|      || SRC_IP      |         |     ||
|      || L4_DST_PORT |         |     ||
|      || L4_SRC_PORT |         |     ||
|      ||-----+-----+-----||
+-----+-----+-----+
| LAG    ||-----+-----+-----|| | |
|      || Hash Field | Algorithm | Seed ||
|      ||-----+-----+-----||
|      || IP_PROTOCOL | CRC_32HI | 10  ||
|      || DST_IP      |         |     ||
|      || SRC_IP      |         |     ||
|      || L4_DST_PORT |         |     ||
|      || L4_SRC_PORT |         |     ||
|      ||-----+-----+-----||
+-----+-----+-----+
| SYMMETRIC ||-----+-----+-----|| | |
|      || State |         |     ||
|      ||-----+-----+-----||
|      || disable |         |     ||
|      ||-----+-----+-----||
+-----+-----+-----+
root@sonic:/home/admin#

```

Hash Config Commands

This subsection explains how to configure switch hash.

config switch-hash global ecmp/lag hash

This command is used to manage switch hash global configuration.

Usage

```
config switch-hash global ecmp-hash <hash_field_list>
```

```
config switch-hash global lag-hash <hash_field_list>
```

Parameters:

hash_field_list: hash fields for hashing packets going through ECMP/LAG. Range: IN_PORT, VLAN_ID, IP_PROTOCOL, DST_IP, SRC_IP, L4_DST_PORT, L4_SRC_PORT, IPV6_FLOW_LABEL. One or more of these can be used, and multiple fields should be separated by spaces.

Example

```
root@sonic:/home/admin# config switch-hash global ecmp-hash IN_PORT VLAN_ID IP_PROTOCOL DST_IP SRC_IP  
L4_DST_PORT L4_SRC_PORT IPV6_FLOW_LABEL
```

config switch-hash global ecmp/lag hash algorithm

This command is used to manage switch hash algorithm global configuration.

Usage

```
config switch-hash global ecmp-hash-algorithm <hash_algorithm>
```

```
config switch-hash global lag-hash-algorithm <hash_algorithm>
```

Parameters:

hash_algorithm: hash algorithm for hashing packets going through ECMP/LAG. Range: CRC, XOR, CRC_32LO, CRC_32HI, CRC_CCITT, CRC_XOR. One of these must be used.

Example

```
config switch-hash global ecmp-hash-algorithm CRC  
config switch-hash global lag-hash-algorithm CRC
```

config switch-hash global ecmp/lag hash seed

This command is used to manage switch hash seed global configuration.

Usage

```
config switch-hash global ecmp-hash-seed <hash_seed>  
config switch-hash global lag-hash-seed <hash_seed>
```

Parameters:

hash_seed: hash seed for hashing packets going through ECMP/LAG. Range:0-4294967295, default:10.

Example

```
config switch-hash global ecmp-hash-seed 100  
config switch-hash global lag-hash-seed 200
```

config switch-hash global symmetric

This command is used to manage switch symmetric hash configuration.

Usage

```
config switch-hash global symmetric <enable/disable>
```

Parameters:

<enable/disable>: Used to enable or disable symmetric hash. Default value: disable.

Example

```
config switch-hash global symmetric enable
```

76 Routing Security

Table of Contents

[Routing Security show commands](#)

[show route-table vrf <vrf_name>](#)

[show route-table ip <vrf_name>](#)

[show route-table ipv6 <vrf_name>](#)

[Routing Security config commands](#)

[config vrf simply-alert set/unset <vrf_name>](#)

[config vrf route-table-limit <ip_version \(ip, ipv6\)> <vrf_name> NUMBER](#)

Routing Security show commands

show route-table vrf <vrf_name>

This command is used to display the routing information installed in all VRFs or a specified VRF.

Usage

```
show route-table vrf <vrf_name>
```

Parameter:

- <vrf_name>: VRF name. For example: "Vrf1".

Note:

- The displayed installed routing information does not include the routing information of the default VRF.

Example

```
admin@sonic:~$ show route-table vrf
```

VRF	Simply alert	IPv4 Max Route limit	IPv6 Max Route limit	Installed Routes	Installed Routes
NUM					

Vrf1	Disabled		128.1.1.0/24	2	
			128.1.1.4		

```
admin@sonic:~$ show route-table vrf Vrf1
```

VRF	Simply alert	IPv4 Max Route limit	IPv6 Max Route limit	Installed Routes	Installed Routes
NUM					

Vrf1	Disabled		128.1.1.0/24	2	
			128.1.1.4		

show route-table ip <vrf_name>

This command is used to display the IPv4 routing information installed in all VRFs or a specified VRF.

Usage

```
show route-table ip <vrf_name>
```

Parameter:

- <vrf_name>: VRF name. For example: "Vrf1".

Example

```
admin@sonic:~$ show route-table ip
```

VRF	Simply alert	IPV4 Max Route limit	Installed Routes	Installed Routes NUM
Vrf1	Disabled	128.1.1.0/24	2	
		128.1.1.4		

```
admin@sonic:~$ show route-table ip Vrf1
```

VRF	Simply alert	IPV4 Max Route limit	Installed Routes	Installed Routes NUM
Vrf1	Disabled	128.1.1.0/24	2	
		128.1.1.4		

show route-table ipv6 <vrf_name>

This command is used to display the IPv6 routing information installed in all VRFs or a specified VRF.

Usage

```
show route-table ipv6 <vrf_name>
```

Parameter:

- <vrf_name>: VRF name. For example: "Vrf1".

Example

```
admin@sonic:~$ show route-table ipv6
```

VRF	Simply alert	IPV6 Max Route limit	Installed Routes	Installed Routes NUM
Vrf1	Disabled	2018::/64	2	
		2018::7		

```
admin@sonic:~$ show route-table ipv6 Vrf1
```

VRF	Simply alert	IPv6 Max Route limit	Installed Routes	Installed Routes NUM
Vrf1	Disabled	2018::/64 2018::7	2	

Routing Security config commands

config vrf simply-alert set/unset <vrf_name>

This command configures whether to only issue a warning message when the maximum number of routes in a VRF exceeds the configured route limit. If only a warning message is issued, new routes can continue to be added to the VRF. If not, once the configured route limit is reached, no new routes will be added to the VRF.

Usage

```
config vrf simply-alert set/unset <vrf_name>
```

Parameter:

- <vrf_name>: VRF name. For example: "Vrf1".

Note:

- The default VRF does not support configuring these values.

Example

```
admin@sonic:~$ sudo config vrf simply-alert set Vrf1
admin@sonic:~$ show route-table ip Vrf1
```

VRF	Simply alert	IPV4 Max Route limit	Installed Routes	Installed Routes NUM
Vrf1	Enabled	128.1.1.0/24	2	
		128.1.1.4		

config vrf route-table-limit <ip_version (ip, ipv6)> <vrf_name> NUMBER

This command configures the maximum number of routes for the VRF.。

Usage

```
config vrf route-table-limit <ip_version (ip, ipv6)> <vrf_name> NUMBER
```

Parameter:

- <ip_version>: You can choose to configure IPv4 and/or IPv6
- <vrf_name>: VRF name. For example: "Vrf1".
- NUMBER : The maximum number of routes for a VRF.

Note:

- The maximum number of IPv4 and IPv6 routes in a VRF are separate.
- The default VRF does not support configuring these values.

Example

```
admin@sonic:~$ sudo config vrf route-table-limit ip Vrf1 6
admin@sonic:~$ show route-table ip Vrf1
admin@sonic:~$ show route-table vrf
```

VRF	Simply alert	IPV4 Max Route limit	IPV6 Max Route limit	Installed Routes	Installed Routes NUM
Vrf1	Enabled	6	128.1.1.0/24	2	
			128.1.1.4		

```
admin@sonic:~$ show route-table ip Vrf1
VRF  Simply alert  IPV4 Max Route limit  Installed Routes  Installed Routes NUM
-----
Vrf1  Enabled      6           128.1.1.0/24           2
      128.1.1.4

admin@sonic:~$ sudo config vrf route-table-limit ipv6 Vrf1 6
admin@sonic:~$ show route-table ipv6 Vrf1
admin@sonic:~$ show route-table ipv6 Vrf1
VRF  Simply alert  IPV6 Max Route limit  Installed Routes  Installed Routes NUM
-----
Vrf1  Enabled      6           2018::/64             2
      2018::7
```

77 Fine-grained ECMP

Table of Contents

[Show Commands](#)

[show fgnhg group](#)

[show fgnhg active-hops](#)

[show fgnhg hash-view](#)

[Config Commands](#)

[config fgnhg group](#)

[config fgnhg member](#)

[config fgnhg prefix](#)

Show Commands

show fgnhg group

This command displays fine-grained ECMP group configurations.

Usage

```
show fgnhg group [OPTIONS] [<fgnhg_group_name>| "all"]
```

Parameter:

fgnhg_group_name: name of the fgnhg group

Example

```
root@sonic:/home/admin# show fgnhg group
```

```
+-----+-----+-----+
| Group Name | Match Mode | Hash Bucket Size |
+=====+=====+=====+
| fg21      | route-based |          64 |
+-----+-----+-----+
| fg22      | nexthop-based |          64 |
+-----+-----+-----+
```

show fgnhg active-hops

This command displays the effective next hop for routes by prefix.

Usage

```
show fgnhg active-hops [OPTIONS] [NHG]
```

Parameter:

NHG: Only route-based fine-grained ECMP group can query the active next hop for the group.

Example

```
root@sonic:/home/admin# show fgnhg active-hops
```

```
+-----+-----+
| FG_NHG_PREFIX | Active Next Hops |
+=====+=====+
| 55.0.0.0/24   | 10.10.1.1        |
|               | 10.10.2.1        |
|               | 10.10.3.1        |
+-----+-----+
| 44.0.0.0/24   | 10.10.1.1        |
|               | 10.10.2.1        |
|               | 10.10.3.1        |
|               | 10.10.4.1        |
+-----+-----+
root@sonic:/home/admin#
```

show fgnhg hash-view

This command displays the next hop hash view for routes by prefix.

Usage

```
show fgnhg hash-view [OPTIONS] [NHG]
```

Parameter:

NHG: Only route-based fine-grained ECMP group can query the next hop hash view for the group.

Example

```
root@sonic:/home/admin# show fgnhg hash-view
```

```
+-----+-----+-----+
| FG_NHG_PREFIX | Next Hop | Hash buckets |
+=====+=====+=====+
| 55.0.0.0/24   | 10.10.1.1 | 0           |
|               |           | 2           |
|               |           | 4           |
|               |           | 6           |
|               |           | 8           |
|               |           | 10          |
|               |           | 12          |
|               |           | 14          |
|               |           | 16          |
|               |           | 18          |
|               |           | 20          |
|               |           | 22          |
|               |           | 24          |
|               |           | 26          |
|               |           | 28          |
|               |           | 30          |
+-----+-----+-----+
| 55.0.0.0/24   | 10.10.2.1 | 1           |
|               |           | 3           |
|               |           | 5           |
|               |           | 7           |
|               |           | 9           |
|               |           | 11          |
|               |           | 13          |
|               |           | 15          |
```

		17	
		19	
		21	
		23	
		25	
		27	
		29	
		31	
+-----+-----+			
55.0.0.0/24	10.10.3.1	32	
		33	
		34	
		35	
		36	
		37	
		38	
		39	
		40	
		41	
		42	
		43	
		44	
		45	
		46	
		47	
		48	
		49	
		50	
		51	
		52	
		53	
		54	
		55	
		56	
		57	
		58	

		59	
		60	
		61	
		62	
		63	
+-----+-----+-----+			
44.0.0.0/24	10.10.1.1	0	
		1	
		2	
		3	
		4	
		5	
		6	
		7	
		8	
		9	
		10	
		11	
		12	
		13	
		14	
		15	
+-----+-----+-----+			
44.0.0.0/24	10.10.2.1	16	
		17	
		18	
		19	
		20	
		21	
		22	
		23	
		24	
		25	
		26	
		27	
		28	

		29	
		30	
		31	
+-----+-----+-----+			
44.0.0.0/24	10.10.3.1	32	
		33	
		34	
		35	
		36	
		37	
		38	
		39	
		40	
		41	
		42	
		43	
		44	
		45	
		46	
		47	
+-----+-----+-----+			
44.0.0.0/24	10.10.4.1	48	
		49	
		50	
		51	
		52	
		53	
		54	
		55	
		56	
		57	
		58	
		59	
		60	
		61	
		62	



Config Commands

config fgnhg group

This command is used to create or delete a fine-grained ECMP group.

Usage

```
config fgnhg add [OPTIONS] <fgnhg_group_name> type <type_value> size <size_value> match-mode <match-mode-value>
```

```
config fgnhg del [OPTIONS] FGNHG_GROUP_NAME
```

Parameter:

fgnhg_group_name/FGNHG_GROUP_NAME: Name of fine-grained ECMP group.

type_value: Only the "static" type is supported.

size_value: Only 64 is supported.

match-mode-value: "route-based" or "nexthop-based"

Note:

- Does not support directly updating the match-mode of an existing group; the old group must be deleted and then recreated.
- The group can only be deleted after all members and prefixes in the group have been removed.

Example

```
root@sonic:/home/admin# config fgnhg add fg21 type static size 64 match-mode route-based  
root@sonic:/home/admin# config fgnhg del fg21
```

config fgnhg member

This command is used to add or delete members from a fine-grained ECMP group.

Usage

```
config fgnhg member add [OPTIONS] FGNHG_GROUP_NAME NEXTHOP_IP <bank_number> [nexthop_intf]  
config fgnhg member del [OPTIONS] FGNHG_GROUP_NAME NEXTHOP_IP
```

Parameter:

FGNHG_GROUP_NAME: Name of fine-grained ECMP group.

NEXTHOP_IP: The next-hop IPv4/IPv6 address of the member.

bank_number: Start from 0 and be added in sequential order. Members in the same bank share the same state.

When a member fails or recovers, flow redistribution occurs among members in the same bank.

nexthop_intf: The local interface name for the next hop. Support Ethernet and PortChannel interface name.

Note:

- If the group has already been configured with a prefix, then no more members can be added to the group. You need to remove the prefix configuration before changing the group members.
- A member can only be configured for one group. If you need to update the group that a member belongs to, you need to delete the old group member and then add the member to the new group.

Example

```
root@sonic:/home/admin# config fgnhg member add fg21 10.10.1.1 0 Ethernet448
```

```
root@sonic:/home/admin# config fgnhg member del fg21 10.10.1.1
```

config fgnhg prefix

This command is used to add or delete prefixes in the route-based mode of a fine-grained ECMP group.

Usage

```
config fgnhg prefix add [OPTIONS] FGNHG_GROUP_NAME PREFIX
```

```
config fgnhg prefix del [OPTIONS] FGNHG_GROUP_NAME PREFIX
```

Parameter:

FGNHG_GROUP_NAME: Name of fine-grained ECMP group.

PREFIX: IPv4/IPv6 network segment used to match ECMP routes.

Note:

- Members must be added to the group first before configuring route prefixes.
- A prefix can only be configured for one group. If you need to update the group that a prefix belongs to, you need to delete the old prefix and then add the prefix to the new group.

Example

```
root@sonic:/home/admin# config fgnhg prefix add fg21 44.0.0.0/24
```

```
root@sonic:/home/admin# config fgnhg prefix del fg21 44.0.0.0/24
```



```

Group ID      : 1
Downlink Up Delay : 0
Uplink Interface : Ethernet512
Downlink Interface : Ethernet513

Interface  Type   Oper Status  Shutdown Reason
-----
Ethernet512 uplink  up
Ethernet513 downlink up

```

Monitor Link Group config commands

config monitor-link group member add

This command is used to add uplink or downlink port to the specified monitor link group.

Usage

```

config monitor-link group member add <group_id>
<types (downlink or uplink)> <interface_name>

```

Example

```

root@sonic:/home/admin# config monitor-link group member add 1 uplink Ethernet512
root@sonic:/home/admin# config monitor-link group member add 1 downlink Ethernet513

```

config monitor-link group member delete

This command is used to delete uplink or downlink port from the specified monitor link group.

Usage

```
config monitor-link group member del <group_id>  
<types (downlink or uplink)> <interface_name>
```

Example

```
root@sonic:/home/admin# config monitor-link group member del 1 downlink Ethernet513
```

config monitor-link group downlink-up-delay set

This command is used to configure downlink up delay for the specified monitor link group.

Usage

```
config monitor-link group downlink-up-delay set <group_id> <downlink_up_delay>
```

Example

```
root@sonic:/home/admin# config monitor-link group downlink-up-delay set 1 10
```

config monitor-link group downlink-up-delay unset

This command is used to delete downlink up delay for the specified monitor link group.

Usage

```
config monitor-link group downlink-up-delay unset <group_id>
```

Example

```
root@sonic:/home/admin# config monitor-link group downlink-up-delay unset 1
```

79 Platform Component Firmware

80 Latency Distribution Histogram (LDH)

Table of Contents

[LDH show commands](#)

[show ldh counter <ldh-name>](#)

[sonic-clear ldhcounters](#)

[LDH config commands](#)

[config ldh timerange add <ldh-name> <time-range>](#)

[config ldh srcport add <ldh-name> <src-port>](#)

[config ldh dstport add <ldh-name> <dst-port>](#)

[config ldh set state <ldh-name> <mode>](#)

[config ldh del <ldh-name>](#)

LDH show commands

show ldh counter <ldh-name>

This command is used to display ldh statistics .

Usage

Usage: show ldh counter [OPTIONS] <ldh-name>

Show ldh counter information

Example

```
root@sonic:/home/admin# show ldh counter LDH0
```

Last cached time was 2025-06-16 02:12:02.367406

RANGE TIME	PACKETS
0-1(ns)	0
2-1000(ns)	0
1001-10000(ns)	0
10001-60000(ns)	0

sonic-clear ldhcounters

This command is used to clear ldh statistics.

Usage

Usage: sonic-clear ldhcounters [OPTIONS]

Clear ldh counters

Example

```
root@sonic:/home/admin# sonic-clear ldhcounters
```

Clear saved counters

LDH config commands

config ldh timerange add <ldh-name> <time-range>

This command is used to configure the time range for LDH.

Usage

Usage: config ldh timerange add [OPTIONS] <ldh-name> <time-range>

config LDH timerange information

Example

```
root@sonic:/home/admin# sudo config ldh timerange add LDH0 0-1,2-1000,1001-10000,10001-60000
```

config ldh srcport add <ldh-name> <src-port>

This command is used to configure the source port of LDH.

Usage

Usage: config ldh srcport add [OPTIONS] <ldh-name> <src-port>

config LDH srcport information

Example

```
root@sonic:/home/admin# sudo config ldh srcport add LDH0 Ethernet8,Ethernet16,Ethernet24
```

config ldh dstport add <ldh-name> <dst-port>

This command is used to configure the destination port of LDH.

Usage

Usage: config ldh dstport add [OPTIONS] <ldh-name> <dst-port>

config LDH srcport information

Example

```
root@sonic:/home/admin# sudo config ldh dstport add LDH0 Ethernet8,Ethernet24,Ethernet32
```

config ldh set state <ldh-name> <mode>

This command is used to enable or disable LDH.

Usage

Usage: config ldh set state [OPTIONS] <ldh-name> <mode>

Example

```
root@sonic:/home/admin# sudo config ldh set state LDH0 enable
root@sonic:/home/admin# sudo config ldh set state LDH0 disable
```

config ldh del <ldh-name>

This command is used to delete the created LDH.

Usage

Usage: config ldh del [OPTIONS] <ldh-name>

Example

```
root@sonic:/home/admin# sudo config ldh del LDH0
```

81 AR

Adaptive Routing show commands

show ar config

This command displays the AR configuration information.

Usage

```
show ar config
```

Example

```
admin@sonic:~$ show ar config
```

```
AR state: enabled
```

```
AR Port
```

```
-----
```

```
Ethernet92
```

```
Ethernet116
```

```
Ethernet140
```

Adaptive Routing config commands

config ar enabled

config ar disabled

This command is used to enable or disable the AR feature.

Usage

```
config ar enabled
```

```
config ar disabled
```

Example

```
admin@sonic:~$ sudo config ar enabled
```

config ar port enabled <interface_name>

config ar port disabled <interface_name>

This command is used to enable or disable the AR feature on an interface.

Usage
config ar port enabled <interface_name> config ar port disabled <interface_name>

Note:

- The AR feature configuration will take effect only after restarting swss. Make sure to save the configuration before restarting swss;
- To enable the AR feature on an interface, the AR feature must also be enabled globally.

Example
admin@sonic:~\$ sudo config ar port enabled Ethernet116

I Further Information

Web www.naddod.com

Email For order requirements: sales@naddod.com
For cooperation: agency@naddod.com
For customer service: support@naddod.com

For other information: info@naddod.com
For technical support: tech@naddod.com

Disclaimer

1. We are committed to continuous product improvement and feature upgrades, and the contents contained in this manual are subject to change without notice.
2. Nothing herein should be construed as constituting an additional warranty.
3. NADDOD assumes no responsibility for the use or reliability of equipment or software not provided by NADDOD.

Copyright © NADDOD.COM All Rights